

SERVICE/MAINTENANCE MANUAL

This manual has been prepared for and is considered part of -

8500-1/8500E-1

Model Number

XXXXXRef

Serial Number

This Manual is Divided into the following Sections:

	SAFETY SECTION
SECTION 1	REFERENCE MATERIALS
SECTION 2	TEST PROCEDURES
SECTION 3	GENERAL
SECTION 4	POWER TRAIN
SECTION 5	HYDRAULIC SYSTEM
SECTION 6	HOIST SYSTEM
SECTION 7	BOOM HOIST SYSTEM
SECTION 8	SWING SYSTEM
SECTION 9	TRAVEL SYSTEM
SECTION 10	ELECTRICAL SYSTEM
SECTION 11	AIR CONDITIONER
SECTION 12	TRANSLIFTER SYSTEM
SECTION 13	TROUBLESHOOTING

NOTICE

The serial number of the crane is the only method the Manitowoc Crane Care Lattice Team has of providing you with correct parts and service information.

Always furnish serial number of crane and its attachments when ordering parts or discussing service problems with your Manitowoc distributor or the Manitowoc Crane Care Lattice Team.



A WARNING

To prevent death or serious injury:

- · Avoid unsafe operation and maintenance.
 - Crane and attachments must be operated and maintained by trained and experienced personnel. Manitowoc is not responsible for qualifying these personnel.
- Do not operate or work on crane or attachments without first reading and understanding instructions contained in Operator Information Manual and Service Manual supplied with crane and applicable attachments.
- Store Operator Information Manual and Service Manual in operator's cab.

If Operator Information Manual or Service Manual is missing from cab, contact your Manitowoc distributor for a new one.



	TABLE OF CONTENTS	
	SAFETY	
1.	REFERENCE MATERIALS	1
2.	MAINTENANCE STANDARDS TEST PROCEDURES	2
3.	GENERAL WORK STANDARD	3
4.	POWER TRAIN	4
5.	HYDRAULIC SYSTEM	5
6.	HOIST SYSTEM	6
7.	BOOM HOIST SYSTEM	7
8.	SWING SYSTEM	8
9.	TRAVEL SYSTEM	9
10.	ELECTRIC SYSTEM	10
11.	AIR CONDITIONER	11
12.	TRANSLIFTER SYSTEM	12
13.	TROUBLESHOOTING	13



SAFETY

1. REFERENCE MATERIALS

1.1	8500-1 SPECIFICATION	1-1
1.1.1	CRANE OUTSIDE DIMENSION	1-1
1.1.2	CRANE SPECIFICATION, PERFORMANCE	1-2
1.1.3	CRANE WORKING RANGES	1-4
1.2	8500-1 DIMENSION, WEIGHT OF EACH COMPONENT	1-7
1.2.1	BASE MACHINE	
1.2.2	COUNTERWEIGHT WITH SELF REMOVAL DEVICE	
1.2.3	ATTACHMENT	1-10
1.3	8500-1 CLAMSHELL RATED LOADS (OPTION)	
1.4	8500-1 SWING AND TRAVEL STABILITY	
1.5	8500-1 TRAVEL ALLOWABLE SLOPE ANGLE	1-18
1.5.1	CRANE ATTACHMENT INSTALLED: BOOM INSERT CONFIGURATION	
1.6	8500E-1 SPECIFICATION	
1.6.1	CRANE OUTSIDE DIMENSION	
1.6.2	CRANE SPECIFICATION, PERFORMANCE	
1.6.3	CRANE WORKING RANGES	
1.7	8500E-1 DIMENSION, WEIGHT OF EACH COMPONENT	
1.7.1	BASE MACHINE	
1.7.2	COUNTERWEIGHT	
1.7.3	COUNTERWEIGHT WITH SELF REMOVAL DEVICE (OPTION)	
1.7.4	ATTACHMENT	
1.8	8500E-1 CLAMSHELL RATED LOADS (OPTION)	
1.9	8500E-1 SWING AND TRAVEL STABILITY	
1.10	8500E-1 TRAVEL ALLOWABLE SLOPE ANGLE	
1.10.1		
1.11	ENGINE MAIN SPECIFICATION	1-52
	INTENANCE OTANDADDO TEOT DOGGEDUDEO	
2. IVI /	AINTENANCE STANDARDS TEST PROCEDURES	
2.1	MAINTENANCE STANDARD	
2.1.1	PIN, BUSHING, SPRING, LINING AND SHEAVE	2-1
2.1.2		
2.2	PERFORMANCE STANDARD AND TEST PROCEDURE	
2.2.1	OPERATING SPEED	
2.2.2	HYDRAULIC PRESSURE	2-18
223	SWING REARING	2-22

3. GENERAL WORK STANDARD

3.1	STANDARD TIGHTENING TORQUE	3-1
3.1.1	TIGHTENING TORQUE OF CAP SCREWS AND NUTS	3-1
3.1.2	TIGHTENING TORQUE OF HYDRAULIC FITTINGS	3-5
3.2	STANDARD PARTS	3-7
3.2.1	BOLT	3-7
3.2.2	O-RING	3-8
3.2.3	BACK-UP RING	3-9
3.2.4	BITE TYPE FITTING	3-10
3.3	CONVERSION TABLE	
3.3.1	UNIT CONVERSION	
3.3.2	MILLIMETER: INCH CONVERSION TABLE	
3.3.3	METER AND FOOT CONVERSION TABLE	
3.3.4	GRADE CONVERSION TABLE	
3.3.5	UNIT WEIGHT TABLE	
3.3.6	SYSTEM INTERNATIONAL (SI) UNIT CONVERSION TABLE	3-18
4 DC	OWER TRAIN	
4.1	APPARATUS AND COMPONENTS LOCATION	
4.2	ENGINE	
4.2.1	REMOVAL OF THE ENGINE	
4.2.2		
4.2.3	INSTALLATION OF THE ENGINE PUMP DRIVE ASSEMBLY	
4.3	CONSTRUCTION OF THE POWER DIVIDER	
4.3.1		
4.3.2 4.3.3	REMOVAL OF EACH PUMP	
	REMOVAL OF EACH PUMP	
4.3.4 4.3.5	REMOVAL OF THE COUPLING	
4.3.6		
4.3.7		
4.3.8		
4.3.9	INSTALLATION OF THE COUPLING	
4.3.10		
4.4	ASSEMBLY AND DISASSEMBLY OF RADIATOR	
4.4.1	CONSTRUCTION OF THE RADIATOR	
4.4.2	REPLACEMENT ORDER OF RADIATOR CORE	
4.5	DEF/AdBlue® SCR SYSTEM	
4.5.1	DEF/AdBlue® TANK	
4.5.2		

5. HY	DRAULIC SYSTEM	
5.1	LOCATION OF MAIN HYDRAULIC COMPONENTS	5-2
5.1.1	COMPONENTS LOCATION ON THE HYDRAULIC SCHEMATIC	5-2
5.1.2	HYDRAULIC COMPONENTS LIST	5-7
5.1.3	LAYOUT OF HYDRAULIC COMPONENTS	5-11
5.2	CONSTRUCTION AND FUNCTION	5-18
5.2.1	OIL FLOW FROM No.1 AND No.2 PUMPS	5-18
5.2.2	OIL FLOW FROM No.3 PUMP	5-20
5.2.3	OIL FLOW FROM No.4 AND No.5 PUMPS	
	(FRONT, REAR DRUM BRAKE COOLING)	
5.2.4	OIL FLOW FROM No.6 PUMP	5-24
5.2.5	OIL FLOW FROM No.7 PUMP	5-28
5.3	VALVE	5-36
6. HC	DIST SYSTEM	
6.1	APPARATUS AND LOCATION OF COMPONENTS	6-2
6.2	CONSTRUCTION AND FUNCTION	
6.2.1	HYDRAULIC SCHEMATIC	
6.2.2	LIFTING A LOAD	6-8
6.2.3	HOLDING A HOISTED LOAD	6-10
6.2.4	LOWERING A LOAD (POWER LOWERING)	6-12
6.2.5	FREE FALL OPERATION	6-14
6.2.6	G WINCH MODE LIFTING	6-22
6.2.7	G WINCH MODE LOWERING	6-23
6.3	WINCH	6-24
6.3.1	WINCH INSTALLATION	6-24
6.3.2	WINCH ASSEMBLY	6-25
6.3.3	REDUCTION UNIT ASSEMBLY	6-26
6.3.4	ADJUSTMENT OF DRUM LOCK	6-28
6.4	BRAKE PEDAL	6-30
6.4.1	ASSEMBLY DRAWING	6-30
6.4.2	ADJUSTING THE BRAKE PEDAL	6-32
6.4.3	BLEEDING AIR FROM BRAKE CIRCUIT	6-33
7. BC	OM HOIST SYSTEM	
7 1	APPARATUS AND COMPONENTS LOCATION	7-2

7.2

7.2.17.2.2

7.2.3

CONSTRUCTION AND FUNCTION......7-4
HYDRAULIC SCHEMATIC......7-4

RAISING BOOM.......7-5

NEUTRAL (HOLDING BOOM)......7-6

7.2.4	LOWERING BOOM	7-7
7.3	BOOM HOIST WINCH	7-9
7.3.1	BOOM HOIST WINCH INSTALLATION	7-9
7.3.2	REDUCTION UNIT ASSEMBLY	7-10
7.3.3	BOOM DRUM LOCK ASSEMBLY	7-12
7.3.4	ADJUSTMENT OF BOOM DRUM LOCK	7-13
8. SW	/ING SYSTEM	
8.1	APPARATUS AND COMPONENTS LOCATION	8-1
8.2	CONSTRUCTION AND FUNCTION	8-3
8.2.1	HYDRAULIC SCHEMATIC	8-3
8.2.2	SWING (NEUTRAL FREE)	
8.2.3	STOPPING (NEUTRAL FREE)	8-6
8.2.4	SWING (NEUTRAL FREE/BRAKE MODE SELECT)	8-7
8.2.5	STOPPING (NEUTRAL FREE/BRAKE MODE SELECT)	
8.3	CONSTRUCTION OF THE SWING SYSTEM	8-11
8.3.1	SWING REDUCTION UNIT	
8.3.2	REDUCTION UNIT ASSEMBLY	
8.3.3	SWING BEARING	8-13
8.3.4	SWING LOCK	8-14
9. TR	AVEL SYSTEM	
9.1	APPARATUS AND COMPONENTS LOCATION	9-1
9.2	CONSTRUCTION AND FUNCTION	9-2
9.2.1	HYDRAULIC SCHEMATIC	9-2
9.2.2	TRAVELING (RIGHT SIDE FORWARD)	9-3
9.2.3	STOPPING	9-4
9.3	CRAWLER	9-5
9.3.1	DRIVE ASSEMBLY	9-5
9.3.2	MOTOR AND REDUCTION UNIT	9-6
9.3.3	ADJUSTMENT OF SHOE	9-9
10. EL	ECTRIC SYSTEM	
10.1	ELECTRICAL	10-3
10.1.1	ELECTRICAL WIRING SCHEMATIC	10-3
10.1.2		
10.1.3	LOCATION AND USE OF FUSE	10-162
10.1.4	WIPER CONTROL RELAY	10-167
10.1.5	PRESSURE SWITCH (FOR TRAVEL MOTION DETECT)	10-168
10.1.6		

10.1.7	PRESSURE SENSOR	10-170
10.1.8	INCLINATION SENSOR	10-173
10.1.9	BUZZER UNIT	10-174
10.1.10	RELAY BOX	10-175
10.1.11	RELAY BOX	10-186
10.1.12	LOAD DETECTOR (CRANE)	10-189
10.1.13	ANGLE SENSOR	10-190
10.1.14	HOW TO CHECK THE FAILURE CONTENTS	10-192
10.1.15	WARNING DISPLAY CONDITION	10-196
10.1.16	ENGINE ECU	10-207
10.2 LO	DAD SAFETY DEVICE	10-210
10.2.1	CONFIGURATION OF SCREENS	10-211
10.2.2	SYSTEM DAIGRAM	10-212
10.2.3	MONITOR DISPLAY	10-213
10.2.4	DETAIL OF ML CONTROLLER	
10.2.5	SHIFTING TO MAINTENANCE SCREEN	10-233
10.2.6	INPUT / OUTPUT SIGNAL	
10.2.7	ML FUNCTION SETTING	10-244
10.2.8	DATA COPY, FORMAT	10-246
10.2.9	LANGUAGE, UNIT SETTING	
10.2.10	ML ADJUSTMENT (NORMAL)	10-251
10.2.11	ML ADJUSTMENT (TEMPORARY)	10-274
10.2.12	OPERATION PROGRESS	
10.2.13	VERSION INFORMATION	10-278
10.2.14	FAILURE HISTORY	10-279
10.2.15	ADJUSTMENT DATA	10-282
	DOWNLOAD ML PROGRAM	
10.2.17	DOWNLOAD OF MONITOR PROGRAM	10-290
10.3 M	AIN CONTROLLER	
10.3.1	ARRANGEMENT OF MAIN CONTROLLER	
10.3.2	COMPOSITION OF SYSTEM	10-296
10.3.3	FUNCTION OF MAIN CONTROLLER	10-297
10.3.4	MAIN CONTROLLER 1, 2 (HARDWARE)	
10.3.5	SPECIFICATIONS OF MAIN CONTROLLER INPUT/OUTPUT	10-334
10.3.6	ARRANGEMENT OF MAIN CONTROLLER CONNECTOR PIN	10-348
10.3.7	ADJUSTMENT OF MAIN CONTROLLER	10-364
10.3.8	CONTROLLER MALEUNCTION EMERGENCY MEASURES	10-369

11. AIR CONDITIONER

11.1	NAME OF THE AIR CONDITIONER PARTS	11-1
11.2	ELECTRIC WIRING DIAGRAM	11-7
11.3	PARTS ILLUSTRATION	11-8
11.4	DISASSEMBLY AND ASSEMBLY OF THE UNIT	11-10
11.4.1	REMOVAL OF THE BLOWER UNIT	11-10
11.4.2	REPLACING THE BLOWER MOTOR	11-11
11.4.3	REPLACING THE BLOWER CONTROLLER	11-11
11.4.4	REMOVAL OF THE HEATER CORE	11-11
11.4.5	REMOVAL OF THE AIR CON. UNIT CASE-FRONT, REAR AND LOWER	11-12
11.4.6	REPLACING THE EVAPORATOR AND EXPANSION VALVE	11-13
11.4.7	INSTALLATION OF EVAPORATOR SENSOR	11-13
11.4.8	REPLACING THE MOTOR ACTUATOR	11-14
11.5	FAULT DETECTION FROM THE CONTROL PANEL INDICATION	11-15
11.5.1		
11.5.2	FAULT IN THE INPUT AND OUTPUT CIRCUIT OF THE MOTOR	
	ACTUATOR	11-15
11.5.3	FAULT IN THE THERMISTOR SENSOR CIRCUIT	11-16
11.6	BASIC SYSTEM OF HVAC	11-17
11.7	RECHARGING OF THE COOLANT	11-23
11.7.1	CAUTION AT WORK	11-23
11.7.2	WORK PROCEDURE	11-25
11.7.3	RECHARGING PROCEDURE	11-27
11.8	TROUBLESHOOTING	11-32
12 TD	ANGLIETED SYSTEM	
	ANSLIFTER SYSTEM	
12.1	APPARATUS AND COMPONENTS LOCATION	
12.2	CONSTRUCTION AND FUNCTION	
12.2.1		
12.2.2		
12.2.3		
12.3	REMOTE CONTROL SWITCH BOX	12-5
3. TR	OUBLESHOOTING	
13.1	ENGINE	13-1
13.2	WINCH SYSTEM	
13.3	SWING SYSTEM	
13.4	TRAVELING SYSTEM	

SAFETY

SAFETY INFORMATION

Most accidents, which occur during operation, are due to neglect of precautionary measures and safety rules. Sufficient care should be taken to avoid these accidents.

Erroneous operation, lubrication or maintenance services are very dangerous and may cause injury or death of personnel.

Thus, precautionary measures, or notes, written in this manual should be read and understood by personnel before starting each task.

Operation, inspection, and maintenance should be carefully carried out, and safety must be given the first priority. Messages of safety are indicated with caution marks.

The safety information contained in this manual is intended only general safety information.

Messages of safety appear in this manual and on the machine.

All messages of safety are identified by the words "DANGER", "WARNING" and "CAUTION".

These words mean the following:



Indicates an imminently hazardous situation which, if not avoided, will result in a loss of life or serious injuries.



Indicates a potentially hazardous situation which, if not avoided, could result in a loss of life or serious injuries.



Indicates a potentially hazardous situation which, if not avoided, may result in a minor or moderate injuries.

It may also be used to alert against possible damage to the machine and its components.

Note

Supplementary explanation.

It is very difficult for us to forecast every danger that may occur during operation.

However, safety can be ensured by operating this machine according to methods recommended by Manitowoc.

While operating machine, be sure to perform work with great care, so as to not damage the machine, or let accidents occur.

Please continue studying this manual until proper operation is completely understood.

EXPLANATION OF WARNING LABELS IN THE MACHINE

Since the warning labels are installed in the machine and indicated with the three stages in the same way as the warning description, confirm the positions and contents of all warning labels first.


Put them to the practical use to secure safety when operating, checking and performing maintenance.


HANDLING OF WARNING LABELS IN THE MACHINE


- 1. When the warning label is damaged or stained, order it to the designated service shop.
- 2. Do not remove the warning labels.
- 3. When the surface of the warning label is soiled and difficult to be seen, wipe it cleanly.


LABEL LAYOUT


Numbers in the drawings correspond with those in the label explanation detail after "P.12"
























1. Ensure to read the operators manual before operation / handling / assembly / disassembly / transportation / inspection / maintenance of the machine.



When paying out the wire rope from the drum, ensure to set the free fall select switch to normal side.

3. The crane may turn over during work based on machine condition.

Install the proper amount of the counterweight and secure them to make proper machine configuration.

WARNING

- To prevent death or serious injury.
- Avoid unsafe operation or maintenance.
- Do not operate or work on this crane without first reading and understanding operator's manual and capacity charts.
- Keep manual in operator's cab. Attach Capacity charts to chain and store on hook provided in operator's cab.
- If operator's manual or capacity charts are lost, contact your nearest dealer for

CAUTION

SET FREE FALL INCREASED SELECTOR SWITCH TO "LOCK" POSITION WHEN REEVING WIRE ROPE.

DRUM AUTOMATICALLY ROTATES WITHOUT LOAD WHEN BRAKE IS RELEASED WITH FREE FALL INCREASED SELECTOR SWITCH SET TO "RELEASE" POSITION.

GG20T01893P1



TIPPING HAZARD! DO NOT LIFT WITH CRAWLERS RETRACTED

EXTEND CRAWLERS TO PROPER POSITION BEFORE LIFTING. COMPLY WITH LIMITATIONS GIVEN IN CAPACITY CHARTS.



GG20T01891P1

Published 12-16-15, Control #244-01 8500-1 / 8500E-1 12

- 4. If machine swings or is assembled / disassembled with crawler retracted, main machinery may turn over to rear side.
 - Read the operator's manual carefully and set the crane to the proper configuration.

- 5. If the brake pedal lock is not completely engaged, lifting load or hook may be lowered unexpectedly and is very dangerous. When locking the brake pedal, press the brake pedal fully and confirm that the pedal is locked completely.
- 6. During crane work if the boom comes to close to the tower or power lines, electric shock may hit the crane.

Keep the boom away from the tower or power lines for safety.

7. When work is done on the upper surface of the guard or counterweight, person may fall off by

Ensure to engage the safety hook on the specified place.

DANGER

TIPPING HAZARD!

When Operating With Retracted Crawlers


- ·DURING SETUP do not swing over retracted crawlers with boom removed (or just boom butt installed) and counterweights installed.
- ·DURING OPERATION comply with swing limitations given in Capacity

GG20T01890P1

CAUTION

WHEN LOCKING THE BRAKE PEDAL, STEP ON THE PEDAL FULLY TO LOCK THE PAWL AT THE BOTTOM NOTCH.

2432T5113



🕰 DANGER


ELECTROCUTION HAZARD


THIS CRANE IS NOT INSULATED

- To avoid death or serious injury, keep all parts of this crame rigging and materials being lifted at least 20ft(Gm)away from all electrical power lines and equipment.
- P Keep away from this crane if it is being operated near electrical power lines or equipment. Before operating this crame in vicinity of power lines or equipment, notify power utility company. Have power turned off.
- O Follow instructions in Operator's Manual.

Tieoff for fall arrest harness. GG20T01818P1 8. When the boom is assembled, disassembled, boom self erection / self lowering or crane work with the low gantry, the gantry or boom may be damaged and may fall off.

Raise the gantry to the proper position for work.





9. Free fall work of load may cause dropping the load by mishandling.

Use power lowering of load in the crane work. (Even on neutral free side, power lowering is possible by turning the lever to lowering side.)

1 DANGER

FALLING LOAD HAZARD!

OPERATING CRANE IN FREE FALL

MODE J MAY CAUSE LOAD TO FALL

DUE TO OPERATIONAL ERROR.

OPERATE CRANE IN FNEUTRAL BRAKE

MODE J.

GG20T01892P1

 This machine contains alloy and heat treated steels.

Do not weld or apply heat without checking with your authorized dealer.

Unauthorized modifications may weaken the machine.

11. Do not lift people with this crane.

Failure to do so may cause serious injury.

12. Wrong handling of battery may cause burns, blindness or explosion by inflammation.

If accumulator is handled in wrong way, burns, loss of eyesight, explosion may be caused.
 Take extra care in handling accumulator.
 (Do not weld, flame cut, dispose or disassemble.)

A CAUTION

THIS MACHINE CONTAINS ALLOY AND HEAT TREATED STEELS. DO NOT WELD OR APPLY HEAT WITHOUT CHECKING WITH YOUR AUTHORIZED DEALER. UNAUTHORIZED MODIFICATIONS MAY WEAKEN THE MACHINE.

2432T4671

A CAUTION

DO NOT LIFT PEOPLE WITH THIS CRANE. FAILURE TO DO SO MAY CAUSE SERIOUS INJURY.

2432T4668

A WARNING





- Electrolyte can cause injury or blindness if it contacts skin or eyes.
- Wear eye protection and protective clothing when handling or servicing batteries.
 If electrolyte contacts skin
- or eyes, flush affected areas immediately with clean water and seek medical attention immediately

GG20T01889P1

A WARNING



- PREVENT BATTERY EXPLOSION
 Batteries gives off hydrogen gases that can explode and cause personal injury.
 Keep sparks, open flames and cigarettes away from batteries.
 Keep metallic articles away from
- batteries.

 'Keep all ventilation caps tightly secured.

 'Never check charge by placing metal articles across battery terminals.

 'Leave battery box open to improve
- ventilation when charging. YN2OTO1001

A WARNING

COMPRESSED NITROGEN

DO NOT WELD, FLAMECUT DISPOSE IN FIRE, OR DISASSEMBLE.

GG20T01554P1

- 14. The accumulator is charged with high pressure nitrogen gas.
 - Charge the nitrogen gas within the specified pressure.
- 15. Using the fuel other than the specified diesel fuel may cause engine failure, fire or explosion. Ensure to use the diesel fuel in the fuel tank. Use ultra low sulfur diesel fuel only. (S50: sulfur content lower than 50 ppm)
- 16. After raising the gantry, ensure to insert the gantry fixing pin.
 - Otherwise the gantry may come off and the boom may drop off.
- 17. Handling the counterweight in wrong way is very dangerous.

Never allow any person to enter under the lifting counterweight.

 When working on the upper surface of the guard, person may fall off the upper surface of the guard.

During high place work on the upper surface of the guard, do not come close to the guard side face to prevent falling off.

During work on the upper surface of the guard, ensure to wear safety belt and hook the safety belt on the upper machinery and firmly stand on the guard.

<u>ACCUMULATOR</u> CHARGING GAS PRESSURE.

3.4 to 3.7MPa (493 to 537psi) GG20T01540P1



1 DANGER

When lock pin is not installed, do not stand under gantry.

JJ20T01097P1

1 DANGER

Do not stand on or under the counterweight during counterweight is moved by installing or removing. Failure to observe this precaution may result in serious injury or the loss of life.

JJ20T01326P1



 While the upper machinery is swinging, person may be crushed with the upper machinery.
 Never allow anybody to enter the swing range.





 During engine running or straight after the engine is stopped, hydraulic oil tank, engine and muffler are hot.

Touching them may cause burns.

Do not touch the hot area.



21. During engine running or right after the engine is stopped, inside of the radiator becomes high pressure and hot.

Person may get burns by hot water blow out when taking off the radiator cap.

Take extra care of opening or closing of the radiator cap.



22. When inspection or work is done by removing the drum flange cover, serious injuries may be caused if the drum rotates unexpectedly. Stop the crane and then remove the drum cover.



BURN AND **CUTTING HAZARD!**

Open only when engine is stopped.

JJ20T01506P1



PINCH HAZARD!

Open only when engine is stopped.

JJ20T01507P1

23. When the machine is transported with the low gantry, connect the tension bar to the revolving frame or counterweight.






FALLING LOAD HAZARD!

gantry pins when gantry is in high position Connect backhitch rtension barsı to rotating bed or counterweight when gantry is in low position

24. When working on the engine area for inspection and maintenance, person may be entangled with the fan belt and may get injured if the engine is running. Stop the engine when inspection or maintenance

work is done.




Rotating parts can cause personal injury.

Keep away from fan and belt when engine is running. Stop engine before servicing. YN20T01009P1

8500-1 / 8500E-1 Published 12-16-15, Control #244-01 18

25. There are some moving parts nearby.




CAUTION

Critical part inside.
Do not crush.

FP20T01116P1

26. This is a connector cover of electrical wiring of safety device.

Do not step on and crush.




Do not allow any person to enter the inside or under the boom during assembly or disassembly.




28. Taking wrong method in using the spreader guide installed on the boom base may damage the spreader guide.


Set the spreader guide to the stowed position except when the upper spreader is connected is connected to the boom base.



29. Taking the wrong installing direction when the rope sockets are installed to the boom tip and jib tip, may damage the boom or may break the wire rope.


Install the rope socket in the proper direction.






30. Free fall work of load may cause dropping the load by mishandling.

Use power lowering of load in the crane work. (Even on neutral free side, power lowering is possible by turning the lever to lowering side.)







31. When fill the water and/or diesel fuel etc. to this tank is danger and may lead to the faults. Fill the specified DEF/AdBlue® only.



32. One of the drum may stop rotation when the front and rear drums are used at the same time.Do not use the front and the rear drums together at the same time.



Not allowed to use main and aux. drums at the same time.

JJ20T01099P1

PRECAUTIONS FOR INSPECTION AND MAINTENANCE

- 1. Service and maintenance must be performed only by authorized personnel who are qualified in compliance with a relevant law or regulation.
- Regular maintenance or inspection should be quickly performed after shutting down the machine and ensuring safety to personnel and equipment.
 Post an "INSPECTION IN PROGRESS. DO NOT START." warning sign on a readily visible location.

GENERAL SAFETY PRECAUTIONS

- 1. Wear safety shoes, helmets and clothing suitable for the job. Also use protective goggles, mask, gloves, etc., as required.
- 2. To ensure safe and correct maintenance, carefully study this SHOP MANUAL and get fully familiar with the instructions in it.
- 3. Place the machine in a safe place. Always maintain safe clearance around the machine.
- 4. Before starting crane operation, hold a safety meeting. Also, make agreement on standardized hand signals.
- 5. When inspecting or handling the battery or oil, do not use exposed flame nearby. To avoid fire accident, only use explosion-proof lighting equipment.
- 6. Start an inspection or maintenance work only after shutting down the engine.
- 7. Certain machine components remain hot immediately after the engine is shut down. Do not touch them.
- 8. Before removing the radiator cap, wait until the coolant water gets sufficiently cool. Next, carefully loosen the cap and release radiator pressure, and them remove the cap.
- 9. Before inspecting or maintaining an electrical system on the machine, turn the power off the machine by, for example, disconnecting the battery cables.
- 10. When working at elevated place, always wear a safety harness.
- 11. When leaving the operator's cab for an inspection or maintenance work, post an "INSPECTION IN PROGRESS. DO NOT START." warning sign on a readily visible location. Also, lock the cab for security.
- 12. Before starting a cleaning or lubrication work on the machine, always shut down the engine.
- 13. Use genuine Manitowoc replacement parts and recommended oils only.
- 14. Always keep the oil containers clean. Protect them against ingress of dust or moisture. Also, fill clean, fresh oils only.
- 15. Once a maintenance work is complete, clean the machine.

 Protect grease nipples, breathers, and oil level gages against ingress of dust.
- 16. Clean the inspection area to allow detecting faulty such as oil leak, crack or looseness easily if existed.

- 17. During machine washing, do not allow high pressure steam to be directly applied to electrical components and connectors.
- 18. After removing O-rings, oil seals, gaskets, etc., clean the mounting seats. Then, install new O-rings, oil seals, gaskets, etc. Also, ensure to thinly apply oil to the seal faces of these parts before installation.
- 19. Before disconnecting pressurized piping, release the inside pressure.
- 20. CAUTIONs for repair work with welding: Turn OFF the key switch and disconnect the negative terminal on battery to power off the electrical circuit. Provide grounding within 1 meter from a weld area and remove electronic components (for example, controller) to prevent possible damage.
- 21. Dispose industrial wastes according to a relevant law or regulation.
- 22. Be extremely careful during an inspection or maintenance work under the carrier. Remember the possibility of being crashed.
 - When jacking up the machine for an inspection or maintenance work, place blocks below to prevent accidental falling.
- 23. Provide positive ventilation when refilling oils or fuel, rinsing parts, or starting the engine.
- 24. To remove a heavy component (20 kg or heavier), use a crane, etc. Always keep safety in mind.
- 25. Illegal, unauthorized, or nonconforming modification is strictly prohibited.
- 26. Do not allow oil or dust to deposit around the engine. Otherwise, fire accident can result.

 Clean the oil or dust adhered to.
- 27. Place removed attachments and components safely so that they do not drop or fall down.
- 28. Always use correct tools that have been well maintained.
- 29. To prevent personnel from being caught by a running fan, belt, shaft etc, shut down the engine before starting an inspection or maintenance work.
- 30. Battery fluid and oils are harmful to human health. If touching any of these materials, immediately wash it away.
- 31. When lifting a load with a crane, first confirm that a load is lifted off the ground surely and then continue lifting work.



1. REFERENCE MATERIALS


1.1	8500-1 SPECIFICATION	1-1
1.1.1	CRANE OUTSIDE DIMENSION	1-1
1.1.2	CRANE SPECIFICATION, PERFORMANCE	1-2
1.1.3	CRANE WORKING RANGES	1-4
1.2	8500-1 DIMENSION, WEIGHT OF EACH COMPONENT	1-7
1.2.1	BASE MACHINE	
1.2.2	COUNTERWEIGHT WITH SELF REMOVAL DEVICE	1-9
1.2.3	ATTACHMENT	1-10
1.3	8500-1 CLAMSHELL RATED LOADS (OPTION)	
1.4	8500-1 SWING AND TRAVEL STABILITY	
1.5	8500-1 TRAVEL ALLOWABLE SLOPE ANGLE	
1.5.1	CRANE ATTACHMENT INSTALLED : BOOM INSERT CONFIGURATION	
1.6	8500E-1 SPECIFICATION	
1.6.1	CRANE OUTSIDE DIMENSION	
1.6.2	CRANE SPECIFICATION, PERFORMANCE	
1.6.3	CRANE WORKING RANGES	
1.7	8500E-1 DIMENSION, WEIGHT OF EACH COMPONENT	
1.7.1	BASE MACHINE	
1.7.2	COUNTERWEIGHT	1-33
1.7.3	COUNTERWEIGHT WITH SELF REMOVAL DEVICE (OPTION)	
1.7.4	ATTACHMENT	
1.8	8500E-1 CLAMSHELL RATED LOADS (OPTION)	
1.9	8500E-1 SWING AND TRAVEL STABILITY	
1.10	8500E-1 TRAVEL ALLOWABLE SLOPE ANGLE	1-46
1.10.1	CRANE ATTACHMENT INSTALLED : BOOM INSERT CONFIGURATION	1-46
1.11	ENGINE MAIN SPECIFICATION	1-52



1. REFERENCE MATERIALS

1.1 8500-1 SPECIFICATION

1.1.1 CRANE OUTSIDE DIMENSION



1.1.2 CRANE SPECIFICATION, PERFORMANCE

8500-1

Туре	Full swing, crawler type	Full swing, crawler type		
Max. rated load × work radius	77.1 t × 3.35 m (170,000 lbs × 11')	77.1 t × 3.35 m (170,000 lbs × 11')		
Boom length				
Basic boom	12.2 m (40')	A		
Maximum boom	61.0 m (200')			
Crane jib	9.1 m (30') to 18.3 m (60')			
Maximum boom and jib	54.9 m (180') Boom + 18.3 m (60') Jib			
Work speed		Wire rope dia.		
Front / Rear hoisting rope speed	120 to 3 m/min (390 to 10 ft/min)	22 mm		
Front / Rear lowering rope speed	120 to 3 m/min (390 to 10 ft/min)	22 mm		
Boom raising rope speed	70 to 2 m/min (230 to 6.6 ft/min)	16 mm		
Boom lowering rope speed	70 to 2 m/min (230 to 6.6 ft/min)	10 mm		
Third hoisting rope speed (option)	120 to 3 m/min (390 to 10 ft/min)	22 mm		
Third lowering rope speed (option)	120 to 3 m/min (390 to 10 ft/min)	22 111111		
Swing speed	4.0 min ⁻¹ (4.0 rpm)			
Travel speed	1.7/1.1 km/h (1.1/0.72 MPH)	1.7/1.1 km/h (1.1/0.72 MPH)		
Gradability	40%	40%		
Working weight *1	75.16 t (165,700 lbs)	75.16 t (165,700 lbs)		
Average ground pressure *1	74.2 kPa (10.8 psi)	74.2 kPa (10.8 psi)		
Engine				
Engine name	Hino J08E-VV	Hino J08E-VV		
Engine out put	213 kW/2,100 min ⁻¹ (286 HP/2,100 rpm	213 kW/2,100 min ⁻¹ (286 HP/2,100 rpm)		

^{*1} Crane (12.2 m [40'], Without rear drum rope, Without main hook)

Note

The wire rope speeds described above are the value of the drum first layer.

Each wire rope speed varies depend on the load.


8500-1

OUTSIDE DIMENSIONS Unit : mm (ft. in.)

Overall width of cab	2,990 (9′ 10″)
Radius of rear end (counterweight)	4,500 (14′ 9″)
Center of rotation to rear end (low gantry position)	5,140 (16′ 10″)
Center of rotation to boom foot pin (from center of rotation)	1,100 (3′ 7″)
Height from ground to boom foot pin	1,750 (5′ 9″)
Height to top of gantry (working position)	6,170 (20′ 3″)
Height to top of gantry (low gantry position)	3,300 (10′ 10″)
Counterweight ground clearance	1,100 (3′ 7″)
Overall length of crawlers	6,280 (20′ 7″)
Distance between centers of tumblers	5,440 (17′ 10″)
Overall width of crawlers (extend/retract)	5,244 / 3,614 (17' 2" / 11' 10")
Width of crawler shoe	914 (3')
Ground clearance of carbody	390 (1′ 3″)


1.1.3 CRANE WORKING RANGES

1. Crane working ranges




2. Jib working range

(1) Offset angle 10 degrees



(2) Offset angle 30 degrees

8500-1



1.2 8500-1 DIMENSION, WEIGHT OF EACH COMPONENT

Dimension and weight of each component when disassembled is shown here.

Use this as reference value.

1.2.1 BASE MACHINE

	Name			Dimension mm : (ft. in.)		Weight : kg (lbs)
	Gantry	0				
on 1	Boom base	0		12,090 (39' 8")		
urati	Boom drum	0		= 12,000 (00 0)		
Transportation configuration 1	Wire rope (Front, rear, boom drum)	0	3,300 (10' 10")		(10' 10')	41,810 (92,200)
tation	Self removal device	0	3 (10	o E a a a a a a a a a a a a a a a a a a		(92,200)
spor	Side step	0			3,615 (11' 10")	
Tran	Crawler	0			< (,	
	Translifter (option)	×				
	Gantry	0				
on 2	Boom base	×		8,210 (26′ 11″)		
urati	Boom drum	0		3,210 (20 11)		
Transportation configuration 2	Wire rope (Front, rear, boom drum)	0	3,300 (10' 10")		(10',10")	39,895
tation	Self removal device	0	3 (10	o E a a a a a a a a a a a a a a a a a a		(88,000)
spor	Side step	0			3,615 (11′ 10″)	
Tran	Crawler	0			< · · · · · · · · · · · · · · · · · · ·	
	Translifter (option)	×				
	Gantry	0				
on 3	Boom base	0		40,000 (201.01)	2,990	
urati	Boom drum	0		12,090 (39' 8")	(9′ 10″)*1	
Transportation configuration 3	Wire rope (Front, rear, boom drum)	0	2,910 (9' 7")	8	(18,8)	27,940 (61,600)
tatio	Self removal device	0	2 (6	N N N N N N N N N N N N N N N N N N N		(61,000)
spor	Side step	×		4,175 (13' 8")	2,990 (9' 10")	
Tran	Crawler	×		 	- ' ' >	
	Translifter (option)	0				

○: With ×: Without

^{*1} With the side step on cabin side : 3,160 (10' 4") With the side steps on the both side : 3,340 (11')


8500-1

	Name		Dimension mm : (ft. in.)	
	Gantry	0		
on 4	Boom base	×	2,990	
urati	Boom drum	0	7,700 (25' 3")	
Transportation configuration 4	Wire rope (Front, rear, boom drum)	0	2,910 (9'7') (9'8')	26,030 (57,400)
tation	Self removal device	0		(57,400)
spor	Side step	×	4,175 (13' 8") 2,990 (9' 10")	
Tran	Crawler	×	 	
	Translifter (option)	0		
Crav	wler		6,280 (20' 7") 914 (3') 08	7,550 (16,700)
Trar	nslifter (option)		1,620 (5' 4")	290 (640) / 1 piece

○: With ×: Without

*1 With the side step on cabin side : 3,160 (10' 4") With the side steps on the both side : 3,340 (11')

1.2.2 COUNTERWEIGHT WITH SELF REMOVAL DEVICE



1.2.3 ATTACHMENT

Name	Dimension mm : (ft. in.)		Weight : kg (lbs)
Boom tip	1,380 (4'6") 6,900 (22'8")		1,025 (2,300)
Boom base	5,970 (19' 7")	1,510 (4' 11") 1,360 (4' 6")	1,120 (2,500)
3.0 m (10') Boom insert	3,165 (10' 5")	1,380 (4, 4, 1, 3, 15)	275 (610)
6.1 m (20') Boom insert	6,210 (20' 4")	1,380	475 (1,100)
12.2 m (40') Boom insert	12,310 (40′ 5″)	1,380 (4, 6,,)	870 (1,900)
12.2 m (40') Boom insert with lug	12,310 (40' 5")	1,380 (4, 4")	885 (2,000)
Backstop	5,130 (16′ 10″)	□ ±	270 (600)

Name	Dimension mm : (ft. in.)	Weight : kg (lbs)
Jib tip	800 (2' 8") 4,910 (16' 1")	220 (490)
Jib base	4,810 (15' 9") 800 (2' 8")	200 (440)
3.0 m (10') Jib insert	3,110 (10'2") 800 (2'8")	95 (210)
6.1 m (20') Jib insert	6,160 (20' 3") 800 (2' 8")	175 (390)
Jib strut	3,620 (11' 11")	210 (460)
Auxiliary sheave	830 (2' 9")	145 (320)
Upper spreader	1,460 (4' 9")	235 (520)

1.3 8500-1 CLAMSHELL RATED LOADS (OPTION)

CLAMSHELL SPECIFICATION

 Rated loads included in the charts are the maximum allowable freely suspended loads at a given boom length, boom angle and load radius, and have been determined for the machine standing level on firm supporting surface under ideal operating conditions.

The user must limit or de-rate rated loads to allow for adverse conditions (such as soft or uneven ground, out-of-level conditions, wind, side loads, pendulum action, jerking or sudden stopping of loads, inexperience of personnel, multiple machine lifts, and traveling with a load).

2. Rated loads do not exceed 66% of minimum tipping loads.

Rated loads based on factors other than machine stability such as structural competence are shown by asterisk * in the charts.

The machine must be reeved and set-up as stated in the operation manual and all the instruction manuals.

If these manuals are missing, obtain replacements.

- Boom backstops are required for all boom lengths.
- Gantry must be fully raised position for all operations.
- Crawlers must be fully extended and be locked in position.
- The crane must be leveled to within 1% on a firm supporting surface.
- 39,000 lbs Counterweight and without carbody weight.
- 4. Do not attempt to lift where no radius is shown on the load chart as crane may tip or collapse.
- 5. Attempting to lift more than rated loads may cause machine to tip or collapse.

Do not tip machine to determine rated loads.

6. Weight of bucket, slings and other lifting devices are a part of the total load.

Their total weight must be subtracted from the rated load to obtain the weight that can be lifted.

- 7. The boom should be erected over the front of the crawlers, not laterally.
- 8. Least stable position is over the side.

MAXIMUM LOAD FOR MAIN BOOM

No. of Part of Line	1
Maximum Loads (lbs)	16,000

Rated loads listed later is to be applied only to the machine as manufactured and designed by manufacture.

Do not apply any modification to this machine and do not use of this machine other than the specified.

- 10. ASSEMBLING THE COUNTERWEIGHT
- 39,000 lbs Counterweight
- Without carbody counterweight.

Operation of this equipment in excess of rated loads or disregard of instruction voids the warranty.





8500-1

CLAMSHELL CAPACITIES IN POUNDS THREE COUNTERWEIGHTS (39,000 lbs) WITHOUT CARBODY WEIGHTS (0 lbs) CRAWLERS: EXTENDED POSITION

40' Boom				
Load	Boom	360°		
Radius	Angle	Rated Load		
(ft.)	(deg.)	(lbs)		
22.0	63.6	16,000 *		
24.0	60.3	16,000 *		
26.0	56.9	16,000 *		
28.0	53.4	16,000 *		
30.0	49.7	16,000 *		
32.0	45.7	16,000 *		
34.0	41.5	16,000 *		
36.0	36.9	16,000 *		
38.0	31.6	16,000 *		
40.0	25.5	16,000 *		

50' Boom				
Load	Boom	360°		
Radius	Angle	Rated Load		
(ft.)	(deg.)	(lbs)		
26.0	64.2	16,000 *		
28.0	61.6	16,000 *		
30.0	58.9	16,000 *		
32.0	56.2	16,000 *		
34.0	53.3	16,000 *		
36.0	50.4	16,000 *		
38.0	47.3	16,000 *		
40.0	44.1	16,000 *		
42.0	40.6	16,000 *		
44.0	36.9	16,000 *		
46.0	32.8	16,000 *		
48.0	28.2	15,400 *		


	60' Boom				
Load	Boom	360°			
Radius	Angle	Rated Load			
(ft.)	(deg.)	(lbs)			
30.0	64.5	16,000 *			
32.0	62.4	16,000 *			
34.0	60.2	16,000 *			
36.0	58.0	16,000 *			
38.0	55.7	16,000 *			
40.0	53.3	16,000 *			
42.0	50.9	16,000 *			
44.0	48.3	16,000 *			
46.0	45.7	16,000 *			
48.0	42.9	15,200 *			
50.0	40.0	14,500 *			
52.0	36.9	13,600			
54.0	33.5	13,000			
56.0	29.8	12,300			
58.0	25.6	11,900			

	70' Boom				
Load	Boom	360°			
Radius	Angle	Rated Load			
(ft.)	(deg.)	(lbs)			
34.0	64.8	16,000 *			
36.0	63.0	16,000 *			
38.0	61.1	16,000 *			
40.0	59.2	16,000 *			
42.0	57.3	16,000 *			
44.0	55.3	15,800 *			
46.0	53.3	15,600 *			
48.0	51.2	15,200 *			
50.0	49.0	14,300 *			
52.0	46.8	13,600 *			
54.0	44.5	13,000 *			
56.0	42.1	12,300 *			
58.0	39.6	11,600 *			
60.0	36.9	11,200 *			
62.0	34.0	10,800 *			
64.0	30.9	10,100 *			
66.0	27.5	9,700 *			

1.4 8500-1 SWING AND TRAVEL STABILITY

The stability while swinging and traveling of the machine is to be varied depending on the mass of counterweight, condition of the attachment, extension or retraction of the crawler and traveling on the slope. The operation must be started after confirm the machine stability while swinging and traveling by referring with following table.

- The table above shows the values for operation on firm ground.
 On a weak ground, operate with care after
 - On a weak ground, operate with care after improving the ground.
- 2. Swinging on a trailer is prohibited.
- 3. Maximum slope angle is 21.8 degrees (40%). This may become lower depending on condition (ground, crane configuration).
- 4. Traveling "forward" means that the counterweight is at the lower side of the slope, and "backward" is the counterweight is at the higher side of the slope.



8500-1

TABLE FOR STABILITY (WITHOUT CARBODY WEIGHT)

Attachment	Counterweight	All-roun	nd swing	Travel on slope	
Attachment	Counterweight	Crawler extend	Crawler retract	Forward	Backward
	Without : 0 t	0	0	0	0
Without attachment	No.1: 9.32 t (20,550 lbs)	0	×	\(\triangle \) (Slope 14 degrees or less)	0
(Base machine only)	No.1 to No.2 : 17.72 t (39,070 lbs)	0	×	×	0
	No.1 to No.3 : 26.12 t (57,590 lbs)	×	×	×	×
	Without : 0 t	0	0	0	0
With boom base	No.1: 9.32 t (20,550 lbs)	0	0	0	0
(Boom angle : 10 degrees or less)	No.1 to No.2 : 17.72 t (39,070 lbs)	0	×	(Slope 5 degrees or less)	0
	No.1 to No.3 : 26.12 t (57,590 lbs)	△ (No abrupt lever control)	×	×	△ (No abrupt lever control)
	Without : 0 t	0	0	0	0
With basic boom (Boom angle : 30 degrees or less)	No.1: 9.32 t (20,550 lbs)	0	0	0	0
	No.1 to No.2 : 17.72 t (39,070 lbs)	0	×	(Slope 11 degrees or less)	0
	No.1 to No.3 : 26.12 t (57,590 lbs)	0	×	×	0

 \bigcirc : Allowed \triangle : With restriction \times : Not allowed

8500-1

TABLE FOR STABILITY (WITH CARBODY WEIGHT)

		All-roun	d swing	Travel o	on slope
Attachment	Counterweight	Crawler extend	Crawler retract	Forward	Backward
	Without : 0 t	0	0	0	0
Without attachment	No.1: 8.31 t (18,320 lbs)	0	△ (No abrupt lever control)	0	0
(Base machine only)	No.1 to No.2 : 19.81 t (43,674 lbs)	0	×	(Slope 4 degrees or less)	0
	No.1 to No.3 : 31.31 t (69,028 lbs)	△ (No abrupt lever control)	×	×	△ (No abrupt lever control)
	Without : 0 t	0	0	0	0
With boom base	No.1: 8.31 t (18,320 lbs)	0	0	0	0
(Boom angle : 10 degrees or less)	No.1 to No.2 : 19.81 t (43,674 lbs)	0	×	△ (Slope 11 degrees or less)	0
	No.1 to No.3 : 31.31 t (69,028 lbs)	0	×	×	0
	Without : 0 t	0	0	0	0
With basic boom	No.1: 8.31 t (18,320 lbs)	0	0	0	0
(Boom angle : 30 degrees or less)	No.1 to No.2 : 19.81 t (43,674 lbs)	0	△ (No abrupt lever control)	△ (Slope 16 degrees or less)	0
	No.1 to No.3 : 31.31 t (69,028 lbs)	0	×	△ (Slope 4 degrees or less)	0

 \bigcirc : Allowed \triangle : With restriction \times : Not allowed

1.5 8500-1 TRAVEL ALLOWABLE SLOPE ANGLE

1.5.1 CRANE ATTACHMENT INSTALLED: BOOM INSERT CONFIGURATION

A CAUTION

Do not travel with the symbol of "-" in the table.


The machine may possible turnover.

Failure to observe this precaution may result in a serious accident.

If the machine has to travel by some reason, observe the following points.

- · Do not travel with a load lifted.
- · Travel with low speed and gently.
- · Travel on the flat and firm ground.
- Ensure to check the ground condition and travel on the slope angle smaller than shown in the chart.
- Travel straight against slope.
- Provide the gentle slope at the beginning and end positions of slope.

TRAVEL UPWARD DOWNWARD ON SLOPE (θ: ALLOWABLE ANGLE)



1. Crane travel allowable slope angle

(1) Without Aux. sheave

8500-1

(Unit : Degree)

(0:1112-03-04)						
		Forward		Backward		
Boom length m (ft.)	Boom angle			Boom angle		
	35	40	50	40	50	60
12.2 (40)	5	5	4	8	8	8
15.2 (50)	6	6	4	8	8	8
18.3 (60)	8	8	6	8	8	8
21.3 (70)	8	8	6	8	8	8
24.4 (80)	8	8	7	8	8	8
27.4 (90)	8	8	8	8	8	8
30.5 (100)	8	8	8	8	8	8
33.5 (110)	8	8	8	8	8	8
36.6 (120)	8	8	8	8	8	8
39.6 (130)	8	8	8	8	8	8
42.7 (140)	8	8	8	8	8	8
45.7 (150)	8	8	8	8	8	8
48.8 (160)	8	8	8	8	8	8
51.8 (170)	8	8	8	8	8	8
54.9 (180)	8	8	8	7	8	8

(2) With Aux. sheave

8500-1

		Forward			Backward			
Boom length m (ft.)	Boom angle			Boom angle				
	35	40	50	40	50	60		
12.2 (40)	5	5	4	8	8	8		
15.2 (50)	6	6	4	8	8	8		
18.3 (60)	8	8	6	8	8	8		
21.3 (70)	8	8	6	8	8	8		
24.4 (80)	8	8	7	8	8	8		
27.4 (90)	8	8	8	8	8	8		
30.5 (100)	8	8	8	8	8	8		
33.5 (110)	8	8	8	8	8	8		
36.6 (120)	8	8	8	8	8	8		
39.6 (130)	8	8	8	8	8	8		
42.7 (140)	8	8	8	8	8	8		
45.7 (150)	8	8	8	8	8	8		
48.8 (160)	8	8	8	8	8	8		
51.8 (170)	8	8	8	8	8	8		

2. Fixed jib travel allow slope angle

8500-1

(Unit : Degree)

Jib length m (ft.)	9.1 (30)					
Offset angle			1	0		
Configuration		Forward			Backward	t
Decree length as (ft.)	Е	Boom ang	le	Е	Boom ang	le
Boom length m (ft.)	35	40	50	40	50	60
24.4 (80)	8	8	8	8	8	8
27.4 (90)	8	8	8	8	8	8
30.5 (100)	8	8	8	8	8	8
33.5 (110)	8	8	8	8	8	8
36.6 (120)	8	8	8	8	8	8
39.6 (130)	8	8	8	8	8	8
42.7 (140)	8	8	8	8	8	8
45.7 (150)	8	8	8	8	8	8
48.8 (160)	8	8	8	8	8	8
51.8 (170)	8	8	8	7	8	8
54.9 (180)	8	8	8	4	7	8

					,	<i>B</i> 09.00)
Jib length m (ft.)	9.1 (30)					
Offset angle			3	0		
Configuration		Forward			Backward	d
Deem length m (ft.)	Е	Boom ang	le	В	oom ang	le
Boom length m (ft.)	35	40	50	40	50	60
24.4 (80)	8	8	8	8	8	8
27.4 (90)	8	8	8	8	8	8
30.5 (100)	8	8	8	8	8	8
33.5 (110)	8	8	8	8	8	8
36.6 (120)	8	8	8	8	8	8
39.6 (130)	8	8	8	8	8	8
42.7 (140)	8	8	8	8	8	8
45.7 (150)	8	8	8	8	8	8
48.8 (160)	8	8	8	8	8	8
51.8 (170)	8	8	8	7	8	8
54.9 (180)	8	8	8	4	7	8

8500-1

(Unit : Degree)

Jib length m (ft.)	12.2 (40)					
Offset angle			1	0		
Configuration		Forward			Backward	ł
Deare langth m (ft)	Е	Boom ang	le	В	oom ang	le
Boom length m (ft.)	35	40	50	40	50	60
24.4 (80)	8	8	8	8	8	8
27.4 (90)	8	8	8	8	8	8
30.5 (100)	8	8	8	8	8	8
33.5 (110)	8	8	8	8	8	8
36.6 (120)	8	8	8	8	8	8
39.6 (130)	8	8	8	8	8	8
42.7 (140)	8	8	8	8	8	8
45.7 (150)	8	8	8	8	8	8
48.8 (160)	8	8	8	8	8	8
51.8 (170)	8	8	8	5	8	8
54.9 (180)	8	8	8	1	5	8

					`	B09.00)
Jib length m (ft.)	12.2 (40)					
Offset angle			3	60		
Configuration		Forward			Backward	I
Decree les ette es (ft.)	E	Boom ang	le	В	oom ang	le
Boom length m (ft.)	35	40	50	40	50	60
24.4 (80)	8	8	8	8	8	8
27.4 (90)	8	8	8	8	8	8
30.5 (100)	8	8	8	8	8	8
33.5 (110)	8	8	8	8	8	8
36.6 (120)	8	8	8	8	8	8
39.6 (130)	8	8	8	8	8	8
42.7 (140)	8	8	8	8	8	8
45.7 (150)	8	8	8	8	8	8
48.8 (160)	8	8	8	8	8	8
51.8 (170)	8	8	8	5	8	8
54.9 (180)	8	8	8	1	5	8

8500-1

(Unit : Degree)

Jib length m (ft.)	15.2 (50)					
Offset angle			1	0		
Configuration		Forward			Backward	t
Doors longth as (ft.)	Е	Boom ang	le	В	Boom ang	le
Boom length m (ft.)	80	40	50	40	50	60
24.4 (80)	4	8	8	8	8	8
27.4 (90)	3	8	8	8	8	8
30.5 (100)	3	8	8	8	8	8
33.5 (110)	2	8	8	8	8	8
36.6 (120)	2	8	8	8	8	8
39.6 (130)	2	8	8	8	8	8
42.7 (140)	2	8	8	8	8	8
45.7 (150)	1	8	8	8	8	8
48.8 (160)	1	8	8	6	8	8
51.8 (170)	1	8	8	2	6	8
54.9 (180)	-	8	8	-	3	8

(Still: Begree)						
Jib length m (ft.)	15.2 (50)					
Offset angle			3	30		
Configuration		Forward			Backward	ł
Doom longth m (ft)	Е	Boom ang	le	В	Boom ang	le
Boom length m (ft.)	80	40	50	40	50	60
24.4 (80)	4	8	8	8	8	8
27.4 (90)	4	8	8	8	8	8
30.5 (100)	4	8	8	8	8	8
33.5 (110)	3	8	8	8	8	8
36.6 (120)	3	8	8	8	8	8
39.6 (130)	2	8	8	8	8	8
42.7 (140)	2	8	8	8	8	8
45.7 (150)	2	8	8	8	8	8
48.8 (160)	2	8	8	6	8	8
51.8 (170)	1	8	8	2	6	8
54.9 (180)	1	8	8	-	3	8

8500-1

(Unit : Degree)

Jib length m (ft.)	18.3 (60)					
Offset angle			1	0		
Configuration		Forward			Backward	t
De ana lamath na (ft)	Е	oom ang	le	В	oom ang	le
Boom length m (ft.)	80	40	50	40	50	60
24.4 (80)	4	8	8	8	8	8
27.4 (90)	3	8	8	8	8	8
30.5 (100)	3	8	8	8	8	8
33.5 (110)	2	8	8	8	8	8
36.6 (120)	2	8	8	8	8	8
39.6 (130)	2	8	8	8	8	8
42.7 (140)	1	8	8	8	8	8
45.7 (150)	1	8	8	8	8	8
48.8 (160)	1	8	8	4	7	8
51.8 (170)	1	8	8	-	4	8
54.9 (180)	-	8	8	-	2	6


					(Dog.oo,
Jib length m (ft.)	18.3 (60)					
Offset angle			3	0		
Configuration		Forward			Backward	d
De ana lameth na (ft.)	E	Boom ang	le	В	oom ang	le
Boom length m (ft.)	80	40	50	40	50	60
24.4 (80)	4	8	8	8	8	8
27.4 (90)	4	8	8	8	8	8
30.5 (100)	4	8	8	8	8	8
33.5 (110)	3	8	8	8	8	8
36.6 (120)	3	8	8	8	8	8
39.6 (130)	3	8	8	8	8	8
42.7 (140)	2	8	8	8	8	8
45.7 (150)	2	8	8	8	8	8
48.8 (160)	2	8	8	4	7	8
51.8 (170)	1	8	8	-	4	8
54.9 (180)	1	8	8	-	1	6

1.6 8500E-1 SPECIFICATION


1.6.1 CRANE OUTSIDE DIMENSION

1. Standard counterweight





2. Counterweight with self-removable device (Option)



1.6.2 CRANE SPECIFICATION, PERFORMANCE

8500E-1

Туре	Full swing, crawler type			
Max. rated load × work radius	80.0 t × 3.0 m (176,370 lbs × 10')			
Boom length				
Basic boom	9.1 m (30')	A		
Maximum boom	54.9 m (180')			
Crane jib	6.1 m (20') to 18.3 m (60')			
. Maximum beam and iib	45.7 m (150') Boom + 12.2 m (40') Jib			
Maximum boom and jib	42.7 m (140') Boom + 18.3 m (60') Jib			
Work speed		Wire rope dia.		
Front / Rear hoisting rope speed	120 to 3 m/min (390 to 10 ft/min)	22 mm		
Front / Rear lowering rope speed	120 to 3 m/min (390 to 10 ft/min)	22 mm		
Boom raising rope speed	70 to 2 m/min (230 to 6.6 ft/min)	16 mm		
Boom lowering rope speed	70 to 2 m/min (230 to 6.6 ft/min)	16 111111		
Third hoisting rope speed (option)	120 to 3 m/min (390 to 10 ft/min)	00		
Third lowering rope speed (option)	120 to 3 m/min (390 to 10 ft/min)	22 mm		
Swing speed	4.0 min ⁻¹ (4.0 rpm)			
Travel speed	1.7/1.1 km/h (1.1/0.72 MPH)			
Gradability	40%			
Working weight *1	75.19 t (165,700 lbs)			
Average ground pressure *1	84.78 kPa (12.3 psi)			
Engine				
Engine name	Hino J08E-VV			
Engine out put	213 kW/2,100 min ⁻¹ (286 HP/2,100 rpm)			

^{*1} Crane (12.2 m [40'], Without rear drum rope, With 80 t hook block)

Note

The wire rope speeds described above are the value of the drum first layer.

Each wire rope speed varies depend on the load.


8500E-1

OUTSIDE DIMENSIONS Unit : mm (ft. in.)

Overall width of cab	2,990 (9' 10")
Radius of rear end (counterweight) (standard/option)	4,300 (14′ 1″) / 4,500 (14′ 9″)
Center of rotation to rear end (low gantry position)	5,140 (16′ 10″)
Center of rotation to boom foot pin (from center of rotation)	1,100 (3′ 7″)
Height from ground to boom foot pin	1,750 (5′ 9″)
Height to top of gantry (working position)	6,170 (20′ 3″)
Height to top of gantry (low gantry position)	3,300 (10′ 10″)
Counterweight ground clearance (standard/option)	1,100 (3′ 7″)
Overall length of crawlers	6,280 (20′ 7″)
Distance between centers of tumblers	5,440 (17′ 10″)
Overall width of crawlers (extend/retract)	5,130 / 3,500 (16' 10" / 11' 6")
Width of crawler shoe	800 (2' 7")
Ground clearance of carbody	390 (1′ 3″)


1.6.3 CRANE WORKING RANGES

1. Crane working ranges




2. Jib working range

(1) Offset angle 10 degrees



(2) Offset angle 30 degrees




8500E-1 DIMENSION, WEIGHT OF EACH COMPONENT

Dimension and weight of each component when disassembled is shown here.

Use this as reference value.

1.7.1 **BASE MACHINE**



○: With ×: Without

With the side step on cabin side: 3,160 (10' 4") With the side steps on the both side: 3,340 (11')


8500E-1

Name			Dimension mm : (ft. in.)	
on 4	Gantry	0		
	Boom base	×	2,990	
urati	Boom drum	0	7,700 (25' 3")	
Transportation configuration 4	Wire rope (Front, rear, boom drum)	0	(9°7") (9°7") (9°8")	24,680 (54,405)
tatior	Self removal device	X		(54,405)
spor	Side step	×	4,175 (13' 8") 2,990 (9' 10")	
Tran	Crawler	×	- (1007) - (1007)	
	Translifter (option)	0		
Crav	wler		6,280 (20' 7") 800 (2' 7") 086 E 1,020 (3' 4")	7,175 (15,820)
Tran	nslifter (option)		1,620 (5' 4")	290 (640) / 1 piece

○: With ×: Without

*1 With the side step on cabin side : 3,160 (10' 4")
With the side steps on the both side : 3,340 (11')

1.7.2 COUNTERWEIGHT



1.7.3 COUNTERWEIGHT WITH SELF REMOVAL DEVICE (OPTION)

Name	Dimension mm : (ft. in.)	Weight : kg (lbs)
	1,010	
Counterweight (1)	4,430 (14′ 6″)	9,320 (20,500)
	825 (2'8")	
Left side Counterweight (2),(4)	910 (2' 12") 1,450 (4' 9") 096 E	4,200 (9,260) / 1 piece
Right side Counterweight (3),(5)	910 (2' 12")	4,200 (9,260) / 1 piece
Self removal unit	1,590 (5' 3") 880 (2' 11")	860 (1,900)

1.7.4 ATTACHMENT

Name	Dimension mm : (ft. in.)		Weight : kg (lbs)
Boom tip	1,490 (4'11") 4,550 (14'11")		1,110 (2,450)
Boom base	5,350 (17' 7")	1,615 (5' 4") 1,490 (4' 11")	1,130 (2,485)
3.0 m (10') Boom insert	3,165 (10′ 5″)	1,490 (4,11,)	310 (675)
6.1 m (20') Boom insert	6,210 (20' 4")	1,490 (4,11,)	525 (1,160)
6.1 m (20') Boom insert with lug	6,210 (20, 4,,)	1,490 (4' 11")	550 (1,215)
9.1 m (30') Boom insert	9,260 (30′ 5″)	1,490 (4,11,1)	745 (1,645)
9.1 m (30') Boom insert with lug	9,260 (30, 2,,)	1,490 (4,11,)	770 (1,700)
Backstop	4,650 (15′ 3″)		245 (530)

Name	Dimension mm : (ft. in.)	Weight : kg (lbs)
Jib tip	670 (2' 2") 3,400 (11' 2")	145 (320)
Jib base	3,180 (10' 5") 670 (2' 2")	125 (275)
6.1 m (20') Jib insert	6,160 (20' 3") 6,160 (20' 3")	140 (310)
Jib strut	3,620 (11' 11")	190 (420)
Auxiliary sheave	1,120 (3' 8")	150 (310)
Upper spreader	1,580 (5' 2") 1,580 (5' 2")	280 (620)

8500E-1


Name	Dimension mm : (ft. in.)	Weight : kg (lbs)
Ball hook	300 (1')	160 (355)
19 t Hook	390 (1, 2, 7) (2, 7) (1, 11, 11, 11, 11, 11, 11, 11, 11, 11,	400 (885)
32 t Hook	330 (2, 7, 7) (1, 11, 1	500 (1,105)
50 t Hook	440 (4, 10") (1, 20 (3' 4") (1, 11, 1) (1, 11, 1) (1, 11, 1)	650 (1,435)
80 t Hook	1,710 (5'7") 1,150 (3'9") (1, 8, 1) 230 (3, 9") (1, 8, 1) (1, 8, 1) (2, 1) (3, 9") (4, 1) (5, 1) (6, 1) (7, 1) (7, 1) (8, 1) (8, 1) (9, 1) (1, 1) (9, 1) (1,	800 (1,765)

1.8 8500E-1 CLAMSHELL RATED LOADS (OPTION)

- Operating radius is the horizontal distance from center line of rotation to a vertical line through the center of gravity of the load.
- Deduct weight of bucket, slings and all other load handling accessories from main boom ratings shown.
- Ratings shown are based on freely suspended loads and make no allowance for such factors as wind effect on lifted load, ground conditions, out-of-level, operating speeds or any other condition that could be detrimental to the safe operation of this equipment.

The operator, therefore, has the responsibility to judge the existing conditions and reduce lifted loads and operating speeds accordingly.

- Rated loads do not exceed 66% of minimum tipping loads.
- Ratings are for operation on a firm and level surface, up to 1% gradient.
- At radii and boom lengths where no ratings are shown on chart, operation is not intended nor approved.
- Boom inserts and guy lines must be arranged as shown in the "OPERATOR'S MANUAL".
- · Boom hoist reeving is 12 part line.
- Gantry must be in raised position for all conditions.
- Boom backstops are required for all boom lengths.
- The boom should be erected over the front of the crawlers, not laterally.
- Crawler frames must be fully extended for all crane operations.



(CLAMSHELL BUCKET LIFTING)

- The total load that can be lifted is the value for weight of bucket, slings, and all other load handling accessories deducted from main boom ratings shown.
- The weight of bucket and materials must not exceed rated load.
- Optimum bucket should be required according to material.
- Bucket capacity (m³) × Specified gravity of material (ton/m³) + Bucket weight (ton) = Rated load.
- Bucket weight must also be decreased according to operating cycle and bucket lowering height.
- Rated loads are determined by stability and boom strength.
 - During simultaneous operations of boom and swing, rapid acceleration or deceleration must be avoided.
- Do not attempt to cast the bucket while swinging or diagonal draw-cutting.


MAIN HOIST LOADS

No. of part of line	1
Maximum loads (kN)	69
Maximum Loads (t)	7.0


ASSEMBLING THE COUNTERWEIGHT

22.8 ton counterweight Without carbody weight

Operation of this equipment in excess of rated loads or disregard of instruction voids the warranty.



COUNTERWEIGHTS



8500E-1

CLAMSHELL CAPACITIES WITH THREE COUNTERWEIGHTS (22.8 ton) WITHOUT CARBODY WEIGHTS (0 ton) CRAWLERS: EXTENDED POSITION


(Unit: metric ton)

				(
	BOOM LENGTH								
Working Radius(m)	9.1m	12.2m	15.2m	18.3m	21.3m				
5	7.0								
5.5	7.0								
6	7.0	7.0							
7	7.0	7.0	7.0						
8	7.0	7.0	7.0	7.0					
9	7.0	7.0	7.0	7.0	7.0				
10		7.0	7.0	7.0	7.0				
12			7.0	7.0	7.0				
14			7.0	7.0	7.0				
16				7.0	7.0				
18					7.0				

1.9 8500E-1 SWING AND TRAVEL STABILITY

The stability while swinging and traveling of the machine is to be varied depending on the mass of counterweight, condition of the attachment, extension or retraction of the crawler and traveling on the slope. The operation must be started after confirm the machine stability while swinging and traveling by referring with following table.

- The table above shows the values for operation on firm ground.
 On a weak ground, operate with care after
 - On a weak ground, operate with care after improving the ground.
- 2. Swinging on a trailer is prohibited.
- 3. Maximum slope angle is 21.8 degrees (40%). This may become lower depending on condition (ground, crane configuration).
- 4. Traveling "forward" means that the counterweight is at the lower side of the slope, and "backward" is the counterweight is at the higher side of the slope.



8500E-1

TABLE FOR STABILITY (WITHOUT CARBODY WEIGHT)

Attachment	Countomusiaht	All-round swing		Travel on slope		
Attachment	Counterweight	Crawler extend	Crawler retract	Forward	Backward	
	Without : 0 t	0	0	0	0	
	No.1: 8.53 t (18,805 lbs)	0	△ (No abrupt lever control)	0	0	
Without attachment (Base machine only)	No.1 to No.2 : 16.39 t (36,135 lbs)	0	×	△ (Slope 0 degrees or less)	0	
	No.1 to No.3 : 22.8 t (50,265 lbs)	△ (No abrupt lever control)	×	×	△ (No abrupt lever control)	
	No.1 to No.4 : 27.2 t (59,965 lbs)	×	×	×	×	
	Without : 0 t	0	0	0	0	
	No.1: 8.53 t (18,805 lbs)	0	0	0	0	
With boom base (Boom angle : 10 degrees or less)	No.1 to No.2 : 16.39 t (36,135 lbs)	0	×	△ (Slope 5 degrees or less)	0	
	No.1 to No.3 : 22.8 t (50,265 lbs)	△ (No abrupt lever control)	×	×	△ (No abrupt lever control)	
	No.1 to No.4 : 27.2 t (59,965 lbs)	(No abrupt lever control)	×	×	△ (No abrupt lever control)	
	Without : 0 t	0	0	0	0	
	No.1: 8.53 t (18,805 lbs)	0	0 0		0	
With basic boom (Boom angle : 30 degrees or less)	No.1 to No.2 : 16.39 t (36,135 lbs)	0	×	\(\triangle \) (Slope 12 degrees or less)	0	
	No.1 to No.3 : 22.8 t (50,265 lbs)	0	×	△ (Slope 2 degrees or less)	0	
	No.1 to No.4 : 27.2 t (59,965 lbs)	△ (No abrupt lever control)	×	×	△ (No abrupt lever control)	

 \bigcirc : Allowed \triangle : With restriction \times : Not allowed

8500E-1

TABLE FOR STABILITY (WITH CARBODY WEIGHT)

Attachment	Countanyoight	All-roun	d swing	Travel on slope		
Attachment	Counterweight	Crawler extend	Crawler retract	Forward	Backward	
	Without : 0 t	0	0	0	0	
	No.1: 8.53 t (18,805 lbs)	0	0	0	0	
Without attachment (Base machine only)	No.1 to No.2 : 16.39 t (36,135 lbs)	0	×	(Slope 8 degrees or less)	0	
	No.1 to No.3 : 22.8 t (50,265 lbs)	0	×	×	0	
	No.1 to No.4 : 27.2 t (59,965 lbs)	△ (No abrupt lever control)	×	×	△ (No abrupt lever control)	
	Without : 0 t	0	0	0	0	
	No.1: 8.53 t (18,805 lbs)	0	0	0	0	
With boom base (Boom angle : 10 degrees or less)	No.1 to No.2 : 16.39 t (36,135 lbs)	0	×	(Slope 12 degrees or less)	0	
	No.1 to No.3 : 22.8 t (50,265 lbs)	0	×	△ (Slope 1 degrees or less)	0	
	No.1 to No.4 : 27.2 t (59,965 lbs)	(No abrupt lever control)	×	×	△ (No abrupt lever control)	
	Without: 0 t	0	0	0	0	
	No.1: 8.53 t (18,805 lbs)	0	0	0	0	
With basic boom (Boom angle : 30 degrees or less)	No.1 to No.2 : 16.39 t (36,135 lbs)	0	△ (No abrupt lever control)	0	0	
	No.1 to No.3 : 22.8 t (50,265 lbs)	0	×	(Slope 7 degrees or less)	0	
	No.1 to No.4 : 27.2 t (59,965 lbs)	0	×	(Slope 1 degrees or less)	0	

 \bigcirc : Allowed \triangle : With restriction \times : Not allowed

8500E-1

TABLE FOR STABILITY WITH COUNTERWEIGHT SELF REMOVAL DEVICE (WITHOUT CARBODY WEIGHT)

Attachment	Counterweight	All-roun	nd swing	Travel on slope		
Attachment	Counterweight	Crawler extend	Crawler retract	Forward	Backward	
	Without : 0 t	0	0	0	0	
Without attachment	No.1: 9.32 t (20,550 lbs)	0	×	\(\triangle \) (Slope 14 degrees or less)	0	
(Base machine only)	No.1 to No.2 : 17.72 t (39,070 lbs)	0	×	×	0	
	No.1 to No.3 : 26.12 t (57,590 lbs)	×	×	×	×	
	Without : 0 t	0	0	0	0	
With boom base	No.1: 9.32 t (20,550 lbs)	0	0	0	0	
(Boom angle : 10 degrees or less)	No.1 to No.2 : 17.72 t (39,070 lbs)	0	×	(Slope 5 degrees or less)	0	
	No.1 to No.3 : 26.12 t (57,590 lbs)	△ (No abrupt lever control)	×	×	△ (No abrupt lever control)	
	Without : 0 t	0	0	0	0	
With basic boom	No.1: 9.32 t (20,550 lbs)	0	0	0	0	
(Boom angle : 30 degrees or less)	No.1 to No.2 : 17.72 t (39,070 lbs)	0	×	(Slope 11 degrees or less)	0	
	No.1 to No.3 : 26.12 t (57,590 lbs)	0	×	×	0	

 \bigcirc : Allowed \triangle : With restriction \times : Not allowed

TABLE FOR STABILITY WITH COUNTERWEIGHT SELF REMOVAL DEVICE (WITH CARBODY WEIGHT)

Attack as and	O to i alat	All-roun	d swing	Travel on slope		
Attachment	Counterweight	Crawler extend	Crawler retract	Forward	Backward	
	Without : 0 t	0	0	0	0	
Without attachment	No.1: 8.31 t (18,320 lbs)	0	△ (No abrupt lever control)	0	0	
(Base machine only)	No.1 to No.2 : 19.81 t (43,674 lbs)	0	×	△ (Slope 4 degrees or less)	0	
	No.1 to No.3 : 31.31 t (69,028 lbs)	△ (No abrupt lever control)	×	×	△ (No abrupt lever control)	
	Without : 0 t	0	0	0	0	
With boom base	No.1: 8.31 t (18,320 lbs)	0	0	0	0	
(Boom angle : 10 degrees or less)	No.1 to No.2 : 19.81 t (43,674 lbs)	0	×	△ (Slope 11 degrees or less)	0	
	No.1 to No.3 : 31.31 t (69,028 lbs)	0	×	×	0	
	Without : 0 t	0	0	0	0	
With basic boom	No.1: 8.31 t (18,320 lbs)	0	0	0	0	
(Boom angle : 30 degrees or less)	No.1 to No.2 : 19.81 t (43,674 lbs)	0	△ (No abrupt lever control)	(Slope 16 degrees or less)	0	
	No.1 to No.3 : 31.31 t (69,028 lbs)	0	×	(Slope 4 degrees or less)	0	

 \bigcirc : Allowed \triangle : With restriction \times : Not allowed

8500E-1

1.10 8500E-1 TRAVEL ALLOWABLE SLOPE ANGLE

1.10.1 CRANE ATTACHMENT INSTALLED: BOOM INSERT CONFIGURATION

A CAUTION

Do not travel with the symbol of "-" in the table.


The machine may possible turnover.

Failure to observe this precaution may result in a serious accident.

If the machine has to travel by some reason, observe the following points.

- · Do not travel with a load lifted.
- · Travel with low speed and gently.
- · Travel on the flat and firm ground.
- Ensure to check the ground condition and travel on the slope angle smaller than shown in the chart.
- Travel straight against slope.
- Provide the gentle slope at the beginning and end positions of slope.

TRAVEL UPWARD DOWNWARD ON SLOPE (θ: ALLOWABLE ANGLE)



1. Crane propel allowable slope angle

(1) Without aux. sheave

8500E-1

(Unit : Degrees)

					(0::::-	ogiccs)
	Forward			Backward		
Boom length m (ft)	В	Boom ang	le	Boom angle		
	35	40	50	40	50	60
9.1 (30)	4	3	3	8	8	8
12.2 (40)	6	5	4	8	8	8
15.2 (50)	7	7	5	8	8	8
18.3 (60)	8	8	6	8	8	8
21.3 (70)	8	8	8	8	8	8
24.4 (80)	8	8	8	8	8	8
27.4 (90)	8	8	8	8	8	8
30.5 (100)	8	8	8	8	8	8
33.5 (110)	8	8	8	8	8	8
36.6 (120)	8	8	8	8	8	8
39.6 (130)	8	8	8	8	8	8
42.7 (140)	8	8	8	8	8	8
45.7 (150)	8	8	8	7	8	8
48.8 (160)	8	8	8	4	6	7
51.8 (170)	8	8	8	2	4	6
54.9 (180)	8	8	8	1	2	5

(2) With aux. sheave

8500E-1

	Forward				Backward	d
Boom length m (ft)	E	oom ang	le	В	oom ang	le
	35	40	50	40	50	60
9.1 (30)	4	3	3	8	8	8
12.2 (40)	6	5	4	8	8	8
15.2 (50)	7	7	5	8	8	8
18.3 (60)	8	8	6	8	8	8
21.3 (70)	8	8	8	8	8	8
24.4 (80)	8	8	8	8	8	8
27.4 (90)	8	8	8	8	8	8
30.5 (100)	8	8	8	8	8	8
33.5 (110)	8	8	8	8	8	8
36.6 (120)	8	8	8	8	8	8
39.6 (130)	8	8	8	8	8	8
42.7 (140)	8	8	8	8	8	8
45.7 (150)	8	8	8	7	8	8
48.8 (160)	8	8	8	4	6	7
51.8 (170)	8	8	8	2	4	6

2. Fixed jib propel allow slope angle

8500E-1

(Unit : Degrees)

					(,
Jib length m (ft)	9.1 (30)					
Offset angle			1	0		
Configuration		Forward			Backward	d
Decree length in (ft)	Е	Boom ang	le	Е	Boom ang	le
Boom length m (ft)	35	40	50	40	50	60
24.4 (80)	8	8	8	8	8	8
27.4 (90)	8	8	8	8	8	8
30.5 (100)	8	8	8	8	8	8
33.5 (110)	8	8	8	8	8	8
36.6 (120)	8	8	8	8	8	8
39.6 (130)	8	8	8	8	8	8
42.7 (140)	8	8	8	6	7	8
45.7 (150)	8	8	8	4	6	7
48.8 (160)	8	8	8	2	4	5
51.8 (170)	8	8	8	-	2	4
54.9 (180)	8	8	8	-		3

					,	, og. ooo,
Jib length m (ft)		9.1 (30)				
Offset angle			3	0		
Configuration		Forward			Backward	t
Doors longth as (ft)	Е	Boom ang	le	В	oom ang	le
Boom length m (ft)	35	40	50	40	50	60
24.4 (80)	8	8	8	8	8	8
27.4 (90)	8	8	8	8	8	8
30.5 (100)	8	8	8	8	8	8
33.5 (110)	8	8	8	8	8	8
36.6 (120)	8	8	8	8	8	8
39.6 (130)	8	8	8	8	8	8
42.7 (140)	8	8	8	6	7	8
45.7 (150)	8	8	8	4	6	7
48.8 (160)	8	8	8	2	4	5
51.8 (170)	8	8	8	-	2	4
54.9 (180)	8	8	8	-	-	3

8500E-1

(Unit : Degrees)

						- 3 /
Jib length m (ft)	12.2 (40)					
Offset angle		10				
Configuration		Forward			Backward	d
Doom longth m (ft)	В	oom ang	le	Е	Boom ang	le
Boom length m (ft)	35	40	50	40	50	60
24.4 (80)	8	8	8	8	8	8
27.4 (90)	8	8	8	8	8	8
30.5 (100)	8	8	8	8	8	8
33.5 (110)	8	8	8	8	8	8
36.6 (120)	8	8	8	8	8	8
39.6 (130)	8	8	8	7	8	8
42.7 (140)	8	8	8	5	7	8
45.7 (150)	8	8	8	3	5	6
48.8 (160)	8	8	8	1	3	5
51.8 (170)	8	8	8	-	1	3
54.9 (180)	8	8	8	-	7.4	2

					(<i>-</i> 09.000)
Jib length m (ft)		12.2 (40)				
Offset angle			3	0		
Configuration		Forward			Backward	ł
Deem length m (ft)	В	oom ang	le	В	oom ang	le
Boom length m (ft)	35	40	50	40	50	60
24.4 (80)	8	8	8	8	8	8
27.4 (90)	8	8	8	8	8	8
30.5 (100)	8	8	8	8	8	8
33.5 (110)	8	8	8	8	8	8
36.6 (120)	8	8	8	8	8	8
39.6 (130)	8	8	8	7	8	8
42.7 (140)	8	8	8	5	7	8
45.7 (150)	8	8	8	3	5	6
48.8 (160)	8	8	8	1	3	5
51.8 (170)	8	8	8	-	1	3
54.9 (180)	8	8	8	-	-	2

8500E-1

(Unit : Degrees)

Jib length m (ft)	15.2 (50)					
Offset angle			1	0		
Configuration		Forward			Backward	t
Decree length as (f4)	Е	Boom ang	le	Е	Boom ang	le
Boom length m (ft)	35	40	50	40	50	60
24.4 (80)	8	8	8	8	8	8
27.4 (90)	8	8	8	8	8	8
30.5 (100)	8	8	8	8	8	8
33.5 (110)	8	8	8	8	8	8
36.6 (120)	8	8	8	8	8	8
39.6 (130)	8	8	8	6	7	8
42.7 (140)	8	8	8	4	6	7
45.7 (150)	8	8	8	2	4	6
48.8 (160)	8	8	8	-	2	4
51.8 (170)	8	8	8	-	-	3
54.9 (180)	8	8	8	-		1

					(- 1 - 1 -	ogioco)
Jib length m (ft)		15.2 (50)				
Offset angle			3	30		
Configuration		Forward			Backward	d
Doors longth as (ft)	Е	Boom ang	le	В	oom ang	le
Boom length m (ft)	35	40	50	40	50	60
24.4 (80)	8	8	8	8	8	8
27.4 (90)	8	8	8	8	8	8
30.5 (100)	8	8	8	8	8	8
33.5 (110)	8	8	8	8	8	8
36.6 (120)	8	8	8	8	8	8
39.6 (130)	8	8	8	6	7	8
42.7 (140)	8	8	8	4	6	7
45.7 (150)	8	8	8	2	4	6
48.8 (160)	8	8	8	-	2	4
51.8 (170)	8	8	8	-	-	3
54.9 (180)	8	8	8	-	-	1

8500E-1

(Unit : Degrees)

Jib length m (ft)	18.3 (60)					
Offset angle			1	0		
Configuration		Forward			Backward	d
Doom longth m (ft)	Е	Boom ang	le	В	oom ang	le
Boom length m (ft)	35	40	50	40	50	60
24.4 (80)	8	8	8	8	8	8
27.4 (90)	8	8	8	8	8	8
30.5 (100)	8	8	8	8	8	8
33.5 (110)	8	8	8	8	8	8
36.6 (120)	8	8	8	7	8	8
39.6 (130)	8	8	8	5	6	8
42.7 (140)	8	8	8	3	5	6
45.7 (150)	8	8	8	1	3	5
48.8 (160)	8	8	8	-	1	3
51.8 (170)	8	8	8	-	-	2
54.9 (180)	8	8	8	-	-	1

					(0	ocgrecs)
Jib length m (ft)		18.3 (60)				
Offset angle			3	80		
Configuration		Forward			Backward	d
Decree length as (ft)	Б	Boom ang	le	В	oom ang	le
Boom length m (ft)	35	40	50	40	50	60
24.4 (80)	8	8	8	8	8	8
27.4 (90)	8	8	8	8	8	8
30.5 (100)	8	8	8	8	8	8
33.5 (110)	8	8	8	8	8	8
36.6 (120)	8	8	8	7	8	8
39.6 (130)	8	8	8	5	6	8
42.7 (140)	8	8	8	3	5	6
45.7 (150)	8	8	8	1	3	5
48.8 (160)	8	8	8	-	1	3
51.8 (170)	8	8	8	-	-	2
54.9 (180)	8	8	8	-	-	1

1.11 ENGINE MAIN SPECIFICATION

Fasing	8500-1: Hino Model J08E-VV diesel engine (complying with the Tier4 & Stage IV Emission Regulations)
Engine	8500E-1: Hino Model J08E-VV diesel engine (complying with the Tier4 & Stage IV Emission Regulations)
Configuration of engine	4 cycle, water cooled, vertical in-line 6, direct injection, turbo-charged, intercooled
Total poston displacement	7.684 L
Rated output	213 kW / 2,100 min ⁻¹
Max. torque	1,017 N·m / 1,600 min ⁻¹
Specific fuel consumption	212 g / kWh / 2,100 min ⁻¹
Dry engine weight	Approx. 719 kg

FUEL CONSUMPTION (REF)

Hourly fuel consumption at engine rated output and at crane works.

Fuel consumption (L/hr)	At rated output	At crane work *1	At foundation work *2	
8500-1 : J08E-VV	54.1	16.2	22.4	
8500E-1: J08E-VV	54.1	16.2	32.4	

- *1 Is calculated with the assumption that the average load ratio is 30% for crane work and the fuel consumption is proportional to the load.
- *2 Is calculated with the assumption that the average load ratio is 60% for foundation work and the fuel consumption is proportional to the load.

Since the fuel consumption may vary depending on the work content, operators technique and waiting time at actual work, the above figure is for reference only.


The fuel consumption based on energy saving function including G engine mode, G winch mode or auto-idling stop are not considered.

8500-1 / 8500E-1 1-52 Published 12-16-15, Control #244-01

ENGINE PERFORMANCE CURVE

This indicates performance curve of single unit of engine.

This does not considered that the engine performance drops due to crane work.





2. MAINTENANCE STANDARDS TEST PROCEDURES

2.1	MAINTENANCE STANDARD	2-1
2.1.1	PIN, BUSHING, SPRING, LINING AND SHEAVE	2-1
2.1.2	TRAVEL DEVICE	2-8
2.2	PERFORMANCE STANDARD AND TEST PROCEDURE	2-15
2.2.1	OPERATING SPEED	2-17
2.2.2	HYDRAULIC PRESSURE	2-18
2.2.3	SWING BEARING	2-22




2. MAINTENANCE STANDARDS TEST PROCEDURES

2.1 MAINTENANCE STANDARD

2.1.1 PIN, BUSHING, SPRING, LINING AND SHEAVE


1. Pin



Unit: mm (in.)


Location	Part number	Std. dimension	Usable limit	Remedy	See figure
(1) Pawl (Front, rear drum)		44.0 (1.732)	43.84 (1.726)	Poplace	P.2-3
(2) Pawl (Boom drum)		45.0 (1.772)	44.82 (1.765)	Replace	P.2-4
(3) Brake pedal		38.1 (1.5)	37.92 (1.493)		P.2-5
(4) Brake pedal		13.0 (0.512)	12.85 (0.506)	Replace	
(5) Brake pedal		13.0 (0.512)	12.85 (0.506)	Replace	
(6) Brake pedal		10.0 (0.394)	9.96 (0.392)		
(7) Boom foot		99.75 (3.927)	99.10 (3.902)	Replace	P.2-6


2. Bushing



Location	Part number	Std. dimension	Usable limit	Remedy	See figure
(8) Pawl (Front, rear drum)		44.0 (1.732)	44.26 (1.743)	Replace	P.2-3
(9) Pawl (Boom drum)		45.0 (1.772)	45.27 (1.782)	Replace	P.2-4
(10)Boom foot		100.0 (3.937)	100.67 (3.963)	Replace	P.2-6

3. Spring






Unit: mm (in.)

Location	Part number	Std. free length	Usable limit	Remedy	See figure
(11) Pawl (Front, rear drum)		Compression: 72 (2.835)	68.4 (2.693)	Replace	P.2-3
(12)Pawl (Boom drum)		Compression : 72 (2.835)	68.4 (2.693)	Replace	P.2-4
(13)Brake pedal		Tension : 61.5 (2.421)	63.9 (2.516)	Replace	P.2-5


4. Sheave




Location	Part number	Std. root dia.	Use limit	Groove radius	Remedy	See figure
(14)Boom point		428 (16.850)	425 (16.732)	12.5 (0.492)		
(15) Idler sheave		428 (16.850)	425 (16.732)	12.5 (0.492)		P.2-7
(16) Auxiliary sheave		495 (19.488)	492 (19.370)	12.5 (0.492)		
(17)Upper spreader		304 (11.969)	299.2 (11.779)	9.0 (2.743)	Replace	P.2-6
(18)Lower spreader		352 (13.858)	347.2 (13.669)	10.0 (0.394)	or	P.2-0
(19) Jib point		428 (16.850)	425 (16.732)	12.5 (0.492)	build-up	P.2-7
(20) Jib strut		428 (16.850)	425 (16.732)	12.5 (0.492)		
(21) Gantry peak		352 (13.858)	347.2 (13.669)	10.0 (0.394)		P.2-6

SEE FIGURE


• Front / rear drum lock assy







2-3

Boom drum lock assy







Brake pedal




Gantry assy



Crane assy




Jib assy



2.1.2 TRAVEL DEVICE

- 1. Crawler shoe
- 914 mm




Unit: mm (in.)

Location	Std. dimension	Usable limit	Remedy
D : Pin hole	36 to 38 (1.417 to 1.496)	39.0 (1.535)	Replace
Pin	36 _{-0.2} (1.417)	34.0 (1.339)	or
P : Pitch	203.2_0 (8.000)	205.0 (8.071)	build-up

Distance between pins when 6 pcs of shoes are connected and tension applied : 1213.2 to 1225.2 mm (47.764 to 48.236 in.)

• 800 mm




Unit: mm (in.)


	Location	Std. dimension	Usable limit	Remedy
1	D : Pin hole	36 to 38 (1.417 to 1.496)	39.0 (1.535)	Build-up
	Pin	36 _{-0.4} (1.417)	34.0 (1.339)	or
	P : Pitch	203.2_0 (8.000)	205.0 (8.071)	replace

Distance between pins when 6 pcs of shoes are connected and tension applied : 1213.2 to 1225.2 mm (47.764 to 48.236 in.)

2. Drive tumbler




3. Idler




						` '	
Symbol	Item		Std	Usable limit	Remedy		
А	Outer diameter	Ф700 (27.559)				Ф692 (27.244)	Replace or build-up
		Std. dimension	Tolerance Standard		Allowable		
В	Gap between shaft and bushing		Shaft	-0.036 (-0.001) -0.071 (-0.003)	Gap	Gap	
and bushing	Ф110 (4.331)	Bore	+0.161 (+0.006) +0.139 (+0.006)	0.175 (0.007) to 0.232 (0.009)	0.1 (0.004)	Replacement of bushing	
Interference of Sprocket and bushing	Ф125 (4.921)	Shaft	+0.117 (+0.005) +0.092 (+0.004)	Interference 0.052 (0.002) to	Interference 0 (0)		
		Bore	+0.040 (+0.002) +0 (+0)				
D	Side clearance of idler (One side)	0.02 to 0.74 (0.001 to 0.029)			1.2 (0.047)		

4. Track roller (Lower roller)



Symbol	Item	Std. dimension				Usable limit	Remedy
А	Outer diameter	Ф260 (10.236)				Ф252 (9.921)	Replace or build-up
		Std. dimension	Tolerance standard		Allowable		
Gap between shaft and bushing	Ф80 (3.150)	Shaft	-0.05 (-0.002) -0.08 (-0.003)	Gap - 0.17 (0.007) to - 0.23 (0.009)	Gan	Replacement of bushing	
		Bore	+0.15 (+0.006) +0.12 (+0.005)				
C Interference of roller and bushing	Φ00 (3 5 43)	Shaft	+0.110 (+0.004) +0.080 (+0.003)	Interference	Interference	Davisas	
	Ф90 (3.543) Воге		+0.035 (+0.001) +0 (+0)	0.045 (0.002) to 0.11 (0.004)	0 (0)	Replace	
D	Side clearance of roller (One side)	0.02 to 0.053 (0.001 to 0.047)			1.2 (0.047)	Replacement of bushing	


5. Guide roller (Upper roller)



Symbol	Item	Std. dimension	Usable limit	Remedy
A	Outer diameter	Ф200 (7.874)	Ф192 (7.559)	Build-up or replace

6. Guide bar

- Left side
- Right side



Unit: mm (in.)

Symbol	Item	Std. dimension	Usable limit	Remedy
Α	Height of guide bar	55 (2.165)	30 (1.181)	Build-up or replace

Detail A

8500-1 / 8500E-1 2-14 Published 12-16-15, Control #244-01

2.2 PERFORMANCE STANDARD AND TEST PROCEDURE

1. The meaning of terminologies described in this standard is as follows.

STANDARD VALUE

Standard values at new machine assembly. However, the value without specified is shown the value for standard specification (the machine equipped with the standard attachment).

USABLE LIMIT

Not to use if exceeding this value. Repair or replace should be performed for keeping the machine performance and safety.

TEMPERATURE OF OIL

It is an oil temperature when performing the test which taken from the hydraulic oil tank and the oil in the circuit shall be kept the some temperature by circulate always.

- 2. As to the items of which limit of use is not shown, referring to standard value as the guidance, repair or replace the part as required.
- The hydraulic hose, O-ring, oil seal and the parts made from rubber would be deteriorated, replace periodically or at the time of overhauling.
- Especially important hoses as safety relative parts are specified as an important security parts, strongly recommended replace it periodically.
- To perform the maintenance works, thoroughly understood the procedure; how to handle the machine, precaution and the lubrication.
 Read thoroughly the shop-manual and understood.

MARNING

Place a signalman to prevent an incident from caught.

Failure to observe this precaution may result in a serious injury or loss of life.

MARNING

Operate the control lever slowly.

Abrupt control lever operation is very dangerous, and may create the unexpected loads to the base machinery and the attachment or load swinging.

▲ WARNING

Off limit signs shall be posted at surrounding area of the machine operating radius.

Failure to observe this precaution may result in a serious injury or loss of life.

MARNING

When performing the test, all unused functions should be locked.

Failure to observe this precaution may result in a serious injury or loss of life.


▲ CAUTION

8500-1 / 8500E-1

Ensure to confirm the functioning of the overload prevention device, as for the details of how to confirm, refer to "3.10.1 CHECK BEFORE ERECT THE BOOM AFTER ASSEMBLY OF THE ATTACHMENT" in OPERATION & MAINTENANCE MANUAL.

2.2.1 OPERATING SPEED

Item	Test condition	Test procedure	Standard value
Boom drum hoisting and lowering wire rope speed	Mode: Power mode Engine min-1: High idling Temperature of oil: 45 to 55 °C (113 to 131°F) Boom Length: Basic boom Loading: No load	 Measure the time taken to rotate drum 10 times. (Start measuring after rotation becomes stable.) Take average of 3 times measuring. 	8.8 to 10.6 sec
Front and rear drum hoisting wire rope speed	Mode: Power mode Engine min ⁻¹ : High idling Temperature of oil: 45 to 55 °C (113 to 131°F) Loading: No load	 Measure the time taken to rotate drum 10 times. (Start measuring after rotation becomes stable.) Take average of 3 times measuring. 	Low: 11.1 to 13.4 sec (Trimmer low) High: 7.9 to 9.7 sec (Trimmer High)
Swing speed	Mode: Power mode Engine min-1: High idling Temperature of oil: 45 to 55 °C (113 to 131 °F) Boom Length: Basic boom Loading: No load Swing mode: Free high	 Measure the time taken to rotate machine one time. Measure the time for 2nd rotation after 1st preliminary rotation. Take average of 3 times measuring. 	14.1 to 16.7 sec
Travel speed	Mode : Power mode Engine min-1 : High idling Temperature of oil : 45 to 55 °C (113 to 131°F) Boom Length : Basic boom Place : Firm and level ground	 Measure the time taken to Travel machine the distance of 20 m (66 ft). Travel machine first preliminary more than 2 m (6.6 ft) before starting the measuring. Take average of 3 times measuring. 	Low: 60.1 to 69.8 sec High: 40.6 to 47.3 sec
Traveling deflection	Mode: G engine mode Engine min-1: High idling Temperature of oil: 45 to 55 °C (113 to 131°F) Boom Length: Basic boom Place: Firm and level ground	 Measure the deflection amount after traveling the distance of 20 m (66 ft). Travel machine first preliminary more than 2 m (6.6 ft) before starting the measuring. Take average of 3 times measuring. 	Within 600 mm (23.6 in)



2.2.2 HYDRAULIC PRESSURE

Use a pressure gauge which has a surplus of more than 10 MPa for pressures to be measured and which has passed the inspection.


Prior to pressure measurement, clean the port for pressure measurement so as to be free from oil and dust.

Connector and hose for measuring pressure.

Connector	
Hose	

1. Main

(Travel right, Boom, Rear drum 1st speed, Front drum 2nd speed)




Test condition	Test procedure	Standard value	
Mode : Power mode	(1) Lower the boom onto the ground.		
Engine speed : High idling	(2) Lock the boom drum with the drum lock.	31.9 MPa (4,627 psi)	
Temperature of oil : 45 to 55 °C	(3) Make the valve relieved by boom drum	31.9 WFa (4,027 psi)	
(113 to 131 °F)	winch lowering operation.		

8500-1 / 8500E-1 2-18 Published 12-16-15, Control #244-01


2. Main

(Travel left, Rear drum 2nd speed, Front drum 1st speed)




Test condition	Test procedure	Standard value	
Mode : Power mode	(1) Lower the front drum hook onto the ground.		
Engine speed : High idling	(2) Lock the front winch drum with the drum lock.	31.9 MPa (4,627 psi)	
Temperature of oil : 45 to 55 °C	(3) Make the valve relieved by front drum winch	31.9 MFa (4,027 psi)	
(113 to 131 °F)	lowering operation. (1st speed detent)		

3. Swing



Test condition	Test procedure	Standard value
Mode : Power mode Engine speed : High idling Temperature of oil : 45 to 55 °C (113 to 131 °F) Swing mode : Free high	(1) Lock the upper with the swing lock pin and parking brake.(2) Make the valve relieved by swing operation.	27.5 MPa (3,989 psi)

4. Control circuit (Primary pressure)




Test condition	Test procedure	Standard value	
I lemperature of oil: 45 to 55 °C	Remove the cap of plug installed in valve block, and instal the pressure gauge.	Relief valve : 7.0 MPa (1,015 psi)Reduction valve : 5.4 MPa (783 psi)	

5. Control circuit (Secondary pressure)

Test condition	Test procedure	Standard value
Engine speed: Low idling Temperature of oil: 45 to 55 °C (113 to 131 °F)	Operate the control lever for the section to be measured. (Operate the speed adjusting knob to the Max. position) Take pressure out from the quick coupler of the control valve spool end.	 Front / rear drum 2.65 to 2.94 MPa (384 to 426 psi) Travel 1.42 to 1.62 MPa (206 to 235 psi) Swing 1.62 to 1.92 MPa (235 to 278 psi) Third 2.65 to 2.94 MPa (384 to 426 psi) Boom 2.50 to 2.79 MPa (363 to 405 psi)


8500-1 / 8500E-1 2-20 Published 12-16-15, Control #244-01

6. Crawler extening




Test condition	Test procedure	Standard value
	(1) Insert the crawler fixing pins to fix the crawlers.(2) Make the valve relieved by operating crawler retraction or extension.	 Extension: 17.0 MPa (2.466 psi)

7. Gantry raising / lowering



Test condition	Test procedure	Standard value
Engine speed : High idling Temperature of oil : 45 to 55 °C (113 to 131 °F)	(1) Raise the gantry high, and fix it with the gantry fixing pin.(2) Make the valve relieved by raising or lowering the gantry operation.	Raise : 20.6 MPa (2.988 psi)

2.2.3 SWING BEARING



COUNTERWEIGHT: FULL

Condition of measurement	Amount of play
Boom length : 12.2 m (40 ft)	
Radius : 5.5 m (18 ft)	Less than 3 mm (0.118")
Load : 51.4 t (113,318 lbs)	0.110)

8500-1 / 8500E-1 2-22 Published 12-16-15, Control #244-01

3. GENERAL WORK STANDARD

3.1	STANDARD TIGHTENING TORQUE	3-1
3.1.1	TIGHTENING TORQUE OF CAP SCREWS AND NUTS	3-1
3.1.2	TIGHTENING TORQUE OF HYDRAULIC FITTINGS	3-5
3.2	STANDARD PARTS	3-7
3.2.1	BOLT	3-7
3.2.2	O-RING	3-8
3.2.3	BACK-UP RING	
3.2.4	BITE TYPE FITTING	3-10
3.3	CONVERSION TABLE	
3.3.1	UNIT CONVERSION	3-12
3.3.2	MILLIMETER: INCH CONVERSION TABLE	
3.3.3	METER AND FOOT CONVERSION TABLE	3-15
3.3.4	GRADE CONVERSION TABLE	
3.3.5	UNIT WEIGHT TABLE	3-17
3.3.6	SYSTEM INTERNATIONAL (SI) UNIT CONVERSION TABLE	3-18



Unit: N·m (ft·lbs)

3. GENERAL WORK STANDARD

3.1 STANDARD TIGHTENING TORQUE

3.1.1 TIGHTENING TORQUE OF CAP SCREWS AND NUTS

Unless otherwise specified, torque all screws and nuts on this machine to the values shown in the following tables.

1. METRIC COARSE THREADS (PLATED)

Nominal		Class	sification	
size	4	Т	7	T
0.20	Dry	Lubricated	Dry	Lubricated
МЗ	0.58 to 0.72	0.40 to 0.48	1.26 to 1.54	0.86 to 1.04
IVIO	(0.43 to 0.53)	(0.29 to 0.35)	(0.93 to 1.14)	(0.63 to 0.77)
M4	1.35 to 1.65	0.90 to 1.10	2.90 to 3.50	2.00 to 2.40
1014	(1.00 to 1.22)	(0.66 to 0.81)	(2.14 to 2.58)	(1.47 to 1.77)
M5	2.60 to 3.20	1.75 to 2.15	5.70 to 6.90	3.80 to 4.60
CIVI	(1.92 to 2.36)	(1.29 to 1.59)	(4.20 to 5.09)	(2.80 to 3.39)
M6	4.50 to 5.50	3.10 to 3.70	9.70 to 11.9	6.60 to 8.00
IVIO	(3.32 to 4.06)	(2.29 to 2.73)	(7.20 to 8.80)	(4.90 to 5.90)
MO	10.8 to 13.2	7.30 to 8.90	23.4 to 28.6	15.8 to 19.2
M8	(8.00 to 9.70)	(5.40 to 6.60)	(17.3 to 21.1)	(11.7 to 14.2)
M10	21.6 to 26.4	14.5 to 17.7	46.8 to 57.2	31.5 to 38.5
IVI IU	(15.9 to 19.5)	(10.7 to 13.1)	(34.5 to 42.2)	(23.2 to 28.4)
M12	36.9 to 45.1	24.7 to 30.3	80.1 to 97.9	54.0 to 66.0
IVI I Z	(27.2 to 33.3)	(18.2 to 22.3)	(59.1 to 72.2)	(39.8 to 48.7)
M14	58.5 to 71.5	39.1 to 47.9	128 to 156	85.5 to 104.5
IVI 14	(43.1 to 52.7)	(28.8 to 35.3)	(94.4 to 115)	(63.1 to 77.1)
M16	89.1 to 108.9	59.4 to 72.6	194 to 236	129 to 157
M16	(66.0 to 80.0)	(44.0 to 54.0)	(143 to 174)	(95.0 to 116)
M18	123 to 151	83.0 to 101	270 to 330	179 to 219
IVI IO	(91 to 111)	(61.0 to 75.0)	(199 to 243)	(132 to 162)
M20	173 to 211	115 to 141	378 to 462	252 to 308
IVIZU	(128 to 156)	(85.0 to 104)	(279 to 341)	(186 to 227)
M22	234 to 286	154 to 188	504 to 616	338 to 412
IVIZZ	(173 to 211)	(114 to 139)	(372 to 454)	(249 to 304)
M24	297 to 363	198 to 242	648 to 792	432 to 528
10124	(219 to 268)	(146 to 178)	(478 to 584)	(319 to 389)
M27	441 to 539	293 to 357	954 to 1,166	635 to 775
IVIZI	(325 to 397)	(216 to 263)	(704 to 860)	(468 to 572)
M30	599 to 731	396 to 484	1,296 to 1,584	864 to 1,056
M30	(442 to 539)	(292 to 357)	(956 to 1,168)	(637 to 779)
M33	801 to 979	531 to 649	1,746 to 2,134	1,161 to 1,419
M33	(591 to 722)	(392 to 479)	(1,288 to 1,574)	(856 to 1,046)
Mae	1,035 to 1,265	689 to 841	2,250 to 2,750	1,494 to 1,826
M36	(763 to 933)	(508 to 620)	(1,659 to 2,028)	(1,102 to 1,347)

2. METRIC FINE THREADS (PLATED)

	Classification			
Nominal size	4	Т	7T	
3120	Dry	Lubricated	Dry	Lubricated
M8	11.4 to 14.0	7.6 to 9.2	24.8 to 30.2	16.5 to 20.1
IVIO	(8.40 to 10.3)	(5.60 to 6.80)	(18.3 to 22.3)	(12.2 to 14.8)
M10	22.5 to 27.5	15.0 to 18.4	48.6 to 59.4	32.9 to 40.1
M10	(16.6 to 20.3)	(11.1 to 13.6)	(35.8 to 43.8)	(24.3 to 29.6)
M42	40.1 to 48.9	26.6 to 32.4	86.4 to 106	57.6 to 70.4
M12	(29.6 to 36.1)	(19.6 to 23.9)	(63.7 to 77.9)	(42.5 to 51.9)
MAG	94.0 to 114	62.1 to 75.9	203 to 247	135 to 165
M16	(69.0 to 84.0)	(46.0 to 56.0)	(150 to 182)	(100 to 122)
M20	189 to 231	123 to 151	410 to 500	270 to 330
IVIZU	(139 to 170)	(91.0 to 111)	(302 to 369)	(199 to 243)
MOA	320 to 390	212 to 258	698 to 852	459 to 561
M24	(236 to 288)	(156 to 190)	(515 to 628)	(338 to 414)
M30	648 to 792	423 to 517	1,413 to 1,727	927 to 1,133
IVIOU	(478 to 584)	(312 to 381)	(1,042 to 1,274)	(684 to 836)
Mae	1,089 to 1,331	716 to 874	2,367 to 2,893	1,557 to 1,903
M36	(803 to 982)	(528 to 645)	(1,746 to 2,133)	(1,148 to 1,403)

Unit : N·m (ft·lbs)

Unit : N·m (ft·lbs)

3. COARSE THREADS UNC

Manakasi	Classification					
Nominal size	Grade 2		Gra	de 5	Grade 8	
3120	Dry	Lubricated	Dry	Lubricated	Dry	Lubricated
1/4	7.50 to 9.10	6.40 to 7.80	11.6 to 14.2	9.90 to 12.1	16.4 to 20.0	14.0 to 17.0
1/4	(5.53 to 6.71)	(4.71 to 5.76)	(8.55 to 10.5)	(7.30 to 8.92)	(12.1 to 14.8)	(10.3 to 12.5)
5/16	14.9 to 18.1	12.5 to 15.3	23.0 to 28.0	19.3 to 23.7	32.0 to 39.0	27.5 to 33.5
5/16	(11.0 to 13.4)	(9.22 to 11.3)	(17.0 to 20.7)	(14.2 to 17.5)	(23.6 to 28.8)	(20.3 to 24.7)
3/8	25.7 to 31.3	21.2 to 25.8	39.6 to 48.4	33.8 to 41.2	55.8 to 68.2	46.8 to 57.2
3/0	(19.0 to 23.1)	(15.6 to 19.0)	(29.2 to 35.7)	(24.9 to 30.4)	(41.2 to 50.3)	(34.5 to 42.2)
7/16	39.6 to 48.4	33.8 to 41.2	62.1 to 75.9	52.2 to 63.8	87.3 to 107	72.9 to 89.1
7710	(29.2 to 35.7)	(24.9 to 30.4)	(45.8 to 56.0)	(38.5 to 47.1)	(64.4 to 78.7)	(53.8 to 65.7)
1/2	62.1 to 75.9	52.2 to 63.8	95.0 to 117.0	80.1 to 97.9	134 to 164	113 to 139
1/2	(45.8 to 56.0)	(38.5 to 47.1)	(70.1 to 86.3)	(59.1 to 72.2)	(98.8 to 121)	(83.3 to 103)
9/16	88.2 to 108	73.8 to 90.2	137 to 167	114 to 140	193 to 237	162 to 198
9/10	(65.0 to 79.5)	(54.4 to 66.5)	(101 to 123)	(84.1 to 103)	(142 to 175)	(119 to 146)
5/8	123 to 151	104 to 128	193 to 237	160 to 196	275 to 335	230 to 280
5/6	(90.7 to 111)	(76.7 to 94.4)	(142 to 175)	(118 to 145)	(203 to 247)	(170 to 206)
3/4	221 to 269	184 to 226	338 to 412	284 to 346	477 to 583	396 to 484
5/4	(163 to 198)	(136 to 167)	(249 to 304)	(209 to 255)	(352 to 430)	(292 to 357)
7/8	212 to 258	176 to 214	540 to 660	450 to 550	756 to 924	634 to 776
770	(156 to 190)	(130 to 158)	(398 to 487)	(332 to 406)	(558 to 681)	(468 to 572)
1	311 to 379	266 to 324	801 to 979	671 to 819	1,134 to 1,386	954 to 1,166
ı	(229 to 279)	(196 to 239)	(591 to 722)	(495 to 604)	(836 to 1,022)	(704 to 860)
1 1/8	450 to 550	378 to 462	1,008 to 1,232	837 to 1,023	1,620 to 1,980	1,359 to 1,661
1 1/0	(332 to 406)	(279 to 341)	(743 to 909)	(617 to 754)	(1,195 to 1,460)	(1,002 to 1,225)
1 1/4	625 to 765	522 to 638	1,404 to 1,716	1,170 to 1,430	2,268 to 2,772	1,908 to 2,332
1 1/4	(461 to 564)	(385 to 471)	(1,035 to 1,265)	(863 to 1,055)	(1,673 to 2,044)	(1,407 to 1,720)
1 3/8	819 to 1,001	689 to 841	1,845 to 2,255	1,548 to 1,892	2,979 to 3,641	2,511 to 3,069
1 3/0	(604 to 738)	(508 to 620)	(1,361 to 1,663)	(1,142 to 1,395)	(2,197 to 2,685)	(1,852 to 2,263)
1 1/2	1,098 to 1,342	918 to 1,122	2,448 to 2,992	2,052 to 2,508	3,960 to 4,840	3,321 to 4,059
1 1/4	(810 to 990)	(677 to 827)	(1,805 to 2,206)	(1,513 to 1,850)	(2,920 to 3,569)	(2,449 to 2,993)

4. FINE THREADS UNF Unit: N·m (ft·lbs)

			Classi	fication		
Nominal size	Grade 2		Grade 5		Grade 8	
3120	Dry	Lubricated	Dry	Lubricated	Dry	Lubricated
1/4	8.40 to 10.2	7.00 to 8.60	13.0 to 15.8	11.0 to 13.4	18.4 to 22.6	15.5 to 18.9
	(6.19 to 7.52)	(5.16 to 6.34)	(9.59 to 11.7)	(8.11 to 9.88)	(13.6 to 16.7)	(11.4 to 13.9)
5/16	16.1 to 19.7	13.6 to 16.6	24.8 to 30.2	21.2 to 25.8	35.1 to 42.9	30.2 to 36.8
3/8	(11.9 to 14.5)	(10.0 to 12.2)	(18.3 to 22.3)	(15.6 to 19.0)	(25.9 to 31.6)	(22.3 to 27.1)
	28.4 to 34.6	23.9 to 29.1	43.2 to 52.8	36.0 to 44.0	62.1 to 75.9	51.3 to 62.7
	(20.9 to 25.5)	(17.6 to 21.5)	(31.9 to 38.9)	(26.6 to 32.5)	(45.8 to 56.0)	(37.8 to 46.2)
7/16	44.1 to 53.9	36.9 to 45.1	68.4 to 83.6	56.7 to 69.3	95.0 to 117	80.1 to 97.9
	(32.5 to 39.8)	(27.2 to 33.3)	(50.4 to 61.7)	(41.8 to 51.1)	(70.1 to 86.3)	(59.1 to 72.2)
1/2	68.4 to 83.6	56.7 to 69.3	105 to 129	87.3 to 107	149 to 181	123 to 151
	(50.4 to 61.7)	(41.8 to 51.1)	(77.4 to 95.1)	(64.4 to 78.7)	(110 to 134)	(90.7 to 111)
9/16	96.0 to 118	81.0 to 99.0	149 to 183	124 to 152	212 to 258	176 to 214
	(70.8 to 87.0)	(59.7 to 73.0)	(110 to 135)	(91.4 to 112)	(156 to 190)	(130 to 158)
5/8	137 to 167	114 to 140	212 to 258	176 to 216	302 to 368	248 to 302
	(101 to 123)	(84.0 to 103)	(156 to 190)	(130 to 159)	(223 to 271)	(183 to 223)
3/4	239 to 291	193 to 237	369 to 451	311 to 379	513 to 627	432 to 528
	(176 to 215)	(142 to 175)	(272 to 333)	(229 to 280)	(378 to 462)	(319 to 389)
7/8	230 to 280	184 to 226	580 to 710	486 to 594	819 to 1,001	680 to 830
	(170 to 206)	(136 to 167)	(428 to 524)	(358 to 438)	(604 to 738)	(501 to 612)
1	338 to 412	275 to 335	864 to 1,056	720 to 880	1,215 to 1,485	1,017 to 1,243
	(249 to 304)	(203 to 247)	(637 to 779)	(531 to 649)	(896 to 1,095)	(750 to 917)
1 1/8	495 to 605	405 to 495	1,098 to 1,342	918 to 1,122	1,773 to 2,167	1,485 to 1,815
	(365 to 446)	(299 to 365)	(810 to 990)	(677 to 827)	(1,308 to 1,598)	(1,095 to 1,339)
1 1/4	680 to 830	567 to 693	1,530 to 1,870	1,260 to 1,540	2,466 to 3,014	2,052 to 2,508
	(501 to 612)	(418 to 511)	(1,128 to 1,379)	(929 to 1,136)	(1,819 to 2,223)	(1,513 to 1,850)
1 3/8	909 to 1,111	756 to 924	2,043 to 2,497	1,692 to 2,068	3,303 to 4,037	2,745 to 3,355
	(670 to 819)	(558 to 681)	(1,507 to 1,841)	(1,248 to 1,525)	(2,436 to 2,977)	(2,024 to 2,474)
1 1/2	1,197 to 1,463	999 to 1,221	2,682 to 3,278	2,232 to 2,728	4,347 to 5,313	3,618 to 4,422
	(883 to 1,079)	(737 to 900)	(1,978 to 2,417)	(1,646 to 2,012)	(3,206 to 3,918)	(2,668 to 3,261)

Use thread lock to prevent bolt and nut from loosening. (LOCTITE #243)

Before using thread lock wash rust, dirt and oil on thread area and dry completely.



LOCTITE #243

3.1.2 TIGHTENING TORQUE OF HYDRAULIC FITTINGS

Excessive or insufficient tightening of hose or tube fittings can cause oil leak and deformation or damage to the metal fittings.

Therefore, to secure and obtain good fixing and performance of fittings it is necessary to tighten to the proper torque.

The follows are the recommended torques.

BITE TYPE TUBE FITTINGS

Size : mm (inch) (Outside diameter × thickness)	Tightening torque : N⋅m (ft⋅lbs)	Remarks
10 (0.364) × 1.5 (0.059)	49 to 69 (36 to 51)	
15 (0.591) × 2.0 (0.079)	127 to 157 (94 to 116)	SLEEVE
18 (0.709) × 2.5 (0.098)	157 to 167 (116 to 123)	
22 (0.866) × 3.0 (0.118)	196 to 216 (145 to 159)	Condition after
28 (1.102) × 4.0 (0.157)	245 to 284 (181 to 210)	tightening 0.2 mm (0.01")
35 (1.378) × 5.0 (0.197)	324 to 353 (239 to 260)	(0.01)

SPLIT FLANGES (From SAE Standard)

Ciro	Tightening torque : N·m (ft·lbs)		Remarks
Size	3,000 psi (210 kg/cm²)	6,000 psi (420 kg/cm²)	Remarks
1/2"	20 to 25 (14.5 to 19)	-	
3/4"	28 to 39 (21 to 29)	34 to 45 (25 to 33)	✓—SPLIT FLANGE
1"	37 to 48 (27 to 35)	56 to 68 (42 to 50)	
1 1/4"	48 to 62 (35 to 45)	84 to 101 (62 to 74)	
1 1/2"	62 to 78 (45 to 58)	158 to 180 (116 to 133)	
2"	74 to 93 (54 to 69)	271 to 294 (200 to 217)	¥

FLARE TYPE TUBE FITTINGS (30 degrees flare, pf threads)

Size	Tightening torque : N·m (ft·lbs)	Remarks
1/4"	25 to 34 (18 to 25)	
3/8"	49 to 69 (36 to 51)	MALE — FEMALE
1/2"	59 to 78 (43 to 58)	IVIALE
3/4"	118 to 157 (87 to 116)	
1"	147 to 186 (108 to 137)	
1 1/4"	167 to 226 (123 to 166)	
1 1/2"	216 to 275 (159 to 202)	
2"	255 to 333 (188 to 246)	

JUBILEE CLIP (Low pressure and suction)


Nominal cord (BS5315)	Diameter : mm (in.)	Recommended torque : N·m (ft·lbs)	Working pressure range : kg/cm² (psi)
12	9.5 to 12 (3/8" to 1/2")	3.4 (2.5)	56.0 (796)
16	11 to 16 (1/2" to 5/8")	3.4 (2.5)	56.0 (796)
20	13 to 20 (1/2" to 3/4")	3.4 (2.5)	56.0 (796)
22	16 to 22 (5/8" to 7/8")	4.5 (3.3)	56.0 (796)
25	18 to 25 (3/4" to 1")	4.5 (3.3)	56.0 (796)
30	22 to 30 (7/8" to 1-1/8")	4.5 (3.3)	56.0 (796)
35	25 to 35 (1" to 1-3/8")	4.5 (3.3)	56.0 (796)
40	27 to 40 (1-1/8" to 1-5/8")	4.5 (3.3)	35.0 (498)
50	35 to 50 (1-1/4" to 1-7/8")	4.5 (3.3)	35.0 (498)
55	40 to 55 (1-1/2" to 2-1/8")	5.9 (4.3)	21.0 (299)
60	45 to 60 (1-3/4" to 2-3/8")	5.9 (4.3)	21.0 (299)
70	55 to 70 (2" to 2-3/4")	5.9 (4.3)	16.8 (239)
80	60 to 80 (2-3/8" to 3-1/8")	5.9 (4.3)	16.8 (239)
90	70 to 90 (2-3/4" to 3-1/2")	6.8 (5.0)	16.8 (239)
100	85 to 100 (3-1/4" to 4")	6.8 (5.0)	16.8 (239)
120	90 to 120 (3 3/4" to 4 1/2")	6.8 (5.0)	10.5 (149)
140	110 to 140 (4-1/8" to 5-1/2")	6.8 (5.0)	10.5 (149)
150	130 to 150 (5" to 5-3/4")	6.8 (5.0)	10.5 (149)
165	135 to 165 (5-1/4" to 6-1/2")	6.8 (5.0)	9.8 (139)
190	160 to 190 (6-1/4" to 7-1/2")	6.8 (5.0)	9.8 (139)
215	185 to 215 (7-1/4" to 8-1/2")	7.6 (5.6)	9.0 (128)
240	205 to 240 (8-1/4" to 9-1/2")	7.6 (5.6)	9.0 (128)
270	235 to 270 (9-1/4" to 10-1/2")	7.6 (5.6)	9.0 (128)
290	255 to 290 (10-1/4" to 11-1/2")	7.6 (5.6)	9.0 (128)
320	285 to 320 (11-1/4" to 12-1/2")	7.6 (5.6)	9.0 (128)

Trade mark : an adjustable steel band secured with a screw.

3.2 STANDARD PARTS

3.2.1 BOLT

Size and kind of bolt can be identified as shown below.



11,16

12,27

13,18


23

4T

7T

10T


Hex. socket screw




4.8 (4T)	7T	10.9 (10T)
ZS11F	ZS12F	ZS13F
ZS16F	ZS17F	ZS18F
ZS11C	ZS12C	ZS13C
ZS16C	ZS17C	ZS18C

3.2.2 O-RING

Size and kind of O-Ring are identified as shown below.







Rubber material classification For practical use, these are identified as color dot on O-ring, blue, red, green, or yellow.


Symbol	ID mark	Rubber material	Hardness	Operating temperature
11	One blue dot	Nitrile rubber	Hs70	-25 to 120 °C
12	Two blue dots	Nitrile rubber	Hs90	-25 to 120 °C
-	One red dot	Nitrile rubber	Hs70	Gasoline resistant type
-	One yellow dot	Styrol rubber	Hs70	-
-	One green dot	Fluorine rubber	Hs70	-15 to 200 °C


3.2.3 BACK-UP RING

Size and kind of back-up ring are identified as shown below.











3.2.4 BITE TYPE FITTING

PLUG FOR TUBE



Nominal diameter : mm	Made by IHARA KOHATSU (ZF)	Made by NIHON AMC (ZA)
10		
15		
18		
22		
28		
35		


PLUG FOR CONNECTOR



Nominal diameter : mm	Made by IHARA KOHATSU (ZF)	Made by NIHON AMC (ZA)
10		
15		
18		
22		
28		
35		


8500-1 / 8500E-1 3-10 Published 12-16-15, Control #244-01

NUT



Nominal diameter : mm	Made by IHARA KOHATSU (ZF)	Made by NIHON AMC (ZA)
10		
15		
18		
22		
28		
35		

SLEEVE



Nominal diameter : mm	Made by IHARA KOHATSU (ZF)	Made by NIHON AMC (ZA)
10		
15		
18		
22		
28		
35		

Tightening torque ZF Type

Nominal diameter : mm	10	15	18	22	28	35
Tightening torque :	49 to 69	98 to 138	157 to 197	196 to 236	246 to 304	314 to 372
N⋅m (ft⋅lbs)	(36 to 50)	(73 to 101)	(116 to 144)	(146 to 174)	(180 to 220)	(233 to 273)

Tightening torque ZA Type

Nominal diameter : mm	10	15	18	22	28	35
Tightening torque : N·m (ft·lbs)	39 to 49	108 to 128	128 to 166	197 to 235	246 to 304	385 to 443
	(28 to 36)	(80 to 94)	(94 to 122)	(146 to 174)	(180 to 220)	(291 to 319)

3.3 CONVERSION TABLE

3.3.1 UNIT CONVERSION

Figures in () show number of zero down a decimal point.

Ex) 0.(2)1 = 0.001

LENGTH

Unit	mm	cm	m	km	in.	ft	yd	mile
mm	1	0.1	0.001	0.000001	0.03937	0.0032808	0.0010936	0.(6)6214
cm	10	1	0.01	0.00001	0.3937	0.032808	0.010936	0.(5)6214
m	1000	100	1	0.001	39.37	3.28083	1.0936	0.(3)6214
km	1000000	100000	1000	1	39370	3280.83	1093.61	0.62137
in.	25.4	2.540	0.0254	0.(4)254	1	0.0833	0.02778	0.(4)1578
ft	304.8	30.48	0.3048	0.(3)3048	12	1	0.3333	0.(3)1894
yd	914.4	91.44	0.9144	0.(3)9144	36	3	1	0.(3)5682
mile	1609347.0	160934.70	1609.35	1.60935	63360	5280	1760	1

VOLUME

Unit	cm ³	m³	ltr.	kltr.	in³	ft³	yd³	gal
cm ³	1	0.(5)1	0.001	0.(5)1	0.06102	0.(4)3531	0.(5)1308	0.(3)2642
m³	1000000	1	1000	1	61020	35.31	1.308	264.2
Itr.	1000	0.001	1	0.001	61.02	0.03531	0.001308	0.2642
kltr.	1000000	1	1000	1	61020	35.31	1.308	264.2
in ³	16.39	0.(4)1639	0.01639	0.(4)1639	1	0.(3)5787	0.(4)2143	0.004329
ft³	28320	0.02832	28.32	0.02832	1728	1	0.03704	7.48055
yd ³	764500	0.7645	764.5	0.7645	46660	27	1	201.974
gal	3785	0.003785	3.785	0.003785	231	0.1337	0.004951	1

WEIGHT

Unit	kg	OZ	lb	(2000lbs) nt*1	(2240lbs) gt*2	mt*³
kg	1	35.2740	2.20462	0.001102	0.(3)9842	0.001
oz	0.02835	1	0.06250	0.(4)3125	0.(4)2790	0.(4)2835
lb	0.45359	16	1	0.00050	0.(3)4460	0.(3)4536
nt	907.185	32000	2000	1	0.89286	0.90719
gt	1016.05	35840	2240	1.12	1	1.016052
mt	1000	35274	2204.6	1.10231	0.98421	1

*1 nt : ton (U.S. unit)
*2 gt : ton (British unit)
*3 mt : ton (Metric)

3.3.2 MILLIMETER: INCH CONVERSION TABLE

 $mm \to in. \\$

	1 mm to 99 mm									
mm	0	1	2	3	4	5	6	7	8	9
					ir	٦.				
0	0.0000	0.0394	0.0787	0.1181	0.1575	0.1969	0.2362	0.2756	0.3150	0.3543
10	0.3937	0.4331	0.4724	0.5118	0.5512	0.5906	0.6299	0.6693	0.7087	0.7480
20	0.7874	0.8268	0.8661	0.9055	0.9449	0.9843	1.0236	1.0630	1.1024	1.1417
30	1.1811	1.2205	1.2598	1.2992	1.3386	1.3780	1.4173	1.4567	1.4961	1.5354
40	1.5748	1.6142	1.6535	1.6929	1.7323	1.7717	1.8110	1.8504	1.8898	1.9291
50	1.9685	2.0079	2.0472	2.0866	2.1260	2.1654	2.2047	2.2441	2.2835	2.3228
60	2.3622	2.4016	2.4409	2.4803	2.5197	2.5591	2.5984	2.6378	2.6772	2.7165
70	2.7559	2.7953	2.8346	2.8740	2.9134	2.9528	2.9921	3.0315	3.0709	3.1102
80	3.1496	3.1890	3.2283	3.2677	3.3071	3.3465	3.3858	3.4252	3.4646	3.5039
90	3.5433	3.5827	3.6220	3.6614	3.7008	3.7402	3.7795	3.8189	3.8583	3.8976

25.4 mm = 1 in.

in. \rightarrow mm

in.	0	1	2	3	4	5	6	7	8	9
					m	m				
0	0.000	25.400	50.800	76.200	101.600	127.000	152.400	177.800	203.200	228.600
1/64	0.397	25.797	51.197	76.597	101.997	127.397	152.797	178.197	203.597	228.997
1/32	0.794	26.194	51.594	76.994	102.394	127.794	153.194	178.594	203.994	229.394
1/16	1.588	26.988	52.388	77.788	103.188	128.588	153.988	179.388	204.788	230.188
3/32	2.381	27.781	53.181	78.581	103.981	129.381	154.781	180.181	205.581	230.981
1/8	3.175	28.575	53.975	79.375	104.775	130.175	155.575	180.975	206.375	231.775
5/32	3.969	29.369	54.769	80.169	105.569	130.969	156.369	181.769	207.169	232.569
3/16	4.763	30.163	55.563	80.963	106.363	131.763	157.163	182.563	207.963	233.363
7/32	5.556	30.956	56.356	81.756	107.156	132.556	157.956	183.356	208.756	234.156
1/4	6.350	31.750	57.150	82.550	107.950	133.350	158.750	184.150	209.550	234.950
9/32	7.144	32.544	57.944	83.344	108.744	134.144	159.544	184.944	210.344	235.744
5/16	7.938	33.338	58.738	84.138	109.538	134.938	160.338	185.738	211.138	236.538
11/32	8.731	34.131	59.531	84.931	110.331	135.731	161.131	186.531	211.931	237.331
3/8	9.525	34.925	60.325	85.725	111.125	136.525	161.925	187.325	212.725	238.125
13/32	10.319	35.719	61.119	86.519	111.919	137.310	162.719	188.119	213.519	238.919
7/16	11.113	36.513	61.913	87.313	112.713	138.113	163.513	188.913	214.313	239.713
15/32	11.906	37.306	62.706	88.106	113.506	138.906	164.306	189.706	215.106	240.506
1/2	12.700	38.100	63.500	88.900	114.300	139.700	165.100	190.500	215.900	241.300
17/32	13.494	38.894	64.294	89.694	115.094	140.494	165.894	191.294	216.694	242.094
9/16	14.288	39.688	65.088	90.488	115.888	141.288	166.688	192.088	217.488	242.888
19/32	15.081	40.481	65.881	91.281	116.681	142.081	167.481	192.881	218.281	243.681
5/8	15.875	41.275	66.675	92.075	117.475	142.875	168.275	193.675	219.075	244.475
21/32	16.669	42.069	67.469	92.869	118.269	143.669	169.069	194.469	219.869	245.269
11/16	17.463	42.863	68.263	93.663	119.063	144.463	169.863	195.263	220.663	246.063
23/32	18.256	43.656	69.056	94.456	119.856	145.256	170.656	196.056	221.456	246.856
3/4	19.050	44.450	69.850	95.250	120.650	146.050	171.450	196.850	222.250	247.650
25/32	19.844	45.244	70.644	96.044	121.444	146.844	172.244	197.644	223.044	248.444
13/16	20.638	46.038	71.438	96.838	122.238	147.638	173.038	198.438	223.838	249.238
27/32	21.431	46.831	72.231	97.631	123.031	148.431	173.831	199.231	224.631	250.031
7/8	22.225	47.625	73.025	98.425	123.825	149.225	174.625	200.025	225.425	250.825
29/32	23.019	48.419	73.819	99.219	124.619	150.019	175.419	200.819	226.219	251.619
15/16	23.813	49.213	74.613	100.013	125.413	150.813	176.213	201.613	227.013	252.413
31/32	24.606	50.006	75.406	100.806	126.206	151.606	177.006	202.406	227.806	253.206

3.3.3 METER AND FOOT CONVERSION TABLE

Foot	Meter	Foot	Meter	Foot	Meter
5	1.52	175	53.34	345	105.12
10	3.05	180	54.86	350	106.68
15	4.57	185	56.39	355	108.20
20	6.10	190	57.91	360	109.73
25	7.62	195	59.44	365	111.25
30	9.14	200	60.96	370	112.78
35	10.67	205	62.48	375	114.30
40	12.19	210	64.01	380	115.82
45	13.72	215	65.53	385	117.35
50	15.24	220	67.06	390	118.87
55	16.76	225	68.58	395	120.40
60	18.29	230	70.10	400	121.92
65	19.81	235	71.63	405	123.44
70	21.34	240	73.15	410	124.97
75	22.86	245	74.68	415	126.49
80	24.38	250	76.20	420	128.02
85	25.91	255	77.72	425	129.54
90	27.43	260	79.25	430	131.06
95	28.96	265	80.77	435	132.59
100	30.48	270	82.30	440	134.11
105	32.00	275	83.82	445	135.64
110	33.53	280	85.34	450	137.16
115	35.05	285	86.87	455	138.68
120	36.58	290	88.39	460	140.21
125	38.10	295	89.92	465	141.73
130	39.62	300	91.44	470	143.26
135	41.15	305	92.96	475	144.78
140	42.67	310	94.49	480	146.30
145	44.20	315	96.01	485	147.83
150	45.72	320	97.54	490	149.35
155	47.24	325	99.06	495	150.88
160	48.77	330	100.58	500	152.40
165	50.29	335	102.11		
170	51.82	340	103.63		

¹ foot = 0.3048 meter

3.3.4 GRADE CONVERSION TABLE

Degrees.	% (tan θ)
1	1.8
2	3.5
3	5.2
4	7.0
5	8.8
6	10.5
7	12.3
8	14.1
9	15.8
10	17.6
11	19.4
12	21.3
13	23.1
14	24.9
15	26.8

Degrees.	% (tan θ)
16	28.7
17	30.6
18	32.5
19	34.4
20	36.4
21	38.4
22	40.4
23	42.5
24	44.5
25	46.6
26	48.8
27	51.0
28	53.2
29	55.4
30	57.7

Degrees.	% (tan θ)
31	60.1
32	62.5
33	64.9
34	67.5
35	70.0
36	72.7
37	75.4
38	78.1
39	81.0
40	83.9
41	86.9
42	90.0
43	93.3
44	96.6
45	100.0

3.3.5 UNIT WEIGHT TABLE

Material	Weight per Cub. Meter (t)
Lead	11.4
Copper	8.9
Steel	7.8
Cast iron	7.2
Aluminum	2.7
Concrete	2.3
Soil	2.0
Gravel	1.9

Material	Weight per Cub. Meter (t)
Sand	1.9
Coal cold	0.8
Coal powder	1.0
Coke	0.5
Oak	0.9
Cedar	0.4
Cypress	0.4
Paulownia	0.3

Note

Weight of wood is that of the dried. Value shown in the table may well be taken for specific gravity.

3.3.6 SYSTEM INTERNATIONAL (SI) UNIT CONVERSION TABLE

International System of Units (SI : System International Unit)		Conversion Formula	
Types	Unit symbols	Meaning	CGS unit system to SI unit system
Mass	kg	Kilogram	Mass (kg) = Weight (kgf)*1
Force (Load)	N kN	Newton Kilonewton	1 (N) = 1 (kg) × 9.80 1 (kN) = 1 (N) × 1000
Moment of force	N·m	_	1 (N·m) = 1 (N) × 1 (m)
Stress	N/mm²	_	1 (N/mm²) =1 (N) ÷ 1 (mm²)
Pressure (hydraulic pressure, pneumatic pressure) ground pressure	Pa kPa MPa	Pascal Kilopascal Megapascal	1 (Pa) = 1 (N/mm²) 1 (kPa) = 1 (Pa) × 1000 1 (MPa) = 1 (kPa) × 1000
Horsepower (Motive power)	kW	Kilowatt	1 (kW) = 1 (PS)*2 ÷ 0.7355
Energy	J	Joule	1 (J) = 1 (N·m)

^{*1} f = gravity

^{*2} PS = horsepower

Gravimetric unit	— × → ← ÷ —	SI unit
kgf	9.807	N
lbf	4.448	N
kgf-cm	0.0981	N·m
lbf-ft	1.356	N·m
lbt-in	0.113	N·m
kgf/cm ³	0.0981	MPa
atm	0.1013	MPa
lbf/in²	0.0069	MPa
kgf/cm ³	98.1	kPa
atm	101.3	kPa
lbt/in²	6.9	kPa
mm Hg	133.3	Pa
in Hg	3386	Pa

Gravimetric unit	— × → ← ÷ —	SI unit
kgf-m/s	0.00981	kW
lbf-ft/s	0.00136	kW
PS	0.7355	kW
HP	0.746	kW
kgf-m	9.807	J
kcal	4186	J
kgf-s/cm ³	98067	Pa-s
cP	0.001	Pa-s
Р	0.1	Pa-s
cSt	1×10 ⁻⁶	m²/s
cSt	1	mm²/s
St	0.0001	m²/s
atm-cc/s	0.1013	Pa-m³/s

8500-1 / 8500E-1 3-18 Published 12-16-15, Control #244-01

4. POWER TRAIN

4.1	APPARATUS AND COMPONENTS LOCATION	4-3
4.2	ENGINE	4-6
4.2.1	REMOVAL OF THE ENGINE	4-6
4.2.2	REPAIR AND MAINTENANCE OF THE ENGINE	4-9
4.2.3	INSTALLATION OF THE ENGINE	4-10
4.3	PUMP DRIVE ASSEMBLY	4-14
4.3.1	CONSTRUCTION OF THE POWER DIVIDER	
4.3.2	CONSTRUCTION OF THE COUPLING	4-20
4.3.3	REMOVAL OF EACH PUMP	
4.3.4	REMOVAL OF THE POWER DIVIDER	
4.3.5	REMOVAL OF THE COUPLING	
4.3.6	DISASSEMBLING THE POWER DIVIDER	4-24
4.3.7	CHECK AND REPAIR OF THE POWER DIVIDER.	
4.3.8	ASSEMBLING THE POWER DIVIDER	4-27
4.3.9	INSTALLATION OF THE COUPLING	
4.3.10	INSTALLATION OF EACH PUMP	4-29
4.4	ASSEMBLY AND DISASSEMBLY OF RADIATOR	4-30
4.4.1	CONSTRUCTION OF THE RADIATOR	
4.4.2	REPLACEMENT ORDER OF RADIATOR CORE	4-31
4.5	DEF/AdBlue® SCR SYSTEM	
4.5.1	DEF/AdBlue® TANK	4-37
4.5.2	INDUCEMENT CONTROL SYSTEM	4-40



4. POWER TRAIN

This crane is a full hydraulic crawler crane.

The engine drives following pumps via the power divider.

MAIN PUMP


This pump is a tandem type variable displacement pump mounted on the power divider and provides a power to left and right travel motors, boom hoist motor, each of front and rear hoist motor through the two control valves.


Furthermore, by adding an exclusive control valve it provides power to the third (option) hoist motor.

- Front and rear hoist motors
 Drives drum shafts through respective reduction unit and hoisting, lowering or stop the respective hoist drums through the drum built in clutch.
- Boom hoist motor
 Drives drum shafts through reduction unit and hoisting, lowering or stop the boom hoist drum.
- Left and right travel motor
 Drives drive tumblers through respective reduction units to travel the machine.

SWING PUMP

This pump is a plunger pump mounted on the power divider and provides the power to swing motor through the reduction unit to swing the upper machinery.






GEAR PUMP

This pump is the tandem type gear pump mounted on the power divider.

Gear pump sends hydraulic oil to free fall cooling circuit of the front/rear hoist drum.




GEAR PUMP


This pump is the tandem type gear pump mounted on the swing pump.


No.6 pump sends hydraulic oil to control circuit.


No.7 pump sends hydraulic oil to gantry raising cylinder, crawler extend/retract cylinder and tagline (option) circuit.



4.1 APPARATUS AND COMPONENTS LOCATION







4.2 ENGINE

This chapter explains how to remove and re-install the engine.

Refer to the manual provided by the engine manufacturer for maintenance and repair details.

4.2.1 REMOVAL OF THE ENGINE

Proceed as follows when removing the engine from the machine.

MARNING

Right after stop the engine, the oils and cooling water of the machine may be extremely hot and may cause scald.

Inspection, replacement, draining and replenishment are to be carry out after cool down.

Failure to observe this precaution may result in a serious injury.

A CAUTION

Remove the pump drive assembly together with engine from the base machine.

A CAUTION

When the oil is cool, warming up the oil to reasonable temperature (approx. 20 to 40 °C [68 to 104 °F]) and drain the oil.

- 1. Lower the boom on the ground.
- 2. Take out the ground cable first in the battery.
- 3. Drain the hydraulic oil, engine oil and cooling water.
- Remove the cover of the diesel particulate filter and remove the flange bolts (4 pcs.) of the exhaust tube.
- 5. Remove the air cleaner, expansion reservoir and air inlet hoses from the engine.
- 6. The inter-cooler piping is secured on the guard beam.

Remove these bolts.


- Remove the electric wiring connectors which are connected to the diesel particulate filter and air cleaner.
- Remove the guard and the engine hood assy. required to remove the engine and pump drive assy.
- 9. Remove the fan shroud from the radiator.
- Remove the hyd. pump piping and label them.
 Put the cover on all the ports and hoses to prevent from entering of foreign objects.
- Label on the engine cooling piping, inter-cooler, fuel piping, and electric wiring and remove them.

Put the caps on the cooling water piping, intercooler piping and fuel piping to prevent from entering of foreign objects.

- 12. Check that all the electric wiring, mechanical connection and fuel piping are disconnected and there would be no interference for removing the engine.
- 13. Install the appropriate capacity of lifting gear to the engine.

(The engine has three lifting hooks.)

14. Remove the bolts and washers from the rubber mounts on the engine and the power divider.




 Lift up the engine and pump drive assy. as one unit slowly and take out from the machine.
 Weight is approx. 1,250 kg (2,756 lbs).



Take necessary action to prevent overturning of the engine.

16. Inspect the rubber mount and replace them if required.




8500-1 / 8500E-1 4-8 Published 12-16-15, Control #244-01

4.2.2 REPAIR AND MAINTENANCE OF THE ENGINE

Regarding the repair and maintenance of the engine, refer to the manual provided by the engine manufacturer.

The engine manufacturer	HINO MOTORS, LTD.		
The engine model	8500-1	J08E-VV	
The engine model	8500E-1	300E-VV	



4.2.3 INSTALLATION OF THE ENGINE

Proceed as follows when installing the engine.

- Check to make sure that no fuel lines, coolant water hoses, mechanical connection parts or other items are left to interfere with the installation.
- 2. If the rubber mounts were removed, replace them.
- 3. Using a enough capacity lifting gear, lift the engine and place it onto the mounting place.
- 4. Use LOCTITE #263 on the rubber mount holding bolts and tighten to the specified torque.

Front side	360 to 440 N·m
(Engine cooling fan side)	(266 to 324 ft·lbs)
Rear side	504 to 616 N·m
(Engine flywheel side)	(372 to 454 ft·lbs)

- 5. Install all the hydraulic hoses to the hydraulic pumps.
- 6. Install the fan shroud.

The clearance between the fan shroud and the fan should be even all around.

- 7. Connect all the electric wirings that were disconnected when the engine was removed.
- 8. Install all the fuel and inter-cooler piping that were removed when the engine was removed.



9. Install the guard, engine hood assembly.

MARNING

- The battery generates the flammable hydrogen gas, keep away flammable to prevent an ignition and explosion.
 - Failure to observe this precaution may result in serious injuries, property damage or loss of life.
- Do not put the tools or the likes on or near the battery to avoid any sparks.
 - Failure to observe this precaution may result in serious injuries, property damage or loss of life.
- If the handling of booster cable is incorrect may cause battery explosion.
 Ensure to take correct handling and not to made mistake of ⊕ terminal and ⊝ terminal.
 Failure to observe this precaution may result in serious injuries, property damage or loss of life.
- Install the air cleaner, expansion reservoir and air inlet hoses that were removed when the engine was removed.
 Install the exhaust tube and the diesel particulate
 - filter cover.
- 11. Refill the engine with coolant water and engine oil to the required levels.
- 12. Connect the battery cable.

4-11

13. Remove the air from the fuel lines.

Loosen the air venting bolt of the fuel filter, move the priming pump forward and back to discharge the air from the fuel system.

A CAUTION

The maintenance method differs according to the fuel filter type.


Carefully check the type, then perform the maintenance work.


Refer to the article 7 "INSPECTION METHOD OF EACH POINT" of the operator's manual.

⚠ WARNING


Sound the signal horn to warn the surrounding personnel before starting the engine.

Failure to observe this precaution may result in a serious injury or loss of life.





Start the engine and set it to low idle.
 Check for water and fuel leaks, and any strange noises.



PUMP DRIVE ASSEMBLY 4.3

This chapter explains how to remove, inspect, repair and re-install the pump drive assembly.


The pump drive assembly is mounted directly onto the rear of the engine.

It consists of a coupling, a power divider, main pumps, and 2 section gear pumps, swing pump and 2 section gear pumps which are connecting to the swing pump. The power of the engine is transferred from a flywheel


through the coupling to the input shaft and the helical gear of the power divider.


The power then is divided by 3 sets of helical gears (4 sets when option is selected) to the main pump shaft, swing pump shaft, cooling pump shaft.


(Closed with the flange when free less is selected.) (Refer to the article "4.3.3 REMOVAL OF EACH PUMP".)




4.3.1 CONSTRUCTION OF THE POWER DIVIDER










SHIM (ITEM 39 to 46) ADJUSTING PROCEDURE

- Assemble (54) housing, (2) stand, (3) shaft and (27) bearing tentatively without inserting the shims.
 - (47) O-ring and (28) oil seal to be installed to (2) stand after adjustment of shims.
- 2. Place the (54) housing so that (3) shaft is to be faced upward.
- Confirm if the clearance between (54) housing and (2) stand is evenly by checking with thickness gauge and tighten the (33) hex head socket bolt (for mounting the stand) 4 locations at even space.
 - (Tightening torque 19.4 to 23.6 N·m [14.3 to 17.4 ft·lbs] without LOCTITE)
- 4. Loosen the (33) hex head socket bolt and take them off.
- Rotate the (3) shaft 2 to 3 turns with hand.
 (So that removing the preload from the (27) bearing)
- 6. Measure the clearance between (54) housing and (2) stand with thickness gauge.
- 7. Select the shims (39 to 46) so that the total thickness of shim = Amount of clearance "S" + (0.15 to 0.25) = "X"
- 8. Insert selected shims to the clearance and assemble again tentatively.
- 9. Again rotate the (3) shaft 2 to 3 turns by hand and confirm the (27) bearing has no preload.




POWER DIVIDER

(2) Stand	(18)Plate	(34) Machine screw
(3) Shaft	(19)Plate	(35)90 degrees elbow
(4) Gear	(20) Plate	(36)Tube
(5) Gear	(21)Bearing	(37)Cap
(6) Gear	(22) Roller bearing	(38)Plug
(7) Gear	(23)Ball bearing	(39)Shim
(8) Support	(24)Ball bearing	(40)Shim
(9) Support	(25)Ball bearing	(41)Shim
(10)Support	(26) Ball bearing	(42)Shim
(11) Support	(27) Roller bearing	(43)Shim
(12)Plate	(28) Oil seal	(44)Shim
(13)Plate	(29) Oil level gauge	(45)Shim
(14)Plate	(30) Plate	(46)Shim
(15)Plate	(31)Rivet	(47) O-ring
(16)Plate	(32) Capscrew	(54) Housing
(17)Plate	(33) Capscrew	

- *1 Take note of installation phase angle of pump mounting bolt hole and bearing oil fill port of item (2) stand and item (8), (9), (10), (11) support. (See figure)
- *2 Install item (24), (25) bearing so that position of one side shield becomes on pump mounting side. (See figure)

4.3.2 CONSTRUCTION OF THE COUPLING



Tightening torque: 71.1 to 86.9 N·m (52.4 to 64.1 ft·lbs)

Do not apply LOCTITE to the thread if micro capsule is coated.


Confirm the threaded surface has been coated the micro capsule and tight.

(Confirm the color that micro capsule is blue.)

Apply Urea type heat resistant grease (NOK Clewbar -Amblygon,Eneos -Pilo knock universal 2 or equivalent) thoroughly on spline area of both shaft and hub to prevent fretting corrosion.

Insert the coupling hub to the spline step area by pushing and secure with clamp screw.

Tightening torque: 37.8 to 46.2 N·m (27.9 to 34.1 ft·lbs)
Do not apply LOCTITE to the thread if micro capsule is coated.
Confirm the threaded surface has been coated the micro capsule and tight.
(Confirm the color that micro capsule is blue.)



Coupling

- (1) Outer ring
- (2) Rubber body
- (3) Inner hub

- (4) Hex head socket bolt
- (5) Hex head socket bolt
- (6) Plane washer

4.3.3 REMOVAL OF EACH PUMP

After the pump drive assembly is removed together with the engine from base machine, remove from the engine as following procedure.


As to removal of the engine is to be referred "4.2.1 REMOVAL OF THE ENGINE"

A CAUTION

Remove the pump drive assembly together with engine from the base machine.

- 1. Drain the oil in the power divider through the port on the lower part of the power divider.
- 2. Remove each pump from the power divider.

Item	No,	Weight
MAIN PUMP	No.1, No.2	143.0 kg (315.0 lbs)
SWING PUMP+GEAR PUMP	No.3+No.6, No.7	57.4 kg (126.5 lbs)
GEAR PUMP (When "with free" is selected)	No.4, No.5	8.4 kg (18.5 lbs)




4.3.4 REMOVAL OF THE POWER DIVIDER


 Attach the appropriate capacity of appropriate lifting gear to the threaded holes of power divider. (Thread size of hole: M16)

Remove the capscrew which are mounted on the flywheel of the engine and slowly shift the power divider toward to the rear of the engine and remove the power divider after disengage the coupling.

Weight of the power divider (Dry): Approx. 210 kg (465 lbs)




* The parts which remain to the flywheel side are outer ring and bolts/washers for mounting.




4.3.5 REMOVAL OF THE COUPLING

1. Loosen the mounting bolts and remove only rubber body of the coupling.

The outer ring of the coupling is secured to the engine side.



2. Draw the hub out from the shaft.



4.3.6 DISASSEMBLING THE POWER DIVIDER

Proceed as follows when disassembling the power divider.


Refer to "4.3.1 CONSTRUCTION OF THE POWER DIVIDER" or corresponding numbers in the explanation below.

- 1. Place the power divider on the block facing the flywheel side up.
- 2. Remove the (33) capscrews and remove the (2) stand using two pull out screw holes (M10) of the (2) stand.
- 3. Remove the (28) oil seal and the outer race of the (27) taper roller bearing from the (2) stand and then take out the (39) to (46) shims. In this time, keep the (39) to (46) shim as a set. If required, remove the (34) screw and the (16) plates.
- Remove the (3) shaft and drive (4) gear as an assy.
 If required, pull out the inner race of both side (27) taper roller bearings and then pull out the drive (4) gear.
- Pull out the outer race of the (27) taper roller bearing from the (1) housing.
 If required, remove the (34) screws and the (20) plate.
- 6. Place the power divider on the block facing the pump side up.
- 7. Remove the (33) capscrews and the (8) support using two pull out screw holes (M10) of the (8) support.
- 8. Remove the (32) capscrews and the (13) plate.
- 9. Remove the (33) capscrews and the (9) support using two pull out screw holes (M10) of the (9) support.

If required, remove the (32) capscrews and the (15) plate.

10. Remove the (5) gear and both side (21), (22) bearings if required.

- 11. Remove the (32) cap screw and the (12) plate.
- 12. Remove the (33) capscrews and remove the (10) support using two pull out screw holes (M10) of the (10) support.
 If required, remove the (34) screws and the (17) plate.
- 13. Remove the (6) gear and both side (23), (24) bearings.
- 14. If required, remove the (34) screws and the (16) plate.
- 15. Remove the (33) capscrews and the (11) support using two pull out screw holes (M10) of the (11) support.
 If required, remove the (34) screws and the (18) plate.
- 16. Remove the (7) gear and if required, remove both side (25), (26) bearing.
- 17. If required, remove the (34) screws and the (19) plate.
- 18. If required, remove the (32) capscrews and (14) plate.



4.3.7 CHECK AND REPAIR OF THE POWER DIVIDER

Check all parts prior to reassembling the power divider. All questionable parts should be replaced to maximize the re-assembled power divider's service life and to avoid further break downs.

Checking should proceed in the following order.

- Clean all the parts with fresh cleaning oil and blow them dry.
- Check bearing balls, rollers, inner and outer races to see that they are free from pitching and scratches.
 Replace bearing if any defect is observed.
- Bearings with no pitching or scratches should be coat the lubrication oil slightly, but replace any bearings that develop rattles due to excessive clearances toward the axial direction or circumferential direction.
- Check the bearings' outer and inner races.
 Replace if any indications of slipping and/or rolling.
- 5. Check the teeth of all the gears and replace if any pitching, scratch, signs of friction wear, peeling or cracking.
- 6. Check the shafts and replace any with signs of cracking, deformation, wear at contact surfaces or bearing slippage are observed.
- Check the splines of the shafts and gears.
 Replace or fix if any cracking, signs of wear or impact damage are observed.
- 8. Check the bearing casings and replace if any slip wear or other deformations.
- 9. Check the gear case and replace or fix if any cracks, deformation or scratches.
- All the O-rings and oil seals should be replaced with new ones.
- Check capscrew and screw hole threadings and replace or repair if any signs burr or permanent strain on the threads.
- Take out the breather cap and clean in the pipe and check the orifice hole for clogging.

4.3.8 ASSEMBLING THE POWER DIVIDER

Assembling the power divider is in reverse order of disassembling.

Take extra care on the following points in assembling. Refer to "4.3.1 CONSTRUCTION OF THE POWER DIVIDER" for corresponding numbers in the explanation below.

- 1. Apply clean oil on each part and then assemble. But ensure to remove any oil on the mating face of the (1) housing, the (2) stand and the (8) to (11) support and apply LOCTITE #515 evenly on these face and also apply LOCTITE #243 on the (33) capscrews and tighten them to torque 63 to 77 N·m (46.5 to 56.7 ft·lbs).
- 2. When assembling the (3) shaft, the (4) drive gear, the (27) taper roller bearing and the (2) stand, adjust the clearance shown in "4.3.1 CONSTRUCTION OF THE POWER DIVIDER" to become 0.15 to 0.25 mm with the (39) to (46) shims
- Install the (2) stand and the (8) to (11) support to the (1) housing to make oil groove comes to the position as shown in "4.3.1 CONSTRUCTION OF THE POWER DIVIDER" (UP cast mark upward)
- 4. After assembly, check that the input shaft turns lightly by hand.



Published 12-16-15, Control #244-01 4-27 8500E-1

4.3.9 INSTALLATION OF THE COUPLING

1. Push the hub in until contact to the step of the shaft (spline).

Note

Apply Urea type heat resistant grease to the spline of the shaft and hub to prevent the fretting corrosion.

The hub is to be secured its deformation to the shaft, therefore if it is used once may be difficult to reuse.

If the hub originally installed is removed, replace with new one.

2. Install the rubber body of the coupling to the hub and tighten the mounting bolts with specified torque.

(Tightening torque : 71.1 to 86.9 N·m (52.4 to 64.1 ft·lbs)


The outer ring of the coupling is secured to the engine side.


Note


Confirm the threaded surface has been coated the micro capsule and tight.

Do not apply LOCTITE to the thread if micro capsule is coated.

If the bolt is to be reused, apply LOCTITE #243. Wipe off excess LOCTITE thoroughly to avoid adhesive to the rubber body scatters by rotation








8500-1 / 8500E-1 4-28 Published 12-16-15, Control #244-01


4.3.10 INSTALLATION OF EACH PUMP


- Apply the grease to the O-ring to prevent drops it and installs the O-ring to the grooves of respective pumps.
- 2. Refer with the right figures; install each pump with the specified tightening torque.
- Fill the lubricant to the specified level of the power divider and install a plug to the fill port. (More than red rounded mark of the level gauge and within the visible range of the oil level from the level gauge.)


	Oil Level hall be ubove red mark point
	on the level gauge, and be withIn the
Oil Amount	range where level can be visually
	checked
	(Approx. 10.7 L [2.8 gal])
Coosified Oil	Extreme pressure gear oil #90
Specified Oil	Extreme pressure gear oil #90 Grade GL-3 by API classification

- 4. Refer to the article "4.2.3 INSTALLATION OF THE ENGINE", Install engine and pump drive assembly as one unit to the machine.
- 5. Start the engine with low idling and confirm if any abnormal sounds, oil leakages etc.










Published 12-16-15, Control #244-01 4-29 8500-1 / 8500E-1

4.4 ASSEMBLY AND DISASSEMBLY OF RADIATOR

4.4.1 CONSTRUCTION OF THE RADIATOR

THE WEIGHT OF EACH PARTS FOLLOWING TABLE

Radiator assy	150 kg (335 lbs)
Radiator	25 kg (55 lbs)
Inter-cooler	24.5 kg (54 lbs)
Oil cooler	30 kg (66 lbs)
Frame	51 kg (112 lbs)
Shroud	8 kg (18 lbs)



8500-1 / 8500E-1 4-30 Published 12-16-15, Control #244-01

4.4.2 REPLACEMENT ORDER OF RADIATOR CORE

Note

Removal of the oil cooler is not required.



All the cores are made of aluminum. Ensure not to apply any nicks or gouges.

- Remove the shroud and the inter-cooler.
 Lift and hold the inter-cooler when removing it's mounting blots.
- 2. Remove the bolts (2 pcs) for radiator mount.
- Hooking to the lifting holes provided at both end of the radiator and lift up the core to right above direction.
 In case of removal of the fuel cooler and oil

cooler, remove the bolts (4 pcs) and pull them up.

- 4. Align the radiator lower pin and the lower cushion and insert the radiator core.
- Fix the radiator upper mount portion as described in the drawings while lifting the radiator core.
 The female thread for the mounting bolt is helicoid insert, take extreme care of tightening torque when the bolting up.
 M10 bolt (for helicoid insert) tightening torque:
 44 N·m (32.5 ft·lbs)
- 6. Install the shroud and the inter-cooler.
- 7. The tightening torque for each bolts, see following table.


Size	Tightening torque	
M8	16 to 34 N·m (11.8 to 25.1 ft·lbs)	
M10	34 to 74 N·m (25.1 to 54.6 ft·lbs)	
M12	55 to 123 N·m (40.6 to 90.7 ft·lbs)	

4.5 DEF/AdBlue® SCR SYSTEM

DEF/AdBlue® SCR system is a system for emission control.

The emission from diesel engine creates NOx due to oxidize of nitrogen in the air.

DEF/AdBlue® system is to split poisonous NOx into nitrogen and water by injection with DEF/AdBlue® in the muffler and purify exhaust gas.



Handling of DEF/AdBlue®

 DEF/AdBlue® is the product from the industrial urea solution is dissolved with the pure water of which is colorless and transparent 32.5% urea solution.

Urea solution is colorless and harmless liquid and widely used for cosmetics, pharmaceuticals and fertilizers.

DEF/AdBlue[®] is the safe and harmless product, not require any official qualification to handle it.

- DEF/AdBlue® is not specified as dangerous article and/or poison and powerful drugs. It is possible to store the goods under the general climate in the world for long period. However, should not be exposed to direct sunlight and keep in well ventilated place.
- DEF/AdBlue[®] is frozen at -11°C (12°F) with urea solution temperature.
- The pot life of DEF/AdBlue[®] is differ with stored temperature as shown below.

Stored Temperature °C (°F)	Pot Life	
0 (32)	∞	
10 (50)	75 years	
20 (68)	11 years	
30 (86)	23 months	
40 (104)	4 months	
50 (122)	1 month	
60 (140)	1 week	

▲ WARNING

Use the DEF/AdBlue® only.

Use other than specified DEF/AdBlue® or dilute with water, not only degradation in processing performance but also may resulted in damage the engine internal parts and other components.

In case of replenished other than DEF/AdBlue® in mistake, contact authorized Manitowoc distributor immediately.

After run control of DEF/AdBlue®

- When dosing of DEF/AdBlue[®] is stopped due to stop the engine, there is a control system to sucking back the DEF/AdBlue[®] from remaining DEF/AdBlue[®] in the lines.
 - If the DEF/AdBlue® is remains in the lines may be it frozen at cold or crystallized by dryness and may lead to malfunction.
- The pumping sound can be hear after stop the engine but it is not the failure.
- When removing battery lines or disconnect wire harness/connectors at maintenance, wait until after run control is completed.
 - If disconnect the battery line before completion of the after run, lead to the engine output limitation may be functioned.

As to frozen of DEF/AdBlue®


- DEF/AdBlue® is frozen at -11°C (12°F) with urea solution temperature.
- When judged as frozen by the respective temperature sensor, circulate the engine cooling water to the DEF/AdBlue® tank, DEF/AdBlue® supply module and DEF/AdBlue® lines as defreeze function is activate and melting the frozen DEF/AdBlue®.
- When frozen DEF/AdBlue[®] is judged as melt, inject DEF/AdBlue[®] when the injection condition is satisfied.
- Even when the DEF/AdBlue[®] is above -11°C (12°F), start the thermal function to the DEF/AdBlue[®] tank and DEF/AdBlue[®] lines if the DEF/AdBlue[®] is cold enough.

When disconnect the DEF/AdBlue® lines

- When remove the heat insulation on the DEF/ AdBlue[®] lines, ensure to furnish in proper position for avoid frozen of DEF/AdBlue[®].
- When disconnect the DEF/AdBlue[®] lines, install them without breaking, bending and kinking.
- When disconnect the DEF/AdBlue® lines, start the engine within 10 seconds after the key on for test run and confirm no engine cooling water leakage.

Due to the length of DEF/AdBlue[®] lines, repeat this task 2 to 3 times.


The cooling water shut valve opens 20 seconds after the key on regardless of ambient temperature and the cooling water flows as defreeze.



When dismantle the DEF/AdBlue® dosing module, DEF/AdBlue® supply module and DEF/AdBlue® sensor


When dismantle the DEF/AdBlue® dosing module, DEF/AdBlue® supply module and DEF/AdBlue® sensor, confirm engine cooling water level. If it is diminish in quantity, replenish the engine cooling water to FULL position and start the engine within 10 seconds and repeat 2 to 3 times.

FLOW WHEN THE AMBIENT TEMPERATURE IS HIGH




*Without ID. tape

FLOW WHEN THE AMBIENT TEMPERATURE IS LOW



4.5.1 DEF/AdBlue® TANK



1. DEF/AdBlue® tank removal

Discharge contents in the DEF/AdBlue® tank and clean inside of DEF/AdBlue® tank and DEF/AdBlue® sensor.


To discharge the contents in the DEF/AdBlue[®] tank, suck up contents with a siphon pump which available in the market from the fill port.

Residual quantity of the contents is to be discharge from the drain port by removing the drain plug.

Use 10 mm hexagon head socket wrench for removing the drain plug.


When reinstalling it, attach a O-ring on the plug.


DEF/AdBlue® Tank	Mass	Approx. 72 kg (159 lbs)
	Volume	Approx. 60 L (15.9 gal)




2. Sensor installation

- (1) Insert a DEF/AdBlue® sensor cap to the protrude part of the tank bottom.
- (2) Apply LOCTITE #243 to the mounting bolts for sensor controller and tighten with 7.3 to 8.9 N⋅m (5.4 to 6.6 ft⋅lbs).
- (3) Tighten the clamp on the sensor installation part with 5.3 to 6.5 N·m (3.9 to 4.8 ft·lbs).







4.5.2 INDUCEMENT CONTROL SYSTEM


An inducement control is to be issued a warning display, alarming and decreasing machine output when the emission control is not functioned properly or possibility of malfunction.

And this control system urges to return to the normal condition.

The engine output decreases depending on the contents of occurrence and become difficult to operate as normal work.

The engine output will be limited by the inducement control when faced following conditions.

- DEF/AdBlue® level becomes lower.
- DEF/AdBlue® quality becomes deteriorated.
- · Parts of SCR system failure.



The engine output limitation differs depend on respective conditions.


J08E

				Normal	RL1	RL2	RL3	RL4
	DEF/AdBlue® tank	Conditions		_	Warnig	Warning	Severe inducement	Final inducement
1	level warning	Engine speed	At max. torque (rpm)	2,100	2,100	2,100	1,680	800
		Engine loading ratio	Max. load ratio at limitation (%)	100	100	100	50	0
		Conditions		Normal	RQ1	- <	RQ3	RQ4
2	2 DEF/AdBlue® quality abnormal warning			I	Warning	İ	Severe inducement	Final inducement
		Engine speed	At max. torque (rpm)	2,100	2,100	1	1,680	800
		Engine loading ratio	Max. load ratio at limitation (%)	100	100	-	50	0
	DEF/AdBlue® SCR	Conditions		Normal		TF2	TF3	TF4
3 · SCR	failure warning		Iditions	-	-	Warning	Severe inducement	Final inducement
	· SCR system failure · EGR system failure	Engine speed	At max. torque (rpm)	2,100	_	2,100	1,680	800
	· NOx control abnormal	Engine loading ratio	Max. load ratio at limitation (%)	100	_	75	50	0

DEF/AdBlue® tank level lower

The output limitation will be limited step by step as follows.

Replenish with specified DEF/AdBlue® immediately.




 DEF/AdBlue[®] tank level lower (The method of release when display RL1 or RL2 on the monitor)


When warning is displayed, follow the instruction below in order.

- (A) Turn a key switch to OFF position.
- (B) Replenish the DEF/AdBlue® (20 L [5.3 gal] or more)
- (C) Turn the key to ON position and confirm if the warning has been released.

(After replenish the DEF/AdBlue® of which reflects to the monitor may be required few minutes)

If in case the warning is still existed, confirm the residual DEF/AdBlue® is more than 3 blocks and repeat the above steps (A) to (C)





(2) DEF/AdBlue[®] tank level lower (The method of release when display RL3 or RL4 on the monitor)

When warning is displayed, follow the instruction below in order.


- (A) Turn a key switch to OFF position.
- (B) Replenish the DEF/AdBlue® (20 L [5.3 gal] or more)
- (C) Turn the key to ON position and confirm if the warning has been released.

(After replenish the DEF/AdBlue® of which reflects to the monitor may be required few minutes)

If in case the warning is still existed, confirm the residual DEF/AdBlue® is more than 3 blocks and turn the key switch to OFF again.

- (D) Confirm the acceleration grip is in low idle and control levers are in neutral position.
 - If in case of the G engine mode is selected, change to power mode.
 - (As for the G engine mode, refer to the article 2 "HOOK HOISTING / LOWERING OPERATION" of the operator's manual.)
- (E) Start the engine and confirm if the engine speed limit has been released.
 - (Turn the acceleration grip and the engine speed correspond with the grip.)
- (F) If no warning is issued and the engine output limitation is released at step (E), normal returned already.

If in case the engine output is not released, turn the key switch to OFF position once, repeat the steps (D) and (E).




	J08E	
Conditions		Normal
		-
Engine speed At max. torque (rpm)		2,100
Engine loading ratio Max. load ratio at limitation (%)		100

2. Deteriorate the DEF/AdBlue® quality


The output limitation will be limited step by step as follows.

Replace with specified DEF/AdBlue® immediately.

First time and at 40 hours elapsed after normal return



· Redetect within 40 hours elapsed after normal return




Deteriorate the DEF/AdBlue[®] quality
 (The method of release when display RQ1 on the monitor)


When warning is displayed, follow the instruction below in order.

- (A) Turn the key switch to OFF position.
- (B) Drain the DEF/AdBlue® from the tank and fill the specified DEF/AdBlue® 20 L (5.3 gal) or more.
- (C) Turn the key to ON position and confirm if the warning has been released.

(Require to release the warning approx. 5 to 10 minutes)

If in case the warning is still existed, confirm the residual DEF/AdBlue® is more than 3 blocks and repeat the above steps (A) to (C).





4-45

(2) Deteriorate the DEF/AdBlue® quality (The method of release when display RQ3 or RQ4 on the monitor)

When warning is displayed, follow the instruction below in order.

- (A) Turn the key switch to OFF position.
- (B) Drain the DEF/AdBlue® from the tank and fill the specified DEF/AdBlue® 20 L (5.3 gal) or more.
- (C) Turn the key to ON position and confirm if the warning has been released.

(Require to release the warning approx. 5 to 10 minutes)

If in case the warning is still existed, confirm the residual DEF/AdBlue® is more than 3 blocks and repeat the above steps (A) to (C).


- (D) Turn the key switch to OFF position again.
- (E) Confirm the acceleration grip is in low idle and control levers are in neutral position.

If in case of the G engine mode is selected, change to power mode.

(As for the G engine mode, refer to the article 2 "HOOK HOISTING / LOWERING OPERATION" of the operator's manual.)

- (F) Start the engine and confirm if the engine speed limit has been released.
 - (Turn the acceleration grip and the engine speed correspond with the grip.)
- (G) If no warning is issued and the engine output limitation is released at step (F), normal returned already.

If in case the engine output is not released, turn the key switch to OFF position once, repeat the steps (E) and (F).




	J08E	
Conditions		Normal
	_	
Engine speed	Engine speed At max. torque (rpm)	
Engine loading ratio	Max. load ratio at limitation (%)	100

3. SCR system parts failure


The output limitation will be limited step by step as follows.

Contact authorized Manitowoc distributor immediately for repair.

• First time and at 40 hours elapsed after normal return



Redetect within 40 hours elapsed after normal return



SCR system parts failure
 (The method of release when display TF2, TF3 or TF4 on the monitor)

When warning is displayed, follow the instruction below in order.


- (A) Turn the key switch to OFF position.
- (B) Specify the failure location and repair it.
- (C) Turn the key to ON position and confirm if the warning has been released.
- (D) Turn the key switch to OFF position again.
- (E) Confirm the acceleration grip is in low idle and control levers are in neutral position.

If in case of the G engine mode is selected, change to power mode.

(As for the G engine mode, refer to the article 2 "HOOK HOISTING / LOWERING OPERATION" of the operator's manual.)

- (F) Start the engine and confirm if the engine speed limit has been released.
 - (Turn the acceleration grip and the engine speed correspond with the grip.)
- (G) If no warning is issued and the engine output limitation is released at step (F), normal returned already.

If in case the engine output is not released, turn the key switch to OFF position once, repeat the steps (E) and (F).



		J08E
Conditions		Normal
		_
Engine speed	At max. torque (rpm)	2,100
Engine loading ratio	Max. load ratio at limitation (%)	100

(2) SCR system parts failure (Method of release with DST-i)

When the following P codes are displayed on the monitor with reaching the TF4 condition, refer to the engine workshop manual.

	SAE code	Function
	P0106	Boost pressure sensor - rationality
	P0401	EGR low flow
P code (ECU side)	P0101	Air flow sensor - rationality
	P204F	Reductant system performance
	P0096	Intake air temperature sensor (intake manifold) - rationality
	P203B	DEF/AdBlue® tank level sensor failure
	P2201	SCR upstream NOx sensor - Performance and Monitoring capability
P code (DCU side)	P2214	SCR downstream NOx sensor - Performance and Monitoring capability
	P2483	SCR upstream temperature sensor - rationality
	P204B	Abnormal DEF/AdBlue® pressure sensor
	P0667	Abnormal temperature sensor of the dosing control unit
	P2047	DEF/AdBlue® injector failure
	P20F4	DEF/AdBlue® consumption failure
	P208B	Abnormal DEF/AdBlue® pump motor
	P20E8	Abnormal DEF/AdBlue® piping pressure (Low)
	P20E9	Abnormal DEF/AdBlue® piping pressure (High)

4. Inducement final limitation recovery mode

Under the final limitation, the crane operation is not possible.

Display following warning and enter to the final limitation and "FINAL LIMIT RECOVERY ICON" is pop up.

When press this icon, the crane can be able to operate temporally for evacuation purpose.



Residual quantity final limit (RL4)	DEF/AdBlue® bar gauge 0 block
Quality final limit (RQ4)	210 minutes after quality abnormal detect
SCR system parts final limit (TF4)	210 minutes after SCR parts failure detect

A CAUTION

- The final limit recovery icon use only at the evacuation purpose.
- The crane can be able to operate temporally but the motion is very slow.
- The crane operation may be difficult depending on the work load.
- There is a possibility of stalling the engine at evacuation when perform the combined controls.

MARNING

- Under the final limitation, the crane operation is not possible.
 - Before entering to the final limitation, contact authorized Manitowoc distributor.
- There is a possibility of not restating the engine if stop the engine under the final limitation.

MARNING

- If operated the machine continuously with the warning of inducement control indicated may result in the engine or related component damage.
- Perform the action to normal return as soon as possible after evacuation.

5. HYDRAULIC SYSTEM

5.1	LOCATION OF MAIN HYDRAULIC COMPONENTS	5-2
5.1.1	COMPONENTS LOCATION ON THE HYDRAULIC SCHEMATIC	5-2
5.1.2	HYDRAULIC COMPONENTS LIST	5-7
5.1.3	LAYOUT OF HYDRAULIC COMPONENTS	5-11
5.2	CONSTRUCTION AND FUNCTION	5-18
5.2.1	OIL FLOW FROM No.1 AND No.2 PUMPS	5-18
5.2.2	OIL FLOW FROM No.3 PUMP	5-20
5.2.3	OIL FLOW FROM No.4 AND No.5 PUMPS	
	(FRONT, REAR DRUM BRAKE COOLING)	5-22
5.2.4	OIL FLOW FROM No.6 PUMP	5-24
5.2.5	OIL FLOW FROM No.7 PUMP	5-28
5.3	VALVE	5-36



5. HYDRAULIC SYSTEM


This chapter provides a general outline of the overall hydraulic system.


The pressurized oil in this circuit is supplied by the 3 variable displacement pumps driven with the power divider directly connected to the engine and 2 section gear pumps connected to them.

2 pumps (2 section) out of these 3 variable displacement pumps are for front drum, rear drum, boom drum and travel and one other pump is for swing.

Inner side pump out of 2 section gear pumps directly connected to the swing pump is for control purpose and outer side one is for auxiliary units such as gantry cylinder, crawler extending and other optional circuit.

2 gear pumps directly connected with power divider are for front and rear drum brake cooling.







5.1 LOCATION OF MAIN HYDRAULIC COMPONENTS

5.1.1 COMPONENTS LOCATION ON THE HYDRAULIC SCHEMATIC

WITHOUT FREE FALL (STD)





8500-1 / 8500E-1 5-2 Published 12-16-15, Control #244-01




Published 12-16-15, Control #244-01 5-3 8500-1 / 8500E-1


WITH FREE FALL







8500-1 / 8500E-1 5-4 Published 12-16-15, Control #244-01











8500-1 / 8500E-1





8500-1 / 8500E-1 5-6 Published 12-16-15, Control #244-01

5.1.2 HYDRAULIC COMPONENTS LIST


Name of component	Use for	Specification
Main pump (No.1) Main pump (No.2)	Third drum (option) Boom drum	Swash plate type, variable displacement Max. delivery : 255 L/min (67.4 gal/min) Max. working press. : 31.9 MPa (4,627 psi)
1. Main pump (No.2)	Travel	Wax. Working press 31.9 Wil a (4,027 psi)
3. Swing pump (No.3)	Swing	Swash plate type, variable displacement Max. delivery : 177 L/min (46.8 gal/min) Max. working press. : 27.5 MPa (3,989 psi)
4. Gear pump (No.6)	Control	Max. delivery : 61 L/min (16.1 gal/min) Max. working press. : 7.0 MPa (1,015 psi)
4. Gear pump (No.7)	 Gantry Crawler Tagline (option)	Max. delivery : 40 L/min (10.6 gal/min) Max. working press. : 20.6 MPa (2,988 psi)
5. Gear pump (No.4) (option)	Front, rear drum brake	Max. delivery : 73 L/min (19.3 gal/min)
5. Gear pump (No.5) (option)	cooling	Max. working press. : 1.0 MPa (145 psi)
8. Motor	Front, rear drum	Swash plate type, variable displacement
9. Motor (option)	Third drum (option)	Max. delivery : 255 L/min (67.4 gal/min) Max. working press. : 31.9 MPa (4,627 psi)
10. Motor	• Boom	Bent axis type, fixed displacement Max. delivery : 255 L/min (67.4 gal/min) Max. working press. : 31.9 MPa (4,627 psi)
11. Motor (option)	Tagline (option)	Max. delivery : 40 L/min (10.6 gal/min) Relief press. : 13.7 Mpa (1,987 psi)
12. Motor	• Swing	Swash plate type, variable displacement Max. delivery : 177 L/min (46.8 gal/min) Max. working press. : 27.5 MPa (3,989 psi)
13. Motor	• Travel	Swash plate type, 2 speed motor Max. delivery : 255 L/min (67.4 gal/min) Max. working press. : 31.9 MPa (4,627 psi)
17. Control valve	Travel R.H.Boom drumMain2, aux.1	Max. delivery : 255 L/min (67.4 gal/min) Max. working press. : 31.9 MPa (4,627 psi)
18. Control valve	Travel L.H.Main1, aux.2	Max. delivery : 255 L/min (67.4 gal/min) Max. working press. : 31.9 MPa (4,627 psi)
19. Control valve (option)	Third drum (option)	Max. delivery : 255 L/min (67.4 gal/min) Max. working press. : 31.9 MPa (4,627 psi)
20. Control valve	Swing	Max. working press. : 27.5 MPa (3,989 psi)
21. Control valve	Crawler ext. / ret.	Crawler extending Press. push : 17.0 MPa (2,466 psi) Press. pull : 21.0 Mpa (4,627 psi)
22. Control valve	Gantry	Set press. : 20.6 MPa / 4.9 Mpa (2,988 psi / 711 psi)
23. Control valve (option)	Swing free / brake	Max. working press. : 27.5 MPa (3,989 psi)
24. Control valve	Counterweight self removal	Max. delivery : 40 L/min (10.6 gal/min) Max. working press. : 21.0 MPa (3,046 psi)


Name of component	Use for	Specification
25. Control valve (8500-1 : STD. / 8500E-1 : OPT.)	Crawler self removal Counterweight self removal	Set press. : 21.0 / 4.9 MPa (3,046 / 711 psi)
26. Control valve (option)	TranslifterCrawler ext. / ret.	Set press. : 17.0 / 21.0 MPa (2,466 / 3,046 psi)
27. Valve block (8-section)	Automatic stop and speed control	 Front drum hoist remote control pressure Front drum lowering remote control pressure Rear drum hoist remote control pressure Rear drum lowering remote control pressure Boom raise remote control pressure Boom lowering remote control pressure Third drum hoist remote control pressure (option) Third drum lowering remote control pressure (option)
28. Valve block (5-section)	Limit stop	 Boom raise stop Boom lower stop Rear drum hoist stop Front drum lower stop Third drum hoist stop (option)
29. Valve block (4-section)	Motor brake	 Front drum motor parking brake Rear drum motor parking brake Boom drum motor parking brake Third drum motor parking brake (option)
30. Valve block (2-section)	Remo-con press. source cut etc	 Remo-con cut Swing parking brake Travel speed Hi / Low select Swing Hi / Low pressure select
31. Valve block (1-section)	Swing counterforce	Swing counterforce
32. Valve block (3-section) (option)	Sol prop valve	Swing angle limit
33. Valve block (4-section)	Wet type free fall	 Rear drum clutch Rear drum emergency clutch Front drum emergency clutch Front drum clutch
34. Valve block (3-section)	Wet type free fall speed acceleration	Front drum free fall speed accelerationRear drum free fall speed acceleration
36. Valve block (option)	For hyd. oil heat	Hydraulic oil heat
37. Valve block (2-section)	Feathering, Qmax cut	
39. Valve block (2-section) (option)	Third wet type free fall	Third drum clutch Third drum emergency clutch engage
41. Solenoid valve (option)	Third drum (option)	Third drum automatic stop
42. Solenoid valve (option)	Third drum (option)	Third drum limit stop
45. Remote control valve	Front, rear drum	Press. : 2.65 to 2.94 Mpa (384 to 426 psi)
40. Remote control valve	Boom drum	Press. : 2.50 to 2.79 Mpa (363 to 405 psi)
46. Remote control valve	Swing	Press. : 1.62 to 1.92 Mpa (235 to 278 psi)
47. Remote control valve	Travel	Press. : 1.42 to 1.62 MPa (206 to 235 psi)


Name of component	Use for	Specification
48. Control valve (option)	Brake	
49. Remote control valve (option)	Boom drum control pedal	
50. Remote control valve (option)	Third drum (option)	Press. : 2.65 to 2.94 Mpa (384 to 426 psi)
51. Cylinder	Gantry hoist	Tube I.D : 75 mm dia. (2-15/16" dia.) Rod O.D : 40 mm dia. (1-9/16" dia.) Stroke : 304 mm (11-31/32") Press. push : 20.6 MPa (2,988 psi) Press. pull : 4.9 Mpa (711 psi)
52. Cylinder	Crawler ext. / ret.	Tube I.D : 150 mm dia. (5-29/32" dia.) Rod O.D : 70 mm dia. (2-3/4" dia.) Stroke : 1,111 mm (43-3/4") Press. push : 17.0 MPa (2,466 psi) Press. pull : 21.0 Mpa (4,627 psi)
53. Cylinder (8500-1 : STD. / 8500E-1 : OPT.)	Counterweight self removal	Tube I.D : 110 mm dia. (4-11/32" dia.) Rod O.D : 85 mm dia. (3-11/32" dia.) Stroke : 1,330 mm (52-3/8")
54. Check valve		For valve block
56. Cylinder (option)	Translifter	Tube I.D : 115 mm dia. (4-17/32" dia.) Rod O.D : 80 mm dia. (3-5/32" dia.) Stroke : 700 mm (27-9/16")
57. Cylinder (option)		Press. push : 20.6 MPa (2,988 psi) Press. pull : 20.6 Mpa (2,988 psi)
58. Swivel joint		
59. Swivel joint (8 port)		A, B, C, D: Travel E: Travel speed select F: Tank G: Crawler H: Drain
60. Relief valve / reducing valve	• Control	Relief press. : 7.0 Mpa (1.015 psi) Reducing sec. press. : 5.4 Mpa (783 psi)
61. Sol. prop relief valve (option)	Tagline (option)	Mechanical relief press. setting : 14.7 Mpa (2,132 psi) Proportional relief press. setting : 13.7 MPa (1,987 psi) (at 0.25 Amp.)
62. Flow control valve (option)	Tagline (option)	
63. Shuttle valve (option)		
64. Slow return check valve (option)	Tagline (option)	
65. Slow return check valve	Motor brake	0.8 mm dia. (0.032" dia.)
66. Suction strainer		80 Mesh
67. Return filter		β₁₀≥ 8
68. Return filter (option)	Wet type clutch	10 μm
69. Drain filter		10 μm
70. Line filter	Control	100 Mesh (149 μm)
71. Line filter	Aux. actuator	100 Mesh (149 μm)


Name of component	Use for	Specification
73. Bypass check valve	Oil cooler	0.294 MPa (43 psi)
74. Bypass check valve (option)	Front, rear drum brake cooling	0.294 MPa (43 psi)
75. Bypass check valve (option)	Third drum (option)	0.490 MPa (71 psi)
76. Accumulator		N ₂ Gas 2,900 cm ³
77. Plug (option)		
79. Pressure sensor	Remo-con press. detect	3.0 MPa (435 psi)
80. Pressure sensor	Swing	50.0 MPa (7,252 psi)
81. Pressure sensor	Clutch	19.6 MPa (2,843 psi)
82. Pressure switch (option)	Control	
83. Pressure switch	Travel remo-con press. detect	
84. Hyd. oil temperature sensor	Hyd. oil tank	
85. Hyd. oil temperature switch (option)		130 °C (266 °F)
86. Hyd. oil temperature switch (option)		60 °C (140 °F)
87. Valve block		DPF re-generation
88. Double pilot check valve (option)		
89. Cylinder (option)	Crawler self removal	


5.1.3 LAYOUT OF HYDRAULIC COMPONENTS























5.2 CONSTRUCTION AND FUNCTION

5.2.1 OIL FLOW FROM No.1 AND No.2 PUMPS


No.1 and No.2 pumps are main pumps and are tandem connected variable displacement double pumps.

At neutral, pressurized oil from No.1 pump flows into 4 section side control valve circuit (front / rear drum / right travel / boom).


At the same time, pressurized oil from No.2 pump flows into 3 section side control valve circuit (front / rear drum / left travel) and passes through each control valve and return to the oil tank without load.

When any of control valve spools is moved by pressurized control oil from the remote control valve, pressurized main pump oil is led to each actuator.

When the inching speed switch is handled, inching speed solenoid becomes energized to actuate the pump regulator and minimize oil delivery from the main pump.



OIL FLOW FROM No.1 AND No.2 PUMPS




5.2.2 OIL FLOW FROM No.3 PUMP

No.3 pump is swing pump and is variable displacement pump.

When the swing remote control valve is in neutral, pressurized oil from No.3 pump flows into the swing control valve and returns to oil tank without load.


When the swing control valve is actuated with the pressurized oil from the remote control valve, pressurized oil from the swing pump flows into the swing motor to swing the upper machinery.

OIL FLOW FROM No.3 PUMP




5.2.3 OIL FLOW FROM No.4 AND No.5 PUMPS (FRONT, REAR DRUM BRAKE COOLING)

No.4 and No.5 pumps are gear pumps and are used for cooling of front and rear drum brake (clutch). The pressurized oil from both pumps passes through the front and rear drum brake (clutch) and returns to the tank through the filter.



OIL FLOW FROM No.4 AND No.5 PUMPS (FRONT, REAR DRUM BRAKE COOLING)



5.2.4 OIL FLOW FROM No.6 PUMP

No.6 pump is gear pump and is used for control. Pressurized oil from the pump passes through the line filter and is pressure-reduced to 5.4 MPa and flows into the accumulator and then flows into 2 4-section valves and 2 2-section valves and the foot brake valve.


1. When function lock lever is in "LOCK" position

When the function lock lever is in "LOCK" position, pressurized oil sent to 2-section valve which is shut off with the function lock (Remo-con cut) solenoid valve (SOL-3) and is not sent to the remote control valve.

Therefore under this condition, even when the control lever is operated, control pressure will not be generated and the machine will not move.




OIL FLOW FROM No.6 PUMP (WHEN FUNCTION LOCK LEVER IS IN "LOCK" POSITION)




2. When function lock lever is in "WORK" position

When the function lock lever is in "WORK" position, pressurized oil sent to 2-section valve passes through the function lock (Remo-con cut) solenoid valve (SOL-3) and flows into the remote control valve.

Under this condition, when the control lever is operated, remote control pressure is sent to the main control valve and make each actuator functioned.



OIL FLOW FROM No.6 PUMP (WHEN FUNCTION LOCK LEVER IS IN "WORK" POSITION)



5-27

5.2.5 OIL FLOW FROM No.7 PUMP

1. Crawler extending cylinder

No.7 pump (Aux. device pump) is fixed displacement gear pump and is used for crawler extending cylinder.


When the lower pressure source valve located in the downstream side of the gantry raise control valve is operated, the pressurized oil from the pump passes through the swivel joint and flows into the crawler extending valve.

When the crawler extending cylinder is being operated, return oil from the cylinder passes through the swivel joint and returns to the tank.



OIL FLOW FROM No.7 PUMP (CRAWLER EXTENDING CYLINDER)

CRAWLER EXTENDING CYLINDER (ARROW DIRECTION INDICATOR CYLINDER EXTENDING)




2. Translifter

No.7 pump (Aux. device pump) is fixed displacement gear pump and is used for the translifter cylinder.

When the lower pressure source valve located in the downstream side of the gantry raise control valve is operated, the pressurized oil from the pump passes through the swivel joint and flows into the translifter valve.

When the translifter cylinder is being operated, return oil from the cylinder passes through the swivel joint and returns to the tank.

OIL FLOW FROM No.7 PUMP (TRANSLIFTER)




3. Gantry raise cylinder

No.7 pump (Aux. device pump) is fixed displacement gear pump and is used for gantry raise.

The pressurized oil from the pump flows into the gantry raise control valve.

When the gantry raise control valve is in neutral, the pressurized oil passes through the valve and returns to the tank without load.

OIL FLOW FROM No.7 PUMP (GANTRY HOIST CYLINDER)




4. Counterweight self removal cylinder

No.7 pump (Aux. device pump) is fixed displacement gear pump and is used for counterweight self removal.


The pressurized oil from the pump flows into the counterweight self removal control valve.


When the counterweight self removal control valve is in neutral, the pressurized oil passes through the valve and returns to the tank without load.

OIL FLOW FROM No.7 PUMP (COUNTERWEIGHT SELF REMOVAL CYLINDER)





5.3 VALVE








8-SECTION VALVE (WITH SHUTTLE VALVE)















· Beside of swing motor




In the cab deck










MAIN CONTROL VALVE (4-SECTION)







MAIN CONTROL VALVE (3-SECTION)





MAIN CONTROL VALVE (THIRD 1-SECTION)







6. HOIST SYSTEM

6.1	APPARATUS AND LOCATION OF COMPONENTS	6-2
6.2	CONSTRUCTION AND FUNCTION	6-6
6.2.1	HYDRAULIC SCHEMATIC	6-6
6.2.2	LIFTING A LOAD	6-8
6.2.3	HOLDING A HOISTED LOAD	6-10
6.2.4	LOWERING A LOAD (POWER LOWERING)	6-12
6.2.5	FREE FALL OPERATION	6-14
6.2.6	G WINCH MODE LIFTING	6-22
6.2.7	G WINCH MODE LOWERING	6-23
6.3	WINCH	6-24
6.3.1	WINCH INSTALLATION	
6.3.2	WINCH ASSEMBLY	
6.3.3	REDUCTION UNIT ASSEMBLY	
6.3.4	ADJUSTMENT OF DRUM LOCK	6-28
6.4	BRAKE PEDAL	
6.4.1	ASSEMBLY DRAWING	
6.4.2	ADJUSTING THE BRAKE PEDAL	
6.4.3	BLEEDING AIR FROM BRAKE CIRCUIT	6-33



6. HOIST SYSTEM

The hoist system consists of the front drum and rear drum assembly.


Each drum assy. consists of hoist motor (brake built in), reduction unit, drum clutch (common to free fall brake) and drum lock.


The pressurized oil delivered from 2 main pumps (No.1, No.2) is controlled by the control valve and flows into each motors.


6.1 APPARATUS AND LOCATION OF COMPONENTS


Note


Refer to the article "6.2 CONSTRUCTION AND FUNCTION" for circuit diagram and function.













Published 12-16-15, Control #244-01 6-5 8500-1 / 8500E-1

6.2 CONSTRUCTION AND FUNCTION

6.2.1 HYDRAULIC SCHEMATIC



8500-1 / 8500E-1 6-6 Published 12-16-15, Control #244-01



6.2.2 LIFTING A LOAD

Function of the front drum and the rear drum are exactly same.

The front drum is explained here as an example.

Pressurized oil from the main pump (No.1, No.2) flows through the main control valve, and transmitting the power to the hoist system.

While the function lock lever is in the "WORK" position (SOL-3: "ON" position), oil pressure from the control pump flows to the accumulator and into the foot brake valve block, the clutch valve block, brake valve block (4-section pilot operated valve) and through the valve block (2-section solenoid valves) and into the remote control valve.


The pressurized oil is also fed to the both sides oil chambers of the front drum clutch cylinder ("CLM", "ESM") via the clutch valve block (4-section solenoid valves).

Since the cylinder thrust force by the pressurized oil is not generated, the clutch is connected with the spring.


When the front drum control lever is operated in the "hoist load" direction, it directs control pressure oil through the remote control valve and into the "PUM" and "PUM2" ports of the main control valve where it moves the spool.

At the same time, the control pressurized oil flows into the "PBM" port of the brake cylinder built in the winch motor via the brake valve block (4-section pilot operated valves), and the motor brake is released.

As directed by the position of the spool, the main pump (No.1, No.2) oil flowing into the control valve is sent to the hoist side of the hoist motor to drive the front drum and thereby hoist the load.



8500-1 / 8500E-1 6-8 Published 12-16-15, Control #244-01



6.2.3 HOLDING A HOISTED LOAD

With the main control lever turned back to its neutral position, the control pressure coming from the remote control valve is cut and the spool in the main control valve returns to its neutral position.

When the spool returns to neutral, the pressurized oil to the main motor is cut off and the motor stops.


Now, although the weight of the suspended load continues to pull on the drum, further rotation of the drum is prevented by a motor counterbalance valve that blocks the return of oil to the hydraulic tank.

At the same time, the control oil pressure in the motor brake cylinder is directed back to the hydraulic tank and the motor brake (nega-brake) actuates.


The pressurized oil is fed to the both sides oil chambers of the clutch cylinder ("CLM", "ESM"), and the cylinder thrust force by the pressurized oil is not generated.

Therefore, the clutch remains engaged with the spring.

The load is now held in suspension by the combined effects of the motor counterbalance valve, the motor brake and the clutch.



8500-1 / 8500E-1 6-10 Published 12-16-15, Control #244-01



Published 12-16-15, Control #244-01 8500E-1

6.2.4 LOWERING A LOAD (POWER LOWERING)

Pressurized oil from the main pump (No.1, No.2) flows through the main control valve and transmitting the power to the front drum lowering system.

When the function lock lever is in the "WORK" position (SOL-3: "ON" position), oil pressure from the control pump flows to the accumulator and into the foot brake valve block, the clutch valve block, brake valve block (4-section pilot operated valve) and flows through the valve block (2-section solenoid valves) and into the remote control valve.

The pressurized oil is fed to the both sides oil chambers of the clutch cylinder ("CLM", "ESM") via the clutch valve block (4-section solenoid valves).

Since the cylinder thrust force by the pressurized oil is not generated, the clutch is engaged with the spring.


When the main control lever is operated to the "lower load" direction, this control oil pressure is directed by the remote control valve to flow into the port "PDM" of the main control valve and it moves the spool.

At the same time, control pressure is also directed through the brake valve block (4-section pilot operated valve) to the "PBM" port of the motor brake cylinder.


It causes the motor brake to disengage.

Now the main pump (No.1, No.2) oil flowing into the control valve, as directed by the position of the spool, activates the hoist motor to drive the drum and thereby lower the load.

The counterbalance valve is opened by pilot pressure from the "running in" side to allow the main motor to rotate and lower the load.



8500-1 / 8500E-1 6-12 Published 12-16-15, Control #244-01



Published 12-16-15, Control #244-01 8500E-1


6.2.5 FREE FALL OPERATION

FREE FALL


When the brake select switch for front drum is set to the "FREE FALL" side, the solenoid valve (SOL-22) in the clutch valve block (4-section solenoid valves) is switched over.

When the solenoid valve is switched over and the front drum foot brake is released, the pressurized oil in the "CLM" side oil chamber of the front drum clutch cylinder returns to the tank, and the cylinder thrust force is generated against the spring to release the clutch.

As a result, the load falls freely (free fall), and the brake can be applied with the foot brake.




8500-1 / 8500E-1 6-14 Published 12-16-15, Control #244-01




BRAKING

When the brake pedal is operated, the control pressurized oil flows into the "CLM" side oil chamber of the clutch cylinder through the front drum foot brake valve, and the cylinder thrust force is increased to actuate the brake (braking with the clutch).



8500-1 / 8500E-1 6-16 Published 12-16-15, Control #244-01



FREE FALL ACCELERATION

Free fall with the "FREE FALL SPEED SELECT SWITCH" on the left upper switch panel set to the "HIGH" position.


When the free fall speed select switch is turned to HIGH, the solenoid valve (SOL-10) is switched over, and pressurized oil from the clutch valve block (4-section SOL) flows into the "PDM" port of the main control valve through the shuttle valve and solenoid proportional valve (SOL-55) to move the spool.

At the same time, the oil also goes into the brake cylinder "PBM" port of the winch motor through the brake valve block (4-section pilot operated valves) to release the motor brake.


Then, the motor rotates to the lowering direction.

Though the clutch is released while the "FREE FALL" mode is selected and the foot brake is released, the rotation of the winch motor is transmitted to the drum, and the free fall speed is increased by the power lowering, because the rotation resistance of the clutch is larger than that of the drum.

In this status, the drum can rotate without any load.



8500-1 / 8500E-1 6-18 Published 12-16-15, Control #244-01




Published 12-16-15, Control #244-01 8500E-1

BRAKING WHILE FREE FALL ACCELERATION


When the brake pedal is depressed, pressurized oil is fed to the "CLM" side of the clutch cylinder through the front drum foot brake valve.

Then, the cylinder thrust force is decreased to slow down the free fall speed, and the control pressure from the solenoid valve (SOL-10) in the 3-section valve block is also decreased by the proportional valve (SOL-55) and the solenoid valve (SOL-10) to return the main control valve spool to the neutral position.

When the spool is returned to the neutral position, pressurized oil to the motor is shut off, and the main motor stops rotating.



8500-1 / 8500E-1 6-20 Published 12-16-15, Control #244-01



Published 12-16-15, Control #244-01 8500E-1

6.2.6 G WINCH MODE LIFTING


Refer to "ELECTRIC CONTROL" for condition of switching over to G winch mode.

Function of the front drum and the rear drum are exactly same.

The front drum is explained here as an example.

The function of respective parts for G winch mode is same as "6.2.2 LIFTING A LOAD".

In addition to these, the control pressure from a proportional solenoid valve SOL-65 will be output to the motor for minimum capacity (Minimum displacement for G winch) to create the G winch mode.



8500-1 / 8500E-1 6-22 Published 12-16-15, Control #244-01

6.2.7 G WINCH MODE LOWERING


Refer to "ELECTRIC CONTROL" for condition of switching over to G winch mode.

Function of the front drum and the rear drum are exactly same.

The front drum is explained here as an example.

The function of respective parts for G winch mode is same as "6.2.4 LOWERING A LOAD (POWER LOWERING)".


In addition to these, the control pressure from a proportional solenoid valve SOL-65 will be output to the motor for minimum capacity (Minimum displacement for G winch) to create the G winch mode.



Published 12-16-15, Control #244-01 8500E-1


6.3 WINCH

6.3.1 WINCH INSTALLATION



8500-1 / 8500E-1 6-24 Published 12-16-15, Control #244-01

6.3.2 WINCH ASSEMBLY



Note

After assembly, fill oil to the specified level. (Approx. 15 L [4.0 gal])

Higher than level gauge red point and within the oil. Extreme pressure gear oil SAE #80W-90 (APOLOIL GEAR HE MULTI-SPECIAL).

6.3.3 REDUCTION UNIT ASSEMBLY


- 1. On mating surface, apply LOCTITE #515 on inner face of sleeve and both of outer periphery surfaces of the press fit in assembling.
- 2. Apply 1 coat painting before winch drum is installed.


But except machining face.

As for paint and film thickness, follow KSC00H50Z003.

After assembling is completed, press the 1st sun gear into the reduction unit by tapping it

Punch to prevent coming off after insertion. $(3 \times 2 \text{ locations})$






Punch to prevent

coming off after insertion.

 $(3 \times 2 \text{ locations})$

Detail item 26

lightly and confirm that it turns easily.



- 1. Spider
- 2. Gear ring
- 3. Retainer
- 4. Sun gear
- 5. Support housing
- 6. Sun gear
- 7. Support
- 8. Ring gear
- 9. Spacer
- 10. Collar
- 11. Bearing

- 12. Oil seal
- 13. Sleeve
- 14. Sleeve
- 15. Bearing
- 16. Spacer
- 17. Pin
- 18. Thrust washer
- 19. Bearing
- 20. Pinion
- 21. Spring pin
- 22. Bolt

- 23. Snap ring
- 24. Snap ring
- 25. Bearing
- 26. Spring pin
- 27. Thrust washer
- 28. Bearing
- 29. Pinion
- 30. Pin
- 31. Snap ring
- 32. Shim
- 33. Pin

6.3.4 ADJUSTMENT OF DRUM LOCK

MARNING


Do not adjust the drum locks until the boom and hook block have been lowered to the ground. Failure to observe this precaution may result in a serious injury or loss of life.

- Pull the drum lock knob in the lock position and check to see that the pawl is engaged in the bottom of the drum ratchet.
 - If the pawl is not engaged in the bottom of the ratchet, adjust the spring length to allow the pawl to be engaged.
- 2. With the release position, adjust the respective dimension as shown in the figure to the right.
- 3. Push the drum lock knob in the release position and check to see that the pawl is clear of the ratchet by at least 20 mm (13/16 in.).
- Operate the knob to the lock position, and to the release position and confirm that the pawl moves smoothly.



Place a signal person to prevent accident from rotating drum.

Failure to observe this precaution may result in a serious injury.






Published 12-16-15, Control #244-01 8500E-1

6.4 BRAKE PEDAL

6.4.1 ASSEMBLY DRAWING



8500-1 / 8500E-1 6-30 Published 12-16-15, Control #244-01

1.	Bracket	20.	Spacer	39.	Pedal
2.	Lever assembly	21.	Bolt	40.	Brake valve
3.	Link	22.	Spacer	41.	Sems bolt
4.	Pedal	23.	Shim (0.4)	42.	Capscrew
5.	Pawl	24.	Shim (0.6)	43.	Lock washer
6.	Link	25.	Shim (0.9)	44.	Connector
7.	Link	26.	Cotter pin	45.	Connector
8.	Link	27.	Cotter pin	46.	Plug
9.	Bracket	28.	Cotter pin	47.	Capscrew
10.	Bracket	29.	Bolt	48.	90 degrees Elbo
11.	Sems bolt	30.	Bolt	49.	90 degrees Elbo
12.	Pin	31.	Sems bolt	50.	Cover assembly
13.	Pin	32.	Nut	51.	Eye bolt
14.	Pin	33.	Nut	52.	Spring
15.	Pin	34.	Washer	53.	Pressure switch
16.	Bearing	35.	Lock washer	54.	Rubber
17.	Pin	36.	Plate	55.	Rubber
18.	Bolt	37.	Washer	56.	Bracket

TIGHTENING TORQUE TABLE

19. Spacer

Name	Size	Tightening Torque
29. Bolt	M12 × 40	37.3 to 45.1 N·m (27.5 to 33.2 ft·lbs)
42. Capscrew	M10 × 70	30.4 to 38.2 N·m (22.4 to 28.2 ft·lbs)

38. Washer

- When installing item 16. Bearing, fill in enough amount of grease.
- Apply MOLYKOTE on each rotating area.

6.4.2 ADJUSTING THE BRAKE PEDAL

Adjustment

- 1. Adjust the eye bolt until the dimension S is 53 mm (2-3/32 in.).
- 2. Depress the brake pedal until the valve spool reaches the stroke end.

(Dimension S = 37.5 mm [1-8/16 in.])

3. Bring the (47) capscrew into contact with the (2) lever assembly in the status described in the 2 above, and loosen 3/4 turn (protrude upward) to adjust the dimension S until it is 38 mm (1-8/16 in.) to 38.3 mm (1-8/16 in.). Then, tighten the nut.

4. Raise the (2) lever assembly up, and return the valve spool to the neutral position.

(Dimension S = 53 mm [2-3/32 in.])


Bring the (30) bolt into contact with the (2) lever assembly, and loosen 3/4 turn (protrude left).

Then, tighten the nut.

(Dimension S =

52.3 to 52.5 mm [2-3/32 to 2-1/16 in.])

- 5. Adjust the (52) spring until the dimension L is 70 mm (2-6/8 in.) in the status described in the 4 above.
- 6. Ensure that the effective stroke of the (40) valve from the time when the pedal is depressed to the time it is released is 15 mm (19/32 in.).



6.4.3 BLEEDING AIR FROM BRAKE CIRCUIT

If air remains in the piping from the brake valve to the cylinder built in the winch, the brake response becomes poor.

If the brake valve and piping are removed, bleed air by the following sequences shown below.


MARNING

When bleed the air from the brake circuit, be sure to lower the hook onto the ground, and select the "free fall" mode.

Then, ensure that the drum does not rotate even when you release your foot from the brake pedal. Failure to observe this precaution may result in a serious injury or loss of life.

- Bypass the quick coupler of the winch brake section with a hose, while the engine is stopped.
- 2. Start the engine, and set the engine speed to the high idling.
- 3. Fully depress the brake pedal, and press the brake select switch to enter the "Free fall mode".
- * The free fall indicator lamp lights up.
- Release your foot from the brake pedal, and wait for approx. 1 minute.
 At this time, air bleed.
- 5. Return to the "Neutral brake mode", and stop the engine.

After the engine is stopped, wait until the control pressure is released (approx. 1 minute), and then, remove the bypass hose.





7. BOOM HOIST SYSTEM

7.1	APPARATUS AND COMPONENTS LOCATION	7-2
7.2	CONSTRUCTION AND FUNCTION	7-4
7.2.1	HYDRAULIC SCHEMATIC	7-4
7.2.2	RAISING BOOM	7-5
7.2.3	NEUTRAL (HOLDING BOOM)	7-6
7.2.4	LOWERING BOOM	7-7
7.3	BOOM HOIST WINCH	7-9
7.3.1	BOOM HOIST WINCH INSTALLATION	7-9
7.3.2	REDUCTION UNIT ASSEMBLY	7-10
7.3.3	BOOM DRUM LOCK ASSEMBLY	7-12
7.3.4	ADJUSTMENT OF BOOM DRUM LOCK	7-13




7. BOOM HOIST SYSTEM

The boom hoist system consists of the main pump (No.1), the main control valve, the boom drum motor, the reduction unit, the boom drum and the drum lock mechanism.

The pressurized oil for the boom hoist system is supplied by the main pump (No.1) installed on the engine's power divider.


From this pump, the oil flows through the 4 section side control valve to drive the motor of the boom drum.




7.1 APPARATUS AND COMPONENTS LOCATION

Note

Refer to the article "7.2 CONSTRUCTION AND FUNCTION" for circuit diagram and function.






Published 12-16-15, Control #244-01 7-3 8500E-1

7.2 CONSTRUCTION AND FUNCTION

7.2.1 HYDRAULIC SCHEMATIC



8500-1 / 8500E-1 7-4 Published 12-16-15, Control #244-01

7.2.2 RAISING BOOM

Pressurized hydraulic oil from the No.1 pump flows into 4 section side of the main control valve.


The pressurized oil from the pump for control flows into the valve block and remote control valve through the accumulator.

(Function lock lever is in "WORK" position: 2 section valve block SOL-3 is "CHANGING" position)

At this time, turning the control lever to raising side, make the control pressured oil pass through the remote control valve, 8 section valve, 5 section valve and 4 section valve and enter into the [PUB] port of the control valve to move the boom section spool.

At the same time, control pressured oil also enters into the negative brake cylinder through the valve block (4 section hyd. selecting valve) and the motor brake is released.

Main pressured oil flows into the control valve enters into the raising side of the boom drum motor by the boom section spool and the boom is raised.



Published 12-16-15, Control #244-01 7-5 8500E-1

7.2.3 NEUTRAL (HOLDING BOOM)

When the control lever is returned to neutral, control pressure from the remote control valve is shut off and main control valve spool returns to neutral and pressured oil from the No.1 pump passes through the control valve and returns to the tank without load.


The stopped motor tends to rotate toward lowering side by boom weight.

But the return oil flow is shut off by the counterbalance valve and motor does not rotate.

At the same time, pressured oil flows into the boom drum motor brake cylinder returns to the tank through the valve block (4 section hyd. selecting valve) and the motor brake becomes actuated.

(Negative brake)

Therefore the boom is held by the counterbalance valve and motor brake.



8500-1 / 8500E-1 7-6 Published 12-16-15, Control #244-01

7.2.4 LOWERING BOOM

The pressured oil from the No.1 pump flows into the 4 section side main control valve.


The pressurized oil from the pump for control flows into the valve block and remote control valve through the accumulator.

(Function lock lever is in "WORK" position: 2 section valve block SOL-3 is "CHANGING" position)

At this time, turning the control lever to lowering side, to make the pressurized oil for control pass through the remote control valve, 8 section valve, 5 section valve and 4 section valve and enter into the [PDB] port of the control valve to move the boom section spool.

At the same time, pressurized oil for control also enters into the built in motor brake in the boom drum motor and the motor brake is released.

Main pressured oil flows into the control valve enters into the lowering side of the boom drum motor by the control valve and open the return counterbalance valve and the boom is lowered.





8500-1 / 8500E-1 7-8 Published 12-16-15, Control #244-01

7.3 BOOM HOIST WINCH


7.3.1 BOOM HOIST WINCH INSTALLATION

When boom hoist winch is to be installed or removed, perform work observing the following tightening torque and note.

Note


After assembly, fill oil to the specified level. (Approx. 5 L [1.3 gal])

Higher than level gauge red point and within the oil. Extreme pressure gear oil SAE#90 (API-GL4) or SAE#80W-90.



7.3.2 REDUCTION UNIT ASSEMBLY

* Apply LOCTITE #515 on the mating surface as shown



- 1. Cover
- 2. Grease fitting
- 3. Cap
- 4. Sleeve
- 5. Plate
- 6. Oil seal
- 7. Drum
- 8. Bearing
- 9. Bearing
- 10. Cover
- 11. Pin
- 12. Thrust washer
- 13. Pinion
- 14. Needle bearing
- 15. Ring gear
- 16. Spring pin
- 17. Spacer
- 18. Bearing

- 19. Thrust washer
- 20. Needle bearing
- 21. Pinion
- 22. Hex. set screw
- 23. Pin
- 24. Sleeve bearing
- 25. Bearing
- 26. Snap ring
- 27. Hex. set screw
- 28. Hex. set screw
- 29. Hex. set screw
- 30. Snap ring
- 31. Bearing
- 32. Plate
- 33. Hex. set screw
- 34. Sun gear
- 35. Carrier
- 36. Snap ring


- 37. Sun gear
- 38. Ring gear
- 39. Carrier
- 40. Spacer
- 41. Plug
- 42. O-ring
- 43. Snap ring
- 44. Collar
- 45. Pin
- 46. Oil seal
- 47. Sleeve
- 48. Plate
- 49. Retainer
- 50. Plate
- 51. Plate
- 52. Stud bolt

TIGHTENING TORQUE TABLE

Name	Size	Tightening Torque : N·m (ft·lbs)
22. Hex. set screw	M16 × 90	222 to 272 (164 to 201)
27. Hex. set screw	M16 × 35	222 to 272 (164 to 201)
28. Hex. set screw	M20 × 70	436 to 534 (322 to 394)
29. Hex. set screw	M12 × 85	92 to 112 (68 to 83)
33. Hex. set screw	M12 × 25	92 to 112 (68 to 83)
41. Plug		70.6 to 86.4 (52 to 64)

7.3.3 BOOM DRUM LOCK ASSEMBLY

When the assembly is complete, fill grease until it is squeezed out from the clearances of the pawl.




7.3.4 ADJUSTMENT OF BOOM DRUM LOCK

MARNING

Do not adjust the drum locks until the boom and hook block have been lowered to the ground. Failure to observe this precaution may result in a serious injury or loss of life.

- Pull the drum lock knob in the lock position and check to see that the pawl is engaged in the bottom of the drum ratchet.
 If the pawl is not engaged in the bottom of the ratchet, adjust the spring length to allow the pawl to be engaged.
- 2. With the release position of drum lock, adjust the respective dimension as shown in the figure to the below.



- 3. Push the drum lock knob in the release position and check to see that the pawl is clear of the ratchet by at least 26 mm (1 in.).
- Operate the knob to the lock position, and to the release position and confirm that the pawl moves smoothly.

MARNING

Place a signal person to prevent accident from rotating drum.

Failure to observe this precaution may result in a serious injury.



8. SWING SYSTEM

8.1	APPARATUS AND COMPONENTS LOCATION	8-1
8.2	CONSTRUCTION AND FUNCTION	8-3
8.2.1	HYDRAULIC SCHEMATIC	8-3
8.2.2	SWING (NEUTRAL FREE)	8-5
8.2.3	STOPPING (NEUTRAL FREE)	8-6
8.2.4	SWING (NEUTRAL FREE/BRAKE MODE SELECT)	8-7
8.2.5	STOPPING (NEUTRAL FREE/BRAKE MODE SELECT)	8-9
8.3	CONSTRUCTION OF THE SWING SYSTEM	8-11
8.3.1	SWING REDUCTION UNIT	
8.3.2	REDUCTION UNIT ASSEMBLY	
8.3.3	SWING BEARING	8-13
8.3.4	SWING LOCK	8-14




SWING SYSTEM 8.

8.1 APPARATUS AND COMPONENTS LOCATION

The swing system consists of the swing pump (No.3), the swing motor (built in swing brake), the swing control valve, the reduction unit, the swing bearing ring, the swivel joint, the swing gear and the swing lock.

To swing the upper machinery, pressurized oil from the swing pump (No.3) mounted on the power divider is sent to the swing motor by way of the control valve which is directly mounted on the swing motor.




This page is blank for editing convenience.


8.2 CONSTRUCTION AND FUNCTION

8.2.1 HYDRAULIC SCHEMATIC

1. Swing neutral free circuit



2. Swing neutral free/brake, swing angle limit (Option)



8500-1 / 8500E-1 8-4 Published 12-16-15, Control #244-01

8.2.2 SWING (NEUTRAL FREE)

The working principle of right swing, and left swing are identical.

The right swing is explained here.

[The swing brake is released ("SPB" SOL-5 is actuated).]


The pressurized oil from the swing pump (No.3) is led to the swing control valve.

On the other hand, the control pressurized oil from the control pump flows through the accumulator, and into the valve block, swing remote control valve.

[The function lock lever is in the "WORK" position (SOL-3 is actuated).]

When the swing control lever is turned to right swing (toward to the operator), control oil pass through the remote control valve and flows into the (PSb) port of the control valve and move the spool (A).

The main pressurized oil control by the control valve is fed the swing motor to run the swing motor.



Published 12-16-15, Control #244-01 8500E-1

8.2.3 STOPPING (NEUTRAL FREE)

When the swing control lever is returned from the swing position to the neutral position, the control pressure from the remote control valve is shut off, and the control valve spool (A) returns to neutral.


As a result, the main pressurized oil from the swing pump (No.3) returns to the tank with no load.

Although oil supply to the swing motor is cut off, but the return oil circulates within the motor and valve.

Therefore motor continues to rotate with its inertia.

(When the swing brake released position selected.)

To stop the swing motion, turn the swing control lever gently to the opposite direction to generate the brake pressure at the swing motor outlet port by the pump pressure.



8500-1 / 8500E-1 8-6 Published 12-16-15, Control #244-01

8.2.4 SWING (NEUTRAL FREE/BRAKE MODE SELECT)


The working principle of the rightward swing, identical to that of the leftward swing, is shown below.[The swing brake is released ("SPB" SOL-5 is actuated).]The pressurized oil from the swing pump is led to the swing control valve. On the other hand, the control pressurized oil from the control pump flows into the valve block, swing remote control valve, and brake mode select solenoid valve (SOL-48) built in the swing control valve through the accumulator. [The function lock lever is at the "Work" position (SOL-3 is actuated).]

1. Neutral free mode

When the swing mode selector switch on the monitor in the operator's cab is set to the "free" side, the control pressurized oil flows through the solenoid valve (SOL-48) to move the spool (B) of the swing control valve to the full stroke.

In this status, when the swing control lever is swung down to the right swing side (back ward), the control oil flows through the remote control valve, and is led to the (PSb) port of the control valve to move the spool (A).

The main pressurized oil controlled by the control valve is fed to the swing motor to run the motor.




Published 12-16-15, Control #244-01 8500E-1

2. Neutral brake mode

When the swing mode selector switch on the monitor in the operator's cab is set to the "brake" side, the solenoid valve (SOL-48) is actuated to connect the both pilot ports, the swing control valve spool (A) and (B).

In this status, when the swing control lever is swung down to the right swing side (back ward), the control oil flows is led to the (PSb) port of the control valve to move the spools (A) and (B) at the same time.

The main pressurized oil controlled by the control valve is fed to the swing motor to run the motor.



8500-1 / 8500E-1 8-8 Published 12-16-15, Control #244-01

8.2.5 STOPPING (NEUTRAL FREE/BRAKE MODE SELECT)


When the swing control lever is returned from the swing mode to the neutral mode, the control pressure from the remote control valve is lost, and the control valve spool (A) returns to neutral.

Thus, the main pressurized oil returns to the tank with no load.

1. Neutral free mode

Although the pressurized oil flow to the swing motor is shut down, the returned oil circulates in the motor and valves, since the spool (B) has been moved to the full stroke by the pilot pressure.

Thus, the motor continues rotating by inertia. (The swing brake is released.)
To stop the swing motion, carefully swing down the swing control lever to the opposite side.



Published 12-16-15, Control #244-01 8500E-1

2. Neutral brake mode

The brake mode select solenoid valve (SOL-48) is actuated, and the spool (B) returns to neutral.

The brake pressure is generated at the exit port of the swing motor by the oil returned from the swing motor passing the restrict or section of the control valve spool (B).

The swing motor is decelerated by the brake pressure until the motor is stopped smoothly.


(The swing brake is released.)

The main pressurized oil returned from the swing motor is interrupted by the orifice of the spool (B), then the swing stops.

If an unusually high pressure occurs, the overload valve is actuated to protect the circuit from damage.

(At the neutral brake mode, the overload valve relief set is Low side.)


However, remember that the motor will not be stopped completely when external forces are always applied, including the operation on a slope or on windy days.



8500-1 / 8500E-1 8-10 Published 12-16-15, Control #244-01

8.3 CONSTRUCTION OF THE SWING SYSTEM


8.3.1 SWING REDUCTION UNIT



Name	Tightening Torque	Weight
Reduction unit	-	395 kg (875 lbs)
2. Motor	-	64 kg (141 lbs)
3. O-Ring		-
4. Bolt	M16×45 mm / 145 to 177 N·m (107 to 131 ft·lbs)	-
5. Tube	-	-
6. Level gauge	-	-
7. Bolt	M20×140 mm / 500 to 618 N·m (369 to 456 ft·lbs)	-

Published 12-16-15, Control #244-01 8500-1 / 8500E-1

8.3.2 REDUCTION UNIT ASSEMBLY



1. Housing	32. Shim (t=0.2)
2. Housing	33. Shim (t=0.5)
4. Pinion	35. Shim (t=1.2)
7. Sun gear	39. Shim (t=1.6)
8. Pinion	42. Spacer
9. Pinion	43. Thrust button
13. Pin	44. Retainer
16. Bearing	45. Shim (t=0.1)
17. Bearing	46. Shim (t=0.2)
18. Bearing	47. Shim (t=0.3)
19. Bearing	48. Housing
20. Bearing	49. Shaft
21. Oil seal	50. Ring gear
22. Plug	51. Gear
24. Plug	52. Pin
25. Retaining ring	53. Pin
26. Capscrew	54. Plate
27. Capscrew	55. Spring pin
28. Capscrew	56. Shim (t=1.0)
29. Capscrew	57. Shim (t=0.4)
31. Capscrew	

TIGHTENING TORQUE

Name	Size	Tightening torque : N·m (ft·lbs)
22. Plug	PT 1/2	57.9 to 71.6 (42.7 to 52.8)
24. Plug	PT 3/4	88.3 to 108 (65.1 to 79.6)
26. Capscrew [*]	M20×140	500 to 618 (369 to 456)
27. Capscrew*	M20×150	500 to 618 (369 to 456)
28. Capscrew [*]	M12×35	109 to 132 (80.4 to 97.4)
29. Capscrew*	M16×40	255 to 314 (188 to 232)
31. Capscrew [*]	M8×20	31.4 to 39.2 (23.2 to 28.9)

 $^{^{\}star}$ $\,$ Apply LOCTITE #243 to capscrew.

Assembly total weight

8500-1 / 8500E-1 8-12 Published 12-16-15, Control #244-01


8.3.3 SWING BEARING

BOLT TIGHTENING PROCEDURE

- 1. Lower frame side
- (1) Tighten 2 bolts which are positioned 180 degrees apart each other on the lower frame side with 147 N·m (108 ft·lbs) torque.
- (2) Tighten 2 bolts which are positioned 90 degrees apart from the previously tightened bolts with 147 N·m (108 ft·lbs) torque.
- (3) Tighten diagonally positioned bolts with 147 N·m (108 ft·lbs) torque.
- (4) Tighten all bolts with 311 to 381 kN (69,915 to 85,652 lbf) tightening force.(Tightening torque shall be checked with axial force measurement.)
- * Ref : tightening torque 1.75 to 2.13 kN·m (1,290 to 1,571 ft·lbs)
- (5) After tightening to the lower frame, apply enough amount of molybdenum sulfide grease (Shell Alvania EP grease LF) on the gear tooth face.
- 2. Upper frame side
- (1) Tighten 4 bolts on both side of front, both side of rear of the upper frame with 147 N·m (108 ft·lbs) torque.
- (2) Tighten diagonally positioned bolts with 147 N·m (108 ft·lbs) torque in order.
- (3) Tighten all bolts with 255 to 311 kN (57,326 to 69,915 lbf) tightening force.
 (Tightening torque shall be checked with axial force measurement.)
- Ref: tightening torque 1.28 to 1.56 kN·m (944 to 1,150 ft·lbs)


The figure shows the outer race is rotated 180 degrees.

Assembly total weight Approx. 769 kg (1,695 lbs)



Published 12-16-15, Control #244-01 8500E-1

8.3.4 SWING LOCK



8500-1 / 8500E-1 8-14 Published 12-16-15, Control #244-01

9. TRAVEL SYSTEM

9.1	APPARATUS AND COMPONENTS LOCA	ATION9-1
9.2	CONSTRUCTION AND FUNCTION	9-2
9.2.1	HYDRAULIC SCHEMATIC	9-2
9.2.2	TRAVELING (RIGHT SIDE FORWARD)9-3
9.2.3	STOPPING	9-4
9.3	CRAWLER	9-5
	DRIVE ASSEMBLY	
	MOTOR AND REDUCTION UNIT	
9.3.3	ADJUSTMENT OF SHOE	9-9



9. TRAVEL SYSTEM

9.1 APPARATUS AND COMPONENTS LOCATION

The travel system consists of the No.1 pump, the main control valves, the travel motors, the travel reduction units, the upper/lower rollers, the drive tumblers, idlers and shoes.


Pressurized oil from the No.1 pump is controlled by the 2 main control valves.


This pressurized oil flows through the swivel joint and then into the left and right travel motors to run their respective motors.

A spring set/hydraulic release disk brake is installed on each of the two travel motors (built-in type).

As for circuit diagram and function of travel (right forward and stopping), refer to the article "9.2 CONSTRUCTION AND FUNCTION".

LOWER ROLLER-






Published 12-16-15, Control #244-01 9-1 8500E-1

9.2 CONSTRUCTION AND FUNCTION

9.2.1 HYDRAULIC SCHEMATIC



8500-1 / 8500E-1 9-2 Published 12-16-15, Control #244-01

9.2.2 TRAVELING (RIGHT SIDE FORWARD)

Traveling the right and left sides, to the forward and reverse are basically the same operation.

We will use a right side forward operation as the example here.

Pressurized oil from the No.1 pump is directed into the control valve.

The oil from the No.3-1 pump, however, goes through the accumulator and into the travel-circuit's remote control valve, (The function lock lever remains in the "WORK" position [SOL-3: ON position].)


When the right travel control lever is shifted to "FORWARD", the control oil runs through the remote control valve to the control valve's [PRF] port to shift the spool of the travel section.

The pressurized oil directed by the control valve then goes through the swivel joint and run into the travel motor.

At the same time, this oil runs into the pilot of the brake valve and the brake cylinder.

The oil in this cylinder releases the negative brake, and the oil in the brake valve pilot moves the spool, so that the pressurized oil releases the mechanical and hydraulic brake.

The pressurized oil that activated in the travel motor is free to return to the reservoir.



Published 12-16-15, Control #244-01 9-3 8500-1 / 8500E-1

9.2.3 STOPPING

When the right travel control lever is shifted back to neutral from travel position, the flow from the remote control valve is cut and the spool of the control valve moves to neutral position.

At the same time, the pilot pressure on the travel brake valve is discontinued, and the spool in the brake valve also moves to neutral position.


At this time inertia may continue momentarily to rotate the travel motor.

This creates negative pressure on the supply side and high pressure on the return side.

Therefore, the supply side is connected to the reservoir in neutral.

If extreme pressure develops on the return side, an over load relief valve will open to protect the circuit


At the same time, the pressurized oil in the brake cylinder is returned to the reservoir, and the parking brake engages slowly.




8500-1 / 8500E-1 9-4 Published 12-16-15, Control #244-01

9.3 CRAWLER


9.3.1 DRIVE ASSEMBLY






Assembly weight Approx. 510 kg (1,120 lbs)

9.3.2 MOTOR AND REDUCTION UNIT





Assembly weight Approx. 510 kg (1,120 lbs)

1.	Cover	25.	Ring gear	49.	Pivot	73.	Plug
2.	Carrier	26.	Housing	50.	Spring holder	74.	Plug
3.	Carrier pin	27.	Taped roller bearing	51.	Piston assy	75.	O-ring
4.	Bearing	28.	Shim	52.	D-ring	76.	O-ring
5.	Thrust washer	29.	Spring pin	53.	D-ring	77.	O-ring
6.	Planetary gear	30.	Floating seal	54.	Check valve	78.	O-ring
7.	Spring pin	31.	Thrust ring	55.	Retaining ring of C type	79.	Overload relief assy
8.	Spacer	32.	Shim	56.	Retaining ring	80.	Spool
9.	Sun gear	33.	Capscrew	57.	Shifter piston	81.	Plug
10.	Sun gear	34.	Capscrew	58.	Piston seal	82.	Spring holder
11.	Carrier	35.	Capscrew	59.	Ball joint	83.	Spring
12.	Carrier pin	36.	Capscrew	60.	Ball	84.	Connector
13.	Bearing	37.	Capscrew	61.	M6 restrictor	85.	Spool assy
14.	Thrust washer	38.	Casing	62.	Oil seal	86.	Cover
15.	Planetary gear	39.	Rear cover	63.	Spring of check valve	87.	Spring
16.	Spring pin	40.	Cylinder block	64.	Spring of cylinder	88.	Spring holder
17.	Sun gear	41.	Shoe retainer	65.	Spring of brake	89.	Restrictor
18.	Carrier	42.	Friction plate	66.	Bearing	90.	Spring
19.	Carrier pin	43.	Brake piston	67.	Bearing	91.	Plug
20.	Niddle bearing	44.	Separated plate	68.	Hex. socket head bolt	92.	O-rings
21.	Thrust washer	45.	Valve plate	69.	Shim	93.	O-ring
22.	Planetary gear	46.	Shaft	70.	Parallel pin	94.	Socket head cap screw
23.	Coupling	47.	Coupling	71.	Plug		
24.	Holder	48.	Swash plate	72.	Plug		

TIGHTENING TORQUE TABLE

Name	Size	Tightening torque : N·m (ft·lbs)	Remarks
33. Capscrew	M10 × 30	61.74 to 75.46 (45.5 to 55.7)	Apply LOCTITE #243
34. Capscrew	M12 × 30	106.2 to 129.8 (78.3 to 95.7)	Apply LOCTITE #243
35. Capscrew	M16 × 45	264.6 to 323.4 (195 to 239)	Apply LOCTITE #243
36. Capscrew	R (PT) 3/4	88.29 to 107.91 (65.1 to 79.6)	
37. Capscrew	M8 × 35	30.38 to 38.22 (22.4 to 28.2)	Apply LOCTITE #243
68. Hex. socket head bolt	M16 × 45	206.5 to 254.5 (152 to 187)	
71. Plug	NPT 1/16	11.74 to 15.66 (8.7 to 11.6)	Apply LOCTITE #243
72. Plug	NPT 1/16	9.81 to 11.8 (7.2 to 8.7)	
73. Plug	G (PF) 1/8	12.74 to 16.66 (9.4 to 13.3)	
74. Plug	G (PF) 1/4	26.46 to 32.34 (19.5 to 23.9)	
79. Overload relief assy		98.1 to 118 (72.4 to 87)	
81. Plug	G3/8	49 to 58.8 (36.1 to 43.4)	
84. Connector		49 to 58.8 (36.1 to 43.4)	
91. Plug		24.5 to 29.4 (18.1 to 21.7)	
94. Socket head cap screw	M12 × 35	88.29 to 107.91 (65.1 to 79.6)	

9.3.3 ADJUSTMENT OF SHOE

If the crawler tension is high, the shoes wear quickly and connection between two shoes could break.

On the other hand, if the tension too loose, the shoes may run off the drive tumbler or idler wheel during traveling.

To prevent these, it is necessary to adjust shoe tension.


Travel forward about 7 m (23 ft.) with the drive tumbler at rear and then adjust the shim to make upper shoe slackening to be 10 to 20 mm (3/8 to 7/8 in.).


To adjust shoe tension, proceed as follows:

- Travel the machine forward about one crawler length so that the slack in the crawler shoes appear on the top of the crawler.
- 2. Remove all the shims from shim pack (a).
- Position the hydraulic jack between the bracket and block of the side frame.
 Operate the jack to push the idler wheel and remove the slack in the shoes.
- 4. Insert the shims removed from pack (a) in step(2) into the vacant room of pack (b).Insert the remaining shims into pack (a).
- After the shims are installed, install the mud cover (c) on the shim installation area (a).
 Install the cover (d) to the elongated hole area of both crawler frames.



Equalize the tension in right and left crawler tracks.







10. ELECTRIC SYSTEM

10.1 E	ELECTRICAL	10-3
10.1.1	ELECTRICAL WIRING SCHEMATIC	10-3
10.1.2	CONNECTOR LAYOUT	10-24
10.1.3	LOCATION AND USE OF FUSE	10-162
10.1.4	WIPER CONTROL RELAY	
10.1.5	PRESSURE SWITCH (FOR TRAVEL MOTION DETECT)	10-168
10.1.6	PRESSURE SWITCH (FOOT BRAKE)	10-169
10.1.7	PRESSURE SENSOR	
10.1.8	INCLINATION SENSOR	
10.1.9	BUZZER UNIT	
10.1.10	RELAY BOX	10-175
10.1.11	RELAY BOX	
	LOAD DETECTOR (CRANE)	
	ANGLE SENSOR	
	HOW TO CHECK THE FAILURE CONTENTS	
	WARNING DISPLAY CONDITION	
	ENGINE ECU	
10.2 L	OAD SAFETY DEVICE	
10.2.1	CONFIGURATION OF SCREENS	
10.2.2	SYSTEM DAIGRAM	
10.2.3	MONITOR DISPLAY	
10.2.4	DETAIL OF ML CONTROLLER	
10.2.5	SHIFTING TO MAINTENANCE SCREEN	
10.2.6	INPUT / OUTPUT SIGNAL	
10.2.7	ML FUNCTION SETTING	
10.2.8	DATA COPY, FORMAT	
10.2.9	LANGUAGE, UNIT SETTING	
10.2.10	ML ADJUSTMENT (NORMAL)	
10.2.11		
	OPERATION PROGRESS	
	VERSION INFORMATION	
	FAILURE HISTORY	
	ADJUSTMENT DATA	
	DOWNLOAD ML PROGRAM	
	DOWNLOAD OF MONITOR PROGRAM	
10.3 N	MAIN CONTROLLER	
10.3.1	ARRANGEMENT OF MAIN CONTROLLER	
10.3.2	COMPOSITION OF SYSTEM	
10.3.3	FUNCTION OF MAIN CONTROLLER	
10.3.4	MAIN CONTROLLER 1, 2 (HARDWARE)	10-333

10.3.5	SPECIFICATIONS OF MAIN CONTROLLER INPUT/OUTPUT.	10-334
10.3.6	ARRANGEMENT OF MAIN CONTROLLER CONNECTOR PIN	10-348
10.3.7	ADJUSTMENT OF MAIN CONTROLLER	10-364
10.3.8	CONTROLLER MALFUNCTION EMERGENCY MEASURES	10-369



8500-1 / 8500E-1 Published 12-16-15, Control #244-01

10. ELECTRIC SYSTEM



Ensure to turn the key switch OFF to avoid any adverse effect to the electric devices when the connectors are in the process of connecting or disconnecting.

Failure to observe this precaution may lead to damage parts.

A CAUTION

When disconnect the connector, hold it with both hands and draw it straight, while pressing down the catch.

DO NOT pull on the cable.

Otherwise, lead to the breaking of a wire.

NEVER twist or pry the connector.

Otherwise, its internal female terminal will be expanded, lead to faulty connection.

▲ CAUTION

When connection in the connector, fully insert it until the catch is engaged (clicks into position).

A CAUTION

Otherwise, faulty connection can occur later. When performing a continuity test or voltage measurement on the connector, follow the procedure below.

· Square connector

For easy measurement, place the measurement probes of the multi tester onto the pins of male side connector from the electric wire inlet side. NEVER insert the probe of the multi tester into the socket of the female side connector. Otherwise, faulty connection can occur later.


Round waterproof connector

The male side connector has waterproof construction, and the measurement probe of the multi tester cannot touch its pins from the electric wire inlet side.

Therefore, place the measurement probes onto the terminals side connector.


NEVER forcibly insert the measurement probe.

Otherwise, faulty connection can occur later. Short-circuiting across terminals inside a connector can damage electronic components. Be absolutely careful to prevent short-circuit.




10.1 ELECTRICAL

10.1.1 ELECTRICAL WIRING SCHEMATIC




(1/21)

Published 12-16-15, Control #244-01 8500E-1




(2/21)

8500-1 / 8500E-1 10-4 Published 12-16-15, Control #244-01




8500-1 / 8500E-1




(4/21)

8500-1 / 8500E-1 10-6 Published 12-16-15, Control #244-01




(5/21)

Published 12-16-15, Control #244-01 8500E-1




(6/21)

8500-1 / 8500E-1 10-8 Published 12-16-15, Control #244-01




(7/21)


Published 12-16-15, Control #244-01 10-9 8500-1 / 8500E-1




8500-1 / 8500E-1 10-10 Published 12-16-15, Control #244-01




(9/21)




8500-1 / 8500E-1 10-12 Published 12-16-15, Control #244-01




(11/21)



8500-1 / 8500E-1 10-14 Published 12-16-15, Control #244-01



(13/21)



(14/21)

8500-1 / 8500E-1 10-16 Published 12-16-15, Control #244-01

				RELAY	
RL-NO.		TERMINAL SHEET No.	TYPE	USE	Manitowoc PART NO.
RL-B (sub)	1	1	N. O.	BATTERY RELAY(sub)	
RL-B	1	1	N. O.	BATTERY RELAY	
RL-Ho	10	10	N. O.	HORN RELAY	
RL-C	1		N. O.	CUT OUT RELAY	
RL-H	2	2	N. O.	HEATER RELAY	
RL-ST	1	1	N. O.	STARTER RELAY	
RL-01	1	1	N. C.	ALTERNATOR DETECT RELAY	
RL-02	1	1	N. C.	SAFETY RELAY	
RL-03	8	8	N. O.	OIL COOLER MOTOR	
RL-04	1	1	N. C.	AIS RELAY	
RL-05	1	1	N. C.	STATER LOCK RELAY	
RL-06	1	1	N. C.	ATTESTATION RELEASE RELAY	
RL-07	1	1	N. O. N. C.	E/G STOP RELAY	
RL-08	10	10	N. O.	REMOTE HORN RELAY	
RL-09	1	1	N. C.	SWING PARKING CONTROL RELAY	
RL-10	1			SWING PARKING 1 RELAY	
RL-10-1		1	N. O.	SWING PARKING 1	
RL-10-2		1	N. O.	SWING PARKING 2	
RL-12	1	1	N. C.	SWING PARKING 3 RELAY	
RL-13	6	1	N. C.	PILOT PRESSURE CUT	

RELAY					
RL-NO.	COIL SHEET No.	TERMINAL SHEET No.		U S E	Manitowoc PART NO.
RL-14	6	6	N. C.	SWING HIGH LOW SPEED SELECT	
RL-15	6	6	N. O.	SWING NEUTRAL BRAKE SELECT	
RL-16	1	11	N. O.	TRAVEL ALARM RELAY	
RL-17	11	11	N. O.	TRAVEL VOICE ALARM RELAY	
RL-18	12	1	N. C.	HYD SELECT RELAY	
RL-19	12	12	N. O.	HYD SELECT RELAY	
RL-20	6	6	N. O.	HYD. OIL HEAT	
RL-21	1	1	N. O.	E/G RESTART RELAY	
RL-22	5			MC1 BYPASS RELAY	
RL-22-1		5	N. O. N. C.	MC1 BYPASS RELAY	
RL-22-2		5	N. O. N. C.	MC1 BYPASS RELAY	
RL-22-3		5	N. O. N. C.	MC1 BYPASS RELAY	
RL-22-4		5	N. O. N. C.	MC1 BYPASS RELAY	
RL-22-5		5	N. O. N. C.	MC1 BYPASS RELAY	
RL-22-6		5	N. O. N. C.	MC1 BYPASS RELAY	
RL-22-7		5	N. O. N. C.	MC1 BYPASS RELAY	
RL-22-8		5	N. O. N. C.	MC1 BYPASS RELAY	
RL-22-9		5	N. O. N. C.	MC1 BYPASS RELAY	
RL-22-10		5	N. O. N. C.	MC1 BYPASS RELAY	
RL-23	1	1	N. C.	KEY RETURN RELAY	

RELAY				RELAY	
RL=N0.		TERMINAL SHEET No.		USE	Manitowoc PART NO.
RL-24	6	3	N. C.	LMI BYPASS RESET	
RL-25	3			LMI BYPASS KEEP 1	
RL-25-1		3	N. O.	LMI BYPASS KEEP 1	
RL-25-2		3	N. O.	LMI BYPASS KEEP 2	
RL-27	6	11	N. O.	SWING BUZZER	
RL-28	3	5	N. C.	SPEED LIMIT RELEASE	
RL-29	3	5	N. O.	SPEED LIMIT	
RL-30	3	3	N. O.	OVERLOAD ALARM LAMP (GREEN)	
RL-31	3	3	N. O.	OVERLOAD ALARM LAMP (YELLOW)	
RL-32	3	3	N. O.	OVERLOAD ALARM LAMP(RED)	
RL-36	6	3	N. O.	LMI ADJUSTMENT MODE SELECT	
RL-37	6	6	N. O.	DPF RECYCLE RELAY	
RL-38	6	6	N. O.	SWING FLASHER (L. H.) RELAY	
RL-39	6	6	N. O.	SWING FLASHER (R. H.) RELAY	
RL-40	6	6	N. O.	Qmax CUT RELAY	
RL-41	6	6	N. O.	CLM RELAY	
RL-42	6	6	N. O.	ESM RELAY	
RL-43	6	6	N. O.	CLA RELAY	
RL-44	6	6	N. O.	ESA RELAY	
RL-45	6	6	N. O.	CLT RELAY	

	RELAY						
RL-NO.	COIL SHEET No.	TERMINAL SHEET No.	TYPE	U S E	Manitowoc PART NO.		
RL-46	6	6	N. O.	EST RELAY			
RL-47	6	6	N. O.	Fr. DRUM FREE SELECT RELAY			
RL-48	6	6	N. O.	Re. DRUM FREE SELECT RELAY			
RL-49	6	6	N. O.	3rd. DRUM FREE SELECT RELAY			
RL-50	4			JIB OVER HOIST RELAY			
RL-50-1		3	N. O.	JIB OVER HOIST RELAY			
RL-50-2		3	N. O.	JIB OVER HOIST RELAY			
RL-51	4	3	N. O.	NO. 2 LIMIT RELAY			
RL-53	4	3	N. O.	BOOM OVER HOIST RELAY			
RL-54	3	4	N. O.	SELF REMOVAL SELECT			
RL-55	3	4	N. O.	ASSEMBLY DISASSEMBLY SELECT			
RL-56	3	4	N. O.	MAST MODEL SELF REMOVAL SELECT			
RL-57	3			JIB MODEL SELECT			
RL-57-1		4	N. O.	JIB MODE			
RL-57-2		4	N. C.	JIB MODE			
RL-58	3			SELF REMOVAL EXT. STOP			
RL-58-1		12	N. O.	SELF REMOVAL EXT. STOP			
RL-58-2		12	N. O.	SELF REMOVAL EXT. STOP			
RL-60	3	7	N. O.	RAISING/LOWERING RAISE STOP			
RL-61	3	7	N. O.	RAISING/LOWERING LOWER STOP			

				RELAY	
RL-NO.		TERMINAL SHEET No.	TYPE	U S E	Manitowoc PART NO.
RL-62	3	7	N. O.	Fr. DRUM HOIST STOP	
RL-63	3	7	N. O.	Fr. DRUM LOWER STOP	
RL-64	3	7	N. O.	Re. DRUM HOIST STOP	
RL-65	3	7	N. O.	Re. DRUM LOWER STOP	
RL-66	3	7	N. O.	3rd. DRUM HOIST STOP	
RL-67	3	7	N. O.	3rd. DRUM LOWER STOP	
RL-68	7			MC2 BYPASS RELAY	
RL-68-1		7	N. O. N. C.	MC2 BYPASS RELAY	
RL-68-2		7	N. O. N. C.	MC2 BYPASS RELAY	
RL-68-3		7	N. O. N. C.	MC2 BYPASS RELAY	
RL-68-4		7	N. O. N. C.	MC2 BYPASS RELAY	
RL-68-5		7	N. O. N. C.	MC2 BYPASS RELAY	
RL-68-6		7	N. O. N. C.	MC2 BYPASS RELAY	
RL-68-7		7	N. O. N. C.	MC2 BYPASS RELAY	
RL-68-8		7	N. O. N. C.	MC2 BYPASS RELAY	
RL-68-9		7	N. O. N. C.	MC2 BYPASS RELAY	
RL-68-10		7	N. O. N. C.	MC2 BYPASS RELAY	
RL-68-11		7	N. O. N. C.	MC2 BYPASS RELAY	
RL-68-12		7	N. C. N. C.	MC2 BYPASS RELAY	
RL-68-13		7	N. C. N. C.	MC2 BYPASS RELAY	

	RELAY						
-					RELAY		
	RL-NO.	COIL SHEET No.	TERMINAL SHEET No.	TYPE	USE	Manitowoc PART NO.	
	RL-68-14		7	N. O. N. C.	MC2 BYPASS RELAY		
	RL-68-15		7	N. O. N. C.	MC2 BYPASS RELAY		
	RL-68-16		7	N. O. N. C.	MC2 BYPASS RELAY		
	RL-69	8	8	N. O.	Fr. DRUM INDEPENDENCE JUNCTION SELECT RELAY		
	RL-70	8	8	N. O.	Re. DRUM INDEPENDENCE JUNCTION SELECT RELAY		
	RL-71	8	8	N. O.	DPR LOAD MULTIPLIED RELAY		
	RL-79	1	1	N. O.	INJECTOR COOLING FAN MOTOR RELAY		
	RL-80	9	9	N. O.	FAN MOTOR RELAY		
	RL-81	1	9	N. C.	A/C CUT RELAY		
	RL-82	6	11	N. O.	TW LATCH CYLINDER		
	RL-83	9	9	N. O.	AIS A/C CUT RELAY		
	RL-84	6	4	N. C.	SOL CUT RELAY 1		
	RL-85	6	1	N. C.	SOL CUT RELAY 2		
	RL-86	6	6	N. C.	SOL CUT RELAY 3		
	RL-87	3	3	N. O.	OVER LOAD ALARM BUZZER		
	RL-90	14	14	N. C.	OBSTRUCTION LIGHT RELAY		
	RL-91	6	1	N. O.	SUB BATTERY RELAY 2		
	RL-93	1	1	N. C.	ACC CUT RELAY 1		
	RL-94	6	1	N. O.	ACC CUT RELAY 2		

8500-1 / 8500E-1 10-18 Published 12-16-15, Control #244-01

				RELAY	
RL-NO.	COIL SHEET No.	TERMINAL SHEET No.	TYPE	USE	Manitowoc PART NO
RL-95	14	14	N. O.	FOUNDATION CIVIL ENGINEERING MODE RELAY	
RL-96	14	14	N. O.	Fr. DRUM LOCK RELAY	
RL-97	14	14	N. O.	Re. DRUM LOCK RELAY	
RL-98	14	14	N. O.	3rd. DRUM LOCK RELAY	
RL-99	14	14	N. O.	BOOM DRUM LOCK RELAY	
RL-100	14	14	N. O.	CYLINDER CONTRACTION CUT RELAY	
RL-106	12	12	N. C.	LEFT CYLINDER RET. CUT RELAY	
RL-107	12	12	N. C.	RIGHT CYLINDER EXT. CUT RELAY	
RL-108	12	12	N. C.	LEFT CYLINDER EXT. CUT RELAY	
RL-109	12	12	N. C.	RIGHT CYLINDER RET. CUT RELAY	
RL-110	14	14	N. O.	WIND VELOCITY ALARM LAMP RELAY	
RL-111	13	14	N. O.	FREE ALARM POWER RELAY	
RL-112	14	14	N. C.	Fr. DRUM LAMP SELECT RELAY	
RL-113	14	14	N. C.	Re. DRUM LAMP SELECT RELAY	
RL-114	14	14	N. C.	3rd. DRUM LAMP SELECT RELAY	
RL-115	6	2	N. O.	ENGINE RELAY	
RL-116	6	2	N. O.	OPERATION RECOVERY RELAY	
RL-120	6	1	N. C.	GITC RETURN RELAY	
RL-121	1	1	N. O.	WEBASTO HEATER RELAY	

		FUSE		
F-NO.	RATED		SHEET NO.	Manitowoc PART NO.
F-01	20	ELECTRIC POWER SOURCE	1	
F-02	5	POWER SUPPLY-VOLTAGE WATCH	1	
F-03	5	ITC POWER SOURCE	1	
F-04	5	BACK-UP	1	
F-05	10	BYPASS SWITCH	3	
F-06	5	RELEASE SWITCH	3	
F-07	10	LMI CONTROL POWER	4	
F-08	10	LMI OUTPUT POWER	4	
F-09	10	MC1 CONTROL POWER	5	
F-10	20	MC1 OUTPUT POWER	5	
F-11	10	AUTO STOP	3	
F-12	10	ENGINE CONDITION	1	
F-13	5	ONE WAY/RADIO	10	
F-14	20	WIPER	9	
F-15	10	FUNCTION LOCK	1	
F-16	10	REMOTE CONTROL	12	
F-17	5	MONITOR	11	
F-18	15	A/C	9	
F-19	10	A/C 2	9	
F-20	10	FAN MOTOR	9	

		FUSE		
F-N0.	RATED	USE	SHEET NO.	Manitowoc PART NO.
F-21	5	GENERATION OF ELECTRICITY SENSOR	1	
F-22	20	DCU POWER SOURCE	2	
F-23	5	ECU POWER SOURCE	1	
F-24	15	ECU (+BF)	2	
F-25	20	ECU (+B)	2	
F-26	15	ECU	2	
F-27	20	OIL COOLER FAN MOTOR 1	8	
F-28	20	OIL COOLER FAN MOTOR 2	8	
F-29	10	SWING FLASHER/VOICE ALARM	11	
F-30	5	STARTER	1	
F-31	10	MC2 CONTROL POWER	7	
F-32	20	MC2 OUTPUT POWER	7	
F-33	5	MC2 EARTH OUTPUT POWER	8	
F-34	5	OVERHOIST L/S	4	
F-35	10	FUEL PUMP/CIGARETTE LIGHTER	9	
F-36	10	MC1 EARTH OUTPUT POWER 1	6	
F-37	10	MC1 EARTH OUTPUT POWER 2	6	
F-38	5	NEUTRAL FREE	6	
F-39	10	LIGHT	11	
F-40	10	SPARE	11	

(17/21)

		FUSE		
F-N0.	RATED [A]	U S E	SHEET NO.	Manitowoc PART NO.
F-41	20	USER	1	
F-42	1	CAMERA PAWER	11	
F-43	3	WIND VELOCITY ALARM LAMP	14	

	SOLENOID VAL	VΕ	
SOL-NO.	USE	SHEET NO.	Manitowoc PART NO.
SOL-3	FUNCTION LOCK	1	
SOL-4	TRAVEL SPEED SELECT	1	
SOL-5	SWING PARKING ON FOR RELEASE OFF FOR PARKING	1	
S0L-10	Fr. DRUM C/V	8	
SOL-11	Re. DRUM C/V	8	
SOL-12	3rd. DRUM C/V	8	
SOL-15	Fr. DRUM MOTOR BOOST	8	
SOL-16	Re. DRUM MOTOR BOOST	8	
SOL-17	3rd.DRUM MOTOR BOOST	8	
SOL-18	3rd.RAISE STOP	3	
SOL-19	Fr. DRUM CLUTCH ESM	6	
SOL-20	Re. DRUM CLUTCH ESA	6	
S0L-21	3rd. DRUM CLUTCH EST	6	
SOL-22	Fr. DRUM CLUTCH CLM	6	
S0L-23	Re. DRUM CLUTCH CLA	6	
S0L-24	3rd. DRUM CLUTCH CLT	6	
SOL-26	GANTRY UP	12	
SOL-27	GANTRY DOWN	12	
SOL-35	BOOM RAISE STOP	3	

	SOLENOID VALV	E	
SOL-NO.	USE	SHEET NO.	Manitowoc PART NO.
SOL-36	BOOM LOWER STOP	3	
SOL-37	Fr. DRUM HOIST STOP	3	
SOL-38	Re. DRUM HOIST STOP	3	
S0L-42	SWING HIGH LOW SPEED SELECT	6	
S0L-44	TRANSLIFTER SELECT	12	
SOL-45	HYD. SELECT (FOOT PIN/REEVING)	1	
S0L-47	HYD. OIL HEAT	6	
S0L-48	SWING NEUTRAL SELECT	6	
SOL-49	SWING NEUTRAL SELECT	6	
SOL-69	JIB RAISING/LOWERING DRUM LOCK (ON FOR UNLOCK)	1	
S0L-77	RAISING/LOWERING PEDAL	1	
SOL-80	VERTICAL CYLINDER EXT. (Fr. R. H.)	12	
SOL-81	VERTICAL CYLINDER EXT. (Re. R. H.)	12	
SOL-82	CRAWLER PIN CYLINDER (Re. EXT)	12	
SOL-83	CRAWLER PIN CYLINDER (Fr. EXT)	12	
SOL-84	VERTICAL CYLINDER EXT. (Re. L. H.)	12	
SOL-85	VERTICAL CYLINDER EXT. (Fr. L. H.)	12	
SOL-86	VERTICAL CYLINDER RET. (Fr. R. H.)	12	
SOL-87	VERTICAL CYLINDER RET. (Re. R. H.)	12	
SOL-88	CRAWLER PIN CYLINDER (Re. RET)	12	

	SOLENOID VALV	E	
SOL-NO.	USE	SHEET NO.	Manitowoc PART NO.
SOL-89	CRAWLER PIN CYLINDER (Fr. RET)	12	
SOL-90	VERTICAL CYLINDER RET. (Re. L. H.)	12	
SOL-91	VERTICAL CYLINDER RET. (Fr. L. H.)	12	
SOL-95	LEFT CYLINDER RET.	12	
SOL-96	LEFT CYLINDER EXT.	12	
SOL-97	RIGHT CYLINDER RET.	12	
SOL-98	RIGHT CYLINDER EXT.	12	
SOL-101	Fr. DRUM INDEPENDENCE JUNCTION SELECT	8	
SOL-102	Re. DRUM INDEPENDENCE JUNCTION SELECT	8	
SOL-104	Qmax CUT	6	
SOL-105	CRAWLER EXT. RET. (LEFT/RIGHT)	1	
SOL-106	CRAWLER EXT. RET. (LEFT/RIGHT)	1	
SOL-111	DPF RECYCLE	8	
SOL-120	CYLINDER CONTRACTION	14	
SOL-121	CYLINDER EXPANSION	14	
SOL-130	a1 VALVE	14	
SOL-131	b1 VALVE	14	
SOL-132	a2 VALVE	14	
SOL-133	b2 VALVE	14	
SOL-134	a3 VALVE	14	

(18/21)

8500-1 / 8500E-1 10-20 Published 12-16-15, Control #244-01

SOLENOID VALVE			
SOL-NO.	USE	SHEET NO.	Manitowoc PART NO.
SOL-135	b3 VALVE	14	
SOL-136	a4 VALVE	14	
SOL-137	b4 VALVE	14	
SOL-138	a5 VALVE	14	
SOL-139	b5 VALVE	14	
SOL-140	a6 VALVE	14	
SOL-141	b6 VALVE	14	
SOL-142	a7 VALVE	14	
SOL-143	b7 VALVE	14	

SOLENOID VALVE					
PSOL-NO.	USE	SHEET NO.	Manitowoc PART NO.		
PSOL-1	MAIN PUMP 1	5			
PSOL-2	BOOM PUMP	5			
PSOL-6	MAIN PUMP 2	5			
PSOL-40	Fr. DRUM TURN GRIP	6			
PS0L-41	Re. DRUM TURN GRIP	6			
PSOL-43	3rd. DRUM TURN GRIP	6			
PSOL-46	BOOM DRUM TURN GRIP	6			
PSOL-50	MAIN PUMP POWER REDUCTION	5			
PSOL-51	SWING REACTION	5			
PSOL-52	BOOM RAISE CONTROL	7			
PSOL-53	BOOM LOWER CONTROL	7			
PSOL-54	Fr. DRUM HOIST CONTROL	7			
PSOL-55	Fr. DRUM LOWER CONTROL	7			
PSOL-56	Re. DRUM HOIST CONTROL	7			
PSOL-57	Re. DRUM LOWER CONTROL	7			
PSOL-58	3rd. DRUM HOIST CONTROL	7			
PSOL-59	3rd. DRUM LOWER CONTROL	7			
PSOL-62	TAGLINE	5			
PSOL-65	Fr. DRUM CONTROL PROPORTIONAL VALVE	7			
PSOL-66	Re. DRUM CONTROL PROPORTIONAL VALVE	7			

SOLENOID VALVE						
PSOL-NO.	USE	SHEET NO.	Manitowoc PART NO.			
PSOL-67	3rd. DRUM CONTROL PROPORTIONAL VALVE	7				
PSOL-70	BOOM PUMP POWER REDUCTION	5				
PSOL-72	SWING CONSTANT SPEED	5				
PSOL-103	Fr. Re. MOTOR CHP CONTROL SYSTEM	7				
PSOL-107	Fr. DRUM MIDDLE DITENT	5				
PSOL-108	Re. DRUM MIDDLE DITENT	5				
PSOL-109	R. H. SWING STOP	5				
PS0L-110	L. H. SWING STOP	5				
PSOL-112	REEVING WINCH SOLENOID (ROLL UP)	14				
PS0L-113	REEVING WINCH SOLENOID (ROLL DOWN)	14				

SWITCH					
SW-NO.	USE	SHEET NO.	Manitowoc PART NO.		
SW-1	E/G KEY	1			
SW-8	TRAVEL SPEED SELECT	1			
SW-9	INCHING SPEED SELECT	1			
SW-11	SWING PARKING	1			
SW-12	GANTRY CONTROL	12			
SW-13	HOOK OVERHOIST RELEASE	3			
SW-14	BOOM OVERHOIST RELEASE	3			
SW-15	LMI RELEASE	3			
SW-16	MASTER KEY	3			
SW-17	WIPER (FRONT)	9			
SW-18	WIPER (ROOF)	9			
SW-19	WASHER SWITCH	9			
SW-20	ROOM LIGHT	10			
SW-21	HEAD LIGHT SWITCH	10			
SW-22	WORK LIGHT (REAR)	11			
SW-23	SWING FLASHER	11			
SW-24	HORN SWITCH	10			
SW-25	CRAWLER EXPANSION AND CONTRACTION	1			
SW-26	TRAVEL ALARM VOICE	11			
SW-27	MULTI VOICE	11			

(19/21)

SWITCH				
SW-NO.	USE	SHEET NO.	Manitowoc PART NO.	
SW-33	DRUM TURN DETECT GRIP	11		
SW-35	AUTO STOP CHECK	3		
SW-36	POSTURE SELECT	3		
SW-37	LMI BYPASS MAIN	3		
SW-38	MC1 BYPASS	5		
SW-39	MC2 BYPASS	7		
SW-45	FREE FALL PERMIT	1		
SW-50	SMULTANEOUS CONTROL POSSIBLE	3		
SW-51	DRUM SELECT	3		
SW-53	Fr. DRUM FREE FALL SELECT	6		
SW-54	Re. DRUM FREE FALL SELECT	6		
SW-55	3rd. DRUM FREE FALL SELECT	6		
SW-56	Fr. DRUM FREE FALL SPEED	6		
SW-57	Re. DRUM FREE FALL SPEED	6		
SW-58	3rd. DRUM FREE FALL SPEED	6		
SW-64	RAISING/LOWERING PEDAL SELECT	1		
SW-65	HYDRAULIC SELECT	1		
SW-71	E/G EMERGENCY STOP SWITCH	2		
SW-72	AUXILIARY ACCELE SW	2		
SW-74	FAN	10		

SWITCH					
SW-NO.	USE	SHEET NO.	Manitowoc PART NO.		
SW-75	LATCH LOCK OPERATION	11			
SW-77	WORK LIGHT (DRUM)	11			
SW-79	JIB RAISING/LOWERING DRUM LOCK	1			
SW-81	AIS MODE SELECT	6			
SW-82	Re. DRUM G WINCH	1			
SW-83	G ENGINE	6			
SW-84	Fr. DRUM G WINCH	1			
SW-85	SPOT LIGHT	10			
SW-86	G WINCH MODE SELECT	6			
SW-87	POWER SW	14			
SW-88	a2/b2 SW	14			
SW-89	a2/b2 SW	14			
SW-90	a3/b3 SW	14			
SW-91	a4/b4 SW	14			
SW-92	a5/b5 SW	14			
SW-93	a6/b6 SW	14			
SW-94	a7/b7 SW	14			
SW-95	KEY SW	14			
SW-96	CYLINDER EXPANSION AND CONTRACTION SWITCH	14			
SW-97	REEVING WINCH SWITCH	14			

LSW-NO.	USE	SHEET NO.	Manitowoc PART NO.
LSW-1	FUNCTION LOCK	1	
LSW-2	HOOK OVERHOIST 1	4	
LSW-3	HOOK OVERHOIST 2	4	
LSW-4	HOOK OVERHOIST (AUX)	4	
LSW-5	JIB OVER HOIST	4	
LSW-6	HOOK OVERHOIST (JIB)	4	
LSW-7	BOOM OVER HOIST	4	
LSW-8	MAST HOOK OVERHOIST 1	4	
LSW-9	BOOM OVERHOIST (No. 1)	4	
LSW-10	MAST HOOK OVERHOIST 2	4	
LSW-12	BOOM OVERHOIST (No. 2)	4	
LSW-14	ROOM LIGHT (DOOR)	10	
LSW-15	ENG. OIL FILTER ALARM	6	
LSW-20	BRAKE COOLING OIL TEMP. (Fr. DRUM)	6	
LSW-21	BRAKE COOLING OIL TEMP. (Re. DRUM)	6	
LSW-22	LINE FILTER ALARM	6	
LSW-24	MAST CYLINDER	4	
LSW-26	Fr. DRUM OVER PAY OUT	4	
LSW-27	Re. DRUM OVER PAY OUT	4	
LSW-28	3Th. DRUM OVER PAY OUT	4	

	LIMIT SWITCH				
LSW-NO.	USE	SHEET NO.	Manitowoc PART NO.		
LSW-30	HYD. OIL TEMP.	1			
LSW-35	AIR CLEANER ALARM	6			
LSW-38	TOWER JIB BENDS LOSS	4			
LSW-39	TOWER LATCH REIATIONS LIMIT SWITCH	4			
LSW-40	TOWER LATCH THE EDGE LIMIT SWITCH	4			
LSW-41	GANTRY STAND UP DETECT	4			

(20/21)

8500-1 / 8500E-1 10-22 Published 12-16-15, Control #244-01

	PRESSURE SWITCH				
PSW-NO.	TYPE	U S E	SHEET NO.	Manitowoc PART NO.	
PSW-1	N. C.	Fr. DRUM FOOT BRAKE PRESSURE SW	6		
PSW-2	N. C.	Re. DRUM FOOT BRAKE PRESSURE SW	6		
PSW-3	N. C.	3rd.DRUM FOOT BRAKE PRESSURE SW	6		
PSW-7	N. O.	TRAVEL CONTROL DETECT SW. (R. H.)	1		
PSW-8	N. C.	ENGINE OIL PRESSURE SW	2		
PSW-9	N. O.	A/C PRESSURE SWITCH	9		
PSW-10	N. O.	TRAVEL CONTROL DETECT SW. (L. H.)	1		

PRESSURE SENSOR					
PT-NO.	U S E	SHEET NO.	Manitowoc PART NO.		
PT-1	SWING PUMP PRESSURE	5			
PT-3	Fr. DRUM HOISTING PRESSURE SENSOR	7			
PT-4	Fr. DRUM LOWERING PRESSURE SENSOR	7			
PT-5	Re. DRUM HOISTING PRESSURE SENSOR	7			
PT-6	Re. DRUM LOWERING PRESSURE SENSOR	7			
PT-7	3rd. DRUM HOISTING PRESSURE SENSOR	7			
PT-8	3rd. DRUM LOWERING PRESSURE SENSOR	7			
PT-9	Fr. DRUM CLUTCH PRESSURE	5			
PT-10	Re. DRUM CLUTCH PRESSURE	5			
PT-11	3rd. DRUM CLUTCH PRESSURE	5			
PT-12	BOOM RAISEING PRESSURE SENSOR	7			
PT-13	BOOM LOWERING PRESSURE SENSOR	7			
PT-14	Re. DRUM CONTROL PROPORTIONAL PRESSURE SENSOR	7			
PT-15	3rd DRUM CONTROL PROPORTIONAL PRESSURE SENSOR	7			
PT-16	CONTROL PRIMARY PRESSURE	5			
PT-17	Fr. DRUM INDEPENDENCE JUNCTION SELECT PRESSURE SENSOR	7			
PT-18	Re. DRUM INDEPENDENCE JUNCTION SELECT PRESSURE SENSOR	7			
PT-19	MAIN AUX. CHP START PRESSURE SENSOR	7			

	PRESSURE SENS	OR	
PT-N0.	USE	SHEET NO.	Manitowoc PART NO.
PT-20	Fr. DRUM CONTROL PROPORTIONAL PRESSURE SENSOR	7	
PT-21	Qmax CUT FB	5	
PT-22	SWING CONTROL (R. H.)	5	
PT-23	SWING CONTROL (L. H.)	5	
PT-24	POWER SHIFT PRESSUER	5	
PT-25	BOOM DRUM POWER SHIFT PRESSURE SENSOR	5	

	PILOT LAMP		
PL-NO.	U S E	SHEET NO.	Manitowoc PART NO.
PL-7	CHECK ENG. LAMP (RED)	2	

(21/21)


10.1.2 CONNECTOR LAYOUT

Wire color list

· Basic single color

Color sign	Color name
В	Black
W	White
R	Red
G	Green
Y	Yellow
Br	Brown
L	bLue

Color sign	Color name
Lg	Light green
Gr	Gray
0	Orange
Sb	Skyblue
Р	Pink
V	Violet
Free	Free



Multi color

• Multi d	Multi color							
Color sign	Color name	Line color						
B/W	Black	White						
B/R	Black	Red						
B/G	Black	Green						
B/Y	Black	Yellow						
B/L	Black	bLue						
W/B	White	Black						
W/R	White	Red						
W/G	White	Green						
W/Y	White	Yellow						
W/L	White	bLue						
W/O	White	Orange						
R/B	Red	Black						
R/W	Red	White						
R/G	Red	Green						
R/Y	Red	Yellow						
R/L	Red	bLue						
G/B	Green	Black						
G/W	Green	White						
G/R	Green	Red						
G/Y	Green	Yellow						
G/L	Green	bLue						


	Color sign G/O	Color name	Line color
	G/O		
1 —		Green	Orange
	Y/B	Yellow	Black
	Y/W	Yellow	White
	Y/R	Yellow	Red
	Y/G	Yellow	Green
	Y/L	Yellow	bLue
	Y/V	Yellow	Violet
	Br/B	Brown	Black
	Br/W	Brown	White
	Br/R	Brown	Red
	Br/G	Brown	Green
	Br/Y	Brown	Yellow
	Br/L	Brown	bLue
	L/B	bLue	Black
	L/W	bLue	White
	L/R	bLue	Red
	L/G	bLue	Green
	L/Y	bLue	Yellow
	L/O	bLue	Orange
	Lg/B	Light green	Black
	Lg/W	Light green	White

Color sign	Color name	Line color
Lg/R	Light green	Red
Lg/Y	Light green	Yellow
Lg/L	Light green	bLue
Gr/B	Gray	Black
Gr/W	Gray	White
Gr/R	Gray	Red
Gr/L	Gray	bLue
O/B	Orange	Black
O/Y	Orange	Yellow
O/L	Orange	bLue
O/W	Orange	White
Sb/B	Skyblue	Black
Sb/R	Skyblue	Red
Sb/L	Skyblue	bLue
P/B	Pink	Black
P/W	Pink	White
P/R	Pink	Red
P/G	Pink	Green
P/L	Pink	bLue
V/R	Violet	Red


8500-1 / 8500E-1 10-24 Published 12-16-15, Control #244-01

Harness name	Parts No	Page
1. FLOOR PLATE		P.10-26
FLOOR PLATE HARNESS (a)		P.10-30
FLOOR PLATE HARNESS (b)		P.10-35
2. LOWER		P.10-41
LOWER HARNESS		P.10-43
3. UPPER		P.10-47
UPPER HARNESS		P.10-48
4. LEFT DECK		P.10-49
MAIN HARNESS		P.10-56
RELAY HARNESS		P.10-61
5. RIGHT DECK		P.10-64
RIGHT DECK HARNESS (a)		P.10-68
RIGHT DECK HARNESS (b)		P.10-73
POWER SUPPLY HARNESS		P.10-74
STARTER (TERMINAL B) TO BATTERY RELAY		P.10-76
STARTER (TERMINAL C) TO SAFETY RELAY		P.10-76
6. RIGHT DECK (GUARD)		P.10-77
GUARD HARNESS (a)		P.10-80
GUARD HARNESS (b)		P.10-81
GUARD HARNESS (c)		P.10-83
NOx SENSOR HARNESS		P.10-84
7. CAB		P.10-85
CAB MAIN HARNESS		P.10-88
O CIMINIC FRAME	GG	P.10-93
8. SWING FRAME	GH	P. 10-93
SWING FRAME HARNESS		P.10-99
JUNCTION BOX		P.10-104
ATT. JUNCTION HARNESS		P.10-105
9. ENGINE		P.10-107
STARTER MOTOR TO ENGINE GROUND		P.10-108
STARTER MOTOR TERMINAL B ALTERNATOR B TERMINAL		P.10-108
10. MONITOR		P.10-109
MONITOR HARNESS		P.10-110
11. COUNTERWEIGHT SELF REMOVAL		P.10-111
COUNTERWEIGHT SELF REMOVAL HARNESS		P.10-113


Harness name	Parts No.	Page
12. COUNTERWEIGHT DETECTOR / 3-C/W / OPT.		P.10-114
COUNTERWEIGHT DETECTOR HARNESS (a)		P.10-116
COUNTERWEIGHT DETECTOR HARNESS (b)		P.10-117
COUNTERWEIGHT DETECTOR HARNESS (c)		P.10-118
13. COUNTERWEIGHT DETECTOR / 4-C/W / OPT.		P.10-119
COUNTERWEIGHT DETECTOR HARNESS (a)		P.10-120
COUNTERWEIGHT DETECTOR HARNESS (b)		P.10-121
COUNTERWEIGHT DETECTOR HARNESS (c)		P.10-123
COUNTERWEIGHT DETECTOR HARNESS (d)		P.10-125
14. CARBODY WEIGHT DETECTOR / OPT.		P.10-127
CARBODY WEIGHT DETECTOR HARNESS (a)		P.10-128
CARBODY WEIGHT DETECTOR HARNESS (b)		P.10-129
CARBODY WEIGHT DETECTOR HARNESS (c)		P.10-130
15. BOOM OVER HOIST PREVENTING		P.10-131
BOOM OVER HOIST PREVENTING HARNESS (a)		P.10-135
BOOM OVER HOIST PREVENTING HARNESS (b)		P.10-136
BOOM OVER HOIST PREVENTING HARNESS (c)		P.10-137
BOOM OVER HOIST PREVENTING HARNESS (d)		P.10-139
16. JIB OVER HOIST PREVENTING		P.10-140
JIB OVER HOIST PREVENTING HARNESS (a)		P.10-141
JIB OVER HOIST PREVENTING HARNESS (b)		P.10-142
17. TRANSLIFTER		P.10-143
TRANSLIFTER HARNESS		P.10-144
18. HOIST DRUM TURN SENSOR		P.10-145
HOIST DRUM TURN SENSOR HARNESS		P.10-147
19. THIRD DRUM TURN SENSOR		P.10-148
THIRD DRUM TURN SENSOR HARNESS		P.10-149
20. DEF/AdBlue® TANK		P.10-150
DEF/AdBlue® TANK		P.10-151
21. CAMERA CONTROLLER		P.10-152
CAMERA CONTROLLER HARNESS (a)		P.10-154
CAMERA CONTROLLER HARNESS (b)		P.10-156
22. DRUM LIGHT INSTAL		P.10-157
DRUM LIGHT INSTAL HARNESS		P.10-158
23. BACK LIGHT INSTAL		P.10-159
BACK LIGHT INSTAL HARNESS		P.10-159
24. IT CONTROLLER INSTALLATION		P.10-160




8500-1 / 8500E-1 10-26 Published 12-16-15, Control #244-01




(2/4)




8500-1 / 8500E-1 10-28 Published 12-16-15, Control #244-01



FLOOR PLATE HARNESS (a)




8500-1 / 8500E-1 10-30 Published 12-16-15, Control #244-01




(2/5)

Published 12-16-15, Control #244-01 8500E-1

3FY-CNA



8500-1 / 8500E-1 10-32 Published 12-16-15, Control #244-01



8500-1 / 8500E-1

(4/5)

2MY-CNA+D

2MY-CNA+D

WIRE NO	WIRE NO	COLO WIRE TYPE	SIZE	FROM	2MIRE CONNECT NO	CONNECTION	2WIRE CONNECT N	I T
MIRE NU	W/G	AVS	1.25	CN-473F	ZWINE CONNECT NO	CUNNECTION	DS-B15	CN-425F
11	W/G	AVSS	1.25	CN-511M	DS-B01	•	DS-B15	CN-425F
11	W/G	AVSS	1.25	CN-511M	DS-B01			JS-B07
11	W/G	AVS	1.25	CN-293M				JS-B07
11	W/G	AVS	1.25	JS-B07				JS-B08 CN-883F
11 11	W/G W/G	AVS AVSS	1.25	JS-808 JS-808				CN-883F
12	R/Y	AVSS	0.75	CN-31F				CN-511M
13	Y/B	AVSS	0.5	CN-511M				CN-293M
14	G/R	AVSS	1.25	CN-290M		-	DS-B212	CN-511M
14	G/R	AVSS	0.75	CN-404F			DS-B212	CN-511M
15	Br	AVSS	1.25	CN-424F	DS-B213	•		CN-401M
15	Br	AVSS	1.25	CN-424F	DS-B213			JS-B122
15 15	Br Br	AVSS AVSS	0.75	CN-440F CN-511M	DS-B214			JS-B122 JS-B122
15	Br	AVSS	1.25	CN-511M	DS-B214			CN-31F
16	L/Y	AVSS	0.75	CN-511M	DO DELT			CN-424F
17	0	AVSS	1.25	CN-511M	DS-B240	•		JS-B129
17	0	AVSS	0.75	CN-511M	DS-B240			CN-404F
17	0	AVSS	1.25	CN-290M				JS-B129
17	0	AVSS	0.75	CN-37F				JS-B129
18 19	Gr P	AVSS	1.25 0.75	CN-290M CN-511M	_			CN-511M CN-290M
20	W/L	AVSS	1.25	CN-293M	_	-	DS-B04	CN-511M
20	W/L	AVSS	1.25	CN-293M			DS-B04	CN-511M
21	Lg	AVSS	0.75	CN-514M				CN-293M
23	R/G	AVSS	0.75	CN-514M	DS-B215	•		CN-293M
23	R/G	AVSS	0.75	CN-514M	DS-B215			CN-293M
26	L	AVSS	0.75	CN-514M		•	-	CN-473F
26 26	L	AVSS AVSS	0.75	CN-514M CN-679M				JS-B50 JS-B50
26	L	AVSS	0.75	CN-218F				JS-B50
27	P/W	AVSS	0.75	CN-514M	DS-B241	•		CN-427F
27	P/W	AVSS	0.75	CN-514M	DS-B241			CN-442F
31	L	AVSS	0.75	CN-310F		•		CN-512M
31	L	AVSS	0.75	JS-B05				CN-512M
31	L	AVSS	0.75	JS-B05		-	DS-B24	B-1
31 31	L	AVSS	0.75	CN-404F			DS-B24	B-1
39	Y/B	AVSS AVSS	0.75	CN-292M CN-886F	_		1	JS-B05 CN-293M
40	Br/W	AVSS	0.75	CN-521F				CN-512M
41	0	AVSS	1.25	CN-404F				CN-512M
42	Р	AVSS	1.25	CN-512M				CN-404F
43	R/Y	AVSS	1.25	CN-512M				CN-404F
44	Gr	AVSS	0.75	CN-512M				CN-290M
48	R/L	AVSS	0.75	CN-429F				CN-290M CN-290M
52 53	Y/G L/R	AVSS AVSS	0.75	CN-425F CN-425F			DS-B18	CN-523F
53	L/R	AVSS	0.75	JS-B114			DS-B18	CN-523F
53	L/R	AVSS	0.75	JS-B114				CN-290M
53	L/R	AVSS	0.75	JS-B114				JS-B123
53	L/R	AVSS	0.75	CN-31F				JS-B123
53 54	L/R	AVSS	0.75	CN-31F CN-425F				JS-B123
82	W/L G/L	AVSS AVSS	0.75	CN-293M				CN-512M CN-255F
82	G/L	AVSS	0.75	CN-432F		•		CN-255F
82	G/L	AVSS	0.75	CN-432F				CN-216F
83	O/W	AVSS	0.75	JS-B46				CN-31F
83	0/W	AVSS	0.75	JS-B46				CN-307M
83	0/W	AVSS	0.75	JS-B46				CN-473F
84 138	Y G/B	AVSS AVSS	0.75	CN-514M CN-442F	_			CN-290M CN-428F
138	G/B	AVSS	0.75	CN-442F				CN-428F
145	Y/L	AVSS	0.75	CN-290M				CN-403F
146	Gr	AVSS	0.75	CN-290M				CN-403F
147	0/L	AVSS	0.75	CN-JB14F		•		CN-290M
147	0/L	AVSS	0.75	CN-JB14F		+		CN-470M
147 147	0/L	AVSS AVSS	0.75	CN-JB14F CN-JB14F		•		CN-404F CN-31F
148	G/W	AVSS	0.75	CN-JB14F		-		CN-31F
148	G/W	AVSS	0.75	CN-JB14F		+		CN-294M
148	G/W	AVSS	0.75	CN-JB14F		+		CN-470M
148	G/W	AVSS	0.75	CN-JB14F		•		CN-403F
149	L/W	AVSS	0.75	CN-JB14F		•		CN-31F
149 149	L/W L/W	AVSS AVSS	0.75	CN-JB14F CN-JB14F				CN-470M CN-403F
149	L/W	AVSS	0.75	CN-JB14F		1		CN-290M
156	P/W	AVSS	0.75	CN-472F				CN-294M
157	W	AVSS	0.75	CN-471M				CN-294M
158	R/W	AVSS	0.75	CN-472F				CN-294M
160	G	AVSS	0.75	CN-307M		_	DS-B45	CN-424F
160 161	G	AVSS AVSS	0.75	CN-37F CN-424F	DS-B46		DS-B45	CN-424F CN-307M
161	Y/R Y/R	AVSS	0.75	CN-424F	DS-B46			CN-401M
162	Y/G	AVSS	0.75	CN-307M				CN-440F
165	Gr/R	AVSS	0.75	CN-294M		-		CN-JB14F
165	Gr/R	AVSS	0.75	CN-424F		-		CN-JB14F
165	Gr/R	AVSS	0.75	CN-438F	DS-B220	•		CN-JB14F
165	Gr/R	AVSS	0.75	CN-438F	DS-B220	_	DS-B221	CN-437F
165 166	Gr/R	AVSS AVSS	0.75	CN-436F JS-B115	+		DS-B221	CN-437F CN-294M
166	Lg/W Lg/W	AVSS	0.5	JS-B115 JS-B115		==		CN-294M CN-438F
166	Lg/W	AVSS	0.5	JS-B115				CN-404F
167	Lg/Y	AVSS	0.5	JS-B116				CN-294M
167	Lg/Y	AVSS	0.5	JS-B116				CN-404F
167	Lg/Y	AVSS	0.5	JS-B116				CN-437F
168	Lg/R	AVSS	0.5	CN-307M		-	DS-B222	CN-436F
168	Lg/R	AVSS	0.75	CN-31F	-		DS-B222	CN-436F
170	R/G	AVSS	0.5 1.25	CN-294M	-			CN-32F
	G/L Gr/W	AVSS	0.75	CN-440F CN-307M				CN-307M JS-B121
172	JUL 2 17		0.75	CN-403F	_			JS-B121
176	Gr/W	IAVSS			1			
	Gr/W Gr/W	AVSS AVSS	_	CN-31F				
176 176	Gr/W		0.75					JS-B121 CN-33F
176 176 176		AVSS	0.75	CN-31F CN-404F CN-33F				JS-B121
176 176 176 212	Gr/W G/W	AVSS AVSS	0.75 0.75	CN-31F CN-404F				JS-B121 CN-33F


Time									
SOL Y	luine u	1	W105 T105		5000	Amine amines us		Tamas assurat u	.1
SIR AVS	-). WIRE COLOR				2WIRE CONNECT NO.	CONNECTION	2WIRE CONNECT N	
199		Υ							
200 W/Y				_					
SAC AVS									
255 W.C. AVSS 076 DV-29M DV									
366 G/R A/SS 076 O-1-291M O-2-291M O-2-29				_					
337 O.L. AVSS									
338 G. P. AVSS OTS ON-471M ON-291M ON-471M ON-291M ON-471M ON-291M ON-471M ON-291M ON-471M				_					
339 P									
SS									
341 W.L. AVSS 0.75 (0-291M		ľ		_					
343									
SAM SAW AVSS C/75 C)-H-671M C)-P-291M C)				_			-		
365 Lay									
366 R.I. AVSS 0.75 OH-29MM		G/W							
\$364 R.W. AVSS 0.75 ON-259M D.P404M D.P405M S.B. G.YY AVSS 0.75 ON-259M D.P470M		Lg/Y		_					
Sept Sept									
386	383	R	AVSS	0.75	CN-294M				CN-419M
386 O AVSS 0.75 OH-282M	384	R/W	AVSS	0.75	CN-292M				CN-470M
394 1.0	385	G/Y			CN-470M				CN-292M
366 P.I. AVSS	386	0	AVSS	0.75	CN-292M				CN-470M
395 P.I. AVSS	394	Lg	AVSS	0.75	CN-31F				CN-416F
AVS	395	R/L	AVSS	0.75	CN-290M		-	DS-B230	CN-418M
402 V/W AVSS 0.75 0H-37F .	395	R/L	AVSS	0.75	CN-424F			DS-B230	CN-418M
AVSS	402	V/W	AVSS	0.75	CN-294M		I		JS-B21
AVSS	402	V/W	AVSS	0.75	CN-37F				JS-B21
411 W/Y ANSS 0.75 OH-2004 OH-242F 419 W/Y ANSS 0.75 OH-242F 429 0 ANSS 0.75 OH-242F 429 0 ANSS 0.75 OH-268H 429 0 ANSS 0.75 OH-268H 429 0 ANSS 0.75 OH-268H 420 0 ANSS 0.75 OH-268H 421 ANSS 0.75 OH-268F 4225 PY/G ANSS 0.75 OH-268F 4235 PY/G ANSS 0.75 OH-268F 4245 PY/G ANSS 0.75 OH-268F 4245 PY/G ANSS 0.75 OH-268F 4241 Y/B ANSS 0.75 OH-268F 4241 Y/B ANSS 0.75 OH-268H 4241 Y/B ANSS 0.75 OH-268H 4241 Y/B ANSS 0.75 OH-268H 424 Y/B ANSS 0.75 OH-268H 424 PY/B ANSS 0.75 OH-268H 424 PY/B ANSS 0.75 OH-268H 425 PY/G ANSS 0.75 OH-268H 426 PY/G ANSS 0.75 OH-268H 427 PY/B ANSS 0.75 OH-268H 428 PY/G ANSS 0.75 OH-268H 429 ANSS 0.75 OH-268H 420 ANSS 0.75 OH-268H 421 PY/B ANSS 0.75 OH-268H 422 PY/B ANSS 0.75 OH-268H 423 PY/G ANSS 0.75 OH-268H 424 PY/B ANSS 0.75 OH-268H 425 PY/G ANSS 0.75 OH-268H 426 PY/G ANSS 0.75 OH-268H 427 PY/B ANSS 0.75 OH-268H 428 PY/G ANSS 0.75 OH-268H 429 ANSS 0.75 OH-268H 429 ANSS 0.75 OH-268H 421 PY/B ANSS 0.75 OH-268H 422 PY/B ANSS 0.75 OH-268H 423 PY/Y ANSS 0.75 OH-268H 424 PY/P ANSS 0.75 OH-268H 425 PY/Y ANSS 0.75 OH-268H 426 PY/Y ANSS 0.75 OH-268H 427 PY/P ANSS 0.75 OH-268H 428 PY/P ANSS 0.75 OH-268H 429 PY/P ANSS 0.75 OH-268H 420 PY/P ANSS 0.75 OH-268H 420 PY/P ANSS 0.75 OH-268H 420 PY/P ANSS 0.75 OH-							ļ		
429 G AVSS 0.75 0H-291M			AVSS				ļ		
429 G AVSS 0.75 DN-290M DN-32F 435 BYG AVSS 0.75 DN-883F J.5-B126 435 BYG AVSS 0.75 DN-832F J.5-B126 435 BYG AVSS 0.75 DN-832F J.5-B126 435 BYG AVSS 0.75 DN-523F J.5-B126 435 BYG AVSS 0.75 ON-523F J.5-B131 435 BYG AVSS 0.75 ON-523F J.5-B131 441 Y/B AVSS 0.75 ON-473F J.5-B131 441 Y/B AVSS 0.75 ON-473F J.5-B132 442 R/B AVSS 0.75 ON-473F J.5-B132 442 R/B AVSS 0.75 ON-292M J.5-B132 442 R/B AVSS 0.75 ON-293M J.5-B133 442 R/B AVSS 0.75 ON-293M J.5-B133 <t< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td> </td><td></td><td></td></t<>									
435 BY/G AVSS 0.75 0H-8397	-			_					
AVSS							—		
### ### ### ### ### ### ### ### ### ##							l		
### ### ### ### ### ### ### ### ### ##						1	•		
### ### ### ### ### ### ### ### ### ##						1	-		
### 435 BY/G AVSS 0.75 0N-929F				_			•		
### AVS						 			
441 Y/B AVSS 0.75						_		_	
A41						-		_	
4422 R/B AVSS 0.75 CN-220M JS-B132 442 R/B AVSS 0.75 CN-473F JS-B132 442 R/B AVSS 0.75 CN-473F JS-B132 442 R/B AVSS 0.75 CN-4299M JS-B133 444 G/R AVSS 0.75 CN-239M JS-B133 444 G/R AVSS 0.75 CN-239M DN-2474F 445 R/Y AVSS 0.75 CN-239M DN-474F 463 R/Y AVSS 0.75 CN-239M DN-474F 463 R/Y AVSS 0.75 CN-239M DN-428M 464 R/Y AVSS 0.75 CN-239M DN-428M 465 L/Y AVSS 0.75 CN-239M DN-427F 465 L/Y AVSS 0.75 CN-239M DN-427F 465 L/Y AVSS 0.75 CN-428M DN-428M 485 </td <td></td> <td></td> <td></td> <td></td> <td></td> <td>_</td> <td></td> <td>_</td> <td></td>						_		_	
A42 R/B									
AUS AVS AVS O.75 ON-293M ON-259T ON-293M ON-274F ON-275F ON-275F ON-275F ON-275F ON-275F ON-275F ON-275M ON-274F ON-293M ON-274F ON-293M ON-274F ON-293M ON-274F ON-293M						-		-	
444 G/R AVSS 0.75 ON-293M JS-B133 444 G/R AVSS 0.75 ON-293M JS-B133 444 G/R AVSS 0.75 ON-893F JS-B134 445 R/Y AVSS 0.75 ON-893F JS-B134 446 R/Y AVSS 0.75 ON-392M ON-493F ON-894M 447 AVSS 0.75 ON-393M ON-493F ON-894M 453 R/W AVSS 0.75 ON-393M ON-493F ON-493F 455 L/Y AVSS 0.75 ON-293M JS-B134 455 L/Y AVSS 0.75 ON-293M JS-B134 456 L/Y AVSS 0.75 ON-293M ON-493M ON-493M 457 AVSS 0.75 ON-293M ON-493M ON-493F 458 AVS 0.75 ON-293M ON-493F JS-B134 458 L/B AVSS 0.75 ON-293M ON-493F ON-293M 459 AVSS 0.75 ON-293M ON-493F ON-293M 460 O/L AVSS 0.75 ON-293M ON-493F 460 O/L AVSS 0.75 ON-293M ON-493F 470 R AVSS 0.75 ON-294M ON-493F 471 O AVSS 0.75 ON-294M ON-493F 471 O AVSS 0.75 ON-294M ON-493F 471 O AVSS 0.75 ON-254F ON-254F 472 G7 AVSS 0.75 ON-254F 473 AVSS 0.75 ON-254F 474 ON-254F 475 ON-254F 476 O AVSS 0.75 ON-254F 477 ON-254F 478 ON-254F 479 AVSS 0.75 ON-254F 470 AVSS 0.75 ON-254F 471 O AVSS 0.75 ON-254F 472 G7 AVSS 0.75 ON-254F 473 AVSS 0.75 ON-254F 474 ON-254F 475 ON-254F 476 O AVSS 0.75 ON-254F 477 ON-254F 478 ON-254F 479 AVSS 0.75 ON-254F 470 AVSS 0.75 ON-254F 471 O AVSS 0.75 ON-254F 472 G7 AVSS 0.75 ON-254F 473 AVSS 0.75 ON-254F 474 ON-254F 475 ON-254F 476 O AVSS 0.75 ON-255F 577 ON-254F 477 ON-254F 478 ON-254F 479 ON-254F 470 AVSS 0.75 ON-31F 471 ON-254F 472 ON-254F 473 AVSS 0.75 ON-31F 474 ON-254F 475 ON-254F 476 O AVSS 0.75 ON-31F 477 ON-254F 478 ON-254F 479 ON-254F 470 ON-254F 471 ON-254F 472 ON-254F 473 ON-254F 474 ON-254F 475 ON-254F 477 ON-254F 477 ON-254F 478 ON-254F 479 ON-254F 479 ON-254F 470 ON-254F 470 ON-254F 471 ON-254F 472 ON-254F 473 ON-254F 474 ON-254F 475 ON-254F 477 ON-254F 477 ON-254F 478 ON-254F 479 ON-254F 479 ON-254F 470 ON-254F 471 ON-254F 471 ON-254F 472 ON-254F 473 ON-254F 474 ON-254F 475 ON-254F 477 ON-254F 477 ON-254F 478 ON-254F 478 ON-254F 479 ON-254F 479 ON-254F 470 ON-254F 470 ON-254F 470 ON-25						-			
444 G./R AVSS 0.75 ON-472F J.S-B133 444 G./R AVSS 0.75 ON-883F J.S-B133 445 R./Y AVSS 0.75 ON-292M ON-474F 448 G./Y AVSS 0.75 ON-292M ON-474F 448 G./Y AVSS 0.75 ON-295M ON-401M 453 R./W AVSS 0.75 ON-295M ON-401M 454 R./Y AVSS 0.75 ON-295M ON-401M 455 L./Y AVSS 0.75 ON-295M ON-401M 455 L./Y AVSS 0.75 ON-295M J.S-B134 456 L./Y AVSS 0.75 ON-295M J.S-B134 457 L./Y AVSS 0.75 ON-883F J.S-B134 458 L./B AVSS 0.75 ON-415M ON-401M 458 L./B AVSS 0.75 ON-415M ON-477F 468 O AVSS 0.75 ON-294M ON-477F 470 R AVSS 0.75 ON-254F ON-294M ON-294F 471 O AVSS 0.75 ON-254F ON-254F 472 Gr AVSS 0.75 ON-254F ON-259F 472 Gr AVSS 0.75 ON-258F ON-258F 472 Gr AVSS 0.75 ON-258F ON-258F 473 Y AVSS 0.75 ON-258F J.S-01 474 AVSS 0.75 ON-258F J.S-01 475 ON-258F ON-258F J.S-02 476 O AVSS 0.75 ON-258F J.S-02 477 AVSS 0.75 ON-258F J.S-02 478 AVSS 0.75 ON-258F J.S-01 479 AVSS 0.75 ON-258F J.S-01 470 R AVSS 0.75 ON-258F J.S-01 471 O AVSS 0.75 ON-258F J.S-01 472 Gr AVSS 0.75 ON-258F J.S-01 473 Y AVSS 0.75 ON-258F J.S-02 476 O AVSS 0.75 ON-258F J.S-01 477 ON-258F J.S-02 477 AVSS 0.75 ON-258F J.S-02 478 ON-258F J.S-02 479 AVSS 0.75 ON-258F J.S-02 479 AVSS 0.75 ON-258F J.S-02 479 AVSS 0.75 ON-258F J.S-02 470 AVSS 0.75 ON-258F J.S-02 471 O AVSS 0.75 ON-258F J.S-02 472 Gr AVSS 0.75 ON-258F J.S-02 473 Y AVSS 0.75 ON-258F J.S-02 475 ON-258F J.S-02 476 ON-258F J.S-02 477 ON-258F J.S-02 477 ON-258F J.S-02 477 ON-258F J.S-02 477 ON-258F J.S-02 478 ON-258F J.S-02 479 ON-258F J.S-02 479 ON-258F J.S-02 470 ON-258F J.S-02 471 ON-258F J.S-02 472 OR AVSS 0.75 ON-258F J.S-02 473 ON-258F J.S-02 474 ON-258F J.S-02 475 ON-258F J.S-03 476 ON-258F J.S-03 477 ON-258F J.S-03 478 ON-258F J.S-03 479 ON-258F J.S-03 470 ON-258F J.S-03 470 ON-258F J.S-03 471 ON-258F J.S-03 472 OR AVSS 0.75 ON-258F J.S-03 473 ON-258F J.S-03 474 ON-258F J.S-03 475 ON-258F J.S-03 476 ON-258F J.S-03 477 ON-258F J.S-03				_		-			
444 G/R AVSS 0.75 ON-883F US-8134 445 R/Y AVSS 0.75 ON-928M ON-928M ON-928M 453 R/W AVSS 0.75 ON-928F ON-928M 454 R/Y AVSS 0.75 ON-93F ON-928M 455 L/Y AVSS 0.75 ON-939M US-8134 455 L/Y AVSS 0.75 ON-939M US-8134 455 L/Y AVSS 0.75 ON-939M US-8134 456 L/Y AVSS 0.75 ON-939M US-8134 457 L/Y AVSS 0.75 ON-939M US-8134 458 L/B AVSS 0.75 ON-939M US-8134 458 L/B AVSS 0.75 ON-939M US-8134 458 L/B AVSS 0.75 ON-939M US-8134 460 O/L AVSS 0.75 ON-939M US-8134 460 O/L AVSS 0.75 ON-939M US-8134 463 L/B AVSS 0.75 ON-939M US-8134 463 L/B AVSS 0.75 ON-939M US-8134 464 O/L AVSS 0.75 ON-939M US-8134 465 L/Y AVSS 0.75 ON-939M US-8134 467 OR AVSS 0.75 ON-939M US-8134 468 O AVSS 0.75 ON-939M US-8134 470 R AVSS 0.75 ON-939M US-8134 471 O AVSS 0.75 ON-939M US-8134 471 O AVSS 0.75 ON-939M US-8134 471 O AVSS 0.75 ON-939M US-8134 472 Gr AVSS 0.75 ON-934M US-8134 473 O AVSS 0.75 ON-934F US-8134 474 O R AVSS 0.75 ON-934F US-934 475 OF AVSS 0.75 ON-934F US-934 476 O AVSS 0.75 ON-954F US-934 477 O AVSS 0.75 ON-954F US-934 478 O AVSS 0.75 ON-958F US-934 479 O AVSS 0.75 ON-958F US-934 470 R AVSS 0.75 ON-958F US-934 471 O AVSS 0.75 ON-958F US-934 472 Gr AVSS 0.75 ON-958F US-934 473 Y AVSS 0.75 ON-958F US-934 474 ON-958F US-934 486 US-94 AVSS 0.75 ON-958F US-934 487 ON-958F US-934 488 US-94 AVSS 0.75 ON-958F US-934 489 US-94 AVSS 0.75 ON-958F US-934 489 US-94 AVSS 0.75 ON-958F US-934 489 US-94 AVSS 0.75 ON-938F US-981 489 US-94 AVSS 0.75 ON-938F US-9810 489 US-94						_		_	
445 R/Y AVSS 0.75 ON-292M ON-37F 448 G/Y AVSS 0.75 ON-31F ON-32F ON-32F ON-32F ON-32F ON-884M AVSS 0.75 ON-31F ON-884M AVSS 0.75 ON-31F ON-884M AVSS 0.75 ON-293M AVSS 0.75 ON-293M AVSS 0.75 ON-293M AVSS 0.75 ON-293M AVSS 0.75 ON-472F JS-8134 AVSS 0.75 ON-472F JS-8134 AVSS 0.75 ON-418M ON-472F AVSS 0.75 ON-418M ON-37F AVSS 0.75 ON-418M ON-37F AVSS 0.75 ON-294M ON-37F AVSS 0.75 ON-294M ON-37F ON-294M ON-37F ON-294M ON-37F ON-254F AVSS 0.75 ON-254F AV							_		
4483 R./W AVSS 0.75 ON-32F ON-32F ON-32F ON-329M AVSS 0.75 ON-39M ON-401M ON-401M ON-401M AVSS 0.75 ON-290M ON-401M ON-401M AVSS 0.75 ON-290M ON-401M ON-401M AVSS 0.75 ON-290M ON-401M ON-401M AVSS 0.75 ON-293M ON-472F ON-	-								
ASS R/W AVSS O.75 O.N-21F O.N-884M O.N-401M				_					
4856 L/Y AVSS 0.75 ON-293M JS-8134 4858 L/Y AVSS 0.75 ON-293M JS-8134 4858 L/B AVSS 0.75 ON-293M DN-427F 4860 O/L AVSS 0.75 ON-293M DN-427F 4860 O/L AVSS 0.75 ON-293M DN-427F 4860 O/L AVSS 0.75 ON-293M DN-437F 4868 0 AVSS 0.75 ON-294M DN-394F 470 R AVSS 0.75 ON-294M DN-294M DN-399F 471 0 AVSS 0.75 ON-254F DN-294M DN-294M 471 0 AVSS 0.75 ON-254F DN-294M 471 0 AVSS 0.75 ON-254F DN-294M 472 Gr AVSS 0.75 ON-254F DN-294M 472 Gr AVSS 0.75 JS-01 DN-294M 472 Gr AVSS 0.75 JS-01 DN-294M 472 Gr AVSS 0.75 JS-01 DN-294M 473 Y AVSS 0.75 ON-258F JS-02 472 Gr AVSS 0.75 ON-258F JS-01 DN-294M 473 Y AVSS 0.75 ON-258F JS-02 474 Gr AVSS 0.75 ON-258F JS-02 475 ON-258F JS-02 476 O AVSS 0.75 ON-258F DN-258F DN-258F 476 O AVSS 0.75 ON-258F DN-258F 477 ON-258F DN-258F DN-258F 478 O AVSS 0.75 ON-258F DN-258F 479 ON-258F 470 ON-258F DN-258F DN-258F 471 ON-258F 472 Gr AVSS 0.75 ON-258F DN-258F 473 Y AVSS 0.75 ON-258F DN-258F 476 O AVSS 0.75 ON-258F DN-258F 477 ON-258F 478 ON-258F DN-258F 479 ON-258F 480 ON-258F DN-258F 501 Br/W AVSS 0.75 ON-258F DN-258F 502 G/Y AVSS 0.75 ON-258F DN-258F 503 L AVSS 0.75 ON-258F DN-258F 504 Br/W AVSS 0.75 ON-258F DN-258F 505 W/R AVSS 0.75 ON-31F DN-258F 506 W/R AVSS 0.75 ON-31F DN-258F 507 ON-258F 508 W/R AVSS 0.75 ON-31F DN-258F 509 W/R AVSS 0.75 ON-31F DN-258F 500 W/R AVSS 0.75 ON-31F 500 W/R AVSS 0.75 ON-32F 500 W/									
455 L/Y AVSS 0.75 ON-293M JS-B134 455 L/Y AVSS 0.75 ON-472F JS-B134 455 L/Y AVSS 0.75 ON-472F JS-B134 458 L/B AVSS 0.75 ON-293M ON-277 460 O/L AVSS 0.75 ON-293M ON-277 460 O/L AVSS 0.75 ON-218M ON-277 463 L/B AVSS 0.75 ON-218F ON-254F ON-294M ON-377 470 R AVSS 0.75 ON-254F ON-254F ON-259F ON-259F ON-259F ON-259F ON-259F ON-259F ON-259F ON-259F JS-01 ON-259F ON-259									
### ### #### #########################									
## ## ## ## ## ## ## ## ## ## ## ## ##		L .							
AVS									
AGO O/L AVSS O.75 ON-418M ON-37F		L/Y		-					
## AVSS		L/B							
468 O		0/L							
470 R AVSS 0.75 CN-254F CN-254F CN-259F 471 0 AVSS 0.75 CN-254F CN-259F CN-259F 472 Gr AVSS 0.75 JS-01 CN-258F CN-258F 472 Gr AVSS 0.75 JS-01 CN-258F CN-252M 472 Gr AVSS 0.75 JS-01 US-02 LY 472 Gr AVSS 0.75 ON-258F US-02 US-02 472 Gr AVSS 0.75 ON-258F US-02 US-02 472 Gr AVSS 0.75 ON-258F US-02 US-02 473 Y AVSS 0.75 ON-258F US-02 US-02 481 W/B AVSS 0.75 ON-31F ON-258F ON-258F 501 BY/W AVSS 0.75 ON-31F ON-258F ON-258F 501 BY/W AVSS 0.75 <	463	L/B	AVSS	0.75	CN-419M				
471	468	О	AVSS	0.75					CN-499F
4721 0 AVSS 0.75 CN-254F CN-254F 472 Gr AVSS 0.75 JS-01 CN-254F 472 Gr AVSS 0.75 JS-01 CN-254F 472 Gr AVSS 0.75 SN-01 US-02 472 Gr AVSS 0.75 CN-258F US-02 473 Y AVSS 0.75 CN-258F US-02 473 Y AVSS 0.75 CN-258F CN-259F 473 Y AVSS 0.75 CN-258F CN-259F 481 W/B AVSS 0.75 CN-258F CN-259M 485 L9 AVSS 0.75 CN-258F CN-259M 501 Br/W AVSS 0.75 CN-31F CN-259M 501 Br/W AVSS 0.75 CN-31F CN-258F 501 Br/W AVSS 0.75 CN-31F CN-401M 502 G/Y	470	R	AVSS	0.75	CN-254F				CN-294M
472	471	0	AVSS	0.75	CN-254F		•		CN-258F
472 Gr AVSS 0.75 JS-01 JS-02 472 Gr AVSS 0.75 JS-01 JS-02 472 Gr AVSS 0.75 CN-258F JS-02 472 Gr AVSS 0.75 CN-258F JS-02 473 Y AVSS 0.75 CN-258F JS-02 473 Y AVSS 0.75 CN-258F JS-02 474 AVSS 0.75 CN-258F JS-02 481 W/B AVSS 0.75 CN-31F CN-258F CN-258A 485 Gr AVSS 0.75 CN-31F CN-258F CN-258A 486 J9 AVSS 0.75 CN-31F CN-258F CN-258A 501 Br/W AVSS 0.75 CN-31F CN-258F CN-401M 502 G/Y AVSS 0.75 CN-31F CN-401M 503 L AVSS 0.75 CN-31F CN-401M 504 G/Y AVSS 0.75 CN-31F CN-401M 505 W/R AVSS 0.75 CN-31F CN-401M 506 W/R AVSS 0.75 CN-31F CN-401M 507 W/R AVSS 0.75 CN-31F CN-401M 508 BR DV AVSS 0.75 CN-31F CN-401M 509 W/R AVSS 0.75 CN-32F CN	471	0	AVSS	0.75	CN-254F				CN-258F
472	472	Gr	AVSS	0.75	JS-01				CN-292M
4772 Gr AVSS 0.75 DN-258F JS-02 4772 Gr AVSS 0.75 CN-258F JS-02 4773 Y AVSS 0.75 CN-258F JS-02 4773 Y AVSS 0.75 CN-258F CN-258F 4776 O AVSS 0.75 CN-258F CN-258F 481 W/B AVSS 0.75 CN-31F CN-292M 485 Gr/L AVSS 0.75 CN-31F CN-292M 486 Lg AVSS 0.75 CN-31F CN-292M 501 Br/w AVSS 0.75 CN-31F CN-292M 502 G/Y AVSS 0.75 CN-31F CN-292M 503 L AVSS 0.75 CN-31F CN-292M 504 Br/w AVSS 0.75 CN-31F CN-292M 750 W/R AVSS 0.75 CN-31F CN-292M 750 W/R				_					
4772 Gr AVSS 0.75 ON-258F JS-02 4772 Gr AVSS 0.75 ON-258F JS-02 4773 Y AVSS 0.75 ON-258F ON-258F 4776 O AVSS 0.75 ON-31F ON-239M 4881 W./B AVSS 0.75 ON-429F ON-33F 4896 Gr/L AVSS 0.75 ON-258F ON-258F 501 Br/W AVSS 0.75 ON-31F ON-258F 501 Br/W AVSS 0.75 ON-31F ON-258F 501 Br/W AVSS 0.75 ON-31F ON-401M 502 G/Y AVSS 0.75 ON-401M ON-31F 503 L AVSS 0.75 ON-401M ON-401M 750 W/R AVSS 0.75 S-8120 ON-401M 750 W/R AVSS 0.75 S-8120 ON-401M 750		Gr							
4773 Y AVSS 0.75 ON-259F ON-259F ON-259F 4773 Y AVSS 0.75 ON-259F ON-259F 4776 O AVSS 0.75 ON-259F ON-259F 4881 W/B AVSS 0.75 ON-219F ON-239A 4886 GYL AVSS 0.75 ON-259F 501 BY/W AVSS 0.75 ON-259F 501 BY/W AVSS 0.75 ON-259F 502 GYY AVSS 0.75 ON-219F 503 L AVSS 0.75 ON-31F ON-401M 502 GYY AVSS 0.75 ON-31F 503 L AVSS 0.75 ON-31F 504 W/R AVSS 0.75 ON-31F 505 W/R AVSS 0.75 ON-31F 507 W/R AVSS 0.75 ON-31F 508 W/R AVSS 0.75 ON-31F 509 W/R AVSS 0.75 ON-31F 500 W/R AVSS 0.75 ON-31F 500 W/R AVSS 0.75 ON-31F 500 W/R AVSS 0.75 ON-329F 500 W/R AVSS 0.75 ON-219F 500 W/R AVSS 0.75 ON-31F 500 W/R AVSS 0.75 ON-32F 500 W/R AVSS 0.75 ON		Gr					<u> </u>		
473 Y AVSS 0.75 ON-258F ON-259F ON-25									
481 W/B AVSS 0.75 CN-31F CN-29F CN-32F CN-32		Y					<u> </u>		
## AVS 0.75		0		0.75					
486 Gr/L AVSS 0.75 CN-31F CN-258F CN-401M CN-258F CN-401M CN-258F CN-401M CN-4							_		
486 Gr/L AVSS 0.75 CN-31F CN-258F CN-401M CN-258F CN-401M CN-258F CN-401M CN-4	481	W/B	AVSS	0.75	CN-429F				CN-33F
486									
SO1 BY/W AVSS 0.75 CN-31F CN-401M CN-301M CN-401M CN-301M CN-401M									
SOC SCAT SOC				-					
\$603 L AVSS 0.75 CN-31F CN-401M CN-401M CN-428F \$60 W/R AVSS 0.75 S-8120 CN-3287M CN-4283M \$750 W/R AVSS 0.75 S-8120 CN-3287M \$750 W/R AVSS 0.75 CN-4387 DS-861 CN-4287M \$750 W/R AVSS 0.75 CN-4387 DS-861 CN-4287M \$750 W/R AVSS 0.75 CN-4387 DS-810 CN-4377M \$750 W/R AVSS 0.75 CN-3287 DS-8101 CN-2187M \$750 W/R AVSS 0.75 CN-2187 DS-8106 CN-2187M \$750 W/R AVSS 0.75 CN-2187 DS-8106 CN-2187M \$750 W/R AVSS 0.75 CN-2187 DS-826 CN-2187M \$750 W/R AVSS 0.75 CN-401M \$750 W				_					
TSO		L							
TSO		W/R							
750 W/R AVSS 0.75 0N-438F 0S-B61 0S-B69 0N-432F 750 W/R AVSS 0.75 0N-438F 0S-B61 0S-B69 0N-432F 750 W/R AVSS 0.75 0N-438F 0S-B61 0S-B69 0N-432F 750 W/R AVSS 0.75 0N-438F 0S-B61 0S-B60 0N-437F 750 W/R AVSS 0.75 0N-438F 0S-B101 0S-B100 0N-437F 750 W/R AVSS 0.75 0N-438F 0S-B101 0S-B100 0N-437F 750 W/R AVSS 0.75 0N-218F 0S-B106 0S-B100 0N-218F 750 W/R AVSS 0.75 0N-218F 0S-B106 0S-B100 0N-218F 750 W/R AVSS 0.75 0N-218F 0S-B106 0S-B100 0N-218F 750 W/R AVSS 0.75 0N-218F 0S-B26 0S-B30 0N-216F 750 W/R AVSS 0.75 0N-218F 0S-B26 0S-B30 0N-216F 750 W/R AVSS 0.75 0N-216F 0S-B226 0S-B30 0N-216F 750 W/R AVSS 0.75 0N-31F 0S-B21 0N-418M 750 W/R AVSS 0.75 0N-401M 0S-B41 0N-418M 750 0N-806F 0N-216F 0S-B21 0S-B41 0N-418M 750 0N-806F 0N-806F 0S-B21 0N-818F 0S-B41 0N-418M 750 0N-806F 0N-806F 0S-B21 0N-818F 0S-B41 0N-418M 750 0N-806F 0N-806F 0N-806F 0S-B41 0N-418M 750 0N-806F 0N-806F 0N-806F 0S-B41 0N-418M 750 0N-806F 0N-806F 0N-806F 0S-B41 0N-418M 750 0N-806F 0N-806F 0S-B41 0N-418M 750 0N-806F 0S-B41 0N-418M 750 0N-418M									
TSO							•	DS-859	
TSO						DS-B61	•		
TSO							-		
750 W/R AVSS 0.75 CN-218F DS-B101 DS-B102 CN-218F TS-B106 W/R AVSS 0.75 CN-218F DS-B106 DS-B10							•		
TSO									
750 W/R AVSS 0.75 CN-218F 0S-B106 DSA95 CN-216F 750 W/R AVSS 0.75 CN-216F 0S-B226 DSA95 CN-216F 750 W/R AVSS 0.75 CN-216F 0S-B226 DSA95 CN-216F 750 W/R AVSS 0.75 CN-216F 0S-B226 DSA95 CN-216F DSA9									
750 W/R AVSS 0.75 CN-216F 0S-B226									
750 W/R AVSS 0.75 CN-216F 0S-B226 CN-889F 869 Gr AVSS 0.75 CN-37F CN-401M DS-B41 CN-418M 861 L/Y AVSS 0.75 CN-401M DS-B41 CN-418M 861 L/Y AVSS 0.75 CN-31F CS-B41 CN-418M 862 G/O AVSS 0.75 CN-38F CS-B41 CN-418M 862 G/O AVSS 0.75 CN-889F CS-B41 CN-418M 862 G/O AVSS 0.75 CN-889F CS-B41 CN-418M 862 G/O AVSS 0.75 CN-889F CS-B41 CS-B40 862 G/O AVSS 0.75 CN-473F CS-B40 863 G/O AVSS 0.75 CN-473F CS-B40 864 G/O AVSS 0.75 CN-473F CS-B40 865 G/O AVSS 0.75 CN-473F CS-B40 865 G/O AVSS 0.75 CN-473F CS-B40 867 G/O AVSS 0.75 CN-473F CS-B40 868 G/O AVSS 0.75 CN-473F CS-B40 869 Gr AVSS 0.75 CN-473F CS-B40 860 Gr AVSS 0.75 CS-B40 860 Gr AVSS 0.75 CS-B40									
SE9 Gr								DOMOD	
861 L/Y AVSS 0.75 CN-401M DS-B41 CN-418M 861 L/Y AVSS 0.75 CN-31F DS-B41 CN-418M 862 G/O AVSS 0.75 CN-32F DS-B41 CN-418M 862 G/O AVSS 0.75 CN-883F DS-B10 US-B10 862 G/O AVSS 0.75 CN-473F US-810	LDO	W/R	AVSS	0.75	UN-216F	D2-R550			UN-886H
861 L/Y AVSS 0.75 CN-401M DS-B41 CN-418M 861 L/Y AVSS 0.75 CN-31F DS-B41 CN-418M 862 G/O AVSS 0.75 CN-32F DS-B41 CN-418M 862 G/O AVSS 0.75 CN-883F DS-B10 US-B10 862 G/O AVSS 0.75 CN-473F US-810	050	-	AVEC	OPE	CVF3CC				O/F630r1
861 L/Y AVSS 0.75 CN-31F DS-841 CN-418M 862 G/O AVSS 0.75 CN-983F US-810 US-810 862 G/O AVSS 0.75 CN-983F US-810 US-810 862 G/O AVSS 0.75 CN-473F US-810						-		DO D **	
662 G/O AVSS 0.75 CN-32F US-810 662 G/O AVSS 0.75 CN-963F US-910 682 G/O AVSS 0.75 CN-473F US-910							_		
862 G/O AVSS 0.75 CN-888F JS-810 862 G/O AVSS 0.75 CN-473F JS-810						1		U5-B41	
862 G/O AVSS 0.75 CN-473F US-B10						1			
1502 157U AVSS 1076 LN-473F JS-B10									
1804 L/G AVSS 10.75 LN-37F CN-679F									
	264	L/G	AVSS	0.75	UN-37F				UN-679F

WIRE NO.	WIRE COLOR	WIRE TYPE	SIZE	FROM	2WIRE CONNECT NO.	CONNECTION	2WIRE CONNECT NO.	T 0
900	Lg/Y	AVSS	0.75	CN-472F				CN-293M
901	Y/L	AVSS	0.75	CN-411F				CN-293M
902	Gr/R	AVSS	0.75	CN-218F				CN-679M
903	Lg	AVSS	0.75	CN-679M				CN-218F
904	Y/G	AVSS	0.75	CN-216F				JS-B31
904	Y/G	AVSS	0.75	CN-473F			1	JS-B31
904	Y/G	AVSS	0.75	JS-B31				CN-534F
905	I/Y	AVSS	0.75	JS-B30				CN-216F
905	L/Y	AVSS	0.75	CN-473F			1	JS-B30
905	LY	AVSS	0.75	JS-B30			1	CN-535F
923	L/0	AVSS	0.75	CN-31F				CN-401M
924	G/0	AVSS	0.75	CN-31F			_	CN-401M
924 925	Y/G	AVSS	0.75	CN-31F			-	CN-401M
926	R	AVSS	0.75	CN-37F				CN-679F
927	0/W	AVSS	0.75	CN-37F				CN-679F
928	G/L	AVSS	0.75	CN-37F				JS-B48
928	G/L	AVSS	0.75	CN-473F				JS-B48
928	G/L	AVSS	0.75	CN-473F				JS-B48
929	R/Y	AVSS	0.75	CN-37F				CN-472F
930	Gr/R	AVSS	0.75	CN-32F				CN-883F
931	Br/W	AVSS	0.75	CN-32F				CN-883F
945	Y	AVSS	0.75	CN-432F				CN-470M
946	0/L	AVSS	0.75	CN-33F				CN-883F
947	P/G	AVSS	0.75	CN-32F				CN-883F
948	Lg	AVSS	0.75	CN-535F		-	DS-B227	CN-534F
948	Lg	AVSS	0.75	CN-530F	DS-B34	•	DS-B227	CN-534F
948	Lg	AVSS	0.75	CN-530F	DS-B34	•	DS-B39	CN-533F
948	Lq	AVSS	0.75	CN-33F			DS-B39	CN-533F
949	Br	AVSS	0.75	CN-531F	DS-B36			ON-32F
949	Br	AVSS	0.75	CN-531F	DS-B36			CN-530F
950	G	AVSS	0.75	CN-473F	00 000	-	DS-B37	CN-532F
950	G	AVSS	0.75	CN-533F			DS-B37	CN-532F
951	0	AVSS	0.75	CN-886F			DO DO1	CN-290M
958	G	AVSS	0.75	CN-31F			_	CN-403F
972	G/L	AVSS	0.75	CN-474F				CN-292M
973		AVSS	0.75	CN-292M				CN-474F
973	0/L	AVSS	0.75	CN-474F			+	CN-292M
	Gr/R							
975	G	AVSS	0.75	CN-307M			-	CN-886F
976	L	AVSS	0.75	CN-294M			-	CN-886F
977	G/Y	AVSS	0.75	CN-307M				CN-474F
978	Y/G	AVSS	0.75	CN-294M			1	CN-474F
981	W	AVSS	0.75	CN-897F7				CN-258F
982	L	AVSS	0.75	CN-897FJ				CN-258F
986	Y/G	AVSS	0.75	CN-427F				CN-884M
991	G	AVSS	0.75	CN-897F				CN-258F
992	P	AVSS	0.75	CN-897FJ				CN-258F
002	Υ	AVSS	0.75	CN-521F		•		CN-883F
002	Υ	AVSS	0.75	CN-521F				CN-473F
JP01A	Υ	AVSS	125	CN-440AM				(CN-440AM
JP01C	Υ	AVSS	125	(CN-440AM)			1	CN-440AM


WIRE NO.		WIRE TYPE	SIZE	FROM	2WIRE CONNECT NO.	CONNECTION	2WIRE CONNECT NO.	
392	0/B	AVSS	0.75	CN-291M		XXXX		CN-32F
393	Sb	AVSS	0.75	CN-291M				CN-32F
371	G	AVSS	0.75	CN-291M		7444		ON-472F
380	W	AVSS	0.75	CN-291M			+	CN-472F
396	P/W	AVSS	0.75	CN-291M		5000		CN-32F
397	Lq/W	AVSS	0.75	CN-291M				CN-32F
194		AVSS	0.75	CN-884M ¬			_	CN-33F
10.1	Y/B		_					
495	L/G	AVSS	0.75	CN-884M				CN-33F
496	G	AVSS	0.75	CN-884M				CN-33F
497	LY	AVSS	0.75	CN-884M				CN-33F
498	R/G	AVSS	0.75	CN-884M		7444		CN-33F
199	L/R	AVSS	0.75	CN-884M				CN-33F
355	L/W	AVSS	0.75	CN-414F			_	CN-293M
356 356		AVSS	0.75	CN-414F		+XXXX $-$		CN-293M
	Lg/B							
952	L/0	AVSS	0.75	CN-472F				CN-32F
953	G/B	AVSS	0.75	ON-32F		_>		CN-472F
954	Br/Y	AVSS	0.75	CN-32F				CN-472F
955	G/L	AVSS	0.75	CN-32F				CN-472F
441	W/B	AVSS	0.75	CN-290M			1	CN-474F
A42	W/L	AVSS	0.75	CN-290M		-***	1	CN-474F
√ +∠	W/L	n+35	0.13	CA COUNT	-		_	011 414
			0.55	CN1 4E-::				011 0
131	G	MVVS	0.75	CN-470M		1-1	1	CN-307M
132	В	MVVS	0.75	CN-470M		\perp		CN-307M
133	R	MVVS	0.75	CN-470M				CN-307M
137	W	MVVS	0.75	CN-470M				CN-307M
-58	B/R	AVSS	0.75	(CN-470F)				CN-307M
ES08	B/R	AVSS	0.75	CN-470M			_	(CN-307M)
_500	D/R	AVSS	0.15	CIV 410W				(CIN-30 (M)
194	R	MVVS	0.75	CN-427F		Δ		CN-307M
195	W	MVVS	0.75	CN-427F		 		CN-307M
196	В	MVVS	0.75	CN-427F		I——		CN-307M
ES10	B/R	MVVS	0.75	CN-427F				CN-307M
	D, 11							
508	W	MVVS	0.75	CN-294M				CN-403F
509	R	MVVS	0.75			\perp		CN-403F
				CN-294M				
510	В	MVVS	0.75	CN-294M				CN-403F
511	G	MVVS	0.75	CN-294M				CN-403F
E0	В	AVSS	1.25	CN-294M		-	DS-B228	LA-B05
EO	В	AVSS	0.75	CN-429F			DS-B228	LA-B05
EO	В	AVSS	0.75	CN-258F		_		LA-B10
E0	В	AVSS	0.75	CN-442F		7		
						<u> </u>		LA-B10
E0	В	AVSS	0.75	CN-442F				CN-258F
E03	В	AVSS	1.25	CN-440F			DS-B25	LA-B03
E03	В	AVSS	0.75	CN-499F	DS-B106	•	DS-B25	LA-B03
E03	В	AVSS	0.75	CN-499F	DS-B106	•	DS-B105	CN-432F
E03	В	AVSS	0.75	CN-438F	DS-B64	•	DS-B105	CN-432F
03	B	AVSS	0.75	CN-438F	DS-B64	•	DS-B63	CN-437F
-03	В	AVSS	0.75	CN-436F	DS-B229		DS-B63	CN-437F
						•		
E03	В	AVSS	0.75	CN-436F	DS-B229		DS-B104	CN-218F
E03	В	AVSS	0.75	CN-218F	DS-B103	•	DS-B104	CN-218F
E03	В	AVSS	0.75	CN-218F	DS-B103		DS-B237	CN-216F
E03	В	AVSS	0.75	CN-216F	DS-B238	•	DS-B237	CN-216F
E03	В	AVSS	0.75	CN-216F	DS-B238	•	DS-B234	CN-886F
E03	В	AVSS	0.75	CN-886F	DS-B235	•	DS-B234	CN-886F
E03	В	AVSS	0.75	CN-886F	DS-B235	_	DS-B239	CN-886F
E03	В	AVSS	0.75	LA-B07	DS-B75	•	DS-B239	CN-886F
E03	В	AVSS	0.75	LA-B07	DS-B75			CN-418M
011	В	AVSS	0.75	LA-B08	DS-B67	•		CN-416F
E011	В	AVSS	0.75	LA-B08	DS-B67			CN-415F
	В	AVS	2	LA-B11	DS-B43	•		CN-310F
E022	В	AVSS	0.75	LA-B11	DS-B43		DS-B242	B-2
	В	AVSS			D3 D43		DS-B242 DS-B242	B-2
E022			0.75	CN-411F	-		U5-B242	
E11	B/W	AVSS	0.75	CN-427F	DS-B108	•		CN-679F
	D 4-1	AVSS	0.75	CN-427F	DS-B108		DS-B109	CN-428F
E11	B/W							

(5/5)


8500-1 / 8500E-1 10-34 Published 12-16-15, Control #244-01



Published 12-16-15, Control #244-01 10-35 8500-1 / 8500E-1




8500-1 / 8500E-1 10-36 Published 12-16-15, Control #244-01




Published 12-16-15, Control #244-01 10-37 8500E-1

(3/6)




8500-1 / 8500E-1 10-38 Published 12-16-15, Control #244-01





NONE LA-B1B LA210 #1 E0 125 B + E0 125 B





(5/6)

THE WIRE NO. /COLOR LIST

WIRE NO	W/G	AVSS	0.75	CB-B12	2WIRE CONNECT NO.	CONNECTION	2WIRE CONNECT NO.	T 0
	-							
22	L/R	AVSS	0.75	CN-517M		l		CN-675F
22	L/R	AVSS	0.75	CN-517M				CN-239F
22	L/R	AVSS	0.75	CN-239F	DS-B200	•		CN-239F
22	_	AVSS	0.75	CN-239F	DS-B200		DS-B08	CN-485F
22	L/R		_		D3 B200		DS-B08	CN-485F
	L/R	AVSS	0.75	JS-B12			D2-B08	
22	L/R	AVSS	0.75	JS-B12				CN-35F
22	L/R	AVSS	0.75	JS-B12				CN-36F
24	Υ	AVSS	1.25	CN-300M				CN-516M
25	R	AVSS	0.75	CN-517M				CN-242F
28	Br	AVSS	2	CN-517M				CN-481F
	DI		_		_			
29	<u> </u>	AVSS	1.25	CN-517M				CN-882F
30	G/0	AVSS	1.25	CN-881F				CN-516M
32	R/W	AVSS	0.75	CN-513M	DS-B12	• •		CN-JB12F
32	R/W	AVSS	0.75	CN-513M	DS-B12	—		CN-JB12F
32	R/W	AVSS	0.75	CN-249F		-		CN-JB12F
32	R/W	AVSS	0.75	CN-249F				CN-JB12F
32	R/W	AVSS	0.75	CN-249F				CN-JB12F
32	R/W		0.75	CN-249F				
		AVSS				•		CN-JB12F
33	G/B	AVSS	0.75	CN-513M		•		CN-486F
33	G/B	AVSS	0.75	CN-513M				CN-675F
34	L/R	AVS	2	CN-513M	DS-809	•		CN-675F
34	L/R	AVSS	0.75	CN-513M	DS-B09			CN-JB12F
34 34	_		_		22 203	T		
	L/R	AVSS	0.75	CN-300M	1	P		CN-JB12F
34	L/R	AVSS	0.75	CN-406F	1	<u> </u>		CN-JB12F
35	Br	AVS	2	CN-513M				CN-675F
					1			
37	G	AVS	2	CN-515M	+	t	<u> </u>	CN-675F
38		AVS	2	CN-515M	+			CN-675F
	R/L		_		+		DC DCC:	
39	Y/B	AVSS	0.75	CN-300M	1	-	DS-B201	CN-515M
39	Y/B	AVSS	0.75	CN-890F	DS-B231		DS-B201	CN-515M
39	Y/B	AVSS	0.75	CN-890F	DS-B231		DS-B232	CN-890F
39	Y/B	AVSS	0.75	JS-B104			DS-B232	CN-890F
39	Y/B	AVSS	0.75	JS-B104				CN-36F
39	+	AVSS	0.75	JS-B104	_			CN-675F
	Y/B		_				50 540	
40	Br/W	AVSS	0.75	CN-675F			DS-B12	CN-516M
40	Br/W	AVSS	0.75	CN-522F	DS-B22	•	DS-B12	CN-516M
40	Br/W	AVSS	0.75	CN-522F	DS-B22			CN-675F
44	Gr	AVSS	0.75	CN-305M				CN-241F
45	W/B	AVSS	1.25	CN-516M				CN-JB12F
	_		_					
45	W/B	AVSS	1.25	CN-675F		<u> </u>		CN-JB12F
45	W/B	AVSS	1.25	CB-B10				CN-JB12F
46	0/L	AVSS	1.25	CN-516M		-	DS-B12	CN-235F
46	0/L	AVSS	0.75	CN-243F	DS-B22		DS-B12	CN-235F
46	0/L	AVSS	0.75	CN-243F	DS-B22			CN-891F
					00 022		-	
46	0/L	AVSS	0.75	CN-402M	-			CN-891F
47	R	AVSS	0.75	CN-492F			DS-47	CN-516M
47	R	AVSS	1.25	CN-JB11F		•	DS-47	CN-516M
47	R	AVSS	1.25	CN-JB11F		-		CN-34F
47	R	AVSS	1.25	CN-JB11F				CN-34F
48	R/L	AVSS	0.75	CN-516M	DS-B204			CN-30F
48	R/L	AVSS	0.75	CN-516M	DS-B204	<u> </u>		JS-B114
	_		_		D3 D204			
48	R/L	AVSS	0.75	CN-305M	1			JS-B114
48	R/L	AVSS	0.75	CN-430F		I —		JS-B114
48	R/L	AVSS	0.75	CN-431F				JS-B114
49	R/W	AVSS	1.25	CN-300M		l		CN-516M
51	Gr/B	AVSS	0.75	CN-516M	1			CN-35F
52	_	AVSS	_		+			
	Y/G		0.75	CN-305M	+	_		CN-235F
53	L/R	AVSS	0.75	CN-302M	1	-		CN-236F
53	L/R	AVSS	0.75	CN-236F				CN-236F
60	Br/R	AVSS	0.75	CN-676M		-	DS-B33	CN-526F
50	Br/R	AVSS	0.75	CN-527F	1		DS-B33	CN-526F
51	Br/W	AVSS	0.75	CN-527F	1			CN-302M
58	+	AVSS	0.75	CN-36F	+			CN-528F
	Y				1	-		
59		AVSS	0.75	CN-528F	1			CN-676M
70	W/Y	AVSS	0.75	CN-676M				CN-35F
81	W/G	AVSS	1.25	CN-JB11F		•		CN-243F
81	W/G	AVSS	1.25	CN-JB11F				CN-30F
81	W/G	AVSS	1.25	CN-JB11F	1			CN-30F
			_		nc_por	t <u>-</u>	 	
32	G/L	AVSS	0.75	CN-242F	DS-B05	-	DO 5 **	CN-300M
32	G/L	AVSS	1.25	CN-242F	DS-B05		DS-B40	CN-458F
32	G/L	AVSS	1.25	CN-JB04F		_	DS-B40	CN-458F
32	G/L	AVSS	0.75	CN-JB04F		1		CN-454M
32	G/L	AVSS	0.75	CN-JB04F				CN-453M
			_		1	+ T	 	
32	G/L	AVSS	0.75	CN-JB04F	1	1		CN-35F
32	G/L	AVSS	0.75	CN-JB04F	1	1		CN-452F
32	G/L	AVSS	0.75	CN-JB04F		1		CN-459F
32	G/L	AVSS	0.75	CN-JB04F	1			CN-460F
32 32		AVSS	0.75	CN-JB04F	1	I		CN-676M
	G/L				+	-		
33	0/W	AVSS	0.75	CN-305M	1	_		CN-241F
84	Υ	AVSS	0.75	CN-305M				CN-235F
142	Y	AVSS	0.75	CN-301M		1		CN-34F
144	R/Y	AVSS	0.75	CN-301M	1			CN-34F
	Br	AVSS	0.75	CN-30F	1			JS-B100
		[C * J]	10.10					N DIOO
150		A1/00	0.00				l .	IC- D400
150 150 150	Br Br	AVSS AVSS	0.75	CN-305M CN-405M				JS-B100 JS-B100

E CONNECT NO. CONNECT ION	ZWIRE CONNECT N	(EJ M.) [] (Ch - 32) [Ch - 32)
		CN-36 CN-37
		CN-35 CN-35 S-81 S-81 S-81 S-81 S-81 S-81 S-81 S-81
		CN-36 US-81
		JS-81
		JS-81
		JS-81
		JS-81
		JS-81
		JS-81
		JS-81
		JS-81
		JS-81
		JS-B1
		JS-81
		JS-81
		JS-81
		JS-81
		JS-B1
		JS-B1 CN-34 CN-36 CN-46
		JS-B1
		US-B1
		US-B1
		JS-B1 JS-B1 JS-B1 JS-B1 JS-B1 ON-34 ON-30 ON-30 ON-30 ON-30 ON-30 ON-30 ON-46
		JS-B1 JS-B1 JS-B1 JS-B1 JS-B1 ON-34 ON-30 ON-30 ON-30 ON-30 ON-30 ON-30 ON-46
		JS-B1
		JS-B1
		JS-B1 ON-32 ON-32 ON-32 ON-32 ON-32 ON-32 ON-32 ON-46
		ON-34 ON-30 ON-30 ON-30 ON-30 ON-30 ON-30 ON-30 ON-46
		CN-3C CN-3C CN-3C CN-3C CN-3C CN-3C CN-4C CN-4C CN-3C CN-4C CN-3C CN-4C CN-4C CN-3C CN-3C CN-3C CN-3C CN-3C CN-3C CN-3C
		CN-30 CN-30 CN-26 CN-30 CN-30 CN-46 CN-46 CN-46 CN-46 CN-46 CN-46 CN-46 CN-46 CN-46
		CN-30 CN-30 CN-26 CN-30 CN-30 CN-46 CN-46 CN-46 CN-46 CN-46 CN-46 CN-46 CN-46 CN-46
		CN-30 CN-26 CN-30 CN-30 CN-46 CN-46 CN-46 CN-46 CN-46 CN-46 CN-46 CN-46 CN-46
		CN-26 CN-3C CN-3C CN-3C CN-46 CN-47 CN-47 CN-47 CN-48
		CN-30 CN-30 CN-46 CN-46 CN-46 CN-30 CN-46 CN-30 CN-46 CN-30 CN-45 CN-45
		CN-3C CN-46 CN-46 CN-46 CN-3C CN-46 CN-3C CN-46 CN-46 CN-45 CN-45
		CN-3C CN-46 CN-46 CN-3C CN-46 CN-46 CN-3C CN-45 CN-45
		CN-46 CN-46 CN-30 CN-46 CN-46 CN-46 CN-30 CN-45 CN-45
		CN-46 CN-46 CN-30 CN-46 CN-46 CN-46 CN-30 CN-45 CN-45
		CN-46 CN-30 CN-30 CN-46 CN-46 CN-30 CN-45 CN-45
		CN-46 CN-30 CN-46 CN-46 CN-30 CN-45 CN-45
		CN-30 CN-46 CN-46 CN-30 CN-45 CN-45
		CN-46 CN-46 CN-30 CN-45 CN-45
		CN-46 CN-30 CN-45
		CN-30 CN-45 CN-45
		CN-45 CN-45
		CN-45 CN-45
		CN-45
	-	
	-	11,4/1-1/10
	-	
	-	CN-48
	-	CN-48
	-	CN-40
	-	CN-89
		CN-40
		CN-30
	-	CN-48
	- T	CN-45
		CN-30
	DS-B41	
- /-1	4	
	DS-B41	
	-	CN-30
	-	CN-45
	-	UN-45
	DS-B23	
		CN-40
	(LEADER 12)	CN-40 3 CN-52
	DS-B23	CN-40 3 CN-52 3 CN-52
	US-B23	CN-40 3 CN-52
	U5-B23	CN-40 3 CN-52 3 CN-52 CN-36
	US=B23	CN-40 3 CN-52 3 CN-52
	US-823	CN-40 3 CN-52 3 CN-52 CN-36
		CN-40 3 CN-52 3 CN-52 CN-36 CN-30 CN-30
	(US-BZ3	CN-40 3 CN-52 3 CN-52 CN-36
	(US-1523	CN-40 3 CN-52 3 CN-52 CN-36 CN-30 CN-30
	(US-1523	CN-40 CN-52 CN-36 CN-36 CN-36 CN-26 CN-45
	US-BZ3	CN-40 3 CN-52 3 CN-52 CN-30 CN-30 CN-30 CN-26 CN-45
	US-1523	CN-40 3 CN-52 3 CN-52 CN-30 CN-30 CN-30 CN-26 CN-45 CN-45 CN-45 CN-45
	LD-1623	CN-40 3 CN-52 3 CN-52 CN-30 CN-30 CN-30 CN-26 CN-45
	LD-1523	CN-40 3 CN-52 3 CN-52 CN-30 CN-30 CN-30 CN-26 CN-45 CN-45 CN-45 CN-45
	LD-1523	CN-46 3 CN-52 3 CN-52 CN-36 CN-36 CN-36 CN-26 CN-26 CN-45 CN-45 CN-45 CN-45 CN-45 CN-45 CN-45
	US-1523	CN-46 3 CN-52 3 CN-52 CN-36 CN-36 CN-36 CN-26 CN-26 CN-45 CN-45 CN-45 CN-45 CN-45 CN-45 CN-45
	LD-1523	CN-4(3) CN-3(3) CN-3(3) CN-3(3) CN-3(3) CN-3(4) CN-4(5) CN-3(4) CN-3(5) CN-2(5) CN-2(5) CN-3(5) CN-2(5) CN-3(5) CN-3(5
	US-1523	CN-46 3 CN-52 3 CN-52 CN-36 CN-36 CN-36 CN-26 CN-46 CN-46 CN-36
	US-1523	CN-4(2) 3 CN-52 3 CN-52 CN-32
	US-1523	CN-46 3 CN-52 3 CN-52 CN-36 CN-37
	US-1523	CN-46 3 CN-52 3 CN-52 CN-30 CN-30 CN-30 CN-30 CN-30 CN-32
	US-1523	CN-46 3 CN-52 3 CN-52 CN-36 CN-37
	US-1523	CN-46 3 CN-52 3 CN-52 CN-30 CN-30 CN-30 CN-30 CN-30 CN-32
	US-1523	CN-46 3 CN-52 3 CN-52 CN-36 CN
	US-1523	CN-46 3 CN-52 3 CN-52 CN-36 CN
	US-1523	CN-46 3 CN-52 3 CN-52 CN-36 CN
	US-1523	CN-46 3 CN-52 3 CN-52 CN-36 CN-36 CN-36 CN-36 CN-26 CN-26 CN-36 CN
	US-1523	CN-4(2) 3 CN-52 3 CN-32
	LD-1523	CN-46 3 CN-52 3 CN-52 CN-36 CN-36 CN-36 CN-36 CN-26 CN-26 CN-36 CN
	US-1523	CN-46 8 CN-52 8 CN-52 CN-32 CN
	US-1523	CN-46 3 CN-52 3 CN-52 CN-32
	US-1523	CN-46 3 CN-52 3 CN-52 CN-36 CN-36 CN-36 CN-36 CN-26 CN-26 CN-36 CN
		CN-46 3 CN-52 3 CN-52 5 CN-36
	US-1523	CN-46 8 CN-52 8 CN-52 CN-32 CN
	US-1523	CN-46 3 CN-52 3 CN-52 5 CN-36


WIRE NO.	MIBE LUI VO	WIRE TYPE	SIZE	FROM	2WIRE CONNECT NO.	CONNECTION	2WIRE CONNECT NO.	T 0
WIKE NU. 431	R/G	AVSS	0.75	JS-B41	ZWINE CUNNECT NO.	CONNECTION	ZMINE CONNECT NO.	CN-304M
131	R/G	AVSS	0.75	JS-B41	1			CN-34F
431	R/G	AVSS	0.75	CN-676M				JS-B41
432	0/W	AVSS	0.75	JS-B42				CN-304M
432	0/W	AVSS	0.75	JS-B42				CN-34F
132	0/W	AVSS	0.75	JS-B42	1			CN-676M
433	P/G	AVSS	0.75	CN-302M	1			CN-676M
434	G/B	AVSS	0.75	CN-30F				CN-676M
436	W/Y	AVSS	0.75	CN-30F				CN-304M
437	0	AVSS	0.75	JS-B35	_			CN-304M
437	0	AVSS	0.75	CN-30F				JS-B35
437	0	_	_		-			
431 440	10	AVSS	0.75	CN-30F CN-304M	-			JS-B35
440	W/R	AVSS	_					JS-B34
	W/R	AVSS	0.75	JS-B34				CN-30F
440	W/R	AVSS	0.75	JS-B34				CN-676M
443	0/L	AVSS	0.75	CN-34F				CN-303M
146	G	AVSS	0.75	CN-303M				CN-235F
147	P	AVSS	0.75	CN-304M				CN-30F
149	Br/L	AVSS	0.75	CN-36F				CN-303M
450	P/G	AVSS	0.75	CN-303M				CN-36F
451	L/B	AVSS	0.75	CN-303M				CN-35F
452	0/B	AVSS	0.75	CN-303M				CN-36F
154	R/Y	AVSS	0.75	CN-305M				CN-490F
457	W/Y	AVSS	0.75	CN-36F				CN-261F
458	L/B	AVSS	0.75	CN-676M		-		CN-JB13F
458	L/B	AVSS	0.75	CN-300M				CN-JB13F
458	L/B	AVSS	0.75	CN-249F		I		CN-JB13F
458	L/B	AVSS	0.75	CN-260F		I		CN-JB13F
459	L9	AVSS	0.75	CN-239F				CN-303M
461	Y/B	AVSS	0.75	CN-30F				CN-456M
462		AVSS	0.75	CN-455M				CN-30F
	G/0	_			DC=D32			
164	P	AVSS	0.75	CN-526F	DS-B32	•		CN-35F
464	1	AVSS	0.75	CN-526F	DS-B32			CN-484F
465	Gr	AVSS	0.75	CN-36F				CN-465F
466	G/W	AVSS	0.75	CN-30F	14			CN-677F
467	P/W	AVSS	0.75	CN-30F				CN-677F
469	L	AVSS	0.75	CN-301M				CN-492F
474	L/B	AVSS	0.75	CN-34F				CN-303M
475	G	AVSS	0.75	CN-36F				CN-464F
478	G/Y	AVSS	0.75	CN-490F				CN-476F
479	0/B	AVSS	0.75	CN-431F				CN-30F
480	Br/B	AVSS	0.75	CN-430F				CN-30F
487	Y/W	AVSS	0.75	CN-677F	1			CN-485F
754	Y/R	AVSS	0.75	CN-35F				CN-300M
B11	R/W	AVS	1.25	CN-677F				CN-481F
812	P/L	AVSS	0.75	CN-677F				CN-881F
813	P	AVS	1.25	CN-881F				CN-677F
B14			0.75		-			
	Y	AVSS	_	CN-889F				CN-891F
815	G	AVSS	0.75	CN-889F				CN-891F
	-							
331	G/Y	AVSS	0.75	CN-482F				CN-483F
332	L/W	AVSS	0.75	CN-482F				CN-483F
333	L/R	AVSS	0.75	CN-482F	-	<u> </u>		CN-483F
334		AVSS	0.75	CN-482F				CN-483F
	Y/W	AVSS			-			CN-483F
335	Y/R		0.75	CN-482F				
336	G/W	AVSS	0.75	CN-482F	_			CN-483F
337	G/R	AVSS	0.75	CN-482F				CN-483F
338	L/Y	AVSS	0.75	CN-482F				CN-483F
339	B/G	AVSS	0.75	CN-482F		l		CN-484F
340	L/G	AVSS	0.75	CN-482F				CN-484F
341	L	AVSS	0.75	CN-484F		<u> </u>		CN-482F
342	G	AVSS	0.75	CN-483F				CN-482F
343	Υ	AVSS	0.75	CN-483F				CN-482F
344	G/L	AVSS	0.75	CN-483F				CN-482F
345	Y/L	AVSS	0.75	CN-483F				CN-482F
346	R/B	AVSS	0.75	CN-483F				CN-481F
347	R/L	AVS	0.85	CN-483F				CN-481F
348	Br/Y	AVSS	0.75	CN-483F	†	<u> </u>		CN-481F
349	Br/W	AVSS	0.75	CN-481F	_			CN-483F
349 358		AVSS	_					
	Br/G		0.75	CN-300M	_			CN-34F
922	Br/W	AVSS	0.75	CN-34F				CN-300M
344	Br	AVSS	0.75	CN-34F				CN-677F
951	0	AVSS	0.75	CN-890F				CN-305M
959	L	AVSS	0.75	CN-36F				CN-402M
962	L/G	AVSS	0.75	CN-890F		l		CN-303M
502	W/O	AVSS	0.75	CN-36F				CN-301M
	0	AVSS	0.75	CN-882F	DS-B206	•		CN-484F
966	Ю		1.25	CN-882F	DS-B206			JS-B102
966 984	0	AVS	125	CIN UULI				
966 984 984		AVS AVS	1.25	CN-481F				JS-B102
966 984 984 984	0	AVS	1.25	CN-481F				JS-B102
966 984 984 984 984 985	0		_					-

WIRE NO			_	FROM	2WIRE CONNECT NO.	CONNECTION	2WIRE CONNECT NO	
983	P/G	AVSS	0.75	CN-30F		-		CN-235F
983	P/G	AVSS	0.75	CN-882F		•—/		CN-235F
983	P/G	AVSS	0.75	CN-882F			DS-01	CN-241F
		_	_			 		
983	P/G	AVSS	0.75	CN-242F	DS-02	•	DS-01	CN-241F
983	P/G	AVSS	0.75	CN-242F	DS-02			CN-243F
123		AVSS	0.75	CN-406F		1		CN-250F
_	Ch	_	_		+			
124	Sb	AVSS	0.75	CN-406F				CN-250F
425	P	AVSS	0.75	CN-406F				CN-250F
426	R	AVSS	0.75	CN-406F				CN-250F
			_					
427	W	AVSS	0.75	CN-406F				CN-250F
428	В	AVSS	0.75	CN-406F				CN-250F
_	-	_	_		+			
429	Y	AVSS	0.75	CN-406F				CN-250F
430	G	AVSS	0.75	CN-406F				CN-250F
431	W/Y	AVSS	0.75	CN-406F				CN-250F
	_	_	_					
432	R	AVSS	0.75	CN-406F				CN-660F
433	G/W	AVSS	0.75	CN-660F				CN-250F
A38	Y	AVSS	0.75	CN-249F				CN-249F
	-		_					
A39	G	AVSS	0.75	CN-249F				CN-249F
119	Y	AVSS	0.75	CN-JB17F				CN-300M
	_	_	_		1	+ T \\\\		
120	L	AVSS	0.75	CN-JB17F		P / V V V _		CN-300M
119	Y	AVSS	0.75	CN-JB17F		H		CN-676M
120	1	AVSS	0.75	CN-JB17F	1	11 1 XXXX		CN-676M
	-				1	PT * * * ` `	-	
119	Υ	AVSS	0.75	CN-JB17F				CN-405M
120	L	AVSS	0.75	CN-JB17F		INXXXX		CN-405M
			_		1	 	-	
119	Y	AVSS	0.75	CN-JB17F	1	HANNE	-	CN-486F
120	L	AVSS	0.75	CN-JB17F				CN-486F
119	Y	AVSS	0.75	CN-JB17F	1	11		CN-249F
	_		_		+	"	-	
120	L	AVSS	0.75	CN-JB17F		-		CN-249F
378	P/W	AVSS	0.75	CN-301M		- A A A	l	CN-451F
379		AVSS	0.75	CN-301M	1	1 XXXX		CN-451F
	Y/G		_		_			
388	B/Y	AVSS	0.75	CN-467F			DS-B30	CN-466F
388	B/Y	AVSS	0.75	CN-301M			DS-B30	CN-466F
		_	_		+	LXXXX •		
389	G/R	AVSS	0.75	CN-301M	1	<u> </u>	DS-B31	CN-466F
389	G/R	AVSS	0.75	CN-467F		I——	DS-B31	CN-466F
390	L/0	AVSS	0.75	CN-469F	1	l	DS-B28	CN-468F
	_		_		+	+		
390	L/0	AVSS	0.75	CN-301M	1		DS-B28	CN-468F
391	Br	AVSS	0.75	CN-301M		_^	DS-B29	CN-468F
391	Br	AVSS	0.75	CN-469F		 	DS-B29	CN-468F
			_		+	+	JU 1063	
488	P/G	AVSS	0.75	CN-34F				CN-301M
489	G	AVSS	0.75	CN-34F				CN-301M
490	_	AVSS	0.75	CN-34F	1	· -		CN-300M
	P/L		_			 		
491	Gr/W	AVSS	0.75	CN-34F		-///		CN-300M
492	R/B	AVSS	0.75	CN-34F				CN-300M
		_	_		+	+ - > > > > > > -		_
493	W/Y	AVSS	0.75	CN-34F	1	1~~~~		CN-300M
419	Y/R	AVSS	0.75	CN-677F				CN-250F
A20	Y/L	AVSS	0.75	CN-677F		 XXXX 		CN-250F
			_		-	v v v C		
421	B/W	AVSS	0.75	CN-677F				CN-250F
A22	L/W	AVSS	0.75	CN-677F		_XXXX_		CN-250F
A41	В	AVSS	0.75	CN-305M				CN-250F
			_			 \ 		
442	W/L	AVSS	0.75	CN-305M				CN-250F
A56	Br	AVSS	0.75	CN-406F				CN-JB13
A57	R/W	AVSS	0.75	CN-406F		XXXXI.		CN-JB13F
			_			- · · ·) 		
A56	Br	AVSS	0.75	CN-249F		I ¬ ^ ^ H		CN-JB13F
A57	R/W	AVSS	0.75	CN-249F				CN-JB13F
A56	Br	AVSS	0.75	CN-677F	1	<u> </u>		CN-JB13F
			_			1 <u>-</u>		
A57	R/W	AVSS	0.75	CN-677F		_XXXX_		CN-JB13F
=0	В	AVSS	1.25	W-300*4	+	<u> </u>	ng_pec	I A_D40
<u>=</u> 0			_	CN-300M		-	DS-B68	LA-B18
ΕO	В	AVSS	1.25	CN-304M			DS-B68	LA-B18
E08	В	AVSS	0.75	CN-243F	1	l		CN-242F
		_	_		+			
E08	В	AVSS	0.75	CN-241F	1	•		CN-242F
E08	В	AVSS	0.75	CN-241F		•		CN-882F
E08	В	AVSS	0.75	CN-881F	1			CN-882F
	_		_		1	1		
E08	В	AVSS	0.75	CN-881F				CN-485F
E08	В	AVSS	1.25	CN-489F		•		CN-485F
E08	В		1.25	CN-489F		-		LB-B02
		AVSS	_		+		-	
E08	В	AVSS	0.75	CN-433F		<u> </u>		LB-B02
E08	В	AVSS	0.75	CN-433F	1		l	CN-486F
		1	15.15	5.1 700	1			3., 400
	+	1	+					1
E013	В	AVSS	0.75	CN-464F				CN-476F
E013	В	AVSS	0.75	LA-B04		I .		CN-476F
			_			1		
E013	В	AVSS	0.75	LA-B04	l			CN-465F
E025	В	AVSS	1.25	LA-B12	DS-B65	•		CN-35F
_020	В	AVSS	1.25	LA-B12	DS-B65			CN-35F
			_		1 200		-	
E025	B	AVS	0.85	CA-B10	1			CN-484F
E025 E027	_	AVSS	1.25	CA-B10	1	\		LA-B14
E025 E027	В	_	1.25	CN-481F		 /		LA-B14
E025 E027 E027					DO 515	+	-	
025 027 027 027	В	AVSS	0.75	LA-B01	DS-B19	•		CN-430F
025 027 027 027 027	B B	AVSS	0.10	LA-B01	DS-B19		I	CN-431F
025 027 027 027 027	В		0.75		1			1
025 027 027 027 027	B B	AVSS	_	C		1 — — —		
025 027 027 027 027	B B	AVSS	_					
025 027 027 027 027	B B	AVSS	_					
E025 E027 E027 E027 E028 E028	B B B	AVSS AVSS	0.75			•		CN-406F
E025 E027 E027 E027 E028 E028	B B B	AVSS AVSS AVSS	1.25	CN-JB14F		1		
E025 E025 E027 E027 E027 E028 E028	B B B	AVSS AVSS	0.75	CN-JB14F CN-JB14F		1		CN-406F CN-249F
E025 E027 E027 E027 E028 E028 E18	B B B	AVSS AVSS AVSS AVSS	0.75 1.25 0.75	CN-JB14F CN-JB14F				CN-249F
E025 E027 E027 E027 E028 E028 E18 E18	B B B B/W B/W	AVSS AVSS AVSS AVSS AVSS	0.75 1.25 0.75 0.75	CN-JB14F CN-JB14F CN-JB14F				CN-249F CN-249F
E025 E027 E027 E027 E028 E028 E18 E18 E18 E18	B B B B/W B/W B/W	AVSS AVSS AVSS AVSS AVSS AVSS	0.75 1.25 0.75 0.75 0.75	CN-JB14F CN-JB14F CN-JB14F CN-JB14F				CN-249F CN-249F CN-249F
E025 E027 E027 E027 E028 E028 E18 E18	B B B B/W B/W	AVSS AVSS AVSS AVSS AVSS	0.75 1.25 0.75 0.75	CN-JB14F CN-JB14F CN-JB14F				CN-249F CN-249F CN-249F
E025 E027 E027 E027 E028 E028 E18 E18 E18 E18 E18	B B B B/W B/W B/W B/W	AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 1.25 0.75 0.75 0.75 0.75	CN-JB14F CN-JB14F CN-JB14F CN-JB14F CN-JB14F				CN-249F CN-249F CN-249F CN-JB14F
E025 E027 E027 E027 E028 E028 E18 E18 E18 E18 E18 E18	B B B B/W B/W B/W B/W B/W	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 1.25 0.75 0.75 0.75 0.75 0.75	CN-JB14F CN-JB14F CN-JB14F CN-JB14F CN-JB14F CN-JB14F				CN-249F CN-249F CN-JB14F CN-JB14F
E025 E027 E027 E027 E028 E028 E18 E18 E18 E18 E18	B B B B/W B/W B/W B/W	AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 1.25 0.75 0.75 0.75 0.75	CN-JB14F CN-JB14F CN-JB14F CN-JB14F CN-JB14F				CN-249F CN-249F CN-249F CN-JB14F


(6/6)

8500-1 / 8500E-1 10-40 Published 12-16-15, Control #244-01

2. LOWER




(1/2)




(2/2)

8500-1 / 8500E-1 10-42 Published 12-16-15, Control #244-01


(1/4)





(2/4)

8500-1 / 8500E-1 10-44 Published 12-16-15, Control #244-01




THE WIRE NO./COLOR LIST

WIRE NO.	WIRE COLOR	WIDE TYPE	SIZE	FROM	% 1	CONNECTION	×1	
11	W/G	AVSS	1.25	CN-909F		CONNECTION	**1	CN-903F
26	w/G	AVSS	1.25	CN-J91F				CN-903F
	L							
26	L	AVSS	1.25	CN-J91F				CN-910F
26	L	AVSS	0.75	CN-J91F		•		CN-909F
441	Y/B	AVSS	1.25	CN-906M				CN-909F
442	R/B	AVSS	1.25	CN-906M				CN-909F
444	G/R	AVSS	1.25	CN-907F				CN-909F
455	L/Y	AVSS	1.25	CN-907F				CN-909F
614	W/Y	AVSS	1.25	CN-913F				CN-908M
862	G/O	AVSS	1.25	CN-907F				CN-909F
904		AVSS	1.25	CN-904F			DS3	CN-920F
	Y/G				DC 4			
904	Y/G	AVSS	0.75	CN-921F	DS4	•	DS3	CN-920F
904	Y/G	AVSS	0.75	CN-921F	DS4			CN-926F
905	L/Y	AVSS	1.25	CN-904F		•	DS1	CN-918F
905	L/Y	AVSS	0.75	CN-919F	DS2	•	DS1	CN-918F
905	L/Y	AVSS	0.75	CN-919F	DS2			CN-926F
932	Br/R	AVSS	0.75	CN-917F				CN-922F
933	Р	AVSS	0.75	CN-917F				CN-924F
934	0	AVSS	0.75	CN-917F				CN-922F
935	G/B	AVSS	0.75	CN-917F		<u> </u>		CN-924F
936	Y/G	AVSS	0.75	CN-J92F				CN-917F
936	Y/G	AVSS	0.75	CN-J92F		†		CN-920F
936	Y/G	AVSS	0.75	CN-J92F		-		CN-922F
937	W/Y	AVSS	0.75	CN-J92F		-		CN-917F
937	W/Y	AVSS	0.75	CN-J92F		-		CN-921F
937	W/Y	AVSS	0.75	CN-J92F		-		CN-922F
938	R/L	AVSS	0.75	CN-J92F		-		CN-917F
938	R/L	AVSS	0.75	CN-J92F				CN-918F
938		AVSS	0.75	CN-J92F		I		CN-924F
	R/L					-		
939	O/W	AVSS	0.75	CN-J92F		1		CN-917F
939	O/W	AVSS	0.75	CN-J92F		<u> </u>		CN-919F
939	O/W	AVSS	0.75	CN-J92F		-		CN-924F
940	B/L	AVSS	0.75	CN-917F				CN-923F
941	Lg	AVSS	0.75	CN-917F				CN-925F
942	R/W	AVSS	0.75	CN-917F				CN-923F
943	L/0	AVSS	0.75	CN-917F				CN-925F
950	G	AVSS	1.25	CN-909F				CN-903F
972	G/Y	AVSS	1.25	CN-910F				CN-908M
973	0/L	AVSS	1.25	CN-910F				CN-908M
974	Gr/R	AVSS	1.25	CN-910F				CN-908M
C02	Y	AVSS	1.25	CN-907F				CN-909F
C03	R/B	AVSS	1.25	CN-905M				CN-927F
C04	G/R	AVSS	1.25	CN-905M				CN-927F
C05	L/R	AVSS	1.25	CN-905M				CN-927F
E01	В	AVSS	0.75	CN-J94F		•	DS5	LA-F1
E02	В	AVSS	0.75	CN-J94F				CN-926F
E03	В	AVSS	0.75	CN-J94F				CN-926F
						I		
E04	В	AVSS	0.75	CN-J94F		I		CN-922F
E05	В	AVSS	0.75	CN-J94F				CN-922F
E030	В	AVSS	0.75	CN-J94F		• •		CN-J94F
E07	В	AVSS	0.75	LA-F2	DS6	• •		CN-J94F
E08	В	AVSS	0.75	CN-922F		1		CN-J94F
E09	В	AVSS	0.75	CN-922F		-		CN-J94F
E010	В	AVSS	0.75	CN-923F		-		CN-J94F
E011	В	AVSS	0.75	CN-923F				CN-J94F
E021	В	AVSS	0.75	CN-J95F			DS5	
								LA-F1 CN-924F
E022	В	AVSS	0.75	CN-J95F		I		
E023	В	AVSS	0.75	CN-J95F				CN-924F
E024	В	AVSS	0.75	CN-J95F		1		CN-924F
E025	В	AVSS	0.75	CN-J95F		+		CN-924F
E031	В	AVSS	0.75	CN-J95F		+		CN-J95F
E027	В	AVSS	0.75	LA-F2	DS6			CN-J95F
E028	В	AVSS	0.75	CN-925F				CN-J95F
E029	В	AVSS	0.75	CN-925F				CN-J95F
	В	AVSS	0.75	CN-913F		I		CN-J95F
E0								

*1 TWO WIRE CONNECT NUMBER





8500-1 / 8500E-1 10-46 Published 12-16-15, Control #244-01



UPPER HARNESS










CN-499M 2MY-CNA


THE WIRE NO. / COLOR LIST

WIRE NO.	WIRE COLOR	WIRE TYPE	SIZE	F R	0	М	% 1	CONNECTION	 *1	T 0
468	0	AVSS	0.75	CN-499N	Л					CN-497F
477	Υ	AVSS	0.75	CN-497F	=					CN-498F
E08	В	AVSS	0.75	CN-499N	1					CN-498F

*1 TWO WIRE CONNECT NUMBER


8500-1 / 8500E-1 10-48 Published 12-16-15, Control #244-01






8500-1 / 8500E-1 10-50 Published 12-16-15, Control #244-01


(2/7)




(3/7)



8500-1 / 8500E-1 10-52 Published 12-16-15, Control #244-01




(5/7)




(6/7)

8500-1 / 8500E-1 10-54 Published 12-16-15, Control #244-01




(7/7)


MAIN HARNESS



Published 12-16-15, Control #244-01




(2/5)



8500-1 / 8500E-1 10-58 Published 12-16-15, Control #244-01

(4/5)





				DR LIST																	
WIRE NO	. WIRE COLOR	AVSS	1.25	FROM CN-849M	ID. SYMBOL	2WIRE CONNECT NO.	CONNECTION	2WIRE CONNECT NO.	ID. SYMBOL	T 0 CN-851F	WIRE NO. 549	V/R	AVSS	0.75	FROM CN-114F	ID. SYMBOL	2WIRE CONNECT NO.	CONNECTION	2WIRE CONNECT NO.	ID. SYMBOL	T 0 CN-813F
11	W/G	AVSS		CN-854F		DS-E21	•			CN-716F	550	P/W	AVSS		CN-114F						CN-813F
11	W/G	AVSS		CN-854F		DS-E21				CN-854F		Gr/B	AVSS		CN-114F						CN-813F
14 15	G/R Br	AVSS	0.75	CN-115F CN-40F						CN-404M CN-401F	552 553	W/R B/W	AVSS	0.75	CN-114F CN-114F						CN-815F CN-815F
17	0	AVSS	0.75	CN-404M						CN-950F	554	R/B	AVSS	0.75	CN-114F						CN-815F
31 34	L	AVSS	0.75	CN-116F CN-406M						CN-404M CN-657M	555 556	Y/R	AVSS		CN-114F CN-114F						CN-814F CN-814F
37	L/R G	AVS	2	CN-848F						CN-852M	557	Lg/W L/B	AVSS		CN-114F						CN-814F
38	R/L	AVS	2	CN-871F						CN-852M	597	P/L	AVSS	0.75	CN-JE4F			•			CN-117F
41	0	AVSS		CN-JE5F CN-JE5F						CN-404M CN-115F	597 597	P/L	AVSS		CN-JE4F CN-JE4F			<u> </u>			CN-836F CN-40F
41	0	AVSS	1.25	CN-JE5F			-			CN-115F	598	P/L L	AVSS	0.75	CN-JE4F			•			CN-117F
42	Р	AVSS		CN-JE4F			•			CN-404M	598	L	AVSS		CN-JE4F			+			CN-837F
42 42	P	AVSS		CN-JE4F CN-JE4F						CN-117F CN-116F	598 601	R/W	AVSS		CN-JE4F CN-851F			•			CN-40F CN-119F
42	P	AVSS		CN-JE4F			-			CN-115F	604	L/B	AVSS		CN-119F						CN-838F
43	R/Y	AVSS		CN-JE5F			<u> </u>			CN-404M	605	Y/R	AVSS		CN-119F						CN-851F
43 43	R/Y	AVSS AVSS	0.75	CN-JE5F CN-JE5F						CN-40F CN-851F		G R/G	AVSS AVSS	0.75	CN-119F CN-119F						CN-40F CN-40F
45	W/B	AVSS	1.25	CN-709F						CB-E2		Br/R	AVSS	0.75	CN-119F						CN-840F
46 145	0/L	AVSS AVSS	0.75	CN-849M						CN-402F CN-403M		P/L	AVSS AVSS		CN-119F						CN-841F
146	Y/L Gr	AVSS	0.75	CN-116F CN-116F						CN-403M		Gr/B B/Y	AVSS		CN-716F CN-716F						CN-119F CN-119F
147	0/L	AVSS	0.75	CN-115F						CN-404M	612	W/L	AVSS	0.75	CN-716F						CN-119F
148 149	G/W L/W	AVSS		ON-115F ON-115F						CN-403M CN-403M	614 615	W/Y	AVSS AVSS		CN-115F CN-700F						CN-716F CN-117F
150	Br Br	AVSS		ON-117F						CN-405F		W/Y Br/W	AVSS		CN-700F						CN-117F
161	Y/R	AVSS	0.75	CN-401F						CN-40F	617	Y/G	AVSS	0.75	CN-851F						CN-848F
166 167	Lg/W Lg/Y	AVSS		CN-404M CN-404M						CN-116F CN-116F	617 617	Y/G Y/G	AVSS		CN-851F CN-851F						CN-871F CN-117F
176	Gr/W	AVSS	0.75	CN-JE1F			•			CN-403M	618	Lg	AVSS	0.75	CN-700F						CN-114F
176	Gr/W	AVSS	_	CN-JE1F						CN-40F	619	L	AVSS	_							CN-114F
176 212	Gr/W G/W	AVSS		CN-JE1F CN-842F						CN-117F CN-404M		G O	AVSS AVSS		CN-709F CN-114F						CN-114F CN-709F
213	Y/W	AVSS	0.75	CN-842F						CN-404M	622	Р	AVSS	0.75	CN-114F						CN-709F
214 215	R/W W	AVSS	0.75	CN-842F CN-405F						CN-404M CN-JE3F	750 751	W/R G/R	AVSS	0.75	CN-401F CN-845F						CB-E3 CN-709F
215	W	AVSS		CN-40F						CN-JE3F	752	Lg/R	AVSS		CN-844F						CN-709F
215	W	AVSS		CN-117F			•			CN-JE3F		R/W	AVSS		CN-846F						CN-700F
216 216	B/R B/R	AVSS AVSS		CN-405F CN-41F						CN-JE3F CN-JE3F		P/L P	AVSS	1.25	CN-846F CN-700F						CN-700F CN-847F
216	B/R	AVSS		CN-117F			-			CN-JE3F	860	Y/L	AVSS		CN-854F			•	DS-E29		E-3
217 217	Lg/Y	AVSS	0.75	CN-405F CN-40F			1			CN-JE3F CN-JE3F	860	Y/L	AVSS		E-1 CN-854F				DS-E29		E-3 CN-401F
217	Lg/Y Lg/Y	AVSS	0.75	CN-40F						CN-JE3F	861 923	L/Y	AVSS	0.75	CN-823F						CN-401F
218	L/0	AVSS	0.75	CN-405F			•			CN-JE3F	924	G/0	AVSS	0.75	CN-822F						CN-401F
218 218	L/0 L/0	AVSS		CN-41F CN-117F						CN-JE3F CN-JE3F	925 925	Y/G	AVSS	0.75	CN-JE2F CN-JE2F			1			CN-819F CN-820F
219	Y/B	AVSS		CN-405F			•			CN-JE6F	925	Y/G Y/G	AVSS	_	CN-JE2F			1.			CN-JE2F
219	Y/B	AVSS	_	CN-41F			-			CN-JE6F	925	Y/G	AVSS	_	CN-821F						CN-JE2F
219 220	Y/B G/Y	AVSS	0.75	CN-117F CN-405F			•			CN-JE6F CN-JE6F	925 956	Y/G L/Y	AVSS	0.75	CN-401F CN-118F			•			CN-JE2F CN-851F
220	G/Y	AVSS	0.75	CN-41F						CN-JE6F	956	L/Y	AVSS	0.75	CN-716F						CN-851F
220	G/Y	AVSS	_	CN-117F			•			CN-JE6F	958	G	AVSS	_	CN-118F			_	DS-E23		CN-816F
221 221	P/B P/B	AVSS		CN-405F CN-40F						CN-JE6F CN-JE6F	958 959	G L	AVSS		CN-403F CN-118F				DS-E23 DS-E24		CN-816F CN-816F
221	P/B	AVSS		CN-117F			-			CN-JE6F	959	L	AVSS	0.75	CN-402F				DS-E24		CN-816F
225 347	P Y/V	AVSS	_	CN-401F CN-119F						CN-950F CN-402F	979 979	R	AVSS	0.75	CN-950F CN-842F						CN-JE1F CN-JE1F
365	L/R	AVSS	0.75	CN-119F						CN-402F		R	AVSS	_	CN-842F						CN-JE1F
366	G/B	AVSS		CN-119F						CN-402F		R/W	AVSS		CN-402F						CN-116F
398 445	G/W R/Y	AVSS		CN-402F CN-716F						CN-116F CN-849M	A23 A24	Sb	AVSS	0.5	CN-406M CN-406M						CN-657M CN-657M
466	G/W	AVSS	0.75	CB-E1						CN-700F	A25	Р	AVSS	0.5	CN-406M						CN-657M
500 501	R/G	AVSS AVSS		CN-111F CN-816F						CN-111F CN-401F		R W	AVSS AVSS	0.5	CN-406M CN-406M						CN-657M CN-657M
502	Br/W G/Y	AVSS		CN-401F						CN-816F		В	AVSS		CN-406M						CN-657M
503	L	AVSS		CN-816F						CN-401F	A29	Υ	AVSS	0.5	CN-406M						CN-657M
504 512	Y/L R	AVSS AVSS		CN-111F CN-112F						CN-111F CN-802F	A30 A31	G W/Y	AVSS AVSS	0.5	CN-406M CN-406M						CN-657M CN-659F
513	W	AVSS	0.75	CN-112F						CN-802F	A32	R			CN-406M						CN-659F
514 515	В	AVSS AVSS		ON-112F ON-112F						CN-802F CN-803F				_							
516	Y/R G/W	AVSS		CN-112F						CN-803F											
517	L/B	AVSS	0.75	CN-112F						CN-803F		R	AVSS		CN-709F	TWST0.75TW2		>>>>			
518 519	Br/R Lg/W	AVSS AVSS	0.75	ON-112F ON-112F						CN-804F	115 119	G Y	AVSS		CN-709F CN-111F	TWST0.75TW2				TWST0.75TW2	
520	O/B	AVSS		ON-112F						CN-804F	120	L	AVSS		CN-111F CN-111F	TWST0.75TW3 TWST0.75TW3		 >>>>C		TWST0.75TW3 TWST0.75TW3	
523	P/W	AVSS		CB-E4						CN-112F	558	W/L	AVSS	0.75	CN-115F	TWST0.75TW1		>		TWST0.75TW1	CN-41F
524 525	Gr/B V/R	AVSS AVSS		CA-E4 CN-112F						CN-112F CN-805F		B/Y R/G	AVSS		CN-115F CN-115F	TWST0.75TW1 TWST0.75TW4				TWST0.75TW1 TWST0.75TW4	
526	Br/W	AVSS	0.75	CN-112F						CN-805F	561	Y/R	AVSS		CN-115F	TWST0.75TW4		>		TWST0.75TW4	CN-41F
527 528	Lg/B W/R	AVSS AVSS		ON-112F ON-112F						CN-805F CN-806F	562	G/B	AVSS		CN-115F	TWST0.75TW5		>>>>			
528	W/R B/W	AVSS		CN-112F						CN-806F	563 564	L/R Br	AVSS AVSS		CN-115F CN-115F	TWST0.75TW5 TWST0.75TW6				TWST0.75TW5 TWST0.75TW6	
530	R/B	AVSS	0.75	CN-112F						CN-806F	565	0/B	AVSS	0.75	CN-115F	TWST0.75TW6		>>>>		TWST0.75TW6	CN-41F
531 532	R W	AVSS		CN-113F CN-113F						CN-807F	566 567	Gr/L	AVSS AVSS		CN-115F CN-115F	TWST0.75TW7 TWST0.75TW7		 >>>>		TWST0.75TW7 TWST0.75TW7	
533	В	AVSS	0.75	CN-113F						CN-807F	567 568	P/W O/W	AVSS			TWST0:75TW20				TWST0.75TW7	
534	L/R	AVSS		CN-114F						CN-808F	569	L/G	AVSS	0.75	CN-115F	TWST0.75TW20		>>>>		TWST0.75TW20	CN-833F
535 536	Br/W P/B	AVSS AVSS		CN-114F CN-114F						CN-808F CN-808F	570 571	P/L Gr/R	AVSS		CN-116F CN-116F	TWST0.75TW8 TWST0.75TW8		 >>>>C		TWST0.75TW8 TWST0.75TW8	
537	Gr/R	AVSS	0.75	CN-114F						CN-809F	572	0/L	AVSS	0.75	CN-116F	TWST0.75TW9				TWST0.75TW9	CN-41F
538	Y/W	AVSS		CN-114F						CN-809F	573	L/G	AVSS		CN-116F	TWST0.75TW9		>		TWST0.75TW9	
539 540	0/B R	AVSS AVSS		CN-114F CN-114F						CN-809F CN-810F	574 575	W/B B/Y	AVSS AVSS		CN-116F CN-116F	TWST0.75TW21 TWST0.75TW21				TWST0.75TW21 TWST0.75TW21	
541	W	AVSS	0.75	CN-114F						CN-810F	576	W/L	AVSS	0.75	CN-116F	TWST0.75TW10		>		TWST0.75TW10	CN-41F
542 543	B G/R	AVSS AVSS		CN-114F CN-114F						CN-810F CN-811F	577 578	G 0/B	AVSS		CN-116F CN-116F	TWST0.75TW10 TWST0.75TW19				TWST0.75TW10 TWST0.75TW19	
544	L/W	AVSS	0.75	CN-114F						CN-811F	579	Gr/B	AVSS	0.75	CN-116F	TWST0.75TW19				TWST0.75TW19	
545	Y/B	AVSS	0.75	CN-114F						CN-811F	583	R/L	AVSS	0.75	CN-116F	TWST0.75TW22		>		TWST0.75TW22	CN-835F
546 547	Lg/R O/W	AVSS AVSS		CN-114F CN-114F	 					CN-812F CN-812F		Y	AVSS AVSS		CN-116F CN-39F	TWST0.75TW22 TWST0.75TW18				TWST0.75TW22 TWST0.75TW18	
548	Br/B	AVSS		CN-114F						CN-812F		В			CN-39F	TWST0.75TW18				TWST0.75TW18	

WIRE NO	WIDE COLOR	WIRE TYPE	S17E	FROM	ID. SYMBOL	2WIRE CONNECT NO.	CONNECTION	2WIRE CONNECT NO.	ID. SYMBOL	T 0
908	W/R	AVSS	0.75	CN-39F	TWST0.75TW11	ZWINE CONNECT NO.		ZWINE CONNECT NO.	TWST0.75TW11	
909	Y/B	AVSS	0.75	CN-39F	TWST0.75TW11		$+ \times \times \times$		TWST0.75TW11	
910	G/R	AVSS	0.75	CN-39F	TWST0.75TW12				TWST0.75TW12	
911	L/B	AVSS	0.75	CN-39F	TWST0.75TW12		$\rightarrow \times \times \times$		TWST0.75TW12	
912	Br/R	AVSS	0.75	CN-39F	TWST0.75TW12			-	TWST0.75TW12	
913		AVSS	0.75	CN-39F	TWST0.75TW13		$\rightarrow \times \times \times$		TWST0.75TW13	
913	Lg/B	AVSS	0.75	CN-39F	TWST0.75TW13				TWST0.75TW13	
914 915	Gr/R	AVSS	0.75	CN-39F	TWST0.75TW14		$\rightarrow \times \times \times$		TWST0.75TW14	
	0/B						3			
916 917	V/R	AVSS AVSS	0.75	CN-39F	TWST0.75TW15		$\rightarrow \times \times \times$		TWST0.75TW15	
	P/B			CN-39F	TWST0.75TW15		2000		TWST0.75TW15	
918	Y/R	AVSS	0.75	CN-39F	TWST0.75TW16				TWST0.75TW16	
919	G/B	AVSS	0.75	CN-39F	TWST0.75TW16		> V V V C		TWST0.75TW16	
920	Lg/R	AVSS	0.75	CN-39F	TWST0.75TW17		$\rightarrow \times \times \times =$		TWST0.75TW17	
921	Gr/B	AVSS	0.75	CN-39F	TWST0.75TW17				TWST0.75TW17	
	Br	AVSS	0.5	CN-406M	TWST0.75TW23		XXXX		TWST0.75TW23	
A57	R/W	AVSS	0.5	CN-406M	TWST0.75TW23		2000		TWST0.75TW23	CN-657M
508	W	MVVS	0.75	CN-403M	MVVS4C1		1-1		MVVS4C1	CN-111F
509	R	MVVS	0.75	CN-403M	MVVS4C1				MVVS4C1	CN-111F
510	В	MVVS	0.75	CN-403M	MVVS4C1		I F		MVVS4C1	CN-111F
511	G	MVVS	0.75	CN-403M	MVVS4C1		J		MVVS4C1	CN-111F
E01	В	AVSS	0.75	LA-E51		DS-E14	•			CN-819F
E01	В	AVSS	0.75	LA-E51		DS-E14				CN-40F
E02	В	AVSS	0.75	CN-820F			-	DS-E1		LA-E52
E02	В	AVSS	0.75	CN-821F				DS-E1		LA-E52
E04	В	AVSS	0.75	LA-E53		DS-E2	•			CN-822F
E04	В	AVSS	0.75	LA-E53		DS-E2				CN-823F
E06	В	AVSS	0.75	E-2			- 9	DS-E30		E-4
E06	В	AVSS	0.75	LA-E48		DS-E31	•	DS-E30		E-4
E06	В	AVSS	0.75	LA-E48		DS-E31				CN-950F
E07	В	AVSS	0.75	LA-E50			-	DS-E13		LA-E44
E07	В	AVSS	0.75	CA-E3		DS-E24		DS-E13		LA-E44
E07	В	AVSS	0.75	CA-E3		DS-E24				CA-842F
E09	В	AVSS	0.75	CN-837F			-	DS-E4		LA-E59
E09	В	AVSS	0.75	CN-836F				DS-E4		LA-E59
E011	В	AVS	2	CN-871F			-	DS-E25		LA-E58
	В	AVSS	0.75	CN-838F				DS-E25		LA-E58
E012	В	AVSS	0.75	LA-E57		DS-E23				CN-840F
E012	В	AVSS	0.75	LA-E57		DS-E23				CN-841F
	В	AVS	1.25	CN-847F		00 220		DS-E8		LA-E55
	В	AVS	2	CN-848F				DS-E8		LA-E55
E021	B	AVSS	0.75	LA-E37				00 20		CA-E1
	В	AVSS	0.75	CN-845F				DS-E7		LA-E56
	В	AVSS	0.75	CN-845F	-			DS-E7		LA-E56
E023		AVSS	1.25	LA-E39	-	DS-E10		DU-E1		CN-708M
E2	B/W	AVSS	1.25	LA-E39	-	DS-E10 DS-E10	•			CN-708M
	B/W	_			-	D2_E10		DC_E44		
E3	B/W	AVSS	1.25	CN-708M			-	DS-E11		LA-E40
E4	B/W	AVSS		CN-708M				DS-E11		LA-E40
E5	B/W	AVSS	1.25	CN-708M		DO FO				LA-E43
E6	B/W	AVSS	0.75	LA-E41		DS-E3	•			CN-115F
E6	B/W	AVSS	0.75	LA-E41		DS-E3		DO 510		CN-115F
E8	B/W	AVSS	1.25	CN-700F			-	DS-E12		LA-E42
E8	B/W	AVSS	1.25	CN-700F				DS-E12		LA-E42
E10	B/W	AVSS	0.5	LA-E38		DS-E9	•			CN-708M
E11	B/W	AVSS	0.75	LA-E38		DS-E9				CN-709F
E18	B/W	AVSS	1.25	CN-406M			•			CN-JE7F
E18	B/W	AVSS	1.25	CN-406M			+			CN-JE7F
E18	B/W	AVSS	1.25	CN-JE7F			•			CN-JE7F
E18	B/W	AVSS	0.5	CN-JE7F			+			CN-657M
E10		AVSS	1.25	CN-JE7F						LA-E84
E18	B/W	AVSS	120	0.4 0.11			T			

Published 12-16-15, Control #244-01

10-60






8500-1 / 8500E-1 10-62 Published 12-16-15, Control #244-01

THE WIRE NO. /COLOR LIST

%1 IDENTIFICATION SYMBOL
%2 TWO WIRE CONNECT NUMBER

WIRE NO.	WIRE COLOR	WIRE TYPE	SIZE		% 1	% 2	CONNECTION		% 1	T
1A	R	AVS	2	LA-E11		DS-E16	•			CN-701F
1B	R	AVS	2	LA-E11		DS-E16				CN-701F
1C	R	AVS	2	LA-E10		DS-E6	•			CN-701F
1E	R	AVS	2	LA-E10		DS-E6				CN-701F
1F	R	AVS	2	LA-E12						CN-701F
2A	W	AV	15	LA-E23						LA-E13
2B	W	AV	15	LA-E14						LA-E27
2C	W	AV	15	LA-E33						LA-E15
2E	W	AVS	5	CN-702F						LA-E24
2F	W	AVS	5	CN-703F						LA-E25
2G	W	AVS	5	CN-702F						LA-E26
2H	W	AVS	5	CN-703F						LA-E28
2I	W	AVS	5	CN-704F						LA-E29
2J	W	AVS	5	CN-704F						LA-E30
2K	W	AVS	3	LA-E32		DS-E7	•			CN-705M
2M	W	AVS	2	LA-E32		DS-E7				CN-705M
2L	W	AV	15	LA-E35			<u> </u>			LA-E16
4	Υ	AVSS	1.25	CN-701F						CN-851M
22	L/R	AVSS	0.75	CN-707F						CN-855F
37	G	AVS	2	CN-706F						JS-B01
37	G	AVS	2	JS-B01						CN-852F
37	G	AVSS	0.75	JS-B01			—	DS-E1		CN-818F
37	G	AVSS	0.75	CN-818F				DS-E1		CN-818F
38	R/L	AVS	2	CN-706F						CN-852F
40	Br/W	AVSS	0.75	CN-707F			T			CN-854F
43	R/Y	AVSS	0.75	CN-851M			-	DS-E2		CN-868F
43	R/Y	AVSS	0.75	CN-868F				DS-E2		CN-868F
57	G/R	AVSS	0.75	CN-850F						LA-E19
58	L/R	AVSS	0.75	CN-854F						CN-855F
60	Br/R	AVSS		CN-707F						LA-E18
62	Y/R	AVSS		CN-707F						CN-850F
70	W/Y	AVSS		CN-707F						CN-855F
412	L/G	AVSS	0.75	CN-707F			•	DS-E4		CN-859F
412	L/G	AVSS	0.75	CN-856F				DS-E4		CN-859F
601	R/W	AVSS	0.75	CN-851M						CN-868F
605	Y/R	AVSS		CN-851M						CN-818F
617	Y/G	AVSS		CN-818F						JS-B02
617	Y/G			CN-851M						JS-B02
617	Y/G	AVSS		JS-B03						JS-B02
617	Y/G	AVSS	1	JS-B03						CN-851M
617	Y/G	AVSS		JS-B03			 			CN-851M
956	L/Y	AVSS		CN-851M			•	DS-E3		CN-868F
956	L/Y	AVSS		CN-851M				DS-E3		CN-868F
E017	В	AVSS		CN-855F				1		LA-E34
E017	В	AVSS		LA-E76			 			LA-E34
E13	B/W	AVSS		LA-E75			<u> </u>	DS-E5		CN-859F
E13	B/W	AVSS		CN-856F				DS-E5		CN-859F


(3/3)





(1/4)


8500-1 / 8500E-1 10-64 Published 12-16-15, Control #244-01


(2/4)
















SECTION K-K

8500-1 / 8500E-1 10-66 Published 12-16-15, Control #244-01


(3/4)




(4/4)




8500-1 / 8500E-1 10-68 Published 12-16-15, Control #244-01



(2/5)



8500-1 / 8500E-1 10-70 Published 12-16-15, Control #244-01



(4/5)

THE WIRE NO./COLOR LIST

*1 I DENTIFICATION SYMBOL *2 TWO WIRE CONNECT NUMBER


VIRE NO.	WIRE COLOR	WIRE TYPE AVSS	S I ZE 0.75	F R O M	%1		CONNECTION		% 1	T CN-638
22	L/R	AVSS	0.75	CN-675M						CN-70
33	G/B	AVSS	0.75	CN-614F						CN-679
34	L/R	AVSS	1.25	CN-675M			1			CN-JC
34 34	L/R L/R	AVSS AVSS	1.25 0.75	CN-614F CN-655F			1			CN-JC
35	Br Br	AVSS	1.25	CN-614F						CN-67
37	G	AVS	2	CN-675M						CN-70
88	R/L	AVS	2	CN-675M						CN-70
39	Y/B	AVSS	1.25	CN-772F						CN-67
10	Br/W	AVSS	0.75	CN-707M						CN-67
15	Br/W W/B	AVSS AVSS	0.75 1.25	CN-675M CN-709M						CN-67
iO	Br/R	AVSS	0.75	CN-676M						CN-70
52	Y/R	AVSS	0.75	CN-707M						CN-63
9	Р	AVSS	0.75	CN-676F						CN-63
°O	W/Y	AVSS	0.75	CN-707M						CN-67
32	G/L	AVSS	0.75	CN-634F						CN-67
302 308	R L/Y	AVSS	0.75 0.5	CN-688F CN-674F						CN-63 CN-61
309	G/Y	AVSS AVSS	0.5	CN-674F						CN-61
310	R/Y	AVSS	0.5	CN-674F			İ			CN-61
311	W/Y	AVSS	0.5	CN-674F						CN-61
330	L	AVSS	0.75	LA-C8						CN-67
342	Br/R	AVSS	0.75	CN-671M						CN-60
348	G	AVSS	0.75	CN-671M						CN-60
149 150	I T	AVSS	0.75	CN-671M CN-671M			+==			CN-60
51	O/W	AVSS AVSS	0.75	CN-614F			1			CN-67
352	0 %	AVSS AVSS	0.75	CN-688F						CN-63
853	Lg/B	AVSS	0.75	CN-688F			1			CN-63
54	P	AVSS	0.75	CN-671M						CN-60
355	Gr	AVSS	0.75	CN-671M						CN-60
356 357	Y/L	AVSS	0.75	CN-671M CN-671M						CN-60
358 358	L/B Lg/R	AVSS	0.75	CN-674F			-			CN-65
160	Br/G	AVSS AVSS	0.75	CN-671M						CN-60
161	W/R	AVSS	0.75	CN-671M						CN-60
62	G/R	AVSS	0.75	CN-671M						CN-60
63	R/Y	AVSS	0.75	CN-671M						CN-60
64	Y/W	AVSS	0.75	CN-674F						CN-61
867	Br	AVSS	0.75	CN-670F						CN-60
168 170	0	AVSS	0.75 0.75	CN-670F						CN-60
187	R/G G/L	AVSS AVSS	0.75	CN-670F CN-670F						CN-60
111	W/Y	AVSS	0.75	CN-688F						CN-61
12	L/G	AVSS	0.75	CN-JC03F			•			CN-70
112	L/G	AVSS	0.75	CN-JC03F			—			CN-67
112	L/G	AVSS	0.75	CN-JC03F			—			CN-61
24	L/G	AVSS	0.75	CN-624F						CN-67
125	Y/L	AVSS	0.75	CN-624F						CN-67
26 27	Gr/L R/W	AVSS	0.75	CN-624F CN-624F						CN-67
31	R/G	AVSS AVSS	0.75	CN-626F						CN-67
32	0/W	AVSS	0.75	CN-626F						CN-67
33	P/G	AVSS	0.75	CN-634F			İ			CN-61
34	G/B	AVSS	0.75	CN-673M						JS01
34	G/B	AVSS	0.75	CN-676F						JS01
34	G/B	AVSS	0.75	CN-620F						JS01
35 40	Br/G W/R	AVSS	0.75	CN-883M CN-676F			+==			CN-68
40 53	R/W	AVSS AVSS	1.25	CN-884F			1===			CN-7
56	G/B	AVSS	0.75	CN-615F						CN-6
58	L/B	AVSS	0.75	CN-614F						CN-6
66	G/W	AVSS	0.75	CN-677M						CN-70
67	P/W	AVSS	0.75	CB-C1			<u> </u>			CN-6
82	R	AVSS AVSS	0.75	CN-670F						CN-63
83 84	W B	AVSS	0.75	CN-670F CN-670F						CN-63
87	Y/W	AVSS	0.75	CN-677M						CN-65
15	W/Y	AVSS	0.75	CN-843F						CN-70
16	Br/W	AVSS	0.75	CN-843F						CN-70
18	Lg	AVSS	0.75	CN-843F						CN-70
19	L	AVSS	0.75	CN-843F						CN-70
20	G	AVSS	0.75	CN-843F						CN-70
21 22	O P	AVSS AVSS	0.75 0.75	CN-843F CN-843F						CN-70
51	G/R	AVSS	0.75	CN-709M						CN-6
52	Lg/R	AVSS	0.75	CN-709M						CN-6
53	Gr/R	AVSS	0.75	CN-674F						CN-6:
09	G/W	AVSS	0.75	CN-772F						CN-6
10	Br/G	AVSS	0.75	CN-772F						CN-6°
11	R/W	AVSS	1.25	CN-677M						CN-70
12	P/L	AVSS	1.25	CN-JC03F			1			CN-70
12 12	P/L	AVSS	0.75	CN-JC03F			+			CB-C2
100	P/L	AVSS	0.75	CN-JC03F	I		—			CN-6°

WIRE NO.	WIRE COLOR	WIRE TYPE	SIZE	FROM	X1		CONNECTION	* 2	% 1	T
859	Gr	A1400	0.75	CN-772F						CN-677M
509	Gi	AVSS	0.75	UN-112F						CN-679F
364	1.70	AV/CC	0.75	CN-772F						CN-679F
902	L/G Gr/R	AVSS AVSS	0.75	CN-679F						CN-772F
903	Lg	AVSS	0.75	CN-679F						CN-772F
926	R	AVSS	0.75	CN-772F						CN-679F
327	O/W	AVSS	0.75	CN-772F						CN-679F
930	Gr/R	AVSS	0.75	CN-680M						CN-883M
931	Br/W	AVSS	0.75	CN-680M						CN-883M
944	Br	AVSS	0.75	CN-634F						CN-677M
946	0/L	AVSS	0.75	CN-883M						CN-683F
	P/G	AVSS	0.75	CN-883M						CN-683F
986	Y/G	AVSS	0.75	CN-638M						CN-884F
987	L/0	AVSS	0.75	CN-638M						CN-677M
A01	R	AVSS	0.75	CN-616F						CN-650F
	Br	AVSS	0.75	CN-616F						CN-650F
A03	B/L	AVSS	0.75	CN-616F			T			CN-650F
A04	G/W	AVSS	0.75	CN-616F			T			CN-650F
A05	Gr/R	AVSS	0.75	CN-616F			T			CN-650F
	P	AVSS	0.75	CN-616F			-			CN-655F
	Gr/L	AVSS	0.75	CN-616F			I			CN-655F
A08	W/G	AVSS	0.75	CN-616F						CN-655F
A10	G/L	AVSS	0.75	CN-616F						CN-655F
A11	W/Y	AVSS	0.75	CN-616F						CN-655F
A12	Gr/B	AVSS	0.75	CN-616F					<u> </u>	CN-655F
	R	AVSS	0.75	CN-673M	TWST0.75TW1				TWST0,75TW1	CN-709M
115	G	AVSS	0.75	CN-673M	TWST0.75TW1		 		TWST0.75TW1	CN-709M
119	Y	AVSS	0.75	CN-615F	TWST0.75TW2		1		TWST0.75TW2	CN-676F
120	L	AVSS	0.75	CN-615F	TWST0.75TW2		 		TWST0.75TW2	CN-676F
372	R/Y	AVSS	0.75	CN-673M	TWST0.75TW2		1		TWST0.75TW2	CN-613F
373	W/B	AVSS	0.75	CN-673M	TWST0.75TW3		 _XXXX		TWST0.75TW3	CN-613F
374	L/G	AVSS	0.75	CN-673M	TWST0.75TW4				TWST0.75TW4	CN-612F
375	Br/R	AVSS	0.75	CN-673M	TWST0.75TW4		 _XXXX		TWST0.75TW4	CN-612F
376	0/L	AVSS	0.75	CN-611F	TWST0.75TW5				TWST0.75TW5	CN-673M
377	Gr/L	AVSS	0.75	CN-611F	TWST0.75TW5		 >>>>		TWST0.75TW5	CN-673M
494	Y/B	AVSS	0.75	CN-621F	TWST0.75TW6				TWST0.75TW6	CN-884F
495	L/G	AVSS	0.75	CN-621F	TWST0.75TW6		 		TWST0.75TW6	CN-884F
496	G	AVSS	0.75	CN-622F	TWST0.75TW7				TWST0.75TW7	CN-884F
497	L/Y	AVSS	0.75	CN-622F	TWST0.75TW7		 _XXXX		TWST0.75TW7	CN-884F
498	R/G	AVSS	0.75	CN-884F	TWST0.75TW8		 		TWST0.75TW8	CN-623F
499	L/R	AVSS	0.75	CN-884F	TWST0.75TW8		 		TWST0.75TW8	CN-623F
A19		AVSS	0.75	CN-655F	TWST0.75TW9				TWST0.75TW9	CN-677M
A20	Y/R Y/L	AVSS	0.75	CN-655F	TWST0.75TW9		+		TWST0.75TW9	CN-677M
A21	B/W	AVSS	0.75	CN-655F	TWST0.75TW10				TWST0.75TW10	
A22	L/W		0.75	CN-655F	TWST0.75TW10		 		TWST0.75TW10	
	Br	AVSS AVSS	0.75	CN-615F	TWST0.75TW10				TWST0.75TW10	
	R/W		0.75	CN-615F	TWST0.75TW11		 		TWST0.75TW11	
	Br	AVSS AVSS	0.75	CN-650F	TWST0.75TW12				TWST0.75TW12	
A57	R/W		0.75	CN-650F	TWST0.75TW12		+>xxx		TWST0.75TW12	
A56	Br Br	AVSS AVSS	0.75	CN-677M	TWST0.75TW12		- · · · Y		TWST0.75TW12	
A57	R/W		0.75	CN-677M	TWST0.75TW13		+>xxx		TWST0.75TW13	
A31	IK/ W	AVSS	0.15	CIV OT TIVE	1 W 3 1 0.1 3 1 W 1 3				1 W 3 T 0.1 3 T W 13	CIV 0C00I
E07	В	AVSS	0.75	LA-C9		DSC3	•			CN-620F
	В	AVSS	0.75	LA-C9		DSC3	+			CN-610F
	В	AVSS	1.25	CN-JC01F					 	LA-C7
	В	AVSS	0.75	CN-JC01F			I			CN-626F
	В	AVSS	0.75	CN-JC01F			1			CN-626F
	В	AVSS	0.75	CN-JC01F			<u> </u>			CN-634F
	В	AVSS	1.25	CN-JC01F						CN-JC01F
	В	AVSS	0.75	CN-624F			I			CN-JC01F
	В	AVSS	0.75	CN-624F					 	CN-JC01F
	В	AVSS	0.75	CN-624F			 			CN-JC01F
	В	AVSS	0.75	CN-624F			<u> </u>		<u> </u>	CN-JC01F
	В	AVSS	1.25	LA-C4			<u> </u>			CN-JC01F
	В	AVSS	0.75	CN-650F			-			CN-JC08F
	B	AVSS	1.25	CN-JC08F			I			CN-JC08F
	В	AVSS	0.75	CN-JC08F			1			CA-C1
	В	AVSS	0.75	CN-JC08F				DSC1	<u> </u>	LA-C2
	В	AVSS	0.75	CN-843F				DSC1		LA-C2
	В	AVSS	0.75	CN-608F				DSC6	<u> </u>	CN-607F
	В	AVSS	0.75	LA-C6			 	DSC6		CN-607F
	В	AVS	2	LA-C11			-	5555		CN-675M
E028	i -		1.25	CN-708F						CN-672M
E028 E031	R/W	AVSS	1.25	CN-708F						CN-672M
E028 E031 E1	B/W	A1/99							-	CN-672N
E028 E031 E1 E2	B/W	AVSS		CN-709E						
E028 E031 E1 E2 E3	B/W B/W	AVSS	1.25	CN-708F						
E028 E031 E1 E2 E3	B/W B/W B/W	AVSS AVSS	1.25 1.25	CN-708F						CN-672M
E028 E031 E1 E2 E3 E4 E5	B/W B/W B/W	AVSS AVSS AVSS	1.25 1.25 1.25	CN-708F CN-708F						CN-672M CN-672M
E028 E031 E1 E2 E3 E4 E5 E8	B/W B/W B/W B/W	AVSS AVSS AVSS AVSS	1.25 1.25 1.25 1.25	CN-708F CN-708F CN-700M						CN-672M CN-672M CN-614F
E028 E031 E1 E2 E3 E4 E5 E8	B/W B/W B/W B/W B/W	AVSS AVSS AVSS AVSS AVSS	1.25 1.25 1.25 1.25 1.25	CN-708F CN-708F CN-700M CN-700M						CN-672M CN-672M CN-614F CN-614F
E028 E031 E1 E2 E3 E4 E5 E8 E9 E10	B/W B/W B/W B/W	AVSS AVSS AVSS AVSS	1.25 1.25 1.25 1.25	CN-708F CN-708F CN-700M						CN-672M CN-672M CN-614F

(5/5)

8500-1 / 8500E-1 10-72 Published 12-16-15, Control #244-01


RIGHT DECK HARNESS (b)



WIRE No. AND WIRE COLOR LIST


WIRE No.	COLOR	TYPE	SIZE	FR	0 1	1 2-WIRE CLAMP	CONNECTION	2-WIRE CLAMP	T	0
E-STD	В	AV	60	LA-E4					LA-E5	

POWER SUPPLY HARNESS



(1/2)

8500-1 / 8500E-1 10-74 Published 12-16-15, Control #244-01




THE WIRE NO. / COLOR LIST

*1 IDENTIFICATION SYMBOL *2 TWO WIRE CONNECT NUMBER

WIRE NO.	WIRE COLOR	WIRE TYPE	SIZE	FROM	% 1		CONNECTION		% 1	T 0
1A	R	AVS	2	CN-501F						CN-701M
1B	R	AVS	2	CN-501F						CN-701M
1C	R	AVS	2	CN-501F						CN-701M
1E	R	AVS	2	CN-501F						CN-701M
1F	R	AVS	2	CN-250F						CN-701M
2E	W	AVS	5	CB-B07						CN-702M
2G	W	AVS	5	CB-B06						CN-702M
2H	W	AVS	5	CB-B03						CN-703M
21	W	AVS	5	CB-B01						CN-704M
2J	W	AVS	5	CB-B02						CN-704M
2K	W	AVS	3	CB-B04						CN-705F
2L	W	AVS	2	CN-705F						CN-251F
4	Y	AVSS	1.25	CN-501F						CN-701M
91	L	AVS	2	CN-252F						CN-251F

(2/2)


STARTER (TERMINAL B) TO BATTERY RELAY



THE WIRE NO. /COLOR LIST

	WIRE NO.	WIRE COLOR	WIRF TYPF	SI7F	FROM	IDENTIFICATION SYMBOL	2WIRE CONNECT NO	CONNECTION	2WIRE CONNECT NO	IDENTIFICATION SYMBOL	T O
L		WINE OOLON	*****	0120		100111111101111011	ENTINE CONTINECT TO	0011112011011	LWINE COMMECT NO	1.02.11.11.0711.011.011.002	
	2	В	AV	60	LA-E12						LA-C1

STARTER (TERMINAL C) TO SAFETY RELAY




THE WIRE NO. / COLOR LIST


WIRE NO.	WIRE COLOR	WIRE TYPE	SIZE	F R O M	IDENTIFICATION SYMBOL	2WIRE CONNECT NO	CONNECTION	2WIRE CONNECT NO	IDENTIFICATION SYMBOL	T 0
65	W	AV	8	LA-C2						LA-E31

8500-1 / 8500E-1 10-76 Published 12-16-15, Control #244-01

6. RIGHT DECK (GUARD)




(1/3)



(2/3)


8500-1 / 8500E-1 10-78 Published 12-16-15, Control #244-01



(3/3)


GUARD HARNESS (a)

CN-656M 6MA-JM2




8500-1 / 8500E-1 10-80 Published 12-16-15, Control #244-01

GUARD HARNESS (b)



(1/2)

2FF-APEX



THE WIRE NO. / COLOR LIST


	WIRE COLOR			FROM	% 1		CONNECTION	% 2	% 1	T C
34	L/R	AEX	0.75	CN-655F			•			CN-JC13F
34	L/R	AEX	0.75	CN-649F			+			CN-JC13F
34	L/R	AEX	0.75	CN-649F			-			CN-JC13F
A07	Gr/L	AEX	0.75	CN-640M			•			CN-JC13F
A07	Gr/L	AEX	0.75	CN-656F						CN-JC13F
A07	Gr/L	AEX	0.75	CN-641M			—			CN-JC13F
A06	P	AEX	0.75	CN-655F						CN-640M
A08	W/G	AEX	0.75	CN-656F						CN-641M
A10	G/L	AEX	0.75	CN-656F						CN-642F
A11	W/Y	AEX	0.75	CN-656F						CN-642F
A12	Gr/B	AEX	0.75	CN-656F						CN-642F
A19	Y/R	AEX	0.5	CN-655F	0.75TW4				0.75TW4	CN-651F
A20	Y/L	AEX	0.5	CN-655F	0.75TW4		<u> </u>		0.75TW4	CN-651F
A21	B/W	AEX	0.5	CN-655F	0.75TW5				0.75TW5	CN-654F
A22	L/W	AEX	0.5	CN-655F	0.75TW5				0.75TW5	CN-654F
A56	Br	AEX	0.75	CN-655F	0.75TW1		¬^^^		0.75TW1	CN-JC14F
A57	R/W	AEX	0.75	CN-655F	0.75TW1				0.75TW1	CN-JC14F
A56	Br	AEX	0.75	CN-649F	0.75TW2		¬^^^		0.75TW2	CN-JC14F
A57	R/W	AEX	0.75	CN-649F	0.75TW2				0.75TW2	CN-JC14F
A56	Br	AEX	0.75	CN-649F	0.75TW3		-\^\ /		0.75TW3	CN-JC14F
A57	R/W	AEX	0.75	CN-649F	0.75TW3				0.75TW3	CN-JC14F
E18	B/W	AEX	0.75	CN-649F			-			CN-JC12F
E18	B/W	AEX	0.75	CN-649F			—			CN-JC12F
E18	B/W	AEX	0.75	CN-JC12F			•			CN-JC12F
E18	B/W	AEX	0.75	CN-JC12F			1			CN-649F
E18	B/W	AEX	1.25	CN-JC12F			T			CN-656F

- ***1 IDENTIFICATION SYMBOL**
- **%2 TWO WIRE CONNECT NUMBER**

(2/2)

8500-1 / 8500E-1 10-82 Published 12-16-15, Control #244-01

GUARD HARNESS (c)








#0 E026 0.75 B + E026 0.75 B

WIRE	NO.	WIRE (COLOR	WIRE	TYPE	SIZE	F	R O N	И		 2	CONNECTION	% 2	*1		Т О
358		Lg/R		AVSS		0.75	CN-	-650F							(CB-C3
487		Y/W		AVSS		0.75	CN-	-609F							(CN-650F
A01		R		AVSS		0.5	CN-	-650F							(CN-633F
A02		Br		AVSS		0.5	CN-	-650F							(CN-633F
A03		B/L		AVSS		0.5	CN-	-650F							(CN-633F
A04		G/W		AVSS		0.5	CN-	-650F							(CN-633F
A05		Gr/R		AVSS		0.5	CN-	-650F							(CN-633F
E026		В		AVSS		0.75	CA-	-C3			DS-E1	•			(CN-650F
E026		В		AVSS		0.75	CA-	-C3			DS-E1				(CN-609F


%1 IDENTIFICATION SYMBOL

%2 TWO WIRE CONNECT NUMBER





NOX SENSOR HARNESS





THE WIRE NO. / COLOR LIST

WIRE	NO. WIRE	COLOR	WIRE	TYPE	SIZE	FR	0 M	1 PI	NΙ	NUMBE	R	% 1	CONNEC	CTION	% 1	PIN	N	JMBER	T 0
34	L/R		AEX		0.5	CN-6	52F												CN-649M
34	L/R		AEX		0.5	CN-6	653F												CN-649M
A56	Br		AEX		0.5	CN-6	52F												CN-649M
A56	Br		AEX		0.5	CN-6	553F												CN-649M
A57	R/W		AEX		0.5	CN-6	52F						-						CN-649M
A57	R/W		AEX		0.5	CN-6	653F												CN-649M
E18	В		AEX		0.5	CN-6	52F												CN-649M
E18	В		AEX		0.5	CN-6	52F												CN-649M
E18	В		AEX		0.5	CN-6	53F												CN-649M


%1 IDENTIFICATION SYMBOL

8500-1 / 8500E-1 10-84 Published 12-16-15, Control #244-01






8500-1 / 8500E-1 10-86 Published 12-16-15, Control #244-01





(3/3)

CAB MAIN HARNESS




Published 12-16-15, Control #244-01 8500-1 / 8500E-1 10-88






8500-1 / 8500E-1 10-90 Published 12-16-15, Control #244-01




THE WIPE NO YOUR												
THE WIRE NO. / COLC		WIRE NO. WIRE COLOR WIRE TYPE SIZE FROM	THISE MINERS NO. COMMENT ON THE SHIPE MINERS NO. T	1 WIRE NO. WIRE COLOR WIRE TYPE SIZE FROM 2017E	OMBET TO COMMENT ON THE TOTAL OF	WIRE NO. WIRE COLOR WIRE TYPE SIZE FROM 2NIRE CONNECT NO. CONNECT ION	ZNIRE CONNECT NO. T O WIRE NO. WIRE COLOR WIRE TYPE SIZE FROM ZWIRE CONN	CT NO. CONNECTION 2WIRE CONNECT NO. T 0	INI DE NO MIDE	COLOR WIRE TYPE SIZE FROM 2011	SC COMMENT ON A COMMENT ON THE COMMENT ON T	
11 W/G AVSS 1.25 CN-293F	CN-206E	145 Y/L AVSS 0.5 CN-11-5AF	CN-JA04F	340 Sb AVSS 0.75 CN-291F	CN-103F	468 0 AVSS 0.75 CN-109F	- CN-294F 700 B AVSS 0.5 CN-281F	CN-423F	371 G	AVSS 0.75 CN-105F	3000 ON-2	V-291F
11 W/G AVSS 1.25 CN-293F	DSA35 CN-206F	145 Y/L AVSS 0.75 CN-299F		341 W/L AVSS 0.75 CN-291F	CN-109F	469 L AVSS 0.75 CN-109F	- ON-301F 701 R AVSS 0.5 CN-281F			AVSS 0.75 CN-105F		V-291F
11 W/G AVSS 1.25 JS-A1 11 W/G AVSS 0.75 JS-A1	USA36 UN-206F	145 Y/L AVSS 0.5 CN-290F 146 Gr AVSS 0.5 CN-11-5AF	CN-JA04F	342 Br/R AVSS 0.75 CN-103F 343 Y/B AVSS 0.75 CN-291F	CN-671F		- CN-294F 702 W AVSS 0.5 CN-281F 749 R/Y AVSS 0.75 CN-220F DSA94	ON-423F CN-221F	373 W/E	AVSS 0.75 CN-105F AVSS 0.75 CN-105F		V-673F V-673F
11 W/G AVSS 0.75 JS-A1	CN-229F		I CN-JA04F	344 G/W AVSS 0.75 CN-291F	ON-103F	474 L/B AVSS 0.75 CN-108F	- CN-303F 749 R/Y AVSS 0.75 CN-220F DSA94	DSA97 CN-219F	374 I/G	AVSS 0.75 CN-105F R AVSS 0.75 CN-105F		V-673F V-673F
11 W/G AVSS 0.75 JS-A1 13 Y/B AVSS 0.5 CN-299F	CN-300F CN-281F	146 GF AVSS 0.5 CN-290F 147 O/L AVSS 0.5 CN-11-5AF	ON-JA04F	345 Lg/Y AVSS 0.75 CN-291F 346 R/L AVSS 0.75 CN-291F	CN-103F	476 O AVSS 0.75 CN-109F	- ON-292F 749 R/Y AVSS 0.75 CN-219F DSA98 - ON-306F 749 R/Y AVSS 0.75 CN-219F DSA98	DSA97 ON-219F DSA99 ON-217F	376 0/L	AVSS 0.75 CN-105F	811.6	1-673F
14 G/R AVSS 0.75 CN-226F	CN-JA07F	147 O/L AVSS 0.5 CN-11-5AF 147 O/L AVSS 0.75 CN-290F	CN-JA04F	347 Y/V/26/AVSS 0.75 CN-304F	CN-105F	478 G/Y AVSS 0.75 CN-290F	- CN-670M 749 R/Y AVSS 0.75 JS-A16	DSA99 CN-217F	377 Gr/1	L AVSS 0.75 CN-105F	and the same of th	V-673F
14 G/R AVSS 1.25 CN-11-1AF 14 G/R AVSS 0.75 CN-JA07F	CN-JA07F	147 O/L AVSS 0.75 CN-299F 148 G/W AVSS 0.5 CN-294F	CN-JA04F	F 349 Y AVSS 0.75 CN-104F	ON-671F ON-671F	483 W AVSS 0.75 CN-104F	- ON-670M 749 R/Y AVSS 0.75 US-A16 - ON-104F 749 R/Y AVSS 0.5 US-A17			AVSS 0.75 CN-105F AVSS 0.75 CN-105F		V-301F V-301F
14 G/R AVSS 1.25 CN-JA07F	CN-290F	149 I /W AVSS 0.5 JS-A15		F 350 L AVSS 0.75 CN-104F	CN-671F	485 Gr/L AVSS 0.75 CN-109F	ON-292F 749 R/Y AVSS 1.25 JS-A17	CN-885F	388 B/Y	AVSS 0.75 CN-106F	ON-3	√-301F
14 G/R AVSS 0.75 CN-JA07F	CN-105F	149 L/W AVSS 0.75 JS-A15 149 L/W AVSS 0.75 JS-A15		361 O/W AVSS 0.75 CN-104F 362 O AVSS 0.75 CN-104F	CN-674M	A41 W/B AVSS 0.75 CN-290F A42 W/L AVSS 0.75 CN-290F	- CN-305F 749 R/Y AVSS 1.25 JS-A16 CN-305F 749 R/Y AVSS 1.25 CN-206F DSA100			AVSS 0.75 CN-106F	CN=3	V-301F V-301F
14 G/R AVSS 0.75 CN-JA07F 17 O AVSS 1.25 CN-JA02F	CN-107F CN-290F	150 Br AVSS 0.5 CN-JA04F	ON-11-5A	F 353 Lg/8 AVSS 0.75 CN-104F	CN-689M	PARE 1875 AVSS 10.13 TON ESCH	749 R/Y AVSS 1.25 CN-206F DSA100	DSA94 CN-433F	391 Br	AVSS 0.75 CN-106F		√-301F
17 O AVSS 1.25 CN-JA02F 17 O AVSS 1.25 CN-JA02F	CN-11-1AF		CN-299F CN-305F	F 353 Lg/8 AVSS 0.75 CN-104F 354 P AVSS 0.75 CN-104F 355 Gr AVSS 0.75 CN-104F	CN-671F		749 R/Y AVSS 0.75 CN-434F DSA93 749 R/Y AVSS 0.75 CN-434F DSA93	DSA94 CN-433F DSA92 CN-435F	392 0/B 393 Sh	AVSS 0.75 CN-106F AVSS 0.75 CN-106F		V-291F V-291F
18 Gr AVSS 1.25 CN-JA02F		153 G/Y AVSS 0.5 CN-11-5AF	CN-299F	356 Y/L AVSS 0.75 CN-104F	CN-671F		749 R/Y AVSS 0.75 0N-434F 0SA93 749 R/Y AVSS 0.75 0N-205F 0SA91 749 R/Y AVSS 0.75 0N-205F 0SA91	DSA92	396 P/W	V AVSS 0.75 CN-106F	ON-2	V-291F
18 Gr AVSS 1.25 CN-JA02F 18 Gr AVSS 1.25 CN-JA02F	CN-11-4F CN-11-4F	154 Br/W AVSS 0.5 CN-11-5AF 155 Lg/W AVSS 0.5 CN-299F	CN-299F	357 L/B AVSS 0.75 CN-104F F 358 Lg/R AVSS 0.75 CN-104F	CN-671F CN-674M				331 Lg/	W AVSS 0.75 CN-106F AVSS 0.75 CN-301F	011 0	V-291F V-106F
19 P AVSS 0.75 CN-290F	JS-A11	156 P/W AVSS 0.5 CN-11-5AF	CN-294F	359 L/Y AVSS 0.75 CN-109F	CN-303F		749 R/Y AVSS 0.75 CN-203F DSA89 749 R/Y AVSS 0.75 CN-203F DSA89	DSA88 CN-203F	489 G	AVSS 0.75 CN-301F	-XXX- ON-1	V-106F
19 P AVSS 0.75 CN-105F 19 P AVSS 0.75 JS-A12	US-A11	157 W AVSS 0.5 CN-294F 158 R/W AVSS 0.5 CN-11-5AF	ON-11-5A	F 360 Br/G AVSS 0.75 CN-104F 361 W/R AVSS 0.75 CN-104F	CN-671F CN-671F		749 R/Y AVSS 0.75 CN-202F DSA87 749 R/Y AVSS 0.75 CN-202F DSA87	DSA88 CN-203F DSA86 CN-202F	490 P/L 491 Gr/	AVSS 0.75 CN-300F W AVSS 0.75 CN-300F		V-106F V-106F
19 P AVSS 0.75 JS-A12	CN-105F	160 G AVSS 0.5 CN-11-5AF	CN-307F	362 G/R AVSS 0.75 CN-104F	CN-671F		749 R/Y AVSS 0.75 CN-201F DSA85	DSA86 CN-202F	492 R/B	AVSS 0.75 CN-300F	->>>> ON-1	V-105F
19 P AVSS 0.75 JS-A12 19 P AVSS 0.75 CN-434F DSA	DSA120 CN-435F DSA121	161 Y/R AVSS 0.5 CN-307F 162 Y/G AVSS 0.5 CN-307F		F 363 R/Y AVSS 0.75 CN-104F F 364 Y/W AVSS 0.75 CN-674M	CN-671F CN-104F		749 R/Y AVSS 0.75 CN-201F DSA85 749 R/Y AVSS 0.75 CN-209F DSA83	DSAB4 CN-201F DSAB4 CN-201F	493 W/\ 851 P./⊌	Y AVSS 0.75 CN-300F W AVSS 0.75 CN-226F	I NES	V-105F V-227F
19 P AVSS 0.75 CN-434F DSA	A121 ON-433F	163 L/R AVSS 0.5 CN-11-58F	CN-219F	365 L/R AVSS 0.75 CN-105F	CN-303F		749 R/Y AVSS 0.75 CN-209F DSA83	DSA82 ICN-209F	852 B	AVSS 0.75 CN-226F	_XXX_ ON-2	V-227F
20 W/L AVSS 1.25 CN-293F 20 W/L AVSS 1.25 CN-105F	JS-A13 JS-A13	164 Br/R AVSS 0.5 CN-219F 165 Gr/R AVSS 0.5 CN-294F	ON-11-58	F 366 G/B AVSS 0.75 CN-105F F 367 Rr AVSS 0.75 CN-105F	ON-304F		749 R/Y AVSS 0.75 CN-208F DSA81 749 R/Y AVSS 0.75 CN-208F DSA81	DSA82	853 P/W	V AVSS 0.75 CN-226F B AVSS 0.75 CN-226F		V-228F V-228F
20 W/L AVSS 0:75 UN-107-	JS-A13	166 Lg/W AVSS 0.5 CN-294F		F 367 Br AVSS 0.75 CN-105F F 368 O AVSS 0.75 CN-670M	CN-105F		749 R/Y AVSS 0.75 CN-215F DSA102	DSA80 CN-207F	855 L/w	V AVSS 0.75 CN-293F		V-225F
20 W/L AVSS 1.25 CN-293F 20 W/L AVSS 1.25 CN-106F	JS-A14 JS-A14	168 Laza AVSS 05 DN-307F	CN-11-58	F 369 P/B AVSS 0.75 CN-105F F 370 R/G AVSS 0.75 CN-670M	ON-303F		749 R/Y AVSS 0.75 CN-215F DSA102 749 R/Y AVSS 0.75 CN-213F DSA105	DSA103 CN-214F		B AVSS 0.75 CN-293F		V-225F
20 W/L AVSS 0.75 CN-215F DSA	A49 J5-A14	169 O/L AVSS 0.75 ON-214F	CN-107F	381 O/W AVSS 0.75 CN-302F	CN-105F		749 P/V AVSS 0.75 CN-213F DSA105	DSA107 ON-212F	304 R			V-421F
20 W/L AVSS 0.75 CN-215F DSA 20 W/L AVSS 0.75 CN-213F	0SA207 CN-214F DSA207 CN-214F	170 R/G AVSS 0.5 CN-11-5BF 171 Y/B AVSS 0.5 CN-420M	CN-11-58	382 L/W AVSS 0.75 CN-302F F 383 R AVSS 0.75 CN-105F	CN-105F CN-294F		749 R/Y AVSS 0.75 CN-211F DSA109 749 R/Y AVSS 0.75 CN-211F DSA109	USA107 CN-212F CN-210F		MVVS 0.75 CN-101F MVVS 0.75 CN-101F	DN-2	V-421F V-421F
21 Lg AVSS 0.75 CN-293F	DSA209 ON-439F	172 G/L AVSS 0.5 CN-11-58F	CN-307F	384 R/W AVSS 0.75 CN-292F	CN-105F					MVVS 0.75 CN-101F		v-421F
21 Lg AVSS 0.75 CN-208F DSA 21 Lg AVSS 0.75 CN-208F DSA	A200 USA209 CN-439F A200 CN-219F	173 G AVSS 0.5 CN-420M 175 Y AVSS 0.75 CN-238F	CN-11-58 CN-11-6A	F 385 G/Y AVSS 0.75 CN-292F F 386 O AVSS 0.75 CN-107F	CN-105F CN-292F		750 W/R AVSS 1.25 CN-206F DSA101 750 W/R AVSS 1.25 CN-206F DSA101	CN-293F	508 W	MVVS 0.75 CN-294F		V-422F
23 R/G AVSS 0.75 CB-A03 DSA	A13 €	176 Gr/W AVSS 0.75 CN-872F 177 G AVSS 0.75 CN-873F	ON-307F	387 G/L AVSS 0.75 CN-107F	CN-670F		751 G/R AVSS 0.75 CN-204F	CN-670M	509 R	MVVS 0.75 CN-294F MVVS 0.75 CN-294F	CN-2	V-422F
23 R/G AVSS 0.75 C8-A03 DSA 23 R/G AVSS 0.75 CN-226F	CN-293F	179 L/V AVSS 0.75 CN-892F	CN-11-6A	F 395 R/L AVSS 0.75 CN-305F F 395 R/L AVSS 0.75 JS-A3	J5-A3 DN-290F		752 Lg/R AVSS 0.75 CN-670M 753 Gr/R AVSS 0.75 CN-672F	DSA208 CN-207F		MVVS 0.75 CN-294F MVVS 0.75 CN-294F		V-422F V-422F
24 Y AVSS 1.25 CN-231F DSA		181 Lg AVSS 0.75 CN-875F 184 G/R AVSS 0.75 CN-240F	CN-11-6A	F 395 R/L AVSS 0.75 JS-A3	CN-106F		753 Gr/R AVSS 0.75 CN-106F 754 Y/R AVSS 0.75 CN-208F	DSA208 CN-207F	=======================================			
24 Y AVSS 1.25 ON-231F DSA 24 Y AVSS 1.25 JS-A7	A1 DSA5 CN-233F DSA5 CN-233F	185 L/W AVSS 0.75 CN-240F	CN-11-68	F 398 G/W AVSS 0.75 CN-303F F 400 R/Y AVSS 0.75 CN-303F	CN-106F CN-106F		755 R AVSS 0.75 DN-229F	ON-300F	EO B	AVSS 1.25 CN-439F AVSS 1.25 CN-439F		N-300F N-879M
24 Y AVSS 1.25 JS-A7	— CN-232F → DSA206 CN-201F	185 L/W AVSS 0.75 CN-240F 186 Y/L AVSS 0.75 CN-234F 187 G/Y AVSS 0.75 CN-11-68F	CN-11-68	F 401 Gr/B AVSS 0.75 CN-303F 402 V/W AVSS 0.75 CN-294F	CN-106F CN-106F		801 G AVSS 1.25 CN-230F 802 Lg AVSS 1.25 CN-230F	ON-231F ON-231F	E0 B	AVSS 0.75 CA-A03 AVSS 0.75 CA-A03	QN-I	N-879M
24 Y AVSS 125 ON-202F DSA 24 Y AVSS 125 ON-202F DSA 24 Y AVSS 125 ON-202F DSA		188 L/G AVSS 0.75 CN-11-68F	CN-234F	403 Y AVS 0.75 CN-106F	ON-210F		803 O AVSS 125 CN-202F	CN-231F	EO B	AVSS 0.75 US-A08		S-A8 N-226F
24 Y AVSS 1.25 CN-202F DSA	A22 DSA17 CN-203F	189 Lg/Y AVSS 0.75 CN-11-4F		405 Y AVSS 0.75 CN-107F 406 P AVSS 0.75 CN-107F	ON-215F ON-303F		804 Gr AVSS 1.25 CN-231F 805 L AVSS 1.25 CN-233F	CN-202F	EO B	AVSS 0.75 JS-A08 AVSS 0.75 CN-233F	CN-:	N-231F N-231F
24 Y AVSS 1.25 CN-230F 31 L AVSS 0.75 CN-106F	CN-292F	190 O/L AVSS 0.75 CN-11-68F 191 G AVSS 0.75 CN-11-68F	CN-301F	407 Br AVSS 0.75 CN-107F	CN-303F		806 P AVSS 0.75 CN-233F	CN-232F	EO B	11100 0.0E 011.000E 00	- 001404 611	
34 L/R AVSS 0.75 CN-207F DSA 39 Y/B AVSS 0.75 CN-209F DSA	CN-300F	192 W/L AVSS 0.75 ON-301F		F 408 Gr/B AVSS 0.75 CN-213F	CN-107F		807 R AVSS 1.25 CN-233F 808 Br AVSS 1.25 CN-203F	ON-203F	E0 B	AVSS 0.75 CN-240F DS	A172 DSA134 CN-	1-234F
39 Y/B AVSS 0.75 CN-209F DSA	A201 DSA203 CN-211F	193 B/Y AVSS 0.75 CN-11-6AF 194 R AVSS 0.75 CN-11-1DF	CN-307F	409 R/Y AVSS 0.75 CN-224F 410 Br/L AVSS 0.75 CN-303F	CN-107F		809 G/W AVSS 0.75 CN-201F	CN-670M	E0 B	AVSS 0.75 CN-221F DS	A3133	N-240F
39 Y/B AVSS 0.75 CN-212F DSA 39 Y/B AVSS 0.75 CN-212F DSA	A202 DSA203 CN-211F A202 CN-293F	195 W AVSS 0.75 CN-11-1DF 196 B AVSS 0.75 CN-11-1DF	ION-307F	411 W/Y AVSS 0.75 CN-104F 411 W/Y AVSS 0.75 CN-688M	CN-JA02F		810 Br/G AVSS 0.75 CN-201F 867 O/W AVSS 0.75 CN-211F	CN-670M CN-234F	EO B	AVSS 0.75 ON-221F DS	A139 DSA140 CN-	1-220F
44 Gr AVSS 0.75 CN-290F 48 R/L AVSS 0.75 CN-305F	CN-305F	198 Br/G AVSS 0.75 CN-894F	CN-11-6A	F 411 w/Y AVSS 0.75 CN-290F	CN-JA02F		858 Br/G AVSS 0.75 CN-300F	CN-212F	EO B	AVSS 0.75 CN-219F DS	A141 DSA142 CN-	N-219F
48 R/L AVSS 0.75 CN-305F 49 R/W AVSS 1.25 CN-204F DSA	— CN-290F A31	199 P/G AVSS 0.75 CN-301F 200 O AVSS 0.75 CN-11-6AF	ON-11-6A	F 412 L/G AVSS 0.75 CN-674M 413 P AVSS 0.75 CN-109F			900 Lg/Y AVSS 0.75 CN-299F 901 Y/L AVSS 0.75 CN-220F	CN-221F	EO B	AVSS 0.75 ON-217F DS	DSA142 CN- SA143 DSA144 CB-	V-219F R-4∩4
49 R/W AVSS 0.75 CN-204F DSA	A31 DSA33 CN-205F	201 R/W AVSS 0.75 CN-11-6AF	CN-874F	415 Gr/L AVSS 0.75 CN-107F	CN-433F		922 Br/W AVSS 0.75 CN-300F	ON-217F	E0 B	AVSS 0.75 CA-A01 DS	6A168 - DSA144 CB-	8-A04
49 R/W AVSS 0.75 CN-210F 52 Y/G AVSS 0.75 CN-305F	USA33 UN=206F	202 L/R AVSS 0.75 CN-11-6AF 203 G/R AVSS 0.75 CN-11-6AF	CN-876F	416 B/Y AVSS 0.75 CN-107F 417 R/W AVSS 0.75 CN-107F	ON-434F		951 O AVSS 0.75 CN-290F 962 L/G AVSS 0.75 CN-303F	CN-305F CN-109F	E0 B	AUDC ORE ON ADAE DO	AAAF - DCAFO ON	N-433F N-433F
53 L/R AVSS 0.75 CN-106F		203 G/R AVSS 0.75 CN-11-6AF 215 W AVSS 0.75 CN-306F	CN-238F	418 W/R AVSS 0.75 CN-293F	CN-107F		966 W/O AVSS 0.75 CN-301F	CN-894F	E0 B	AVSS 0.75 CN-434F DS	6A145 \ DSA146 CN-	N-435F
53 L/R AVSS 0.5 CN-281F 53 L/R AVSS 0.75 JS-A18	JS-A17 JS-A17	216 B/R AVSS 0.75 CN-306F 217 Lg/Y AVSS 0.75 CN-306F 218 L/O AVSS 0.75 CN-306F	ICN-875F	419 G/Y AVSS 0.75 CN-108F 420 Y/W AVSS 0.75 CN-108F	ON-303F ON-304F		972 G/L AVSS 0.75 CN-292F 973 0/L AVSS 0.75 CN-292F	CN-104F	E0 B	AVSS 0.75 (N-206F DS AVSS 0.75 (N-206F DS	4147 DSA146 CN- A147 DSA167 CN-	N-435F N-205F
53 L/R AVSS 0.75 JS-A18	CN-290F	218 L/O AVSS 0.75 CN-305F	CN-892F	421 R/Y AVSS 0.75 CN-108F 422 P/L AVSS 0.75 CN-108F	CN-304F		974 Gr/R AVSS 0.75 CN-104F	JS-A21	EO B	AV55 U.15 UN-204F U5	6A148 USA167 UN-	N-205F
53 L/R AVSS 0.75 JS-A18 61 Br/w AVSS 0.75 CN-109F	CN-302F CN-302F	219 Y/B AVSS 0.75 ON-305F 220 G/Y AVSS 0.75 ON-305F	CN-893F	423 W/B AVSS 0.75 CN-108F	ON-304F		974 Gr/R AVSS 0.75 CN-104F 974 Gr/R AVSS 0.75 CN-292F	US-A21 US-A21	E0 B	AVSS 0.75 (N-204F US AVSS 0.75 (N-203F DS	A148 DSA149 CN- A154 DSA149 CN-	N-203F N-203F
61 Br/W AVS 0.75 CN-1.09F 82 G/L AVS 0.75 JS-A4 82 G/L AVS 0.75 CN-217F DSA	CN-300F A59 JS-A4	221 P/B AVSS 0.75 CN-305F 222 P/W AVSS 0.75 CN-11-6AF	CN-876F	424 L/G AVSS 0.75 CN-108F 425 Y/L AVSS 0.75 CN-108F	ON-304F		975 G AVS 0.75 (N-888F 976 L AVS 0.75 (N-888F	ON-307F	E0 B	AVSS 0.75 CN-203F DS	A154 DSA152 CN-	N-202F
82 G/L AVSS 0.75 CN-217F DSA	A59 DSA68 CN-220F	223 Y/G AVSS 0.75 CN-11-68F	CN-301F	426 Gr/L AVSS 0.75 CN-108F	CN=304F		976 L AVSS 0.75 CN-294F	JS-A22	E0 B	AVSS 10.75 ION-202F IDS	A150 DSA156 ON-	N-202F N-201F
82 G/L AVSS 0.75 CN-221F 82 G/L AVSS 0.75 CN-293F	DSA68		CN-307F	427 R/W AVSS 0.75 CN-108F	ON-304F		976 L AVSS 0.75 CN-107F 977 G/Y AVSS 0.5 CN-11-5AF	US-A22 QN-307F	E0 B	AVSS 0.75 CN-201F DS	6A157 DSA156 CN-	N-201F
183 O∕w AVSS 0.75 JS-A2	CN-305F	248 G AVSS 0.5 CN-11-5AF 249 L AVSS 0.75 CN-11-6AF	UN-301F	428 Gr/W AVSS 0.75 CN-108F 429 G AVSS 0.75 CN-108F	CN-291F		978 Y/G AVSS 0.5 CN-11-5AF	ON-294F	E0 B	AVSS 0.75 CN-209F DS	6A159 — DSA158 CN-	N-209F N-209F
83 O/W AVSS 0.75 JS-A2 83 O/W AVSS 0.75 JS-A2	CN-299F CN-299F	249 L AVSS 0.75 CN-11-6AF 301 Y AVSS 0.75 CN-109F 302 R AVSS 0.75 CN-104F	ON-292F	430 Br/Y AVSS 0.75 CN-108F 431 R/G AVSS 0.75 CN-108F			987 L/O AVSS 0.75 CN-300F ES3 B/R AVSS 0.75 CN-JA05F	CN-878F 	EO B	AVSS 0.75 CN-209F DS	6A159 DSA160 CN- 6A161 DSA160 CN-	N-208F
B3 O/W AVSS 0.75 JS-A2	CN-307F	308 L/Y AVSS 0.75 CN-101F	CN-674M	432 O/W AVSS 0.75 CN-108F	CN-304F		ES1 B/R AVSS 0.75 CN-JA05F	CN-307F	E0 B	AVSS 0.75 CN-207F DS	A161 DSA162 CN-	N-210F
84 Y AVSS 0.75 CN-305F 101 G/Y AVSS 0.75 CN-11-1AF	CN-290F	309 G/Y AVSS 0.75 CN-674M 310 R/Y AVSS 0.75 CN-674M	CN-101F	433 P/G AVSS 0.75 CN-108F 434 G/B AVSS 0.75 CN-108F	ON-302F ON-673F		ES2 B/R AVSS 0.75 CN-JA05F	ON-296F ON-JA05F	EO B	AVSS 0.75 CN-211F DS		N-210F
102 B AVSS 0.75 CN-11-1AF	ON 2005	244 W 04 AVCC 025 ON 4045	CN-674M	435 Br/G AVSS 0.75 CN-109F	CN-292F		ESJP B/R AVSS 0.75 ON-JA05F ES4 B/R AVSS 0.75 ON-298F	CN-JA05F	E0 B	AVSS 0.75 CN-213F DS	A165 DSA164 CN-	N-212F
103 R AVSS 0.75 CN-11-1AF 107 P AVSS 0.75 JS-A18	ON-295F	312 R/B AVSS 0.75 CN-302F 313 W/B AVSS 0.75 CN-302F		436 W/Y AVSS 0.75 CN-108F 437 O AVSS 0.75 CN-108F	ON-304F		ES5 B/R AVSS 0.75 CN-296F	ON-JA05F ON-JA05F	EO B	AVSS 0.75 ON-213F DS AVSS 0.75 ON-215F DS	6A165 DSA171 CN-	N-214F N-214F
107 P AVSS 0.5 JS-A18 107 P AVSS 0.5 JS-A18	CN-298F	314 P/W AVSS 0.75 CN-302F	CN-102F	438 I /Y AVSS 0.75 CN-209F	CN-109F		ES7 B/R AVSS 0.75 ON-298F ES8 B/R AVSS 0.75 ON-307F	CN-JA05F	E0 B	AVSS 0.75 CN-215F DS	6A170 DSA205 CN-	N-225F
107 P AVSS 0.5 JS-A18 108 Y AVSS 0.75 CN-11-1AF	CN-298F	315 P/L AVSS 0.75 CN-302F 316 W/G AVSS 0.75 CN-302F	ION-102F	439 O/L AVSS 0.75 CN-209F 440 W/R AVSS 0.75 CN-108F	ON-108F		114 R AVSS 0.75 CN-JA03F	- ON-11-1BF	E0 B	AVSS 0.75 JS-A301		N-225F
109 W AVSS 0.75 CN-11-1AF	CN-295F	317 L/Y AVSS 0.75 CN-302F	CN-102F	441 Y/B AVSS 0.75 CN-108F	ON-292F		115 G AVSS 0.75 CN-JA03F	ON-11-18F		AVSS 0.75 JS-A301 AVSS 1.25 JS-A301	JS-A	N-299F S-A302
112 B AVSS 0.75 JS-A19 112 B AVSS 0.5 JS-A19	CN-11-18F	318 R/L AVSS 0.75 CN-102F 319 G/B AVSS 0.75 CN-102F	CN-292F	442 R/B AVSS 0.75 CN-108F 443 0/L AVSS 0.75 CN-109F	ON-292F ON-303F		114 R AVSS 0.5 CN-JA03F 115 G AVSS 0.5 CN-JA03F	ON-282F ON-282F		AVSS 1.25 CN-294F AVSS 0.75 JS-A303	JS-A	G-A302 G-A302
112 B AVSS 0.5 JS-A19	CN-298F	320 W/Y AVSS 0.75 CN-102F	CN-292F	444 G/R AVSS 0.75 CN-109F			114 R AVSS 0.75 ON-JA03F	ON-101F	E0 B	AVSS 1.25 JS-A303	CN-3	√-304F
113 R/W AVSS 0.75 CN-298F 116 R/G AVSS 0.75 CN-11-18F	CN-11-18F	321 B/L AVSS 0.75 CN-302F 322 Y/B AVSS 0.75 CN-302F	CN-102E	445 R/Y AVSS 0.75 CN-108F 446 G AVSS 0.75 CN-109F	ON-292F ON-303F		115 G AVSS 0.75 CN-JA03F 114 R AVSS 0.75 CN-JA03F	01, 0005	EO B	AVSS 1.25 JS-A303	JS-A	G-A304 G-A304
118 W AVSS 0.75 CN-11-18F	CN-298F	323 Br/w AVSS 0.75 CN-302F	CN-102F	447 P AVSS 0.75 CN-109F	CN-304F		115 G AVSS 0.75 CN-JA03F	CN-673F	EO B	AVSS 0.75 CN-885F AVSS 1.25 CN-232F DS	A301 US-/	-A304
123 L AVSS 0.75 JS-A20 123 L AVSS 0.5 JS-A20	CN-11-1CF	324 O/L AVSS 0.75 CN-291F 325 W/O AVSS 0.75 CN-291F	CN-102F	448 G/Y AVSS 0.75 CN-109F 449 Br/L AVSS 0.75 CN-109F	CN-292F CN-303F		114 R AVSS 0.775 CN-JA03F 115 G AVSS 0.775 CN-JA03F	CN-CANAF CN-CANAF	EO B	AVSS 1.25 ON-232F DS	4301 CN-2	1-230F
123 L AVSS 0.5 JS-A20	CN-298F	326 Gr/R AVSS 0.75 CN-291F	CN-102F	450 P/G AVSS 0.75 CN-109F	ON-303F		119 Y AVSS 0.75 CN-JA06F	● △ △ △ / CN-11-1BF		V AVSS 1.25 ON-JA12F		V-672F
124 Y/W AVSS 0.75 CN-11-10F 125 B AVSS 0.75 CN-11-10F	CN-298F	327 R/W AVSS 0.75 CN-302F 328 L/G AVSS 0.75 CN-302F	CN-102F	451 L/8 AVSS 0.75 CN-109F 452 O/B AVSS 0.75 CN-109F	ON-303F		120 L AVSS 0.75 CN-JA06F 119 Y AVSS 0.75 CN-JA06F	7	E1 B/w	v AVSS 0.75 CN-JA12F v AVSS 0.75 CN-JA12F		V-11-1AF
126 R AVSS 0.75 ON-11-10F	ON-296F	329 Y/G AVSS 0.75 CN-302F	CN-102F	454 R/Y AVSS 0.75 (N-109F 454 R/Y AVSS 0.75 (N-290F	JS-A20		120 L AVSS 0.75 CN-JA06F	CN-300F	E2 B/w	V AVSS 1.25 CN-JA12F	→ CN-€	V-672F
128 G AVSS 0.75 CN-11-1CF 129 W AVSS 0.75 CN-11-1CF	CN-298F CN-296F	331 W/B AVSS 0.75 CN-102F	CN-670M	454 R/Y AVSS 0.75 0N-290F 454 R/Y AVSS 0.75 0N-306F	JS-A20 JS-A20		119 Y AVSS 0.75 CN-JA06F 120 L AVSS 0.75 CN-JA06F	ON-101F ON-101F	E2 B/v	v AVSS 0.75 CN-JA12F v AVSS 0.75 CN-JA12F		V-11-4F V-11-4F
131 G AVSS 0.75 CN-11-1DF 132 B AVSS 0.75 CN-11-1DF	CN-307F	332 B/Y AVSS 0.75 CN-223F 333 R/G AVSS 0.75 CN-223F	CN-103F	454 R/Y AVSS 0.75 0N-305F 455 L/Y AVSS 0.75 0N-106F	● DSA73 CN-237F		119 Y AVSS 0.5 CN-JA06F	ON-282F	E3 B/W	V AVSS 1.25 CN-105F V AVSS 1.25 CN-105F	CN-6	V-672F
133 R AVSS 0.75 CN-11-1DF	CN-307F	334 Y/L AVSS 0.75 CN-302F	CN-103F CN-103F	455 L/Y AVSS 0.75 CN-293F 456 G/B AVSS 0.75 CN-237F DSA	DSA73 CN-237F II5 CN-224F		120 L AVSS 0.5 CN-JA06F 119 Y AVSS 0.75 CN-JA06F		E5 B/w	V AVSS 1.25 CN-105F V AVSS 1.25 CN-672F		V-672F V-105F
137 W AVSS 0.75 CN-11-1DF 141 Y/W AVSS 0.5 CN-299F	CN-307F	335 Br/B AVSS 0.75 CN-302F	UN-1U3F	456 G/B AVSS 0.75 CN-237F DSA 458 L/B AVSS 0.75 CN-224F DSA	(15 CN-674M		120 L AVSS 0.75 CN-JA06F			V AVSS 0.5 CN-281F		V-672F
142 Y AVSS 0.75 CN-301F	CN-11-68F	336 Lg/R AVSS 0.75 CN-302F 337 0/L AVSS 0.75 CN-291F	CN-103F	458 L/B AVSS 0.75 ON-224F DSA	210 CN-300F							
144 R/Y AVSS 0.75 CN-11-4F	CN-301F	337 O./L AVSS 0.75 CN-291F 338 Gr/R AVSS 0.75 CN-291F 339 P AVSS 0.75 CN-291F	CN-103F CN-103F	459 Lg AVSS 0.75 CN-109F	ON-303F							
		1 Pro 10.10 104 291F	UV-103-									

(5/5)

8500-1 / 8500E-1 10-92 Published 12-16-15, Control #244-01



• **GH**



8500-1 / 8500E-1 10-94 Published 12-16-15, Control #244-01


DETAIL OF F

• GH

TRAVEL BUZZER CN-731

HYD. SELECT GANTRY SOL CN-750


SECTION J-J



(3/3)


Published 12-16-15, Control #244-01 8500-1 / 8500E-1 10-95

• GG




8500-1 / 8500E-1 10-96 Published 12-16-15, Control #244-01

• GG



(2/3)

• GG





`CN-704

`CN-706

(3/3)


8500-1 / 8500E-1 Published 12-16-15, Control #244-01 10-98






(2/5)

8500-1 / 8500E-1 10-100 Published 12-16-15, Control #244-01



CN-J73AM

CN-J74F 12FA-JM2



NONE NONE NONE NONE NONE

12FA-JM2

INSERT SEALING ON ALL EMPTY PINS

12MA-JM2

INSERT SEALING ON ALL EMPTY PINS

NONE NONE LA-N7 LA-N1 LA210 LA210 #1 E01 0.75 B + E02 0.75 B #1 E021 0.75 B + E021 0.75 B NONE NONE LA-N2 LA-N8 LA210 LA110 #1 E03 0.75 B + E04 0.75 B NONE NONE LA-N3 LA-N9 LA210 LA110 #1 E05 0.75 B + E06 0.75 B NONE NONE LA-N10 LA210 LA110 #1 E07 0.75 B + E08 0.75 B NONE LA-N5 LA110

NONE LA-N6

#1 E019 0.75 B + E020 0.75 B

(4/5)

Published 12-16-15, Control #244-01 8500-1 / 8500E-1 10-102

THE WIRE NO./COLOR LIST


%1 IDENTIFICATION SYMBOL %2 TWO WIRE CONNECT NUMBER

11 11	. WIRE COLOR			F R O M	X1	<u> </u>	CONNECTION	※ 2	<u> </u>	
	W/G	AVSS AVSS	0.75	CN-J76F			I		-	CN-764
1	W/G	AVSS	1.25	CN-J76F			T			CN-473
1	W/G	AVSS	1.25	CN-J76F			1			CN-412
6	W/G	AVSS	0.75	CN-J76F CN-J72F						CN-412
.6	<u> </u>	AVSS	0.75	CN-J72F			Ī			CN-412
6	L			CN-J72F			Ī			
9	L	AVSS AVSS	0.75	CN-J74F			-			CN-764
9	Y/B	AVSS	1.25	CN-J74F			1			CN-730
	Y/B		1.25				T			CN-732
9	Y/B	AVSS		CN-J74F			•			
3 3	0/W	AVSS	0.75	CN-J72F CN-J72F			1			CN-47
	0/W	AVSS	0.75				1			CN-710
13	0/W	AVSS	0.75	CN-J72F			1			CN-71:
3	0/W	AVSS	0.75	CN-J72F			1			CN-712
3	0/W	AVSS	1.25	CN-J72F			1			CN-714
3	0/W	AVSS	0.75	CN-J72F			•			CN-J72
3	0/W	AVSS	1.25	CN-715F						CN-J72
33	0/W	AVSS	1.25	CN-713F			•			CN-J72
.47	0/L	AVSS	1.25	CN-715F						CN-470
.48	G/W	AVSS	1.25	CN-713F						CN-470
49	L/W	AVSS	1.25	CN-470F						CN-714
56	P/W	AVSS	0.75	CN-472M						CN-710
57	W	AVSS	0.75	CN-471F						CN-711
58	R/W	AVSS	0.75	CN-472M						CN-712
37	0/L	AVSS	0.75	CN-723F						CN-47:
38	Gr/R	AVSS	0.75	CN-723F						CN-47:
339	P	AVSS	0.75	CN-723F						CN-47:
340	Sb	AVSS	0.75	CN-725F						CN-47:
341	W/L	AVSS	0.75	CN-725F						CN-47:
343	Y/B	AVSS	0.75	CN-724F			I 1			CN-47:
344	G/W	AVSS	0.75	CN-724F			I			CN-47:
345	Lg/Y	AVSS	0.75	CN-724F						CN-47:
346	R/L	AVSS	0.75	CN-725F						CN-47:
884	R/W	AVSS	0.75	CN-720F						CN-470
385	G/Y	AVSS	0.75	CN-721F						CN-470
386	0	AVSS	0.75	CN-470F			İ			CN-722
387	G/L	AVSS	0.75	CN-683M						CN-727
135	Br/G	AVSS	0.75	CN-683M						CN-413
141	Y/B	AVSS	0.75	CN-J75F						CN-412
141	Y/B	AVSS	0.75	CN-J75F			I			CN-473
141	Y/B	AVSS	0.75	CN-J75F			I			CN-763
442	R/B	AVSS	0.75	CN-J75F						CN-412
142	R/B	AVSS	0.75	CN-J75F			T			CN-473
142	R/B	AVSS	0.75	CN-J75F			I			CN-763
144	G/R	AVSS	0.75	CN-J76F						CN-412
144		AVSS	0.75	CN-J76F			Ī			CN-472
144	G/R	AVSS	0.75				T			CN-763
	G/R	AVSS	0.75	CN-J76F			-		1	_
145	R/Y			CN-474M						
453 453	R/W			ON IDAE						_
157		AVSS	0.75	CN-J74F			•			CN-772
	R/W	AVSS AVSS	0.75 0.75	CN-J74F			1			CN-772
153	R/W R/W	AVSS AVSS AVSS	0.75 0.75 0.75	CN-J74F CN-J74F			1			CN-772 CN-732 CN-730
153 155	R/W R/W L/Y	AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75	CN-J74F CN-J74F CN-J76F						CN-772 CN-732 CN-730 CN-412
153 155 155	R/W R/W L/Y	AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J74F CN-J76F CN-J76F			1			CN-772 CN-732 CN-730 CN-412 CN-472
153 155 155 155	R/W R/W L/Y L/Y	AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J74F CN-J76F CN-J76F CN-J76F						CN-772 CN-732 CN-730 CN-412 CN-472 CN-764
153 155 155 155 155	R/W R/W L/Y L/Y L/Y Gr/B	AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J76F CN-J76F CN-J76F CN-J76F CN-747F						CN-772 CN-732 CN-730 CN-412 CN-472 CN-764 CN-716
153 155 155 155 155 310	R/W R/W L/Y L/Y L/Y Gr/B B/Y	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J76F CN-J76F CN-J76F CN-J76F CN-747F CN-748F						CN-772 CN-732 CN-730 CN-412 CN-472 CN-764 CN-716 CN-716
153 155 155 155 310 311	R/W R/W L/Y L/Y L/Y Gr/B B/Y W/L	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J76F CN-J76F CN-J76F CN-J76F CN-747F CN-747F CN-749F						CN-772 CN-732 CN-730 CN-412 CN-472 CN-764 CN-716 CN-716 CN-716
153 155 155 155 150 151 1512	R/W R/W L/Y L/Y L/Y Gr/B B/Y	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J76F CN-J76F CN-J76F CN-J76F CN-747F CN-748F CN-749F CN-764M						CN-773 CN-732 CN-730 CN-412 CN-473 CN-716 CN-716 CN-716 CN-716
153 155 155 155 150 110 111 112	R/W R/W L/Y L/Y L/Y Gr/B B/Y W/L	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J76F CN-J76F CN-J76F CN-J76F CN-747F CN-747F CN-749F						CN-773 CN-732 CN-730 CN-412 CN-473 CN-716 CN-716 CN-716 CN-716
153 155 155 155 155 150 151 151 151 151 151	R/W R/W L/Y L/Y L/Y L/Y M/L W/L	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J76F CN-J76F CN-J76F CN-J76F CN-747F CN-748F CN-748F CN-749F CN-764M CN-716M CN-474M						CN-773 CN-732 CN-732 CN-732 CN-412 CN-764 CN-718 CN-718 CN-718 CN-771 CN-771 CN-771 CN-771
153 155 155 155 155 1610 1611 1612 1614 1614 1614	R/W R/W L/Y L/Y L/Y L/Y L/Y W/L W/L W/Y	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J74F CN-J76F CN-J76F CN-J76F CN-747F CN-748F CN-749F CN-764M CN-716M CN-772M						CN-773 CN-730 CN-730 CN-412 CN-764 CN-716 CN-716 CN-716 CN-771 CN-771 CN-777 CN-776
153 155 155 155 10 11 11 11 11 11 14 14 14 14 14 18 14	R/W R/W L/Y L/Y L/Y Gr/B B/Y W/L W/Y W/Y W/Y G/W Br/G	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J76F CN-J76F CN-J76F CN-J76F CN-748F CN-749F CN-764M CN-716M CN-474M CN-772M CN-776F CN-766F						CN-773 CN-730 CN-730 CN-7412 CN-764 CN-716 CN-716 CN-7716 CN-7716 CN-776 CN-776 CN-776 CN-776
153 155 155 155 155 110 111 1512 1614 1614 1614 1614 1619 1610 1610 1610 1610 1610 1610 1610	R/W R/W L/Y L/Y L/Y L/Y G/B B/Y W/L W/Y W/Y W/Y G/W Br/G Gr	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J74F CN-J76F CN-J76F CN-J76F CN-749F CN-749F CN-764M CN-716M CN-7172M CN-766F CN-772M						CN-777 CN-732 CN-732 CN-732 CN-412 CN-477 CN-764 CN-716 CN-716 CN-776 CN-776 CN-777 CN-777 CN-777 CN-777
153 155 155 155 155 150 151 151 151 151 151	R/W R/W L/Y L/Y L/Y Gr/B B/Y W/L W/Y W/Y W/Y G/W Br/G	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J74F CN-J76F CN-J76F CN-J76F CN-J76F CN-749F CN-749F CN-749F CN-716M CN-716M CN-772M CN-772M CN-772M CN-J75F						CN-777 CN-732 CN-732 CN-732 CN-412 CN-477 CN-716 CN-716 CN-776 CN-776 CN-777 CN-777 CN-777 CN-777 CN-773 CN-732 CN-412
153 155 155 155 155 110 111 1512 1614 1614 1614 1614 1619 1610 1610 1610 1610 1610 1610 1610	R/W R/W L/Y L/Y L/Y L/Y G/B B/Y W/L W/Y W/Y W/Y G/W Br/G Gr	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J74F CN-J76F CN-J76F CN-J76F CN-749F CN-749F CN-764M CN-716M CN-7172M CN-766F CN-772M						CN-777 CN-732 CN-732 CN-732 CN-412 CN-477 CN-764 CN-716 CN-716 CN-776 CN-776 CN-777 CN-777 CN-777 CN-777 CN-773 CN-732 CN-412
153 155 155 155 155 155 151 151 151 151	R/W R/W L/Y L/Y L/Y L/Y W/L W/Y W/Y W/Y W/Y G/W BF/G G/O	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J74F CN-J76F CN-J76F CN-J76F CN-J76F CN-749F CN-749F CN-749F CN-716M CN-716M CN-772M CN-772M CN-772M CN-J75F						CN-773 CN-732 CN-732 CN-412 CN-473 CN-716 CN-716 CN-716 CN-776 CN-777 CN-777 CN-765 CN-773 CN-732 CN-732 CN-412 CN-412
153 155 155 155 155 160 161 161 162 162 162	R/W R/W L/Y L/Y L/Y L/Y W/L W/Y W/Y W/Y G/W Br/G Gr G/O	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J74F CN-J76F CN-J76F CN-J76F CN-776F CN-747F CN-749F CN-749F CN-716M CN-716M CN-772M CN-772M CN-772M CN-J75F CN-J75F						CN-773 CN-736 CN-736 CN-416 CN-716 CN-716 CN-716 CN-776 CN-776 CN-777 CN-777 CN-773 CN-473 CN-471 CN-471 CN-471 CN-773 CN-773 CN-773 CN-773 CN-773 CN-773 CN-773 CN-773
153 155 155 155 1510 1512 1514 1514 1514 1519 159 162 162 162	R/W R/W L/Y L/Y L/Y L/Y W/L W/Y W/Y W/Y G/W Br/G Gr G/O G/O	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J76F CN-J76F CN-J76F CN-J76F CN-747F CN-747F CN-749F CN-749F CN-716M CN-716M CN-772M CN-772M CN-772M CN-J75F CN-J75F						CN-773 CN-736 CN-736 CN-716 CN-716 CN-716 CN-716 CN-717 CN-77
153 155 155 155 156 151 151 151 151 161 161	R/W R/W L/Y L/Y L/Y Gr/B B/Y W/L W/Y W/Y G/W Br/G Gr G/O G/O L/G	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J74F CN-J76F CN-J76F CN-J76F CN-776F CN-748F CN-749F CN-764M CN-716M CN-772M CN-772M CN-772M CN-772M CN-J75F CN-J75F CN-J75F CN-J75F CN-J75F						CN-773 CN-736 CN-736 CN-736 CN-412 CN-412 CN-716 CN-716 CN-776 CN-777 CN-76 CN-776 CN-773 CN-412 CN-473 CN-473 CN-473 CN-473 CN-473 CN-473 CN-473
153	R/W R/W L/Y L/Y L/Y Gr/B B/Y W/L W/Y W/Y W/Y G/W Br/G Gr G/O G/O G/O L/G Lg/Y	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J74F CN-J76F CN-J76F CN-J76F CN-776F CN-749F CN-764M CN-716M CN-716M CN-772M CN-772M CN-J75F CN-J75F CN-J75F CN-J75F CN-J75F CN-J730F CN-730F CN-7345F						CN-773 CN-733 CN-733 CN-412 CN-473 CN-716 CN-716 CN-771 CN-777 CN-773 CN-412 CN-473 CN-473 CN-473 CN-473 CN-473 CN-773 CN-473 CN-773 CN-473 CN-775 CN-775 CN-775
153	R/W R/W L/Y L/Y L/Y L/Y W/L W/Y W/Y W/Y G/W Br/G Gr G/O G/O L/G L/G L/G C/R Gr/R	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J74F CN-J76F CN-J76F CN-J76F CN-749F CN-749F CN-764M CN-716M CN-716M CN-772M CN-772M CN-775F CN-J75F CN-J75F CN-J75F CN-J75F CN-J775F						CN-773 CN-732 CN-732 CN-412 CN-473 CN-716 CN-716 CN-776 CN-777
153 155 155 155 155 155 151 151 151 151	R/W R/W L/Y L/Y L/Y L/Y W/L W/Y W/Y W/Y G/W BF/G Gr G/O G/O L/G L/G GF/R GF/R GF/R	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J74F CN-J76F CN-J76F CN-J76F CN-J76F CN-749F CN-749F CN-749F CN-716M CN-716M CN-772M CN-772M CN-J75F CN-J75F CN-J75F CN-J75F CN-J75F CN-J75F CN-J77F CN-J77F CN-J77F						CN-773 CN-736 CN-736 CN-736 CN-716 CN-716 CN-716 CN-717 CN-776 CN-777
153 155 155 155 155 151 151 151 151 151	R/W R/W L/Y L/Y L/Y Gr/B B/Y W/L W/Y W/Y G/W Br/G Gr G/O G/O G/O L/G L/G L/G L/G Gr/R Gr/R Gr/R Gr/R	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J74F CN-J76F CN-J76F CN-J76F CN-J76F CN-747F CN-748F CN-749F CN-716M CN-716M CN-7716M CN-772M CN-772M CN-775F CN-J75F CN-J75F CN-J75F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F						CN-773 CN-733 CN-733 CN-733 CN-736 CN-716 CN-716 CN-716 CN-717 CN-76 CN-77 CN-76 CN-77
153	R/W R/W L/Y L/Y L/Y G/B B/Y W/L W/Y W/Y G/W Br/G G G G/O G/O L/G L9/Y Gr/R Gr/R Gr/R L9 L9	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J74F CN-J76F CN-J76F CN-J76F CN-J76F CN-749F CN-764M CN-7716M CN-7716M CN-772M CN-772M CN-J75F CN-J75F CN-J75F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F						CN-77. CN-73. CN-73. CN-73. CN-73. CN-412. CN-76. CN-71. CN-71. CN-77. CN-76. CN-77. CN-76. CN-77. CN-76. CN-77. CN-76. CN-77. CN-76. CN-77. CN-76. CN-77. CN-76. CN-77. CN-76. CN-77. CN-76. CN-77. CN-76. CN-77. CN-76. CN-77. CN-76. CN-77. CN-76. CN-77. CN-76. CN-77. CN-76. CN-77. CN-76. CN-77. CN-76. CN-77. CN-76. CN-77. CN-76. CN-76. CN-77. CN-76.
153	R/W R/W L/Y L/Y L/Y Gr/B B/Y W/L W/Y W/Y W/Y Gr/B Gr/G Gr G/O G/O G/O G/O G/O G/O G/O L/G Lg/Y Gr/R Gr/R Gr/R Lg Lg Lg	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J74F CN-J76F CN-J76F CN-J76F CN-J76F CN-749F CN-749F CN-764M CN-716M CN-7716M CN-772M CN-772M CN-J75F CN-J75F CN-J75F CN-J75F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F						CN-773 CN-733 CN-734 CN-736 CN-7412 CN-761 CN-771 CN-771 CN-771 CN-772 CN-773 CN-473 CN-773 CN-473 CN-773 CN-473 CN-773 CN-473 CN-773 CN-473 CN-773 CN-773 CN-473 CN-773 CN-473 CN-773 CN-473 CN-773 CN-473 CN-773 CN-773 CN-411 CN-773
153 155 155 155 155 155 151 151 151 151	R/W R/W L/Y L/Y L/Y Gr/B B/Y W/L W/Y W/Y W/Y Gr/G Gr G/O G/O G/O G/O G/O G/O G/O L/G L9/Y Gr/R Gr/R Gr/R L9 L9 L9 L9 L9 L9 L9 L9 L9 L9 L9 L9 L9	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J74F CN-J76F CN-J76F CN-J76F CN-J76F CN-749F CN-749F CN-764M CN-716M CN-772M CN-772M CN-775F CN-J75F CN-J75F CN-J75F CN-J77						CN-773 CN-733 CN-733 CN-736 CN-412 CN-412 CN-716 CN-716 CN-716 CN-776 CN-776 CN-776 CN-776 CN-776 CN-777 CN-477 CN-477 CN-477 CN-477 CN-477 CN-477 CN-477 CN-477 CN-776 CN-776 CN-776 CN-776 CN-776 CN-776 CN-776 CN-776 CN-776 CN-776 CN-776 CN-777 CN-776 CN-777 CN-776 CN-777 CN-776 CN-777 CN-776 CN-777 CN-776 CN-777 CN-776 CN-777 CN-776 CN-777 CN-776 CN-777 CN-776 CN-777 CN-777 CN-777 CN-777 CN-777
153 155 155 155 155 155 151 151	R/W R/W L/Y L/Y L/Y L/Y L/Y W/L W/Y W/Y W/Y W/Y G/W Br/G Gr G/O G/O L/G L/G L/G L/G L/G L/G L/G L/G L/G L/G	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J74F CN-J76F CN-J76F CN-J76F CN-J76F CN-749F CN-749F CN-749F CN-764M CN-716M CN-474M CN-772M CN-772M CN-J75F CN-J75F CN-J75F CN-J75F CN-J75F CN-J77						CN-777 CN-736 CN-736 CN-736 CN-716 CN-716 CN-716 CN-716 CN-776 CN-776 CN-777 CN-766 CN-777 CN-776 CN-777 CN-776 CN-777 CN-776 CN-777 CN-776 CN-777 CN-777 CN-776 CN-777 CN-777 CN-777 CN-777 CN-777 CN-777 CN-777 CN-777 CN-777 CN-777 CN-777 CN-777 CN-777
153	R/W R/W L/Y L/Y L/Y Gr/B B/Y W/L W/Y W/Y W/Y G/W Br/G Gr G/O G/O G/O G/O G/O L/G L/G L/G L/G L/G L/G L/G L/G L/G L/G	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J74F CN-J76F CN-J76F CN-J76F CN-J76F CN-747F CN-748F CN-749F CN-764M CN-716M CN-716M CN-772M CN-772M CN-772M CN-775F CN-J75F CN-J75F CN-J75F CN-J77						CN-773 CN-736 CN-736 CN-736 CN-716 CN-716 CN-716 CN-717 CN-76 CN-776 CN-776 CN-776 CN-776 CN-777 CN-776 CN-777 CN-776 CN-777 CN-776 CN-777 CN-776 CN-777 CN-776 CN-777 CN-776 CN-777 CN-776 CN-776 CN-777 CN-776
153	R/W R/W L/Y L/Y L/Y Gr/B B/Y W/L W/Y W/Y W/Y G/W Br/G Gr G/O G/O L/G L/G L/G L/G L/G L/G L/G L/G L/G L/G	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J74F CN-J76F CN-J76F CN-J76F CN-J76F CN-748F CN-748F CN-749F CN-764M CN-7716M CN-772M CN-772M CN-772M CN-J75F CN-J75F CN-J75F CN-J77F CN-J7						CN-773 CN-736 CN-736 CN-736 CN-766 CN-716 CN-716 CN-716 CN-776 CN-777 CN-776 CN-777 CN-776 CN-777 CN-776 CN-777 CN-776 CN-776 CN-776 CN-776 CN-776 CN-776 CN-776 CN-776 CN-776
153 155 155 155 155 155 151 151	R/W R/W L/Y L/Y L/Y L/Y Gr/B B/Y W/L W/Y W/Y W/Y Gr/W Br/G Gr G/O G/O G/O G/O L/G L/G L/G L/G L/G L/G L/G L/G L/G L/G	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J74F CN-J76F CN-J76F CN-J76F CN-J76F CN-776F CN-749F CN-749F CN-764M CN-7716M CN-772M CN-772M CN-775F CN-J75F CN-J775F CN-J776F CN-J777F						CN-773 CN-736 CN-736 CN-736 CN-716 CN-716 CN-716 CN-776 CN-777 CN-766 CN-777 CN-767 CN-777 CN-767 CN-777 CN-767 CN-777 CN
153	R/W R/W L/Y L/Y L/Y L/Y Gr/B B/Y W/L W/Y W/Y W/Y W/Y Gr/G Gr G/O G/O G/O G/O G/O G/O L/G Lg/Y Gr/R Gr/R Gr/R Gr/R Gr/R Gr/R Cr/R Cr/R R CO/W G/L G/L G/L	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J74F CN-J76F CN-J76F CN-J76F CN-J76F CN-J76F CN-749F CN-749F CN-764M CN-716M CN-7716M CN-772M CN-772M CN-J75F CN-J75F CN-J75F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F CN-J77F CN-J777F CN-J777P CN-J772M CN-J77						CN-773 CN-736 CN-736 CN-736 CN-716 CN-716 CN-716 CN-776 CN-776 CN-776 CN-776 CN-777
153 155 155 155 155 150 151 151 151 151 151	R/W R/W L/Y L/Y L/Y L/Y Gr/B B/Y W/L W/Y W/Y W/Y Gr/W Br/G Gr G/O G/O G/O G/O L/G L/G L/G L/G L/G L/G L/G L/G L/G L/G	AVSS AVSS AVSS AVSS AVSS AVSS AVSS AVSS	0.75 0.75 0.75 0.75 0.75 0.75 0.75 0.75	CN-J74F CN-J74F CN-J76F CN-J76F CN-J76F CN-J76F CN-776F CN-749F CN-749F CN-764M CN-7716M CN-772M CN-772M CN-775F CN-J75F CN-J775F CN-J776F CN-J777F						CN-716 CN-773 CN-773 CN-773 CN-776 CN-776 CN-776 CN-776 CN-776 CN-776 CN-776 CN-776 CN-777 CN-777 CN-777 CN-777 CN-777 CN-777 CN-777 CN-777 CN-777 CN-777 CN-777 CN-777 CN-777 CN-777 CN-777 CN-776

WIRE NO.	WIRE COLOR		SIZE	F R O M	% 1		CONNECTION	※ 2	%1	T 0
946	0/L	AVSS	0.75	CN-413F						CN-683M
947	P/G	AVSS	0.75	CN-413F						CN-683M
950	G	AVSS	0.75	CN-764M						CN-473M
956	L/Y	AVSS	0.75	CN-869F						CN-716M
972	G/L	AVSS	0.75	CN-474M						CN-764M
973	0/L	AVSS	0.75	CN-474M						CN-764M
974	Gr/B	AVSS	0.75	CN-474M						CN-764M
988	G	AVSS	0.75	CN-751F			-			CN-J74F
988	G	AVSS	0.75	CN-413F						CN-J74F
988	G	AVSS	0.75	CN-680F						CN-J74F
989	Y/G	AVSS	0.75	CN-751F			•			CN-J74F
989	Y/G	AVSS	0.75	CN-413F						CN-J74F
989	Y/G	AVSS	0.75	CN-680F			-			CN-J74F
C02	Y	AVSS	0.75	CN-J75F			•			CN-412F
C02	Υ	AVSS	0.75	CN-J75F						CN-473M
C02	Υ	AVSS	0.75	CN-J75F						CN-764M
JP717	Y	AVSS	0.75	CN-783F						CN-783F
371	G	AVSS	0.75	CN-472M	0.75TW1				0.75TW1	CN-740F
380	W	AVSS	0.75	CN-472M	0.75TW1				0.75TW1	CN-740F
952	L/0	AVSS	0.75	CN-472M	0.75TW2				0.75TW2	CN-742F
953	G/B	AVSS	0.75	CN-472M	0.75TW2				0.75TW2	CN-742F
954	Br/Y	AVSS	0.75	CN-472M	0.75TW3		¬^^~		0.75TW3	CN-741F
955	G/L	AVSS	0.75	CN-472M	0.75TW3				0.75TW3	CN-741F
A41	W/B	AVSS	0.5	CN-474M	0.5TW1				0.5TW1	CN-628F
A42	W/L	AVSS	0.5	CN-474M	0.5TW1				0.5TW1	CN-628F
131	G	MVVS	0.75	CN-470F	4C2				4C2	CN-760F
132	В	MVVS	0.75	CN-470F	4C2				4C2	CN-760F
133	R	MVVS	0.75	CN-470F	4C2				4C2	CN-760F
137	W	MVVS	0.75	CN-470F	4C2				4C2	CN-760F
ES1	B/R	AVSS	0.75	CN-470F	4C2				4C2	(CN-760F)


(5/5)


JUNCTION BOX



8500-1 / 8500E-1 10-104 Published 12-16-15, Control #244-01

ATT. JUNCTION HARNESS







(1/2)


THE WIRE NO. /COLOR LIST


×1	×2	* 3	×4	F R O M	<u>*</u> 5	<u> </u>	¥7	*8	% 7	¥6	X5	T 0
44	0/W	AVSS	0.75	CN-299M	1	***			7.0	***	7	JS
44	0/W	AVSS	0.75	CN-1061F	11							JS
44	0/W	AVSS	0.75	CN-1061F	3							JS
145	Y/L	AVSS	0.75	CN-1001F	5						10	CN-299M
146	Gr	AVSS	0.75	CN-1001F	6						11	CN-299M
147	0/L	AVSS	0.75	CN-1061F	16						3	CN-299M
149	L/W	AVSS	0.75	CN-1061F	15						2	CN-299M
150	Br	AVSS	0.75	CN-1001F	7						9	CN-299M
153	G/Y	AVSS	0.75	CN-1061F	14						8	CN-299M
154	Br/W	AVSS	0.75	CN-1061F	13						4	CN-299M
155	Lg/W	AVSS	0.75	CN-1061F	12						5	CN-299M
975	G	AVSS	0.75	CN-1061F	2						1	CN-888M
976	L	AVSS	0.75	CN-1061F	1						2	CN-888M
44	R	MVVS	0.75	CN-1001F	10	3C7		<u> </u>		3C7	12	CN-299M
141	W	MVVS	0.75	CN-1001F	8	3C7				3C7	13	CN-299M
EO	В	MVVS	0.75	CN-1001F	9	3C7				3C7	14	CN-299M
ES	B/R	AVSS	0.75	(CN-1001F)		3C7				3C7	20	CN-298M
ES	B/R	AVSS	0.75	CN-1001F	4	3C7				3C7		(CN-299M)
101	Free	MVVS	0.75	CN-1061F	7	10C9		-		10C9	10	CN-298M
107	Free	MVVS	0.75	CN-1061F	5	10C9				10C9	19	CN-298M
108	Free	MVVS	0.75	CN-1061F	6	10C9				10C9	9	CN-298M
112	Free	MVVS	0.75	CN-1061F	8	10C9				10C9	8	CN-298M
113	Free	MVVS	0.75	CN-1061F	10	10C9				10C9	6	CN-298M
118	Free	MVVS	0.75	CN-1061F	9	10C9				10C9	7	CN-298M
123	Free	MVVS	0.75	CN-1001F	1	10C9				10C9	14	CN-298M
124	Free	MVVS	0.75	CN-1001F	3	10C9			4	10C9	4	CN-298M
128	Free	MVVS	0.75	CN-1001F	2	10C9				10C9	5	CN-298M
ES	B/R	AVSS	0.75	(CN-1061F)		10C9				10C9	15	CN-298M
ES	B/R	AVSS	0.75	CN-1061F	4	10C9				10C9		(CN-298M)

(2/2)

Published 12-16-15, Control #244-01 8500-1 / 8500E-1 10-106

9. ENGINE





STARTER MOTOR TO ENGINE GROUND



WIRE No. AND WIRE COLER LIST

WIRE No.	COLER	TYPE	SIZE	F	R	O M	DISTINGUISH SYMBOL	2-WIRE CLAMP No.	CC	NNECT	ON	2-WIRE CLAMP No.	DISTINGUISH SYMBOL	TO
EG1	В	AV	60	LA-	-C11				_		-			LA-C5

STARTER MOTOR TERMINAL B ALTERNATOR B TERMINAL




WIRE No. AND WIRE COLER LIST


WIRE No.	COLER	TYPE	SIZE	FR	0 M	DISTINGUISH SYMBOL	2-WIRE CLAMP No.	CONNECTION	2-WIRE CLAMP No.	DISTINGUISH SYMBOL	ΤO
2M	W	AV	20	LA-C3							LA-C10

8500-1 / 8500E-1 10-108 Published 12-16-15, Control #244-01

10. MONITOR



MONITOR HARNESS




WIRE No. AND WIRE COLOR LIST


WIRE No.	COLOR	TYPE	SIZE	FROM	PIN No.	DISTINGUISH SYMBOL	2-WIRE CLAMP	CONNECTION	2-WIRE CLAMP	DISTINGUISH SYMBOL	PIN No.	ТО
27	P/W	AVSS	0. 75	CN-427M	5						1	D-1
JP01	Υ	AVSS	0. 75	CN-590F	7						8	CN-590F
194	R	MVVS	0. 75	CN-427M	1	3C4		\sim		3C4	3	CN-590F
195	W	MVVS	0. 75	CN-427M	2	3C4				3C4	2	CN-590F
196	В	MVVS	0. 75	CN-427M	3	3C4				3C4	5	CN-590F
ES2	B/R	AVSS	0. 75	CN-427M	7	3C4				3C4		(CN-590F)
E11	B/W	AVSS	0. 75	CN-427M	6						1	D-2

8500-1 / 8500E-1 10-110 Published 12-16-15, Control #244-01


11. COUNTERWEIGHT SELF REMOVAL




(1/2)



8500-1 / 8500E-1 10-112 Published 12-16-15, Control #244-01




12. COUNTERWEIGHT DETECTOR / 3-C/W / OPT.




8500-1 / 8500E-1 10-114 Published 12-16-15, Control #244-01

• 8500-1



COUNTERWEIGHT DETECTOR HARNESS (a) CN-JC02F CN-JC02M CN-JC01F 3FA-JM2+JN 3FA-JM2 3MA-JM2 CN-843M 10MC-SSP+JH CN-001F 6FC-SSR+JH INSERT SEALING (2822357-1) ON ALL EMPTY PINS INSERT SEALING ON ALL EMPTY PINS SUPPLY WITH MATE PAIR INSERT SEALING ON ALL EMPTY PINS CONNECTOR 615 1.25 W NONE NONE NONE NONE CN-JC01F 618 1.25 Lg 619 1.25 JUMPER 3FA-JM2+JN (AVSS 1.25sq) В NONE NONE INSERT SEALING ON ALL EMPTY PINS В JUMPER E026 1.25 B (AVSS 1.25sq) NONE NONE NONE CN-JC02F CN-JC02M CN-843M 3FA-JM2 3MA-JM2 10MC-SSP+JH INSERT SEALING (225-0093-000) ON ALL EMPTY PINS




THE WIRE NO. /COLOR LIST

1 1 1 L	VIIIL 110. /	OOLON LI)							
WIRE	10. WIRE COLC	OR WIRE TYPE	SIZE	FROM	% 1	% 2	CONNECTION	% 2	% 1	T 0
615	W	AVSS	1.25	CN-843M						CN-JC01F
616	Br	AVSS	1.25	CN-843M						CN-001F
618	Lg	AVSS	1.25	CN-843M						CN-001F
619	L	AVSS	1.25	CN-843M						CN-001F
E026	В	AVSS	1.25	CN-843M						CN-JC02F
E026	В	AVSS	1.25	CN-JC01F			-			CN-JC02F
E026	В	AVSS	1.25	CN-001F			——			CN-JC02F


%1 IDENTIFICATION SYMBOL
%2 TWO WIRE CONNECT NUMBER


Published 12-16-15, Control #244-01 8500-1 / 8500E-1 10-116

COUNTERWEIGHT DETECTOR HARNESS (b)




INSERT SEALING (225-0093-000) ON ALL EMPTY PINS





INSERT SEALING (225-0093-000) ON ALL EMPTY PINS







INSERT SEALING ON ALL EMPTY PINS


THE WIRE NO. /COLOR LIST

THE WIRE NO. / COLOR LIST													
WIRE NO.	WIRE COLOR	WIRE TYPE	SIZE	F R O M	※ 1	※ 2	接	続	% 2	※ 1	T 0		
615	W	AEX	1. 25	CN-002M							CN-003F		
616	Br	AEX	1. 25	CN-002M							CN-003F		
618	L9	AEX	1. 25	CN-002M							CN-JC05F		
E013	В	AEX	1. 25	CN-002M				-			CN-JC06F		
E013	В	AEX	1. 25	CN-JC05F				—			CN-JC06F		
E013	В	AEX	1. 25	CN-003F				 -			CN-JC06F		

3MA-JM2


%1 IDENTIFICATION SYMBOL

%2 TWO WIRE CONNECT NUMBER




8500-1 / 8500E-1 10-118 Published 12-16-15, Control #244-01


13. COUNTERWEIGHT DETECTOR / 4-C/W / OPT.




COUNTERWEIGHT DETECTOR HARNESS (a)





INSERT SEALING (225-0093-000) ON ALL EMPTY PINS











THE WIRE NO. /COLOR LIST

1111	THE WINE NO. 7 COLON ETG.													
WIRE NO.	WIRE COLOR	WIRE TYPE	SIZE	F R O M	※ 1	※ 2	接	続	※ 2	※ 1	T 0			
615	W	AEX	1. 25	CN-002M			-	_			CN-003F			
616	Br	AEX	1. 25	CN-002M				_			CN-003F			
618	L9	AEX	1. 25	CN-002M				_			CN-JC05F			
E013	В	AEX	1. 25	CN-002M				•			CN-JC06F			
E013	В	AEX	1. 25	CN-JC05F				-			CN-JC06F			
E013	В	AEX	1. 25	CN-003F				I -			CN-JC06F			


***1 IDENTIFICATION SYMBOL**

CN-003F 6FC-SSR+JH

*2 TWO WIRE CONNECT NUMBER


8500-1 / 8500E-1 Published 12-16-15, Control #244-01 10-120


COUNTERWEIGHT DETECTOR HARNESS (b)




(1/2)


INSERT SEALING (225-0093-000) ON ALL EMPTY PINS





INSERT SEALING (225-0093-000) ON ALL EMPTY PINS





THE WIRE NO. /COLOR LIST

WIRE NO	. WIRE COLOF	WIRE TYPE	SIZE	FROM	※ 1	※ 2	CONNECTION	% 2	※ 1	TO
615	W	AEX	1. 25	CN-001M						CN-002F
616	Br	AEX	1. 25	CN-001M						CN-JC03F
618	Lg	AEX	1. 25	CN-001M						CN-002F
619	L	AEX	1. 25	CN-001M						CN-002F
E013	В	AEX	1. 25	CN-001M						CN-JC04F
E013	В	AEX	1. 25	CN-JC03F						CN-JC04F
E013	В	AEX	1. 25	CN-002F						CN-JC04F


%1 IDENTIFICATION SYMBOL

%2 TWO WIRE CONNECT NUMBER

(2/2)


8500-1 / 8500E-1 10-122 Published 12-16-15, Control #244-01


COUNTERWEIGHT DETECTOR HARNESS (c)




(1/2)


INSERT SEALING (225-0093-000) ON ALL EMPTY PINS





INSERT SEALING (225-0093-000) ON ALL EMPTY PINS





THE WIRE NO. /COLOR LIST


WIRE NO.	WIRE COLOR	WIRE TYPE	SIZE	F R O M	※ 1	※ 2	接続	※ 2	※ 1	T 0
615	W	AEX	1. 25	CN-002M						CN-003F
616	Br	AEX	1. 25	CN-002M						CN-003F
618	Lg	AEX	1. 25	CN-002M						CN-JC05F
619	L	AEX	1. 25	CN-002M						CN-003F
E013	В	AEX	1. 25	CN-002M						CN-JC06F
E013	В	AEX	1. 25	CN-JC05F						CN-JC06F
E013	В	AEX	1. 25	CN-003F						CN-JC06F

- **%1 IDENTIFICATION SYMBOL**
- *2 TWO WIRE CONNECT NUMBER

(2/2)


8500-1 / 8500E-1 10-124 Published 12-16-15, Control #244-01


COUNTERWEIGHT DETECTOR HARNESS (d)




(1/2)


INSERT SEALING (225-0093-000) ON ALL EMPTY PINS





INSERT SEALING (225-0093-000) ON ALL EMPTY PINS





THE WIRE NO. /COLOR LIST


WIRE NO.	WIRE COLOR	WIRE TYPE	SIZE	F R O M	※ 1	※ 2	接続	※ 2	※ 1	T C
615	Y/L	AEX	1. 25	CN-003M						CN-004F
616	Br	AEX	1. 25	CN-003M						CN-004F
618	L9	AEX	1. 25	CN-003M						CN-004F
619	L	AEX	1. 25	CN-003M						CN-JC07F
E013	В	AEX	1. 25	CN-003M						CN-JC08F
E013	В	AEX	1. 25	CN-JC07F						CN-JC08F
E013	В	AEX	1. 25	CN-004F						CN-JC08F

- **X1** IDENTIFICATION SYMBOL
- *2 TWO WIRE CONNECT NUMBER

(2/2)


8500-1 / 8500E-1 10-126 Published 12-16-15, Control #244-01


14. CARBODY WEIGHT DETECTOR / OPT.



CARBODY WEIGHT DETECTOR HARNESS (a)







JPF1A 0.75 Y

CN-914AM 3MA-JM2




WIRE NO.	WIRE COLOR	WIRE TYPE	SIZE	F R O M	% 1	CONNECTION	% 1	T 0
614	W/Y	AVSS	0.75	CN-914F				CN-913M
EO	В	AVSS	0.75	CN-914F				CN-913M
JPF1A	Y	AVSS	0.75	CN-914AM				
JPF1C	Y	AVSS	0.75					CN-914AM


*1 TWO WIRE CONNECT NUMBER


8500-1 / 8500E-1 10-128 Published 12-16-15, Control #244-01

CARBODY WEIGHT DETECTOR HARNESS (b)











THE WIRE NO. / COLOR LIST


	WIRE NO.	WIRE COLOR	WIRE TYPE	SIZE	F	R	0	М	% 1	CONNEC	CTION	% 1	Τ	0
	JE6A	В	AVSS	0.75										
4	JE6C	В	AVSS	0.75										
4	JE7A	В	AVSS	0.75										
	JE7C	В	AVSS	0.75										

*1 TWO WIRE CONNECT NUMBER

CARBODY WEIGHT DETECTOR HARNESS (c)







THE WIRE NO. /COLOR LIST


WIRE NO.	WIRE COLOR	WIRE TYPE	SIZE	F	R	0	М	% 1	CONNECTION	※ 1	T C
JE6A	В	AVSS	0.75								
JE6C	В	AVSS	0.75								
JE7A	В	AVSS	0.75								
JE7C	В	AVSS	0.75								

*1 TWO WIRE CONNECT NUMBER


8500-1 / 8500E-1 10-130 Published 12-16-15, Control #244-01

15. BOOM OVER HOIST PREVENTING

- 8500-1
- 11000-1




(1/4)




8500-1 / 8500E-1 10-132 Published 12-16-15, Control #244-01

- 8500E-1
- 10000E-1



(3/4)



8500-1 / 8500E-1 10-134 Published 12-16-15, Control #244-01

BOOM OVER HOIST PREVENTING HARNESS (a)

.....


BOOM TIP TO JUNCTION BOX(CABLE REEL)


CN-1005F


11FAE-774R16+C-CL16



CONNECT TO THE SWING FRAME FRONT JUNCTION BOX
CN-1001M
11MAE-776P16+C-CL16








THE WIRE NO. / COLOR LIST

WIRE	NO. WIRE	COLOR	WIRE	TYPE	SIZE	F R O M	% 1	% 2	CONNECTION	% 2	% 1	T 0
44	Free		2PNCT-	SB	0.5	CN-1005F	10		$-\Lambda$		10	CN-1001M
123	Free		2PNCT-	SB	0.5	CN-1005F	1				1	CN-1001M
124	Free		2PNCT-	SB	0.5	CN-1005F	3				3	CN-1001M
128	Free		2PNCT-	SB	0.5	CN-1005F	2				2	CN-1001M
141	Free		2PNCT-	SB	0.5	CN-1005F	8				8	CN-1001M
145	Free		2PNCT-	SB	0.5	CN-1005F	5				5	CN-1001M
146	Free		2PNCT-	SB	0.5	CN-1005F	6				6	CN-1001M
150	Free		2PNCT-	SB	0.5	CN-1005F	7				7	CN-1001M
E0	Free		2PNCT-	SB	0.5	CN-1005F	9				9	CN-1001M
FREE	Free		2PNCT-	SB	0.5	CN-1005F	11				11	CN-1001M
ES	Free		SHIELD	1		CN-1005F	4					(CN-1001M)
ES	Free		SHIELD	1		(CN-1005F)					4	CN-1001M

%1 PIN NUMBER %2 TWO WIRE CONNECT NUMBER

BOOM OVER HOIST PREVENTING HARNESS (b)



CN-1021AF

CN-1026AM

Published 12-16-15, Control #244-01 8500-1 / 8500E-1 10-136

AVSS

AVSS


AVSS


1.25

1.25

1.25 CN-1026AM


BOOM OVER HOIST PREVENTING HARNESS (c)





DETAIL A

(1/2)



THE WIRE NO. / COLOR LIST


WIRE	NO.	WIRE	COLOR	WIRE	TYPE	SIZE	F	R O	М	% 1	% 2	CONNECTION	% 2	% 1	T	0
44		R		AVSS		1.25	CN-	-1021	1F						JS	
44		R		AVSS		1.25	CN-	-1022	2M						JS	
44		R		2PNCT	-SR	1.25	CN-	-1018	3M						JS	
145		В		2PNCT	-SR	1.25	CN-	-1021	1F						CN-1018N	√
146		W		2PNCT	-SR	1.25	CN-	-1022	2M						CN-1018N	√l
JP		Y		AVSS		1.25	CN-	-1021	1AM						CN-1021A	AΜ
JP		Υ		AVSS		1.25	CN-	-1022	2AF						CN-1022	4F

%1 IDENTIFICATION SYMBOL
%2 TWO WIRE CONNECT NUMBER

)

8500-1 / 8500E-1 10-138 Published 12-16-15, Control #244-01

BOOM OVER HOIST PREVENTING HARNESS (d)



Published 12-16-15, Control #244-01 8500E-1

CN-1022AM

CN-1027AM

AVSS

AVSS


AVSS

1.25

1.25


1.25 CN-1027AM

16. JIB OVER HOIST PREVENTING



8500-1 / 8500E-1 10-140 Published 12-16-15, Control #244-01

JIB OVER HOIST PREVENTING HARNESS (a)



CN-1043AM


AVSS

1.25


JIB OVER HOIST PREVENTING HARNESS (b)

CONNECT TO AUXILIARY HOOK OVERHOIST LS JUNCTION CABLE

CN-1042F



146




3FC-SSR

THE WIRE NO. / COLOR LIST

WIRE NO.	WIRE COLOR	WIRE TYPE	SIZE	FROM	% 1	% 2	CONNECTION		×1	T 0
46	В	VCTF	1.25	CN-1042F						CN-1027M
146	W	VCTF	1.25	CN-1042F						CN-1027M
JP	Y	AVSS	1.25	CN-1027AF						
JP .	Y	AVSS	1.25							CN-1027AF
JP	Y	AVSS	1.25	CN-1042AM						
JP	Υ	AVSS	1.25							CN-1042AM

%1 IDENTIFICATION SYMBOL
%2 TWO WIRE CONNECT NUMBER

Published 12-16-15, Control #244-01 8500-1 / 8500E-1 10-142




TRANSLIFTER HARNESS CN-909M 10MA-JM2 CONNECT TO LOWER MAIN HARNESS REMOTE CONTROLLER CONNECTION (LOWER PART) 21FAE-774R16+C-CL24 CN-916F /Jamanamanan CN-917M 12MA-JM2 CONNECT TO LOWER MAIN HARNESS NONE NONE NONE 938 Free | 0.75 | Free | NONE | 942 0.75 Free W NONE 943 NONE 0.75 Free 94 NONE NONE 932 0.75 Free NONE SEALING NONE NONE NONE NONE NONE Free 444 Free NONE H NONE NONE NONE NONE NONE GNONE NONE NONE NONE NONE NONE CN-917M CN-909M 12MA-JM2 CN-916F 10MA-JM2 21FAE-774R16+C+CL24

THE WIRE NO. / COLOR LIST


WIRE NO.	WIRE COLOR	WIRE TYPE	SIZE	F R O M	% 1	CONNECTION	×1	T 0
11F	Free	2PNCT-SR	0.75	CN-909M				CN-916F
26	Free	2PNCT-SR	0.75	CN-909M				CN-916F
441	Free	2PNCT-SR	0.75	CN-909M				CN-916F
442	Free	2PNCT-SR	0.75	CN-909M				CN-916F
444	Free	2PNCT-SR	0.75	CN-909M				CN-916F
455E	Free	2PNCT-SR	0.75	CN-909M				CN-916F
862C	Free	2PNCT-SR	0.75	CN-909M				CN-916F
932	Free	2PNCT-SR	0.75	CN-917M				CN-916F
933	Free	2PNCT-SR	0.75	CN-917M				CN-916F
934	Free	2PNCT-SR	0.75	CN-917M				CN-916F
935	Free	2PNCT-SR	0.75	CN-917M				CN-916F
936	Free	2PNCT-SR	0.75	CN-917M				CN-916F
937	Free	2PNCT-SR	0.75	CN-917M				CN-916F
938	Free	2PNCT-SR	0.75	CN-917M				CN-916F
939	Free	2PNCT-SR	0.75	CN-917M				CN-916F
940	Free	2PNCT-SR	0.75	CN-917M				CN-916F
941	Free	2PNCT-SR	0.75	CN-917M				CN-916F
942	Free	2PNCT-SR	0.75	CN-917M				CN-916F
943	Free	2PNCT-SR	0.75	CN-917M				CN-916F
950	Free	2PNCT-SR	0.75	CN-909M				CN-916F
C02A	Free	2PNCT-SR	0.75	CN-909M				CN-916F

8500-1 / 8500E-1 10-144 Published 12-16-15, Control #244-01

18. HOIST DRUM TURN SENSOR



(1/2)




(2/2)

8500-1 / 8500E-1 10-146 Published 12-16-15, Control #244-01

HOIST DRUM TURN SENSOR HARNESS

CONNECT TO SWING FLAME MAIN HARNESS




CONNECT TO BOOM HOIST DRUM TURN SENSOR



CN-794F



2MA-JM2




THE WIRE NO. / COLOR LIST

*1 TWO WIRE CONNECT NUMBER

WIRE NO.	WIRE COLOR	WIRE TYPE	SIZE	FROM	% 1	CONNECTION	% 1	T 0
387	L	AVSS	0.75	CN-727M				CN-794F
E021	В	AVSS	0.75	CN-727M				CN-794F


19. THIRD DRUM TURN SENSOR




8500-1 / 8500E-1 10-148 Published 12-16-15, Control #244-01

THIRD DRUM TURN SENSOR HARNESS

CONNECT TO SWING FRAME MAIN HARNESS








THE WIRE NO. / COLOR LIST

WIRE NO.	WIRE COLOR	WIRE TYPE	SIZE	FROM	% 1	CONNECTION	% 1	T 0	
386	0	AVSS	0.75	CN-722M				CN-793F	
E021	В	AVSS	0.75	CN-722M				CN-793F	

*1 TWO WIRE CONNECT NUMBER


20. DEF/AdBlue® TANK




8500-1 / 8500E-1 10-150 Published 12-16-15, Control #244-01

CN-657F

DEF/AdBlue® TANK HARNESS



12 7 CN-658F 12FA-MCP



WIRE NO.	WIRE COLOR	WIRE TYPE	SIZE	FROM	% 1		CONNECTION	% 2	% 1	T O
34	L/R	AVSS	0.5	CN-661F						CN-657F
A23	L	AVSS	0.5	CN-658F						CN-657F
A24	Sb	AVSS	0.5	CN-658F						CN-657F
A25	Р	AVSS	0.5	CN-658F						CN-657F
A26	R	AVSS	0.5	CN-658F						CN-657F
A27	W	AVSS	0.5	CN-658F						CN-657F
A28	В	AVSS	0.5	CN-658F						CN-657F
A29	Υ	AVSS	0.5	CN-658F						CN-657F
A30	G	AVSS	0.5	CN-658F						CN-657F
A56	Br	AVSS	0.5	CN-661F			$\neg \land \land \land \frown$			CN-657F
A57	R/W	AVSS	0.5	CN-661F						CN-657F

Published 12-16-15, Control #244-01 8500-1 / 8500E-1


E18

B/W


AVSS

0.5 CN-661F

21. CAMERA CONTROLLER




8500-1 / 8500E-1 10-152 Published 12-16-15, Control #244-01




Published 12-16-15, Control #244-01 8500E-1

CAMERA CONTROLLER HARNESS (a)



Published 12-16-15, Control #244-01



THE WIRE NO. /COLOR LIST

% 1		% 3		F R O M	% 5	% 6	※ 7	<u></u>	※ 7 ●	% 6	% 5	Т () <u></u> *9
139E	G	AVSS	0.3	CN-428M	2		DS-B92	9	•		5	CN-574F	300
139F	G	AVSS	0.3	CN-428M	2		DS-B92				5	CN-575F	300
139G	G	AVSS	0.3	CN-428M	4		DS-B94	9	•		5	CN-576F	300
139H	G	AVSS	0.3	CN-428M	4		DS-B94				5	CN-577F	300
140C	Y	AVSS	0.3	CN-428M	1		DS-B90	9	•		2	CN-574F	300
140E	Y	AVSS	0.3	CN-428M	1		DS-B90				2	CN-575F	300
140F	Y	AVSS	0.3	CN-428M	3		DS-B93	9			2	CN-576F	300
140G	Y	AVSS	0.3	CN-428M	3		DS-B93				2	CN-577F	300
204	Free	3C-2W	0.196	CN-574F	1			- - - - - - - - - -			1	CN-570M	200
ES2	В	AVSS	0.3	(CN-574F)							2	CN-570M	100
ES6	В	AVSS	0.3	CN-574F	4							(CN-570M)	100
206	Free	3C-2W	0.196	CN-575F	1						1	CN-571M	200
ES3	В	AVSS	0.3	(CN-575F)							2	CN-571M	100
ES7	В	AVSS	0.3	CN-575F	4							(CN-571M)	100
208	Free	3C-2W	0.196	CN-576F	1						1	CN-572M	200
ES4	В	AVSS	0.3	(CN-576F)							2	CN-572M	100
ES8	В	AVSS	0.3	CN-576F	4							(CN-572M)	100
210	Free	3C-2W	0.196	CN-577F	1			- - - - - - - - - -			1	CN-573M	200
ES5	В	AVSS	0.3	(CN-577F)							2	CN-573M	100
ES9	В	AVSS	0.3	CN-577F	4							(CN-573M)	100

%1 WIRE NO.
%2 WIRE COLOR
%3 WIRE TYPE
%4 SIZE

%5 PIN NUMBER

%6 IDENTIFICATION SYMBOL
%7 TWO WIRE CONNECT NO.

%8 CONNECTION

%9 LENGTH(DESIGN VALUE)

(2/2)


Published 12-16-15, Control #244-01 8500E-1

NONE

E022 0.75 B

NONE

CAMERA CONTROLLER HARNESS (b) CONNECT TO FLORI HARNESS A CN 442M GMY-CNA CAMERA POWER SUPPLY BOX CN-447F 2*Y-CNA CAMERA POWER SUPPLY BOX CN-447F 2*Y-CNA



138 0.75 G/B

NONE

139 0.3 R


NONE

THE WIRE NO. / COLOR LIST

*1 IDENTIFICATION SYMBOL *2 TWO WIRE CONNECT NUMBER

WIRE NO.	WIRE COLOR	WIRE TYPE	SIZE	FROM			CONNECTION			T O
	P/W	AVSS	0.75	CN-442M			-			CN-447F
138	G/B	AVSS	0.75	CN-442M						CN-442M
138	G/B	AVSS	0.75	CN-449F						CN-442M
139	R	AVS	0.3	CN-449F						CN-448M
E022	В	AVSS	0.75	CN-447F						CN-442M

8500-1 / 8500E-1 10-156 Published 12-16-15, Control #244-01



DRUM LIGHT INSTAL HARNESS

CONNECT TO LEFT DECK HARNESS (FP, GG, GD, GH, GK, HF, GN) CONNECT TO THE FRAME HARNESS (JD) CN-845M CA-E5 2MA-JM2 CA104 DRUM LIGHT CB-E5 CB104 CN-845M 2MA-JM2 751 0.75 G/R E01 0.75 B

NONE

CB-E5

CB104

THE WIRE NO./COLOR LIST

*1 I DENTIFICATION SYMBOL *2 TWO WIRE CONNECT NUMBER

WIRE NO.	WIRE COLOR	WIRE TYPE	SIZE	FROM	PIN NUMBER	% 1		CONNECTION		% 1	PIN NUMBER	T 0
751	G/R	AVSS	0.75	CB-E5	2						2	CN-845M
E01	В	AVSS	0.75	CN-845M	1						1	CA-E5

NONE CA-E5

CA104

8500-1 / 8500E-1 Published 12-16-15, Control #244-01 10-158

23. BACK LIGHT INSTAL

BACK LIGHT INSTAL HARNESS





THE WIRE NO./COLOR LIST

*1 IDENTIFICATION SYMBOL *2 TWO WIRE CONNECT NUMBER


762A Lg/R AV55 U.75 UB-E6 2 — 2 U	WIRE NO.	WIRE COLOR	WIRE TYPE	SIZE	F R O	M PIN NUI	IMBER	※1		CONNECTION		※ 1	PIN NUMBER	T 0
	752A	Lg/R		11 (5	II K-Fh	2							2	CN-844M
202 B	E02	В	AVSS	0.75	CA-E6	1							1	CN-844M





Published 12-16-15, Control #244-01 8500E-1

24. IT CONTROLLER INSTALLATION




8500-1 / 8500E-1 10-160 Published 12-16-15, Control #244-01

This page is blank for editing convenience.

10.1.3 LOCATION AND USE OF FUSE

While lifting two locks on the side face of the fuse box, open the cover.

Cover will not open unless the locks are completely unlocked.




CLASSIFICATION OF FUSE USE


Fuse No.	Capacity	Line No.	Use
F1	20A	1A - 11	Main power supply, Work light
F2	5A	4-12	Sub battery voltage monitor
F3	5A	1B - 13	IT controller
F4	5A	1B - 14	Back-up (M/L, MC1, MC2, Radio)
F5	10A	2F - 15	Bypass circuit
F6	5A	2F - 16	Release circuit
F7	10A	2F - 17	Control power (M/L)
F8	10A	2F - 18	Output power (M/L)
F9	10A	2F - 19	Control power (MC1)
F10	20A	2F - 20	Output power (MC1)
F11	10A	2F - 21	Auto-stop
F12	10A	2F - 22	Engine condition
F13	5A	84 - 23	Radio, One-way call
F14	20A	2G - 24	Wiper
F15	10A	2G - 25	Function lock
F16	10A	2G - 26	Remo-con
F17	5A	2G - 27	Monitor
F18	15A	2E - 28	Air conditioner
F19	10A	2E - 29	Air conditioner 2
F20	10A	2E - 30	Fun motor
F21	5A	51 - 31	Generation detect
F22	20A	IC - 32	DCU
F23	5A	IE - 33	ECU (BATT)
F24	15A	2J - 34	ECU (+BF)
F25	20A	2J - 35	ECU (+B)
F26	15A	2J - 36	Spare
F27	20A	2I - 37	DC motor 1 for oil cooler
F28	20A	21 - 38	DC motor 2 for oil cooler
F29	10A	21 - 39	Swing flasher, Voice alarm
F30	5A	54 - 40	Starter
F31	10A	2H - 41	Control power (MC2)
F32	20A	2H - 42	Output power (MC2)
F33	5A	2H - 43	Solenoid valve (Confluence/independent)
F34	5A	2H - 44	Overhoist limit switch
F35	10A	2H - 45	Fuel pump, Cigarette lighter
F36	10A	2K - 46	Relay
F37	10A	2K - 47	Relay
F38	5A	2K - 48	Free fall
F39	10A	2K - 49	Light
F40	10A	2K -	Spare

⚠ DANGER

- Ensure to turn key switch OFF when replacing fuse.
- · Replace the fuse with the same capacity.
- If fuse blows off right after replaced, there is some abnormality in the electric circuit.
 Find out a cause and take necessary action.




Fuse Connection Schematic




Label

F	А		F	А	F	А		F	А
1	20	20A	11	10	21	5	10A	31	10
2	5	X	12	10	22	20		32	20
3	5		13	5	23	5	X	33	5
4	5	2	14	20	24	15	5	34	5
5	10		15	10	25	20		35	10
6	5	15 A	16	10	26	15	5 A	36	10
7	10	×	17	15)	27	20	×	37	10
8	10	1	18	15	28	20	4	38	5
9	10	rre)	19	10	29	10	rre)	39	10
10	20	(Spare)	20	10	30	5	(Spare)	40	10

10.1.4 WIPER CONTROL RELAY




10.1.5 PRESSURE SWITCH (FOR TRAVEL MOTION DETECT)



Use	Part number	[ON] Pressure	[OFF] Pressure
Travel motion detect pressure		490.0 to 588.0 kPa	294.0 to 392.0 kPa
Travel motion detect pressure		(71.1 to 85.3 psi)	(42.6 to 56.9 psi)


8500-1 / 8500E-1 10-168 Published 12-16-15, Control #244-01


10.1.6 PRESSURE SWITCH (FOOT BRAKE)



Use	Part number	[ON] Pressure	[OFF] Pressure
Foot brake pressure		4.5 MPa (653 psi)	3.7 MPa (537 psi)

10.1.7 PRESSURE SENSOR






Use	Part number	Pressure raqnge	Power	Out-put
Main pump power shift control pressure				
Swing motion detect pressure (R/L)				
CHP cracking pressure		0 to 2 MDo (0 to 425 noi)	<i></i>	0.5 to 4.5 \
Remote control pressure		0 to 3 MPa (0 to 435 psi)	5 V	0.5 to 4.5 V
(Front, Rear, 3rd, Swing, Boom)				
Motor control pressure (Front, Rear, 3rd)				
Swing pump pressure				
Independence confluence select		0 to 50 MPa (0 to 7,252 psi)	5 V	0.5 to 4.5 V
Q max cut pressure				

NOTE

Pressure range	0 to 3 MPa (0 to 435 psi)	Pressure range	0 to 50 MPa (0 to 7,252 psi)
Voltage Vcc	4.5 to 5.5 VDC	Voltage Vcc	4.5 to 5.5 VDC
Out-put	1/10 Vcc = 0.5 V to 4.5 V	Out-put	1/10 Vcc = 0.5 V to 4.5 V
Tightning torque	32 N·m (26.7 ft·lbs) max	Tightning torque	73.5 N·m (54.2 ft·lbs) max





Use	Part number	Pressure raqnge	Power	Out-put
Clutch pressure (Front, Rear, 3rd)Control pressure (Primary side)		0 to 19.6 MPa (0 to 2,842 psi)	5 V	0.5 to 4.5 V

NOTE


Tightening torque	73.5 N·m (54.2 ft·lbs)


10.1.8 INCLINATION SENSOR





Electrical shematic






Type	N4AA20010
Angle range	±5 degrees
Power source	10 to 30 VDC
Power consumption	typ. 22 mA
Output	X-axis 0.5 to 4.5 V Y-axis 0.5 to 4.5 V
Load resistance	min.10 kΩ
Zero adjustment	±5 degrees
Resolution	0.04 degrees
Linearity error	1% typ. of angle range

	epetition ccuracy	±0.2 degrees typ.
Ten	nperature drift	1.3% typ.
Prote	ection class	IP 67
	nperature range	-40 to 70°C
	ibration sistance	Endurance 10 to 500 Hz Amplitude width 3 mm X, Y, Z direction 96h (about 20G)
	lmpact sistance	Endurance 500 m/s² (about 50G) X, Y, Z direction about 10th

10.1.9 BUZZER UNIT





Duzzer to be used	High-pitched tone	FDK corp.	EB2210A-38C-12V
Buzzer to be used	Low-pitched tone	Bass Star precession corp.	TMX-12F


Rated Volt	24 V
Work range (Volt)	19 to 32 V
Working temperature range	-10 to 60°C
Storage temperature range	-20 to 70°C
Humidity	0 to 90 %
Sound volume	75 db / 30 cm MIN
Consumption elc. current	Max. 50 mA

10.1.10 RELAY BOX

1. Arrangement of connector










No.	Name
RL-1	Generation detect
RL-2	Safety
RL-3	Separate oil cooler motor
RL-4	AIS
RL-5	Starter lock
RL-6	Certify release
RL-7	Engine stop
RL-8	Remote control horn
RL-9	Swing parking control
RL-10-1	Swing parking 1
RL-10-2	Swing parking 2
RL-12	Swing parking 3
RL-13	Pilot pressure cut
RL-14	Swing Hi/Low pressure select
RL-15	Swing neutral brake select
RL-16	Travel alarm
RL-17	Voice alarm
RL-18	Hyd. pressure select (SOL45)
RL-19	Hyd. pressure select (SOL44)
RL-20	Hyd. oil heat
RL-21	Engine restart
RL-22-1	MC1 bypass (left swing stop +)
RL-22-2	MC1 bypass (left swing stop -)
RL-22-3	MC1 bypass (right swing stop +)
RL-22-4	MC1 bypass (right swing stop -)
RL-22-5	MC1 bypass (main pump 1 +)
RL-22-6	MC1 bypass (main pump 1 -)
RL-22-7	MC1 bypass (main pump 2 +)
RL-22-8	MC1 bypass (main pump 2 -)
RL-22-9	MC1 bypass (boom pump +)
RL-22-10	MC1 bypass (boom pump -)
RL-23	Key resumption
RL-24	ML bypass reset


No.	Name
RL-25-1	ML bypass hold 1
RL-25-2	ML bypass hold 2
RL-27	Swing buzzer
RL-28	Speed limit release
RL-29	Speed limit
RL-30	Outside indication lamp (green)
RL-31	Outside indication lamp (yellow)
RL-32	Outside indication lamp (red)
RL-36	ML adjust mode select
RL-37	DPF Regeneration
RL-38	Swing flasher (L)
RL-39	Swing flasher (R)
RL-40	Pump Qmax cut
RL-41	CLM
RL-42	ESM
RL-43	CLA
RL-44	ESA
RL-45	CLT
RL-46	EST
RL-47	Front free select
RL-48	Rear free select
RL-49	Third free select
RL-50-1	Jib over hoist 1
RL-50-2	Jib over hoist 2
RL-51	No. 2 limit
RL-53	Boom over hoist
RL-54	Self removal select
RL-55	Assy / disassy select
RL-56	Mast model self removal select
RL-57-1	Jib mode select 1
RL-57-2	Jib mode select 2
RL-58-1	Bend - prevent relay (R. upper)
RL-58-2	Bend - prevent relay (L. upper)


2. Relay box schematic























10.1.11 RELAY BOX










No.	Name
RL-60	Boom hoist raise stop relay
RL-61	Boom hoist lower stop relay
RL-62	Front hoist stop relay
RL-63	Front lower stop relay
RL-64	Rear hoist stop relay
RL-65	Rear lower stop relay

No.	Name
RL-66	Third hoist stop relay
RL-67	Third lower stop relay
RL-68	MC bypass relay 1
RL-69	Independence, confluence select (F)
RL-70	Independence, confluence select (R)









10.1.12 LOAD DETECTOR (CRANE)


Model name	LTP-S-50-KNSA10					
Detective capacity	Guy-cable support power					
Rated capacity	5 ton (49.03 KN)					
Load capacity	150%					
Outrout wells as	with no load 1 V ± 0.01 V (at shipping)					
Output voltage	with rated load 5 V ± 0.040 V					
Power source	DC9V ± 15 V (under 30 mA)					
Output resistance	Appr. under 100 Ω					
Insulated resistance	500M Ω / above 25 VDC					
Non Lineality	± 0.01% RO/°C					
Hysteresis	± 0.03% RO/°C					
Temperature compensation range	-30°C + 65°C					
Temperature capacity	-35°C to + 75°C					
Temperature effect at zero point	± 0.1% RO/°C					
Temperature effect at output	± 0.1% RO/°C					
Output cable	None					
Output cable	apex classification 5P water proof plug AE770L14-05P					
Vibration proof	69.6 m/s 33 Hz up/down for 4 hours and left/right, front/back for 2 hours.					
Shock proof	245 m/s, 15 mS X,Y, Z (3 times each)					
Water proof	Conforms to IP67 or equivalent (JIS C0920 non-seaping type)					
Durability	5 × 10⁵ times					
Noise proof	DC700 V 100 ns					
Total integrity	2.9% RO					
Weight	About 3 kg					



10.1.13 ANGLE SENSOR

Model name :	MLA-901A-**C
Object to detect :	Boom angle against ground
Valid operating range :	0 to ± 90 degree
Operation range :	360° endless
Rated output sensitivity :	0.255 V/V ± 0.5%
Input voltage :	10V
Input resistance :	$50 \text{ k}\Omega \pm 5\%$
Output resistance :	$(25000 + 141.6 \times \theta) \Omega \pm 5\%$
Detecting accuracy :	± 1°
Initial imbalance :	Set within ±5°
Insulate resistance :	100M Ω/ 50VDC
Output cable :	Cabtire crolobren cable 0.5 mm² × 4
Cable analysis :	Bending radius : R100, Tensile strength : 8 kg
Cable apex :	5P water proof plug AE776L14-05S+MT12-14+MS3180-14CAL
Control method :	Oil damper
Monitor :	With outside weight 0°, 30°, 60°, 90° Monitorable
Case material :	Plastic (Toshiba premix AP-902S)
Surface treatment :	Non, stripe (Black)
Temperature range :	-20 to 70°C
Store temp. :	-40 to 80°C
Weight:	appr. 1.2 kg (main body), appr. 65 g/m (cable)





A-C Resistance :50KQ


A-B Resistance (R) $:25000+141.6\times0^{\circ}$

This page is blank for editing convenience.

10.1.14 HOW TO CHECK THE FAILURE CONTENTS

DST-1 diag. connector location

CN-486F is located beside of fuse box at behind operator's seat.



1. Table of Diagnosis codes (J08E-TI)

SAE		TCCS	Ι	Check	Egiluro	Resume	Injection volume	Engino	DPF	Egilura judging	EGR		
code	System	digit code	Function	Lamp ON	Failure Level	Timing	limit	Engine Stop action	Regeneration control	Failure judging condition	Motion	Cause of failure	Remark
P0217	Each sensor system & related dialog	6	Over heat	_	2	Instant resume	Limited to 75%	No stop	_	Waater temp 115°C	Stop	Over heat	
P2228	Each sensor system & related	15	Air pressure sensor failure (Lo)	0	2	Instant resume	Limited to 75%	No stop	_	<1.90V	Stop	Sensor failure or unexpected high	
P2229	dialog	13	Air pressure sensor failure (Hi)	0	2	Instant resume	Limited to 75%	No stop	_	>4.20V	Stop	recognition	
P119F			Commonrail press. sensor charact.abnormal	0	1	Instant resume	No limit	No stop	_		-		
P0192	Each sensor system & related	74	Commonrail press. Sensor failure (Lo)	0	2	After IG-OFF	No limit	No stop	No Regeneration	<0.64V	Stop	Sensore failure or harness wire	
P0193 P1197	dialog	<u> </u>	Commonrail press. Sensor failure (Hi) Commonrail sub press. Sensor failure (Lo)	0	2	After IG-OFF Instant resume	No limit No limit	No stop No stop	No Regeneration —	>4.78V <0.89V	Stop —	breaking, short	
P1198		74	Commonrail sub press. Sensor failure (Hi)	 	1	Instant resume	No limit	No stop	-	>4.82V	_	Sensore failure or harness wire breaking, short	Due to main priority, no output limit since limited at B/U main failure.
P0237	Each sensor system & related		Intake air press. (boost P.) sensor failure(Lo)	0	2	After IG-OFF	Limited to 75%	No stop	_	<0.19V	_	Sensore failure or harness wire	Injection volume is surpressed and
P0108	dialog	25	Intake air press. (boost P.) sensor failure(Hi)	0	2	After IG-OFF	Limited to 75%	No stop	_	>4.11	_	breaking, short	futher output down
P0117	Each sensor system & related	.	Water temp sensor failure (Lo)	0	2	Instant resume	Limited to 75%	No stop	_	<0.10V	Stop	Sensore failure or harness wire	
P0118	dialog	11	Water temp sensor failure (Hi)	0	2	Instant resume	Limited to 75%	No stop	_	>4.77V	Stop	breaking, short	
P0182	Each sensor system & related		Combution temp. sensor failure (Lo)	0	1	Instant resume	No limit	No stop	_	<0.10V	_	Sensore failure or harness wire	
P0183	dialog	14	Combution temp. sensor failure (Hi)	0	1	Instant resume	No limit	No stop	_	>4.85V	_	breaking, short	
P2120			Both accel sensor failure	0	1	After IG-OFF	No limit	No stop	-	1 · 2 sensor failed	_		
P2121			Accel sensor 1 voltage abnormal	<u> </u>	1	After IG-OFF	No limit	No stop	-		_	1	
P2122			Accel sensor 1 failure (Lo)	_	1	After IG-OFF	No limit	No stop	-	<0. 30V	_	1	★ C A N is main control
P2123 P2126	Accel sensor system	22	Accel sensor 1 failure (Hi) Accel sensor 2 voltage abnormal	 -	1	After IG-OFF After IG-OFF	No limit No limit	No stop	_	>4. 85V	_	Sensore failure or harness wire	X C A N is main control
P2127			Accel sensor 2 failure (Lo)	 _	1	After IG-OFF	No limit	No stop	_	<0. 30V	_	breaking, short	
P2128			Accel sensor 2 failure (Hi)	 _ 	1	After IG-OFF	No limit	No stop		>4. 85V	_	1	
P1133		23	Work accel sensor (Hi)	 _ 	1	After IG-OFF	No limit	No stop	_	>4. 85V	_	1	
P0335			Main rotate sensor failure, Both rotate sensor failure	0	2	Instant resume	Limited to 75%	No stop	_		Stop	When front rotate sensor failure. harness abnormal, both sensors failed starter ON at certain level.	Intake air volume is required in calculation. At fault Eng. Is closed.
P0336		13	Main rotate sensor pulse abnormal	0	2	Instant resume	Limited to 75%	No stop	-		Stop	otate sensor abnormal, pulse area abnor	
P0016	Rotating sensore system		Main sub,sensor phase shift failure	0	1	Instant resume	No limit	No stop	_		_		
P0340		12	Sub rotate sensor failure	0	1	Instant resume	No limit	No stop	_		_	ub rotate sensor failure, harness abnorma	Starting characteristics becomes
P0341		12	Sub rotate sensor pulse abnormal	0	1	Instant resume	No limit	No stop	_		_	tate sensor abnormal, pulse area abnorn	slightly worse.
P0088		69	Commonrail abnormal hi pressure (1st step)	0	1	After IG-OFF	No limit	No stop	_		_		
P0088		69	Commonrail abnormal hi pressure (2nd step)	0	1	After IG-OFF	No limit	No stop	_		_		
P0088		76	Commonrail pressure hi pressure abnormal	0	1	After IG-OFF	No limit	No stop	_		_		
P0087	Supply pump system	76	Commonrail pressure under abnormal	0	2	After IG-OFF	Limited to 75%	No stop	No Regeneration	1	Stop		
P0629		75	Supply pump sol v. 1failure (no press.feed)	0	3	After IG-OFF	Limited to 75%	No stop	No Regeneration	l	Stop	S C V short (+B)	Half of cylinders do not inject and output
P0628		73	Supply pump sol v. 1failure (All delivery)	0	2	After IG-OFF	Limited to 75%	No stop	_			S C V drive system abnormal	is decreased accordingly.
P2635		76	Supply pump replace	_	1	After IG-OFF	No limit	No stop	_				
P1211			Injector common 1 failure (GND short)	0	3	After IG-OFF	No limit	No stop	No Regeneration	1	Stop		Nia autout Emit
P1214	Injector system	68	Injector common 2 failure (GND short)	0	3	After IG-OFF	No limit	No stop	No Regeneration	1	Stop	injector power harness abnormal	No output limit. Inject inself is decreased into half,
P1212	injector system		Injector common 1 failure (VB short, open)	0	3	After IG-OFF	No limit	No stop	No Regeneration	1	Stop		reduced cylinder running and speed variation becomes large.
P1215			Injector common 2 failure (VB short, open)	0	3	After IG-OFF	No limit	No stop	No Regeneration	1	Stop		Ĭ Š
P0201		61	Injector 1 wire breaking	0	2	After IG-OFF	Limited to 75%	No stop	No Regeneration		Stop	,	
P0202		62	Injector 2 wire breaking	0	2	After IG-OFF	Limited to 75%	No stop	No Regeneration	ı	Stop		
P0203	Injector system	63	Injector 3 wire breaking	0	2	After IG-OFF	Limited to 75%	No stop	No Regeneration		Stop		No output limit. Failed cylinder does not inject and
P0204		64	Injector 4 wire breaking	0	2	After IG-OFF	Limited to 75%	No stop	No Regeneration		Stop	(intake side)	output is decreased accordingly.
P0205		65	Injector 5 wire breaking	0	2	After IG-OFF	Limited to 75%	No stop	No Regeneration		Stop	┥	
P0206		66	Injector 6 wire breaking	0	2	After IG-OFF	Limited to 75%	No stop	No Regeneration	1	Stop	I	I

Published 12-16-15, Control #244-01 8500E-1

П	1	TCCS		Chaal					D.D.E.				
SAE code	System	digit code	Function	Check Lamp ON	Failure Level	Resume Timing	Injection volume limit	Engine Stop action	D P F Regeneration control	Failure judging condition	EGR Motion	Cause of failure	Remark
P0263		61	Inter-cylinder Caribration errer # 1	-	1	After IG-OFF	No limit	No stop	_		_		
P0266		62	Inter-cylinder Caribration errer #2	-	1	After IG-OFF	No limit	No stop	-		_		
P0269	Injector custom	63	Inter-cylinder Caribration errer #3	_	1	After IG-OFF	No limit	No stop	_		_	Intercylinder carbration abnormal or	
P0272	Injector system	64	Inter-cylinder Caribration errer # 4	_	1	After IG-OFF	No limit	No stop	_		_	flow dumper actuation	
P0275		65	Inter-cylinder Caribration errer # 5	_	1	After IG-OFF	No limit	No stop	_		_		
P0278		66	Inter-cylinder Caribration errer # 6	_	1	After IG-OFF	No limit	No stop	_		_		
P0234	Turbo	34	Turbo over boost	0	3	Instant resume	Limited to 50%	No stop	_		_	Over boost Turbo failure	
P0045			VNT actuator failure 1 (major failure)	0	3	After IG-OFF	20%+rotate contro	No stop	-		_		
1 0040	V N T System	35	VNT actuator failure 2 (minor failure)	0	2	After IG-OFF	Limited to 75%	No stop	-	Failure info. Received from	_	Major failure may highly cause VNT drive area sticking.	
P00AF	V IV I Gyolom	00	VNT CONTROLLER FAILURE 1 (MAJOR FAILURE)	0	3	After IG-OFF	20%+rotate contro	No stop	-	VNT controller	_	Or failure of stuck.	
1 00/11			VNT CONTROLLER FAILURE 2 (MAJOR FAILURE)	0	2	After IG-OFF	Limited to 75%	No stop	_		_		
P0611		71	ECU CHARGE CIRCUIT FAILURE (Lo)	0	3	After IG-OFF	Limited to 75%	No stop	No Regeneration		Stop		
P0200			ECU CHARGE CIRCUIT FAILURE (Hi)	0	2	After IG-OFF	Limited to 75%	No stop	No Regeneration		Stop		
P0605	E C U Main body system		Flash ROM abnormal	0	2	After IG-OFF	Limited to 75%	No stop	No Regeneration		_	ECU failure Affecting engine control	
P0606	E 0 0 Main body system	3	CPU failure (Hard detect)	0	3	Instant resume	Forcible stop	Stop	_		_	Loo failure Allecting engine control	
P0607			CPU monitor IC abnormal	0	3	Instant resume	Limited to 75%	No stop	No Regeneration		Stop		
P1601		2	QR code failure	0	1	Instant resume	No limit	No stop	_		_		
P2100			DC motor wrte breakage drive duty wire breaka	0	1	After IG-OFF	No limit	No stop	_		_		
P2103		31	DC motor, GND short	0	3	After IG-OFF	Limited to 50%	No stop	-		Stop		
P2101	Intake air orfice valve		Intake air orifice sensor sticking	0	3	After IG-OFF	Limited to 50%	No stop	-		Stop	ecting to temp. rise at manual regenerat	at Intale throttle full open
P0122		32	Intake air orifice opening sensor failure (Lo)	0	3	After IG-OFF	Limited to 50%	No stop	-	<0.20V	_		
P0123		02	Intake air orifice opening sensor failure (Hi)	0	3	After IG-OFF	Limited to 50%	No stop	-	>4.80V	_		
P1458	E G R related	81	EGR system failure 1 (major failure)	0	2	After IG-OFF	Limited to 75%	No stop	No Regeneration		Stop	EGR close order, but may be stuck	
P1459	E G TY Tolatou	01	EGR system failure 2 (major failure)	0	2	After IG-OFF	Limited to 75%	No stop	-		Stop	EGR close order but close valve stuck	
P06D3		5	Air flow sensor power (+B)	_	1	Instant resume	No limit	No stop	-		_		
P06D4	Air flow sensor		Air flow sensor power (GND)	_	1	Instant resume	No limit	No stop	-		_		
P0104		17	Air flow sensor abnormal 1 (High frequend)	0	2	After IG-OFF	Limited to 75%	No stop	-	<0.85kHz	Stop		
P0104			Air flow sensor abnormal 2 (Low frequend)	0	2	After IG-OFF	Limited to 75%	No stop	-	>9.80kHz	Stop		
P0112	Intake air sensor	17	Intake air temp. sensor abnormal (Low)	0	1	Instant resume	No limit	No stop	-	<0.06V			
P0113			Intake air temp. sensor abnormal (High)	0	1	Instant resume	No limit	No stop	-	>4.55V			
P200C		91	D P F meltdown failure 1	0	1	DPF-reset	No limit	No stop	-		_		
P244A			D P F meltdown failure 2	0	3	DPF-reset	Limited to 50%	No stop	_		_		
P2463	DPF related	92	D P F abnormal clog 1	0	3	DPF-reset	Limited to 50%	No stop	-		_		Failure resume need reset of DPF internal info with special tool.
P244B			D P F abnormal clog 2	0	3	DPF-reset	Limited to 50%	No stop	-		_		Use of tool requiews sparate leveling
P2458		93	DPF catalyst detedeterioration 1	0	3	DPF-reset	Limited to 50%	No stop	No Regeneration		_		
P24A2			DPF catalyst detedeterioration 2	0	3	DPF-reset	Limited to 50%	No stop	No Regeneration		_		
P1427	Pressure difference sensor system	28	Pressure difference sensor abnormal (Lo)	0	3	After IG-OFF	Limited to 50%	No stop	-	<0.50V	_		
P1428	,		Pressure difference sensor abnormal (Hi)	0	3	After IG-OFF	Limited to 50%	No stop	-	>4.46V	_		
P0545			Exhaust air temp. sensor1 abnormal (Lo)	0	1	Instant resume	No limit	No stop	No Regeneration	<0.06V	_		
P0546	Exhaust air temp. system	27	Exhaust air temp. sensor1 abnormal 1 (Hi)	0	1	Instant resume	No limit	No stop	No Regeneration	>4.96V	_		
P2032	. ,		Exhaust air temp. sensor1 abnormal 2 (Lo)	0	1	Instant resume	No limit	No stop	-	<0.06V	_		
P2033			Exhaust air temp. sensor1 abnormal 2 (Hi)	0	1	Instant resume	No limit	No stop	-	>4.96V	_		
P0642			Sensor power 1 abnormal (Lo)	_	1	Instant resume	No limit	No stop	-		_		This occurs at same time with other
P0643	Sensor voltage system	5	Sensor power 1 abnormal (Hi)	_	1	Instant resume	No limit	No stop	-		_		failure.
P0652	J 7444		Sensor power 2 abnormal (Lo)	_	1	Instant resume	No limit	No stop	-		_		Power system check as major cause may help
P0653	3 Se	Sensor power 2 abnormal (Hi)	_	1	Instant resume	No limit	No stop	_		_			

8500-1 / 8500E-1 10-194 Published 12-16-15, Control #244-01

SAE code	System	TCCS digit code	Function	Check Lamp ON	Failure Level	Resume Timing	Injection volume limit	Engine Stop action	D P F Regeneration control	Failure judging condition	EGR Motion	Cause of failure	Remark
P0540	Vehicle system	53	Pre-heating device failure	0	1	Instant resume	No limit	No stop	_		_	Pre-heating device (Shoprt +B, GND)	
P0686	Vehicle system	51	Main relay failure	0	1	Instant resume	No limit	No stop	_		_	Power system failure	
P0219	Vehicle system	7	Engine over run	0	1	Instant resume	No limit	No stop	-		_	Over run	Intake throttle full close
P0617	Vehicle system	45	Starter switch failure	_	1	Instant resume	No limit	No stop	-		_	Switch failure (Shorted continuously)	Low temp strting worsen
U1001			CAN1 failure	0	1	After IG-OFF	No limit	No stop	-		_		
U110A		9	Transmission lost_TSC1 (Isolation command)	0	1	After IG-OFF	No limit	No stop	-		_		
U0073	Transmission related		CAN2 failure	0	3	After IG-OFF	Limited to 50%	No stop	No Regeneration		Stop		
U1122		8	Transmission lost_E G R	0	2	After IG-OFF	Limited to 75%	No stop	_		Stop		
U1123			Transmission lost_V N T	0	3	After IG-OFF	Limited to 50%	No stop	No Regeneration		-		

*How to output diag. code

1. SAE code : This is output when failure is confirmed with failure diagnosis. Failure code is indicated on present and past.

Past failure can be erased only with failure diagnosis tool.

2. 2 digit code: Check for blinking number of engine check clamp.

Present error only is indicated. (Past failure can not be seen)

Indication of failure code: Failure code is indicated in sequence from smaller number of failure codes repeatedly.
 The below shows example of diag. code indication.
 (Upper ... Code 32 and code 21 are indicated. Lower ... normal case.)

Published 12-16-15, Control #244-01 8500-1 / 8500E-1 10-195

10.1.15 WARNING DISPLAY CONDITION

Code	Message	Condition, Action	Warning display condition
MC1-W01	ENGINE PREHEAT	The message is displayed when the engine cooling water temperature is	Indicate 5 seconds when the charging (MC1-B20) is in OFF condition with the engine preheating (MC1-B38) is ON (Approx. 24V).
MC1-W02	PREHEAT COMPLETED	The message is displayed for 5 seconds after the operation is complete.	Indicate 5 seconds when the charging (MC1-B20) becomes ON (Approx. 24V) after indicate "W01".
MC1-W03	CHARGING PROBLEM	The charging circuit is malfunctioned. Consult with your nearest Manitowoc authorize distributor. * That it is not fault even this item is momentarily displayed immediately after the engine is started.	Indicate either the conditions of the engine oil pressure (MC1-B02) is OFF, the engine revolution is more than 100 min ⁻¹ with the charging (MC1-B20) is OFF or the engine oil pressure (MC1-B02) is ON (=GND), the actual engine revolution is less than 100 min ⁻¹ with the charging (MC1-B20) is ON (Approx. 24V) condition.
MC1-W04	PILOT RESSURE (PRIMARY) ABNORMAL	The control primary pressure is abnormal. Stop the operation at once, and consult with your nearest Manitowoc authorize distributor. * That it is not fault even this item is momentarily displayed immediately after the engine is started.	Indicate either the conditions of the engine oil pressure (MC1-B02) is OFF, the charging (MC1-B20) is ON (Approx. 24V) with the control primary pressure (MC1-A12) is less than 4.4 MPa or the engine oil pressure (MC1-B02) is ON (=GND), the charging (MC1-B20) is OFF with the control primary pressure (MC1-A12) is exceeding 4.4 MPa.
MC1-W05	ENGINE OIL PRESSURE	The engine oil pressure is abnormal. Stop the engine at once, and consult with your nearest Manitowoc authorize distributor.	Indicate either the conditions of the charging (MC1-B20) is ON (Approx. 24V), the actual engine revolution is more than 100 min ⁻¹ with the engine oil pressure (MC1-B02) is ON (=GND) or the charging (MC1-B20) is OFF, the actual engine revolution is less than 100 min ⁻¹ with the engine oil pressure (MC1-B02) is in OFF condition.
MC1-W06	ENGINE WATER LEVEL	The cooling water level in the radiator is insufficient. Refill the radiator with cooling water.	Indicate when the cooling water level (MC1-B08) is in ON (=GND) condition with the engine is stopping.
MC1-W08	ENGINE COOLANT TEMPERATURE	The cooling water temperature is excessively high. Idle the engine to lower temperature, and consult with your nearest Manitowoc authorize distributor.	Indicate when the cooling water temperature is exceeding 105°C (221°F).
MC1-W09	ENGINE OIL FILTER	The engine oil filter is clogged. Replace the filter.	Indicate when the engine oil filter clogging (MC1-B09) is ON (=GND) condition.

8500-1 / 8500E-1 10-196 Published 12-16-15, Control #244-01

Code	Message	Condition, Action	Warning display condition
MC1-W10	ENGINE AIR FILTER	The engine air cleaner is clogged. Clean or replace the element.	Indicate when the air cleaner filter clogging (MC1-B04) is ON (=GND) condition.
MC2-W11	EMPTY FUEL	The fuel level is insufficient. Refuel.	Indicate when the fuel level is less than 5% of the tank capacity condition.
MC1-W12	HYDRAULIC OIL TEMPERATURE		Indicate when the hydraulic oil temperature (MC1-A10) is exceeding 90°C (194°F) condition and release becomes less than 80°C (176°F).
MC1-W13	FRONT WINCH COOLING CIRCUIT OIL TEMPERATURE	The temperature of clutch cooling oil of the front drum is excessively high. Idle the engine at a high speed to lower the oil temperature. If this item frequently appears during normal operations, consult with your nearest Manitowoc authorize distributor. At the same time, inform the Manitowoc service of the details of the operation (lifting load, free fall distance, speed, and duration).	Indicate when the main winch brake cooling oil temperature (MC1-B06) is ON condition.
MC1-W14	REAR WINCH COOLING CIRCUIT OIL TEMPERATURE	The temperature of clutch cooling oil of the front drum is excessively high. Idle the engine at a high speed to lower the oil temperature. If this item frequently appears during normal operations, consult with your nearest Manitowoc authorize distributor. At the same time, inform the Manitowoc service of the details of the operation (lifting load, free fall distance, speed, and duration).	Indicate when the auxiliary winch brake cooling oil temperature (MC1-B07) is ON condition.
MC1-W15	WINCH FILTER CLOGGED		Indicate when the cooling line filter (MC1-B37) is ON (=GND) condition with the condition of either the engine oil pressure (MC1-B02) is OFF or charging (MC1-B20) is ON (Approx. 24V).

Code	Message	Condition, Action	Warning display condition
MC1-W16	FRONT SAFETY ESM SOLENOID VALVE IS ENERGIZED	The front drum clutch emergency system is actuated. The free fall of the front drum cannot be normally performed. Place a load and the hook onto the ground, and turn the key switch to the OFF position. Then, consult your nearest Manitowoc authorize distributor. DO NOT operate the key switch with a load or the hook hung in the air, since it may cause drop of the load or the hook.	 Indicate when the ESM-SOL is operating. The conditions of operating the ESM (operate either 1 or 2 below is realized). The main winch clutch pressure (MC1-A21) is less than 3.73 MPa (Approx. 1.26V) with the condition of the engine oil pressure (MC1-B02) is OFF at the brake mode is selected. The main winch clutch pressure is less than 3.73 MPa (Approx. 1.26V) while the lever is manipulating with the free mode is selected.
MC1-W17	REAR SAFETY ESA SOLENOID VALVE IS ENERGIZED	The front drum clutch emergency system is actuated. The free fall of the front drum cannot be normally performed. Place a load and the hook onto the ground, and turn the key switch to the OFF position. Then, consult your nearest Manitowoc authorize distributor. DO NOT operate the key switch with a load or the hook hung in the air, since it may cause drop of the load or the hook.	 Indicate when the ESA-SOL is operating. The conditions of operating the ESA (operate either 1 or 2 below is realized). The auxiliary winch clutch pressure (MC1-A22) is less than 3.73 MPa (Approx. 1.26V) with the condition of the engine oil pressure (MC1-B02) is OFF at the brake mode is selected. The auxiliary winch clutch pressure is less than 3.73 MPa (Approx. 1.26V) while the lever is manipulating with the free mode is selected.
MC1-W18	3RD SAFETY EST SOLENOID VALVE IS ENERGIZED	The front drum clutch emergency system is actuated. The free fall of the front drum cannot be normally performed. Place a load and the hook onto the ground, and turn the key switch to the OFF position. Then, consult your nearest Manitowoc authorize distributor. DO NOT operate the key switch with a load or the hook hung in the air, since it may cause drop of the load or the hook.	 Indicate when the EST-SOL is operating. The conditions of operating the EST (operate either 1 or 2 below is realized). The third winch clutch pressure (MC1-A22) is less than 3.73 MPa (Approx. 1.26V) with the condition of the engine oil pressure (MC1-B02) is OFF at the brake mode is selected. The auxiliary winch clutch pressure is less than 3.73 MPa (Approx. 1.26V) while the lever is manipulating with the free mode is selected.
MC1-W19	HOOK OVER HOIST RELEASE SWITCH IS OPERATING	The hook overhoist automatic stop release switch is actuated.	When hook over hoist limit is released.
MC1-W20	BOOM OVER HOIST RELEASE SWITCH IS OPERATING	The boom overhoist automatic stop release switch is actuated.	When boom over hoist limit is released.

Code	Message	Condition, Action	Warning display condition
MC2-W21	ML BYPASS SWITCH IS OPERATING	·	Indicate when the ML becomes bypass (MC2-B53, B54) is ON (Approx. 24V) condition.
MC1-W22	DPF OPTION SETTING ABNORMAL	Option setting dose not match with engine spec. Contact Manitowoc service shop.	 Indicate when either 1 or 2 below is realized. When the signal of "none DPF equipped" is receiving (CAN) from the ECU with the area (Regulated area) where the DPF is optional (option setting: (O)). When the signal of "none DPF equipped" is not receiving while the DPF option setting is "X".
MC1-W23	FRONT DRUM ROTATION SENSOR ADJUSTMENT	Front drum rotation sensor is not functioning properly. Adjust sensor position. If not corrected even after adjustment, contact Manitowoc service shop.	Indicate when more than continuous 5 times failure of the detection is occurred of the interruption by the main winch rotation sensor during the main winch operating lever back to neutral position after more than 3 seconds manipulated the lever. Release when detect the interruption by the main winch rotation sensor while the main winch lever is manipulating.
MC1-W24	REAR DRUM ROTATION SENSOR ADJUSTMENT	Rear drum rotation sensor is not functioning properly. Adjust sensor position. If not corrected even after adjustment, contact Manitowoc service shop.	Indicate when more than continuous 5 times failure of the detection is occurred of the interruption by the auxiliary winch rotation sensor during the auxiliary winch operating lever back to neutral position after more than 3 seconds manipulated the lever. Release when detect the interruption by the auxiliary winch rotation sensor while the auxiliary winch lever is manipulating.
MC2-W31	FRONT DRUM NEGA BRAKE ABNORMAL	Front drum nega brake function may be abnormal. Contact Manitowoc service shop.	 Indicate when detect the drum rotation after following conditions are realized. The main winch lever is more than 1 second in neutral position. The mode selection is in main neutral brake made. No occurrence of the main rotation sensor adjustment (W23).

Code	Message	Condition, Action	Warning display condition
MC2-W32	REAR DRUM NEGA BRAKE ABNORMAL	Rear drum nega brake function may be abnormal. Contact Manitowoc service shop.	 Indicate when detect the drum rotation after following conditions are realized. The auxiliary winch lever is more than 1 second in neutral position. The mode selection is in auxiliary neutral brake made. No occurrence of the auxiliary rotation sensor adjustment (W24).
MC2-W33	3RD. DRUM NEGA BRAKE ABNORMAL	3rd. drum nega brake function may be abnormal. Contact Manitowoc service shop.	 Indicate when detect the drum rotation after following conditions are realized. The third winch lever is more than 1 second in neutral position. The mode selection is in third neutral brake made. No occurrence of the third rotation sensor adjustment (W25).
MC1-W35	BATTERY RELAY ABNORMAL	Battery relay contact may be adhered. Inspect battery relay. Replace if the deposited at the contact point of the relay.	Indicate when the controller power dose not trip after the battery relay (MC1-C15) is OFF condition with the main key is ON at AIS (Auto Idle Stop) situation.
MC1-W36	PROPEL LEVER INTERLOCKED	Propel (travel) lever is kept ON. Pilot pressure is cut. Return propel (travel)lever back to neutral.	Indicate when the propel (travel) lever is kept manipulating (MC1-B36) position with the function lever (MC1-B19) is ON (Approx. 24V) while this option is effective.
MC2-W37	FRONT DRUM LEVER INTERLOCKED	Front drum is stopped since front drum lever is kept ON. Return front drum lever back to neutral.	Indicate when the main winch lever is in manipulating position at the function lever (MC1-B19) becomes ON (Approx. 24V).
MC2-W38	REAR DRUM LEVER INTERLOCKED	Rear drum is stopped since rear drum lever is kept ON. Return rear drum lever back to neutral.	Indicate when the auxiliary winch lever is in manipulating position at the function lever (MC1-B19) becomes ON (Approx. 24 V).
MC2-W39	3RD. DRUM LEVER INTERLOCKED	3rd. drum is stopped since 3rd. drum lever is kept ON. Return 3rd. drum lever back to neutral.	Indicate when the third winch lever is in manipulating position at the function lever (MC1-B19) becomes ON (Approx. 24V).
MC2-W40	BOOM DRUM LEVER INTERLOCKED	Boom drum is stopped since boom drum lever is kept ON. Return boom drum lever back to neutral.	Indicate when the boom winch lever is in manipulating position at the function lever (MC1-B19) becomes ON (Approx. 24V).
MC1-W41	REMOTE CONTROLLER CONNECTED	Remote control is connected. Disconnect remote control for crane work.	Indicate when the remote-control is connected (MC1-B53 is ON : more than 24V) and the engine emergency stop (MC1-B23) is ON (Approx. 24V) → Monitor lamp is also lit.

Code	Message	Condition, Action	Warning display condition
MC1-W42 MC2-W42	MC1, 2 CHARGE SIGNAL ABNORMAL	Charge signal differs on each MC. Contact Manitowoc service shop.	Indicate when the charging conditions of MC1 and MC2 (MC1-B20, MC2-B20) are not identical.
MC1-W44 MC2-W44	MC1, 2 FUNCTION LOCK SIGNAL ABNORMAL	Function lock signal differs on each MC. Contact Manitowoc service shop.	Indicate when the function lever conditions of MC1 and MC2 (MC1-B19, MC2-B19) are not identical.
MC1-W45 MC2-W45	MC1, 2 INCHING SPEED SELECT SIGNAL ABNORMAL	Inching speed select signal differs on each MC. Contact Manitowoc service shop.	Indicate when the inching switch conditions of MC1 and MC2 (MC1-B21, MC2-B21) are not identical.
MC1-W46	Qmax CUT SOL OUTPUT OFF ABNORMAL	Qmax cut solenoid relay contact is adhered at energize side. The engine revolution will be restricted not to raising the maximum revolution. Contact Manitowoc service shop.	 Indicate when either following condition is realized. MC1-B52 signal is ON (Approx. 24V) at the Qmax Cut (MC1-C11) is OFF. Qmax Cut pressure (MC1-A16) is less than 3 MPa (Approx. 0.74V).
MC1-W47	Qmax CUT SOL OUTPUT ON ABNORMAL	Qmax cut solenoid relay is not functioned. The engine revolution will be restricted not to raising the maximum revolution. Contact Manitowoc service shop.	Indicate when either following condition is realized. • MC1-B52 signal is OFF at the Qmax Cut (MC1-C11) is ON. • Qmax Cut pressure (MC1-A16) is more than 3 MPa (Approx. 0.74V). • Exceeding the engine revolution upper limit. (J08E: more than 1,800 min ⁻¹ , P11C: more than 1,600 min ⁻¹)
MC1-W48	ACTUAL ROTATION IS HIGHER THAN NO LOAD ROTATION	Either front or rear winch motor is running over speed or engine speed is over. Contact Manitowoc service shop.	Indicate when either following condition is realized. • Exceeding the engine revolution upper limit with the G engine mode is selected. (J08E: more than 1,800 min ⁻¹ , P11C: more than 1,600 min ⁻¹) • Detect the main or auxiliary drum over speed rotation when the neutral brake is selected. (More than 115% of specified rotation speed.)
MC1-W49	HIGH LOAD TORQUE	operation is taken. Avoid abrupt lever operation and work with the care.	Indicate the present output torque is reached to 90% or more against the engine owning maximum torque as called 100%. Instruct the operator not to taking abrupt operation to avoid sudden loading.

Code	Message	Condition, Action	Warning display condition
MC1-W50	JOY STICK ABNORMAL	Joy stick accel switch exceeds neutral range. Return it to neutral position. If error continues even at neutral position, contact Manitowoc service shop.	Indicate when following condition is realized. When the acceleration voltage (MC1-A09) is out of neutral position (without adjustment value: 2.4V to 2.6V) at the engine started.
MC1-W51	BACK UP FUSE BLOWN OUT	Back up fuse (F-4) of each controller is blown off. Replace with new one.	Indicate the backup fuse (MC1-B40) becomes OFF.
MC2-W52	HOOK OVERHOIST LS	MC2 detects hook overhoist. Check ML or hook overhoist signal and then contact Manitowoc service shop.	Indicate when detecting the hook overhoist (MC2-B24, B25) is OFF on MC2 while ML is not detecting (not to light up the warning lamp on ML).
MC2-W53	BOOM OVERHOIST LS	MC2 detects boom overhoist. Check ML or boom overhoist signal and then contact Manitowoc service shop.	Indicate when detecting the boom overhoist (MC2-B13) is OFF on MC2 while ML is not detecting (not to light up the warning lamp on ML).
MC2-W54	JIB OVERHOIST LS	MC2 detects jib overhoist. Check ML or jib overhoist signal and then contact Manitowoc service shop.	Indicate when detecting the jib over hoist (MC2-B35) is OFF on MC2 while ML is not detecting (not to light up the warning lamp on ML).
MC2-W55	BOOM BACKSTOP No.1 LS	MC2 detects boom backstop No.1 overhoist. Check ML or boom backstop No.1 overhoist signal and then contact Manitowoc service shop.	Indicate when detecting the boom backstop No.1 (MC2-B14) is OFF on MC2 while ML is not detecting (not to light up the warning lamp on ML).
MC2-W56	BOOM BACKSTOP No.2 LS	MC2 detects boom backstop No.2 overhoist. Check ML or boom backstop No.2 overhoist signal and then contact Manitowoc service shop.	Indicate when detecting the boom backstop No.2 (utmost limit) (MC2-B15) is OFF on MC2 while ML is not detecting (not to light up the warning lamp on ML).

8500-1 / 8500E-1 10-202 Published 12-16-15, Control #244-01

Code	Message	Warning display condition
ME001	Out of working angle.	When press boom/jib lowering icon.
ME002	Hook over hoist release switch is operating.	When hook over hoist limit is released.
ME003	Boom/Jib over hoist release switch is operating.	When boom over hoist limit is released.
ME004	Overload release switch is operating.	When overload release switch is released.
ME005	Over load condition.	When load ratio becomes more than 100%.
ME006	Head wind is strong.	When boom/jib suspending tension drops while the boom/jib is raising.
ME007	Boom is lowered too much.	When boom reaches lowest angle limit.
ME008	Boom is raised too much.	When boom reaches high angle limit or boom over hoist limits are functioning.
ME011	Boom is lowered too much.	When boom reaches low angle limit.
ME012	Boom is raised too much.	When boom reaches high angle limit.
ME013	Jib is lowered too much.	When jib reaches low angle limit.
ME014	Jib is raised too much.	When jib reaches high angle limit.
ME015	Mast is raised too much.	When mast reaches high angle limit while lifting by mast.
ME016	Mast is lowered too much.	When mast reaches low angle limit while lifting by mast.
ME017	Hook over hoist.	When detect hook over hoist limit switch (ML-A01, A02) function.
ME018	Hook over hoist.	When detect hook over hoist limit switch (ML-A01, A02) function.
ME019	Mast cylinder limit switch has not been turned on.	When not detect mast cylinder limit switch (ML-B12) signal.
ME020	Detecting limit switch for high gantry position has not been turned on.	When not detect high gantry limit switch (ML-B12) signal.
ME021	Boom over hoist.	When boom reaches high angle limit.
ME022	Jib over hoist.	When jib reaches high angle limit.
ME024	Overload precautions.	When reaches overload precaution area. (Load ratio get into more than 90 to less than 100%).
ME025	Reached the load limitation value of WORKING AREA LIMIT function.	When reaches to lifting load set value for work area limit.
ME026	Reached 90% of the load limitation value of WORKING AREA LIMIT function.	When reaches to 90% of lifting load set value for work area limit.
ME027	Boom angle reached upper limitation value of WORKING AREA LIMIT function.	When boom reaches high set angle limit for work area limit.
ME028	Boom angle reached lower limitation value of WORKING AREA LIMIT function.	When boom reaches low set angle limit for work are limit.
ME029	Jib angle reached upper limitation value of WORKING AREA LIMIT function.	When jib reaches high set angle limit for work area limit.
ME030	Jib angle reached lower limitation value of WORKING AREA LIMIT function.	When jib reaches low set angle limit for work area limit.
ME031	Working radius reached limitation value of WORKING AREA LIMIT function.	When reaches working radios set value for work area limit.

Code	Message	Warning display condition
ME032	Boom point elevation reached limitation value of WORKING AREA LIMIT function.	When reaches boom point height set value for work area limit.
ME033	Jib point elevation reached limitation value of WORKING AREA LIMIT function.	When reaches jib point height set value for work area limit.
ME034	Crane configuration setting is wrong.	When read internal memory abnormally.
ME035	A moment real load exceeds minimum value.	When detect indefinite load while boom/jib lowering icon is actuated.
ME036	The malfunction of the load cell for the boom (1).	When occurs port error (ML-A1).
ME037	The malfunction of the load cell for the boom (2).	When occurs port error (ML-A2).
ME038	The malfunction of the load cell for the jib (1).	When occurs port error (ML-A3).
ME039	The malfunction of the load cell for the jib (2).	When occurs port error (ML-A4).
ME040	The malfunction of the load cell for the main hook.	When occurs port error (ML-A5).
ME041	The malfunction of the load cell for the aux. hook.	When occurs port error (ML-A6).
ME042	The malfunction of the load cell for the 3rd hook.	When occurs port error (ML-A7).
ME044	The malfunction of the boom base angle sensor.	When occurs port error (ML-A9).
ME045	The malfunction of the boom tip angle sensor.	When occurs port error (ML-A10).
ME046	The malfunction of the mast angle sensor.	When occurs port error (ML-A11 or ML-A12).
ME047	The trouble of the lower jib angle sensor.	When occurs port error (ML-A13)
ME048	The malfunction of the jib tip angle sensor.	When occurs port error (ML-A14).
ME049	CEN Option setting error	When mismatch between CEN option setting and CEN specification recognition (ML-B29).
ME050	Test Mode	When converting test mode for EN13000.
ME051	Options unmatch of civil engineering mode.	When setting of civil engineering works option mode is wrong.
ME052	Data unmatch of civil engineering mode.	When mismatch between selected posture and condition of mode select switch.
ME056	Inspection mode for overload condition.	When actuate overload testing icon. (on the monitor display)
ME058	Set the swing brake mode.	When setting of swing limit with swing free mode. Apply swing parking brake and shift to swing brake mode.
ME060	Boom over hoist.	When boom reaches high angle limit.
ME061	Jib winch wire rope is tightened a little more than normal.	When detect suspending tension between 5 to 8 tons at tower configuration with boom/jib lowering icon is actuated.
ME062	Jib winch wire rope is abnormally tightened.	When detect suspending tension more than 8 tons at tower configuration with boom/jib lowering icon is actuated.
ME063	ML crane configuration does not correspond to the counter weight detecting signal.	When mismatch between detected value and selected posture of counter-weight.
ME066	Danger!! The jib tip touches at the ground.	When detect tower jib prevention limit switch from bending.
ME067	Boom winch wire rope is abnormally tightened.	When detect tension to mast more than 5 tons.

Code	Message	Warning display condition
ME068	Writing error of operator identification ID and/or password.	When write account information fail.
ME069	Writing error of WORKING AREA LIMIT values.	When write setting information of work area limit fail.
ME081	Front winch over pay out	When detect over pay-out No. 1 limit switch signal.
ME082	Rear winch over pay out	When detect over pay-out No. 2 limit switch signal.
ME083	Third winch over pay out	When detect over pay-out No. 3 limit switch signal.
ME084	Lateral inclination is out of range.	When detect inclination exceed more than ±0.2 degrees.
ME085	Longitudinal inclination is out of range.	When detect inclination exceed more than ±0.2 degrees.
ME086	MC1 redundancy switch is operating.	When input MC1 bypass switch (ML-B19).
ME087	MC2 redundancy switch is operating.	When input MC2 bypass switch (ML-B20).
ME088	Connect the weight	When reduced weight specification, detect abnormal of weight.
ME089	Time out error of synchronizing check during the MC1 start-up process.	When not synchronized with MC1 at boot-up. MC1 fault or CAN communication failure.
ME090	Time out error of synchronizing check during the MC2 start-up process.	When not synchronized with MC2 at boot-up. MC2 fault or CAN communication failure.
ME092	Error No.1 of ML internal setting values abnormality. (Optional item setting)	When read option information fail. *1
ME093	Error No.2 of ML internal setting values abnormality. (Crane data)	When read crane date fail. *1
ME094	Error No.3 of ML internal setting values abnormality. (Manufacturer adjustment data)	When read manufacture adjustment data fail. *1
ME095	Error No.4 of ML internal setting values abnormality. (Temporary adjustment data)	When read user adjustment data fail. *1
ME096	Error No.5 of ML internal setting values abnormality. (Crane operation data)	When read operation data fail. *1
ME097	Error No.6 of ML internal setting values abnormality. (Data for each case)	When read option information fail. *1
ME099	Error No.8 of ML internal setting values abnormality. (Failure history data)	When read load/fault history data fail. *1
ME100	Writing error of optional item setting.	When write option information fail.
ME101	Writing error of crane data.	When write crane date fail.
ME102	Writing error of manufacturer adjustment data.	When write manufacture adjustment data fail.
ME103	Writing error of temporary adjustment data.	When write user adjustment data fail.
ME104	Writing error of crane operation data.	When write operation data fail.
ME105	Writing error of the data of each case.	When write occasion demand data fail.
ME108	Error of the MC crane model number unmatched.	When mismatch machine model information between controllers. Resetting machine model require.
ME109	Error of the MC optional item setting unmatched.	When mismatch option information. Resetting option information require. *1

Code	Message	Warning display condition
ME110	Communication error between touch panel monitor.	When communication abnormal between ML monitor and ML.
ME111	Time out error of MC1 & MC2 adjustment response.	When time-out communication while MC adjustment. Readjustment require. *1
ME112	CAN communication error with MC1.	When CAN communication error between MC1 - ML.
ME113	CAN communication error with MC2.	When CAN communication error between MC2 - ML.
ME114	CAN communication sending error with MC1 & MC2.	When communication error with not accept adjustment. Faulty or check communication line.
ME115	Error No.9 of ML internal setting values abnormality. (Failure history data of MC1)	When read MC1 fault history data fail. *1
ME116	Error No.10 of ML internal setting values abnormality. (Failure history data of MC2)	When read MC2 fault history data fail. *1
ME117	Writing error of failure history data for MC1.	When write MC1 fault history data fail.
ME118	Writing error of failure history data for MC2.	When write MC2 fault history data fail.
ME119	Error No.11 of ML internal setting values abnormality. (Operator identification ID and/or password)	When read account information fail. *1
ME120	Error No.12 of ML internal setting values abnormality. (WORKING AREA LIMIT values)	When read work area limit set information fail.
ME121	Access error to NOR flash memory in ML. Setting values can not be written.	When NOR flash memory access faulty. *1
ME122	MC1 & MC2 reset is detected.	When reboot MC1 or MC2.
ME123	Writing error of system information for MC1 or MC2.	When read/write error MC system information. *1
ME124	Writing error of optional item setting for MC1 or MC2.	When write MC option information error.
ME125	Writing error of adjustment data for MC1 or MC2.	When read/write error MC adjustment information. *1
ME126	Writing error of crane operation data for MC1 or MC2.	When read/write error MC adjustment information. *1
ME127	Writing error of No.2. manufacturer adjustment data.	When write manufacture adjustment data 2 fail.
ME128	Error No.13 of ML internal setting values abnormality. (No.2 manufacturer adjustment data)	When read manufacture adjustment data 2 fail. *1

^{*1} Carry out machine model set, MC adjustment (option set etc.). Possibly controller failure if error can't be disappear.


8500-1 / 8500E-1 10-206 Published 12-16-15, Control #244-01

10.1.16 ENGINE ECU

1. ECU terminal number

Engine sub harness connector no.

Connector A: Respond connector: CN-614



Connector B: Respond connector :CN-615

1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16

Connector C: Respond connector :CN-635



Connector D: Respond connector :CN-616

1	2	3	4
5	6	7	8
9	10	11	12

Connector E: Respond connector :CN-638

1	2	3	4
5	6	7	8

2. Input / output table

CONNECTOR A

Ter. symbol	Content	
VNTV		
EGRV	VAIT FOR Review	
+BF1	VNT-EGR Power	
+BF2		
VB1 to 4	ECU main power	
ADG7	Work accel sensor GND	
NUSW	Neutral SW	
CLSW	Clutch SW	
SSWS	Key SW	
SWSS	Key SW-Spare	
GRY1	Heatre relay	
BATT	Battery	
ASCS	Work accel sensor signal	
AVC5	Work accel sensor power	
PTOSW2	Recovery SW	
OIL+	Hyd press. SW	
VNTG		
EGRV	VNT-EGR GND	
CGD1	VINT-EGR GIND	
CGD2		
PGD1 to 4	Power GND	
REV	Reverse SW 1st	
_	_	
_	- ()/	
	VNTV EGRV +BF1 +BF2 VB1 to 4 ADG7 NUSW CLSW SSWS SWSS GRY1 BATT ASCS AVC5 PTOSW2 OIL+ VNTG EGRV CGD1 CGD2 PGD1 to 4	

CONNECTOR C

Terminal No.	Ter. symbol	Content	
1		Grow plug	
2	-	_	
3	_	_	
4	7	_	
5		_	
6	-	_	
7		_	
8	_	_	
9	_	_	
10	_	_	
11	_	_	
12	_	_	
13	_	_	
14	_	_	
15 –		_	
16	_	-	

CONNECTOR B

Terminal No.	Ter. symbol	Content
1	-	Accel sensor 1 power
2	-	ALT-L
3	ST	Stater SW
4	PTO	Work accel sensor SW
5	DPF	DPR LT
6	DPSW	DPR SW
7	-	ALT-R
8	MRL1 MRL2	ECU Main relay
9		Engine check
10	CANIH	CAN HIGH
11	CAN1L	CAN LOW
12	STOP	Engine stop SW
13	ADG8	Accel sensor 2 GND
14	ACS2	Accel sensor 2 signal
15	ADG7	Accel sensor 1 GND
16	ACS1	Accel sensor 1 signal


CONNECTOR D

CONNECTOR D				
Terminal No.	Ter. symbol	Content		
1	TILA	AFM intake air temp sensor		
'	THA+	signal		
2	AGD5	AFM intake air temp sensor		
	AGDS	GND		
3	AFVB	AFM power		
4	AGD6	AFM GND		
5	ADG9	Press. Difference GND		
6	EXPS	Press. Difference signal		
7	AVC5	Press. Difference sensor		
/		power		
8	AFSI AFM Signal			
9	ADG0	Exhaust air temp sensor 1		
		GND		
10	ET3+	Exhaust air temp sensor 1		
10		signal		
11	ADG0	Exhaust air temp sensor 2		
11	ADGU	GND		
12	ET4+	Exhaust air temp sensor 2		
12	L14'	signal		
13	_	_		
14	_	_		
15	_	_		
16	_	-		

CONNECTOR E

Terminal No.	Ter. symbol	Content			
1	GRL	Grow lamp			
2	CE/G	Engine check lamp			
3	DGSW	Daig SW			
4	THW+	Water themometer			
5	_	ALT-P			
6	_	ALT-L			
7	-	ALT-R			
8	_	-			
9	-	-			
10	<u></u>	-			
11	_	-			
12	ı	-			
13	_	_			
14	_	_			
15		_			
16	_	_			

10.2 LOAD SAFETY DEVICE




Note


All values in the monitor displays are for reference only.

8500-1 / 8500E-1 10-210 Published 12-16-15, Control #244-01


10.2.1 CONFIGURATION OF SCREENS



10.2.2 SYSTEM DAIGRAM



10.2.3 MONITOR DISPLAY



_	Name			Evolonation				
H	Name	Explanation						
		Color	Indication	Operation mode (pictorial)	Logic motion mode (when logic is effective)			
		Greer		Off line Running	RUN			
١.		 	Flashing	Running	STOP			
А	STATUS LED	Red	ON	At powe				
			Flashing	Runnning	Major abnormal			
		Orange		Backlight bulb is blown or main machinery failure				
			Flashing	Software is be	ing started.			
		* 1. Backl	ght replacer	ment needs returning to manu	facturer.			
В	Extended unit interface (EXT)			nded unit (Transmission func	tion) * not used			
С	Ethernet interface (LAN)	RJ-45 typ		ck connector (8 pole) * not u				
D	USB Host interface (USB)	2 port. USB 1.1 correspond Type A Voltage DC5V ± 5%, Output current : 500mA (Max) Max transmission distance 5m * not used						
Ε	Extended unit interface 1	For installation of extended unit (Transmission function) * not used						
F	VM unit interface 1	This is to connect VM unit when camera is to be connected.						
G	Aux. input/output / Voice output interface (AUX)	Outside reset, alarm output, buzzer output, sound output. * not used						
Н	Extended memory interface	* not used						
		Green light		n CF card is inserted and cov	ver is closed or CF card is			
и	CF card access	<note></note>						
1			nsert or take	out CF card when LED lamp	is ON			
				e CF card may be destroyed				
J	Power supply connector	DC mode	: Connector	(socket) type				
K	CF card cover							
L	Audio input interface (L-IN / MIC)	This is to connect microphone. Minijack connector (φ 3.5 mm) * not used						
М	Video input interface (V-IN)	NTSC(59.9Hz) / PAL (50Hz) type correspnd RCA connector (75 Ω) * not used						
N	Serial interface (COM1)	D-SUB9 pin plug type,RS232C. This is used for transmission to ML						
0	Serial interface (COM2)	D-SUB9 p	in socket typ	pe. Corespond to RS422 / RS	485. * not used			
Р	Dip Swtich	In the CF card cover. * not used						

1. GENERAL SPECIFICATION

(1) Electrical specification

		DC model
	Rated voltage	DC24V
	Voltage range	DC19.2 to 28.8V
Power supply	Allowable instant power outage time	10ms or less
Сарргу	Power consumption	DC24V 2.08A or less (TYP 1.30A)
	Inrush current	30A or less
Dielectric st	regth	AC1000V 20mA 1 minute (between charging terminal and FG terminal)
Insulating re	esistance	DC500V, more than $10M\Omega$ (between charging terminal and FG terminal)

(2) Environmental specification

	Atmospheric temp for use	0 to 50°C (32 to 122°F) *1		
	Atmospheric temp for storing	-20 to +60°C (-4 to 140°F)		
Physical anvironment	Atmospheric humidity for use	10 to 90%RH (No condensation. Wet bulb temp 39°C (102°F) or lower.		
Physical environment	Atmospheric humidity for storing	10 to 90%RH (No condensation. Wet bulb temp 39°C (102°F) or lower.		
	Dust	0.1mg/m³ or less (No conductive dust)		
	Contamination	Contamination degree 2		

^{*1} As for STN color LCD equipped model, long time use under ambient tenperature higher than 40 degrees C may cause indication quality lowering such as contrast.

(3) Installation specification

	Ground	Functional grounding : D type ground (for both SG-FG)		
		Protection: IP65f equivalent		
		NEMA #250 TYPE 4X/13		
Condition	Construction *1	(Front surface at panel built in.)		
		Shape : Built in type		
		Installation method : Panel built in.		
	Cooling type	Natural cooling		

^{*1} Protective construction of the front area when this unit is installed in the panel. Adaptability has been checked under these conditions but it does not necessary gurantee use under all environmental conditions. Even the oil specified in the test may cause oil ingress due to sheet peeling off of the front area if this unit is exposed in such oil in sprayed condition for long time or exposed in extreamly low viscosity machine oil. In such case, some other countermeasure may become necessary. Use of non specified oil may cause same oil ingress or plastic deterioration. Check environmental condition in adavance before use. Drip proof packing used for long time or resued drip proof packing once installed on the panel has dirt or flaw and may not be good for protection. Periodical replacement of drip proof packing is recommended.

2. OUTER INTERFACE

(1) COM1 (USED FOR TRANSMISSION TO ML)


Recommended connector in cable side	XM2D-0901 Omron
Recommended jack screw	XM2Z-0073 Omron
Recommended cover	XM2S-0913 Omron
Caulking fix fitting	#4-40 (UNC)


Pin No.		RS232C			
PIII NO.	Signal	Content			
1	CD	Carrier detect			
2	RD (RXD)	Received data			
3	SD (TXD)	Transmitted data			
4	ER (DSR)	Data terminal ready			
5	SG	Signal ground			
6	DR (DSR)	Data set ready			
7	RS (RTS)	Transmission request			
8	CS (CTS)	Transmission permit			
9	CI (RI) / (VCC)	Indication + 5 V ± 5% output 0.25 A			

(2) Installation procedure

▲ CAUTION

Overtightening the screws may damage the GP. Proper tightening torque for drip proof effect is $0.5\ N\cdot m$.





3. POWER SUPPLY WIRING

MARNING

 Electric shock may be caused. Ensure to connect under the power supply is disconnected.

Failure to observe these precautions may result in serious injuries or loss of life.


Do not supply other than specified voltage.
 Otherwise the power source line or base machine may be damaged.

Failure to observe these precautions may result in parts damage.

Ensure to connect FG terminal to earth.
 Otherwise electric shock may be caused in case of failure.

Failure to observe these precautions may result in serious injuries or loss of life.

(1) Power cable specification Use copper core wire.



^{*1} If strand wire is used, ensure that the core wire is properly stranded.

Otherwise shortening may occur by strand touching the adjacent terminal.

(2) Power supply connector (plug) specification

FG	\oplus	24V
+	Θ	ov
POWER CABLE CONNECTING AREA	FG	Ground terminal connected to GP body. * Not used

Note

Power supply connector is DIGITAL CA5-DCCNL-01 or PHOENIX-CONTACT GMVSTBW2, 5/3-STF-7, 62.

Use wiring material as shown below.


These are all product of PHOENIX- CONTACT.

Recommended screw driver	SZF 1-0.6 × 3.5 (1204517)			
	AI 0.75-8GY (3200519)			
Recommended terminal	AI 1-8RD (3200030)			
Recommended terminal	AI 1.5-8BK (3200043)			
	AI 2.5-8BU (3200522)			
Recommended crimping tool for terminal	CRIMPFOX ZA 3			
Recommended crimping tool for terminal	(1201882)			

- (3) Procedure of power cable connection
- (A) Ensure that the power is disconnected.
- (B) Take out the power supply connector (plug) from the main body.
- (C) Loosen the 3 screws in the center of power supply connector.
- (D) Peel off the sheath of the power supply cable and twist the strand wire and insert into rod terminal and crimp.
 Install it to the connecting points.
- (E) Secure them with screws.

▲ CAUTION

- When tightening the terminal screw, use flat head screw driver (Size 0.6 × 3.5).
 Tightening torque is 0.5 to 0.6 N·m.
- Do not solder on cable connection point.
 Otherwise extreme heat may cause failure or fire.
- (F) Install the power supply cable to GP and secure it to GP body with left and right power supply connector securing screws.




(4) Handling of the bypass switch when touch panel of the monitor dose not functioning

In case of abnormal phenomenon occurs on the monitor as no functioning of touch panel at the boot up, the crane operation becomes possible by the following bypass processing.

- (A) Remove a fuse F17 (5A) for not applying the power to the monitor.
- (B) Start the engine.
- (C) The main controller 2 bypass switch is to be turned ON once and immediately after turned OFF
- (D) Confirm each levers are ready for operation after the function lock lever is shifted to work side
- (E) If not obtain the crane operation after the step4. above has been carried out, repeat step3. again and reconfirm of the readiness for operation.




This process is to be made only at emergency case. No any indication on the display panel. Evacuate from the situation carefully.



10.2.4 DETAIL OF ML CONTROLLER


1. Outside view and connector layout




CF card contains the adjusted data as backup.
 When replacing the ML controller, ensure to reinsert the original CF card and copy the backup data to the controller.

8500-1 / 8500E-1 10-220 Published 12-16-15, Control #244-01


2. ML controller connector pin layout (View from main machinery harness)




CN-11-1AF



CN-11-1CF



CN-11-18F




CN-11-1DF

Connector No.	Pin No.	Name	Wire No.	Wire color	Specification
	1	Control power (+)	17	0	Main power (IG power +)
	6	Control power (+)	17	0	Main power (IG power +)
	2	Control power (-)	E1	B/W	Main power (IG power GND)
	7	Control power (-)	E1	B/W	Main power (IG power GND)
	3	Backuppower(+)	14	G/R	Subpower(+Bpower+)
	8	Backup power (GND)	Е	BW	Sub power (+B power GND)
	17	Load detector (for crane) power (+)	103	R	12V load detecting power -1 (+)
	25	Load detector (for crane) signal	109	W	12V load detecting signal -1 (0 to 6.2V)
	18	Load detector (for crane) power (-)	102	В	12V load detector power (GND)
	26				12V load detector signal -2 (0 to 6.2V)
	19				12V load detector power -2 (+)
	27	Load detector (for jib) power (+) (Not used)	108	Y	12V load detector power -3 (+)
CN-11-1A	20	Load detector (for jib) signal (Not used)	101	G/Y	12Vloaddetectingsignal-3(0to6.2V)
	28	Load detector (for jib) power (-) (Not used)	107	Р	12V load detector power (GND)
	21				12V load detecting signal -4 (0 to 6.2V)
	29				12V load detector power -4 (+)
	22				12V load detector power -5 (+)
	30				12V load detecting signal -5 (0 to 6.2V)
	23				12V load detector power (GND)
	31				12V load detecting signal -6 (0 to 6.2V)
	24				12V load detector power -6 (+)
	32				12V load detector power -7 (+)
	4				12V load detecting signal -7 (0 to 6.2V)
	9				12V load detector power (GND)
	5				12V load detecting signal -7 (0 to 6.2V)
	10				12V load detector power -8 (+)


Connector No.	Pin No.	Name	Wire No.	Wire color	Specification
	33	Inter main controller transmission 1 (H)	114	R	CAN0 H
	41	Inter main controller transmission 1 (L)	115	G	CAN0 L
	34	Inter main controller transmission 1 (H end)	116	R/G	CAN0 H end
	42	Inter main controller transmission 1 (L end)	116	R/G	CAN0 L end
	35	Shield earth	ES3	B/R	Shield earth signal ground
	43	Inter main controller transmission 2 (H)	119	Υ	CAN1 H
CN-11-1B	36	Inter main controller transmission 2 (L)	120	L	CAN1 L
	44				CAN1 H end
	37				CAN1 L end
	45				Shield earth signal ground
	38	Boom angle detector power (+)	113	R/W	12V ML system sensor power 1-1 (+)
	46	Boom angle detector signal	118	W	12V ML system sensor signal 1-1 (0 to 12V)
	39	Boom angle detector power (GND)	112	В	12V ML system sensor power 1 (GND)
	47				12V ML system sensor signal 1-2 (0 to 12V)
	40				12V ML system sensor power 1-2 (+)
	48	vacant			vacant
	49	Crane mast angle detector power (+) (Not used)	126	R	12V ML system sensor power 1-3 (+)
	55	Crane mast angle detector signal (Not used)	129	W	12V ML system sensor power 1-3 (0 to 12V)
	50	Crane mast angle detector power (GND) (Not used)	125	В	12V ML system sensor power 1 (GND)
0114440	56				12V ML system sensor signal 1-4 (0 to 12V)
CN-11-1C	51				12V ML system sensor signal 1-4 (+)
	57	vacant			vacant
	52	Jib angle detector power (+)	124	Y/W	12V ML system sensor power 2-1 (+)
	58	Jib angle detector signal (OPT)	128	G	12V ML system sensor signal 2-1 (0 to 12V)
	53	Jib angle detector power (GND)	123	L	12V ML system sensor power 2 (GND)
	59				12V ML system sensor signal 2-2 (0 to 12V)
	54				12V ML system sensor power 2-2 (+)
	60	vacant			vacant


Connector No.	Pin No.	Name	Wire No.	Wire	Specification
	11	Swing angle detector power (+)	133	R	12V ML system sensor power 2-3 (+)
	14	Swing angle detector (A) signal	137	W	12V ML system sensor signal 2-3 (0 to 12V)
	61	Swing angle detector power (-)	132	В	12V ML system sensor power 2 (GND)
	69	Swing angle detector (B) signal	131	G	12V ML system sensor signal 2-4 (0 to 12V)
	62				12V ML system sensor power 2-4 (+)
	70				24V load detector power 2-4 (+)
	63				24V load detector signal -1 (0 to 12.5V)
	71				24V load detector power (GND)
	64				24V load detector signal -2 (0 to 12.5V)
	72				24V load detector power -2 (+)
CN-11-1D	65				24V load detector power -3 (+)
	73				24V load detector signal -3 (0 to 12.5V)
	66				24V load detector power (GND)
	74				24V load detector signal -4 (0 to 12.5V)
	67				24V load detector signal -4 (0 to 12.5V)
	75	vacant			vacant
	68	vacant			vacant
	76	vacant			vacant
	12				RS232C (+)
	15	Inter monitor transmission (TXD)	195	W	RS232C (TXD)
	13	Inter monitor transmission (RXD)	194	R	RS232C (RXD)
	16	Inter monitor transmission (GND)	196	В	RS232C (GND)



CN-11-4F

Connector No.	Pin No.	Name	Wire No.	Wire color	Specification
	1	Output power (+)	18	Gr	Extended 24V power (+)
	4				Extended 25V power (+)
	2	Output power (+)	18	Gr	Extended 26V power (+)
CN-11-4	5	Output power (-)	E2	B/W	Extended 24V power (GND)
ON-11-4	6	Output power (-)	E2	B/W	Extended 25V power (GND)
	7				Extended 26V power (GND)
	3	Voice alarm output 4	189	Lg/Y	Ground output (0.1A)
	8	Outside indication light (Red)	144	R	Ground output (0.2A)







CN-11-5AF

CN-11-5BF

Connector	Pin	Name	Wire	Wire	Specification
No.	No.		No.	color	
	1	Hook over hoist LS1	145	Y/L	24V input
	2	Hook over hoist LS2	146	Gr	24V input
	3	Gantry hoist detect LS (Not used)	977	G/Y	24V input
	4	Boom backstop no.2 LS	147	O/L	24V input
	5	Crane boom over hoist LS	148	G/W	24V input
	6	Boom backstop no.1 LS	149	L/W	24V input
	7	Jib over hoist LS	150	Br	24V input
	8	Civil engineering mode SW	248	G	24V input
	9	Work light SW	749	R/Y	24V input
	10				24V input
	11				24V input
CN-11-5A	12	Mast cylinder position detect LS (Not used)	978	Y/G	24V input
	13	TW jib bending prevent LS (Not used)	153	G/Y	24V input
	14	Latch (engage) LS (Not used)	154	Br/W	24V input
	15	Latch (disengage) LS (Not used)	155	Lg/W	24V input
	16	Over payout prevent LS (front)	156	P/W	24V input
	17	Over payout prevent LS (rear)	157	W	24V input
	18	Over payout prevent LS (third)	158	R/W	24V input
	19	Main controller 1 bypass SW	160	G	24V input
	20	Main controller 2 bypass SW	161	Y/R	24V input

Connector No.	Pin No.	Name	Wire No.	Wire color	Specification
	21	Drum select SW (rear)	163	L/R	24V input
	22	Drum select SW (front)	164	Br/R	24V input
	23				24V input
	24	Download start signal	173	G	24V input
	25	Master key SW	165	Gr/R	24V input
	26	Hook over hoist release SW	166	Lg/W	24V input
	27	Boom/Jib over hoist release SW	167	Lg/Y	24V input
CN-11-5B	28	Moment limiter release SW	168	Lg/R	24V input
CIN-11-3D	29	CEN spec. distinct signal	172	G/L	Ground input (330Ω)
	30	Simultaneous control permit signal	162	Y/G	Ground input (330Ω)
	31	Adjustment permit signal	170	R/G	Ground input $(4.7k\Omega)$
	32	Program rewrite permit signal	171	Y/B	Ground input (4.7kΩ)
	33	vacant			vacant
	34	vacant			vacant
	35	Wind speed sensor	141	Y/W	Pulse input (+)
	36				Pulse input (-)






CN-11-6AF

CN-11-6BF

Connector	Pin	Name	Wire	Wire	Specification
No.	No.	rvaine	No.	color	Ореолюцион
	13				24V Output
	30	Front drum hoist stop	175	Υ	24V Output
	12				24V Output
	29	Front drum lower stop	200	0	24V Output
	11	Rear drum hoist stop	177	G	24V Output
	28	Mode select (luffing jib)	198	Br/G	24V Output
	10	Rear drum lower stop	201	R/W	24V Output
	27	Mode select (mast)	199	P/G	24V Output
CN-11-6A	26	Mode select (assy/disassy)	192	W/L	24V Output
CIN-11-0A	25	Third drum hoist stop	179	L/Y	24V Output
	24	Mode select (self removal)	193	B/Y	24V Output
	9	Third drum lower stop	203	G/R	24V Output
	8	Over load alarm buzzer	225	Р	24V Output
	23	Boom drum raise stop	181	Lg	24V Output
	7	Boom drum lower stop	202	L/R	24V Output
	22				24V Output
	6	Civil engieering mode lamp	249	L	24V Output
	21	Mast bending prevent signal	222	P/W	24V Output
	5				24V Output
	20				24V Output
	4				24V Output
	19	Operator authenticate signal	223	Y/G	24V Output
	18	Overload buzzer	185	L/W	24V Output
ON 44 CD	17	Over hoist buzzer	184	G/R	24V Output
CN-11-6B	3	Voice alarm output 5	190	O/L	Ground output (0.1A)
	16	Voice alarm output 1	186	Y/L	Ground output (0.1A)
	2	Voice alarm output 2	187	G/Y	Ground output (0.1A)
	15	Outside indication light (yellow)	142	Υ	Ground output (0.1A)
	1	Voice alarm output 3	188	L/G	Ground output (0.1A)
	14	Outside indication light (green)	191	G	Ground output (0.1A)

3. System block diagram



4. ML input/output

Note

The table of code shown all of code numbers and some of codes would not be indicated depending on the model.

(1) Analogue input [A]

No.	Name	Variation	Input Voltage	Remarks	Judgement	
ML-A01	Crane boom load detector	0 t to rated t	1 to 5V	CN11-1-25		
ML-A02	Spare	1	1	CN11-1-26		
ML-A03	Jib load detector	↑	1	CN11-1-20	Judge detect either	
ML-A04	Spare	↑	↑	CN11-1-21	following.	
ML-A05	Spare	↑	↑	CN11-1-30	Input voltage < 0.29V.	
ML-A06	Spare	↑	1	CN11-1-31	Input voltage > 6.19V.	
ML-A07	Spare	↑	1	CN11-1-4		
ML-A08	Spare	↑	1	CN11-1-5		
ML-A09	Boom base angle detector	-150 to 150 degrees	0.4 to 11.6V	CN11-1-46		
ML-A10	Spare	1	1	CN11-1-47	Judge detect either	
ML-A11	Crane mast angle detector	1	1	CN11-1-55	following.	
ML-A12	Spare	1	↑	CN11-1-56	Input voltage < 0.30V.	
ML-A13	Jib base angle detector	1	↑	CN11-1-58	Input voltage > 12V.	
ML-A14	Spare	1	↑	CN11-1-59		
ML-A15	Swing angle detector A	0 to 180 degrees	0 to 12V	CN11-1-14	Judge when the voltage differential other than 5.0V	
ML-A16	Swing angle detector B	Ť	0 to 12V	CN11-1-69	to 7.0V between the angle detector A and B.	
ML-A17	Spare		0 to 12.5V	CN11-63		
ML-A18	Spare		0 to 12.5V	CN11-64		
ML-A19	Spare		0 to 12.5V	CN11-73		
ML-A20	Spare		0 to 12.5V	CN11-74		

(2) Pulse input (break in) [E]

No.	Name	Condition	Signal level	Remarks	Judgement
ML-E01	Anemometer		GND/OPEN	CN11-5-35	Judge when read the pulse fail.

(3) Digital intput [B]

No.	Name	Condition	Signal level	Remarks	Judgement
ML-B01	Hook over hoist LS1	Normal / Over	+24V/OPEN	CN11-5-1	
ML-B02	Hook over hoist LS2	Normal / Over	+24V/OPEN	CN11-5-2	
ML-B03	Gantry raise detect LS	Not detect / Detect	+24V/OPEN	CN11-5-3	No failure judgement take
ML-B04	Boom B/S No.2 LS	Normal / Over	+24V/OPEN	CN11-5-4	place.
ML-B05	Crane boom over hoist LS	Normal / Over	+24V/OPEN	CN11-5-5	4
ML-B06	Boom B/S No.1 LS	Normal / Over	+24V/OPEN	CN11-5-6	
ML-B07	Jib over hoist LS	Normal / Over	+24V/OPEN	CN11-5-7	
ML-B08		Civil engineering mode / Normal	+24V/OPEN	CN11-5-8	
ML-B09	Work light SW	ON / OFF	+24V/OPEN	CN11-5-9	
ML-B10	Spare		+24V/OPEN	CN11-5-10	
ML-B11	Spare		+24V/OPEN	CN11-5-11	
ML-B12	Mast cylinder LS	Not detect / Detect	+24V/OPEN	CN11-5-12	
ML-B13	TW jib bending prevent LS	Ground / Normal	+24V/OPEN	CN11-5-13	
ML-B14	Latch (engage) LS	Engage / Normal	+24V/OPEN	CN11-5-14	
ML-B15	Latch (disengage) LS	Disengage / Normal	+24V/OPEN	CN11-5-15	
ML-B16	Over payout prevent (Front drum)	Normal / Over	+24V/OPEN	CN11-5-16	
ML-B17	Over payout prevent (Rear drum)	Normal / Over	+24V/OPEN	CN11-5-17	
ML-B18	Over payout prevent (3rd drum)	Normal / Over	+24V/OPEN	CN11-5-18	No failure judgement take place.
ML-B19	MC1 bypass SW	Bypass / Normal	+24V/OPEN	CN11-5-19	
ML-B20	MC2 bypass SW	Bypass / Normal	+24V/OPEN	CN11-5-20	
ML-B21	Drum select (Rear hoist) CEN	Select / Not select	+24V/OPEN	CN11-5-21	
ML-B22	Drum select (Front hoist) CEN	Select / Not select	+24V/OPEN	CN11-5-22	
ML-B23	Spare		+24V/OPEN	CN11-5-23	
ML-B24	DL start SW	Start / Normal	+24V/OPEN	CN11-5-24	
ML-B25	Master key	Release / Normal	+24V/OPEN	CN11-5-25	
ML-B26	Hook over hoist release	Release / Normal	+24V/OPEN	CN11-5-26	
ML-B27	Boom over hoist release	Release / Normal	+24V/OPEN	CN11-5-27	
ML-B28	ML release	Release / Normal	+24V/OPEN	CN11-5-28	
ML-B29	CEN spec. recognize signal	CEN / Normal	GND/OPEN	CN11-5-29	
ML-B30	Simultaneous operate permit	Permit & CEN / Normal	GND/OPEN	CN11-5-30	
ML-B31	For adjusting	Adjusting / Normal	GND/OPEN	CN11-5-31	
ML-B32	For program rewriting	Rewrinting / Normal	GND/OPEN	CN11-5-32	

(4) Analogue output [H]


No.	Name	Condition	Signal level	Remarks	Judgement
ML-H01	Spare				
ML-H02	Spare				

(5) Digital output [C]

No.	Name	Condition	Signal level	Remarks	Judgement
ML-C01	Front drum hoist stop	Actuate / Normal	+24V/OPEN	CN11-6-30	
ML-C02	Front drum lower stop	Actuate / Normal	+24V/OPEN	CN11-6-29	
ML-C03	Rear drum hoist stop	Actuate / Normal	+24V/OPEN	CN11-6-11	
ML-C04	Rear drum lower stop	Actuate / Normal	+24V/OPEN	CN11-6-10	
ML-C05	Third (jib) drum hoist stop	Actuate / Normal	+24V/OPEN	CN11-6-25	
ML-C06	Third (jib) drum lower stop	Actuate / Normal	+24V/OPEN	CN11-6-9	
ML-C07	Boom drum raise stop	Actuate / Normal	+24V/OPEN	CN11-6-23	
ML-C08	Boom drum lower stop	Actuate / Normal	+24V/OPEN	CN11-6-7	
ML-C09	Civil engineering mode	ON / OFF	+24V/OPEN	CN11-6-6	
ML-C10	Wind velocity warning lamp	Warning / Normal	+24V/OPEN	CN11-6-20	
ML-C11	Spare	Actuate / Normal	+24V/OPEN	CN11-6-13	
ML-C12	Spare	Actuate / Normal	+24V/OPEN	CN11-6-12	Y Y
ML-C13	Mode select (jib model)	Jib model / Except jib model	+24V/OPEN	CN11-6-28	
ML-C14	Mode select (mast model)	Mast mode / Except mast model	+24V/OPEN	CN11-6-27	
ML-C15	Mode select (assy/disassy)	Assy disassy / Except assy disassy	+24V/OPEN	CN11-6-26	Judge when mismatch feedback value against output demand.
ML-C16	Mode select (self removal)	Self removal / Except self removal	+24V/OPEN	CN11-6-24	output demand.
ML-C17	Outer indication light buzzer (red)	Actuate / Normal	+24V/OPEN	CN11-6-8	
ML-C18	Spare		+24V/OPEN	CN11-6-22	
ML-C19	Mast bending prevent	Actuate / Normal	+24V/OPEN	CN11-6-21	
ML-C20	Spare		+24V/OPEN	CN11-6-5	
ML-C21	Operator authenticate signal	Actuate / Normal	+24V/OPEN	CN11-6-19	
ML-C22	Spare		+24V/OPEN	CN11-6-4	
ML-C23	Over hoist buzzer	Actuate / Normal	+24V/OPEN	CN11-6-17	
ML-C24	Over load buzzer	Actuate / Normal	+24V/OPEN	CN11-6-18	
ML-C25	Voice alarm 1	Actuate / Normal	GND/OPEN	CN11-6-16	
ML-C26	Voice alarm 2	Actuate / Normal	GND/OPEN	CN11-6-2	
ML-C27	Voice alarm 3	Actuate / Normal	GND/OPEN	CN11-6-1	
ML-C28	Voice alarm 4	Actuate / Normal	GND/OPEN	CN11-4-3	
ML-C29	Voice alarm 5	Actuate / Normal	GND/OPEN	CN11-6-3	
ML-C30	Outer indication light (green)	ON / OFF	GND/OPEN	CN11-6-14	Judge when mismatch
ML-C31	Outer indication light (yellow)	ON / OFF	GND/OPEN	CN11-6-15	feedback value against
ML-C32	Outer indication light (red)	ON / OFF	GND/OPEN	CN11-4-8	output demand.

10.2.5 SHIFTING TO MAINTENANCE SCREEN

1. Press the kew icon in the main screen.



2. Press 💥 switch.




- 3. Input the password (8 digits) with the keyboard.
- * In case of using capital letter, press (CAPS) switch.

CLR	All clear	
DEL	One letter clear	7
BS	One letter clear and back	







5. If password is correct, the maintenance menu becomes displayed.





6. If password is not correct, password area blinks three times and then screen returns to 3. screen.


Check the password and input again.

8500-1 / 8500E-1 10-234 Published 12-16-15, Control #244-01

10.2.6 INPUT / OUTPUT SIGNAL

This screen can check input signal condition of various sensors or switches or output signal condition of solenoid valves, relays and proportional valves.

1. Press [I/O SIGNAL] in the maintenance menu.



How to select the in/out signal display
 Select the controller to confirm signals and
 select signal so the each input/output signal
 screen is to be displayed.



ML






10-235

MC1




MC2

- 2. Input / output check of ML (MOMENT LIMITER)
- Select analog input from ML menu.
 Display state of analog signals of load detector and angle detector etc.



(2) Unit of indicating figure is V (volt). Refer to the article "10.2.4 DETAIL OF ML CONTROLLER" for connection and signal level. 0V is displayed on non connected point.



To controler serect display

(3) To display of the respective sensors, press area of input value, the name of sensor will be displayed.

By push @ icon, previous display indicated.



- (4) By pressing ♠, digital input and digital output become displayed.
- Digital input

This is displayed by "IN".

Digital input consists of 24 V input and ground (GND) input.

In 24 V input, ON is displayed at 24 V and OFF at open (0 V).

In ground input, ON is displayed at ground (GND) and OFF at open.

As for signal name and specification, refer to the article "10.2.4 DETAIL OF ML CONTROLLER".

Digital output

This is displayed by "DOUT".

Digital output consists of 24 V output and ground input.

In 24 V output, ON is displayed at 24 V and OFF at open (0 V).

In ground output, ON is displayed at ground (GND) and OFF at open.

As for signal name and specification, refer to the article "10.2.4 DETAIL OF ML CONTROLLER".


• Digital output (feedback signal)

This is displayed by "DOUT Fb".

This is feedback signal of digital signal (DOUT) which is corresponds to digital output when normal condition.


If it does not correspond to digital signal condition, wire breakage or ground fault is presumed.

To display each value of the I/O, press area of I/O, the name of I/O will be displayed.
 By push previous display indicated.





- 3. Input, output signal check of MC1 (main controller 1)
- (1) Select analog input from MC1 menu. sensors, potentiometers etc.



(2) The first screen indicates conditions of analog signal of pressure sensors, potentiometers etc. Unit of indicating figure is V (volt). As for signal name and specification, refer to the article "10.3.5 SPECIFICATIONS OF MAIN CONTROLLER INPUT/OUTPUT".

0V is displayed on non connected point.




I/O Select

MC2

(3) To display of the respective sensors, press area of input value, the name of sensor will be displayed.

By push @ icon, previous display indicated.





- (4) By pressing , digital input and digital output become displayed.
- · Digital input

This is displayed by "IN".

Digital input consists of 24 V input and ground (GND) input.

In 24 V input, ON is displayed at 24 V and OFF at open (0 V).

In ground input, ON is displayed at ground (GND) and OFF at open.

As for signal name and specification, refer to the article "10.3.5 SPECIFICATIONS OF MAIN CONTROLLER INPUT/OUTPUT".

Digital output

This is displayed by "DOUT".

Digital output consists of 24 V output and ground input.

In 24 V output, ON is displayed at 24 V and OFF at open (0 V).

In ground output, ON is displayed at ground (GND) and OFF at open.

As for signal name and specification, refer to the article "10.3.5 SPECIFICATIONS OF MAIN CONTROLLER INPUT/OUTPUT".


• Digital output (feedback signal)

This is displayed by "DOUT Fb".

This is feedback signal of digital signal (DOUT) which is corresponds to digital output when normal condition.

If it does not correspond to digital signal condition, wire breakage or ground fault is presumed.

To display each value of the I/O, press area of I/O, the name of I/O will be displayed.
 By push , previous display indicated.





- (5) By pressing □, output of proportional valve becomes displayed.
 - Indicated value is displayed on left hand and feedback value on right hand.


Unit of indicating figure is mA (milliampere).


If indicated value is more than 100 mA and feedback value is about 0 mA, wire breakage is presumed.


As for signal name and specification, refer to the article "10.3.5 SPECIFICATIONS OF MAIN CONTROLLER INPUT/OUTPUT".

 To display of the respective proportional solenoid valves, press the area of I/O value, the name of proportional solenoid valve will be displayed.

By push , previous display indicated.










Analog Output

- 4. Input, output signal check of MC2 (main controller 2)
- Select analog input from MC2 menu.
 Display state of analog signals of pressure sensors, potentiometers etc.
- (2) The first screen indicates conditions of analog signal of pressure sensors, potentiometers etc. Unit of indicating figure is V (volt). As for signal name and specification, refer to the article "10.3.5 SPECIFICATIONS OF MAIN CONTROLLER INPUT/OUTPUT". 0V is displayed on non connected point.



I/O Select

Digital

Input/ Output


ML

Analog Input MC2

Valve Output

(3) To display of the respective sensors, press area of input value, the name of sensor will be displayed.

By push 🕮 icon, previous display indicated.



- (4) By pressing ♠, digital input and digital output become displayed.
- Digital input

This is displayed by "IN".

Digital input consists of 24 V input and ground (GND) input.

In 24 V input, ON is displayed at 24 V and OFF at open (0 V).

In ground input, ON is displayed at ground (GND) and OFF at open.

As for signal name and specification, refer to the article "10.3.5 SPECIFICATIONS OF MAIN CONTROLLER INPUT/OUTPUT".

Digital output

This is displayed by "DOUT".

Digital output consists of 24 V output and ground input.

In 24 V output, ON is displayed at 24 V and OFF at open (0 V).

In ground output, ON is displayed at ground (GND) and OFF at open.

As for signal name and specification, refer to the article "10.3.5 SPECIFICATIONS OF MAIN CONTROLLER INPUT/OUTPUT".

Digital output (feedback signal)


This is displayed by "DOUT Fb".

This is feedback signal of digital signal (DOUT) which is corresponds to digital output when normal condition.

If it does not correspond to digital signal condition, wire breakage or ground fault is presumed.

To display each value of the I/O, press area of I/O, the name of I/O will be displayed.

By push , previous display indicated.





- (5) By pressing □, output of proportional valve becomes displayed.
 - Indicated value is displayed on left hand and feedback value on right hand.


Unit of indicating figure is mA (milliampere).

If indicated value is more than 100 mA and feedback value is about 0 mA, wire breakage is presumed.

As for signal name and specification, refer to the article "10.3.5 SPECIFICATIONS OF MAIN CONTROLLER INPUT/OUTPUT".

 To display of the respective proportional solenoid valves, press the area of I/O value, the name of proportional solenoid valve will be displayed.

By push 📾 , previous display indicated.





10.2.7 ML FUNCTION SETTING

 Press "ML FUNCTION" in the maintenance menu.





I/O SIGNAL

ML ADJUSTMENT

(NORMAL)

ML ADJUSTMEN

(TEMPORARY

ADJUSTMENT DATA

MC ADJUSTMENT

/SETTING

ML FUNCTION

VERSION INFORMATION

BACK

NEXT

- Option setting of anemometer
 This is to set with or without wind speed meter.
- Ex) In case of anemometer installed.
- (A) Press "ANEMOMETER" in the menu.
- (B) Option setting screen of anemometer becomes displayed.
- (C) Press "Enable".
- * The selected side turns to blue display.
- (D) Press ® icon.



(2) Setting of LVL function effective

This is to set LVL (auto stop load ratio) effective or not effective.

Refer to the article "10.2.10 ML ADJUSTMENT (NORMAL)".

LVL setting for setting procedure of LVL value.


- Ex) In case of making LVL function effective.
- (A) Press "USE OF LVL" in the menu.
- (B) LVL function screen becomes displayed.
- (C) Press "Enable".
- * The selected side turns to blue display.
- (D) Press (W) icon.
- (3) Setting of camera connection

 This is to set with or without camera.
- Ex) In case camera is added to channel 0.
- (A) Press "CAMERA CONNECTION" in the menu.
- (B) Camera connection setting screen becomes displayed.
- (C) Press "Enable" of channel 0.* The selected side turns to blue display.
- (D) Press SET icon.

- (4) Color adjustment Crane body color in the main screen is to be adjusted.
- (A) Press "COLOR" in the menu.
- (B) Color adjusting screen is displayed.
- (C) Press "Yes".
- (D) Select color.
- (E) Press (B) icon.








10.2.8 DATA COPY, FORMAT

1. Press "DATA COPY, FORMAT" in the maintenance menu.



- 2. Items become displayed.
- (1) Adjustment data reading out

This reads out backup data in the data card into memory in the controller.

Memorized data in the controller are overwritten and are erased.

Actual data to be used for calculation is those in the controller.

Special caution is required for this handling.

- (2) Adjustment data writing in
 This is to copy the memorized data in the controller to the data card.(Adjustment data back up)
- (3) Adjustment data formatting

This is to format the adjustment data memorized in the controller.

The backup data in the data card is not formatted.



(A) Adjustment data reading out

This is to read out the adjusted value (backup data) in the data card to the memory in the controller.

Note

When using this function, the data in the controller being used for calculation is overwritten. Be careful not to use this function in error.

Select "CF Card \rightarrow Controller" in the menu. The screen shown right becomes displayed. Press [SET] for 3 seconds to execute.

When completed properly, the screen shown right is displayed.

By pressing 1, the screen returns to the previous one.

After execution, if error message as shown right is displayed, data card failure (including not enough insertion) is presumed.

Re-insert the card and try again.

By pressing , screen returns to the previous one.

Unless both of ML B31 and MC1 C9 lamps displayed on lower part of the screen light up, can not be accessed to the card and reading out would not be completed properly.

In this case, check the function of ML adjusting mode select relay (R-36).







- (B) Adjustment data writing in This is to copy the adjustment data in the memory of the controller to the data card.
- * Normally whenever adjustment is done, data is copied to the card, but this is used to copy forcibly.

Select "Controller→ CF Card" in the menu. The screen shown right becomes displayed. Press [SET] for 3 seconds to execute.

When completed properly, the screen shown right is displayed.

By pressing \$, the screen returns to the previous one.

After execution, if error message as shown right is displayed, data card failure (including not enough insertion) is presumed.

Re-insert the card and try again.

By pressing , screen returns to the previous one.







(C) Adjustment data formatting This is to format the adjustment data in the memory in the controller.

Note

When using this function, the data in the controller being used for calculation is overwritten. Be careful not to use this function in error.

> Select "FORMAT" in the menu. The screen shown right is displayed. Press [SET] for 3 seconds to execute.

When completed properly, the screen shown right is displayed.

By pressing $\ensuremath{\ensuremath{\mathbb{G}}}$ the screen returns to the previous one.

Unless both of ML B31 and MC1 C9 lamps displayed on lower part of the screen light up, can not be accessed to the card and reading out would not be completed properly.

In this case, check the function of ML adjusting mode select relay (R-36).





10.2.9 LANGUAGE, UNIT SETTING

Press "LANGUAGE/UNIT" in the maintenance menu.



Item becomes displayed.Select the required language, unit.


	Displayed language	Displayed unit	
JPN	Japanese	m, t	
ENG (ft·lbs)	English	feet, klbs	
ENG (m·t)	English	m, t	

Selected item becomes displayed in blue letter. After select, press $\ensuremath{\mathfrak{B}}$.




10.2.10 ML ADJUSTMENT (NORMAL)

1. Press "ML ADJUSTMENT (NORMAL)" in the maintenance menu.



2. Adjustment menu becomes displayed.



Angle sensor adjustment	This is used when error between display of boom angle, jib angle mast angle become larger and their actual angle become larger or whenever the angle detector is replaced.
Loads cell zero offset adjustment	This is used when output voltage deviate from 1.000 V when load is not applied to load cell. This becomes necessary whenever load detector or cable is replaced.
Load-less adjustment	This is used when the hook weight is not properly displayed.
Some load adjustment	This is used when error becomes large on actual load display after load-less adjustment is completed.
LVL adjustment	This is to change auto stop point (warning point).
Work radius adjustment	This is used when error of work radius display and actual work radius becomes larger.
Swing sensor adjustment	This is used when screen display of swing direction differ from the actual direction. This is also used whenever swing angle sensor (slip ring built-in) is replaced.

- 3. Angle detector adjustment
- (1) Select "ANGLE DETECTOR ADJUSTMENT" in the adjustment menu.

Angle detector connected to presently set attachment becomes displayed.

(Figure right shows example of crane with aux. sheave.)

In case with jib, jib angle detector becomes displayed and in case with mast, mast angle detector becomes displayed.

Select the adjustment required angle detector.


This procedure explains boom angle detector as an example.


Jib angle detector and mast angle detector are adjusted in the same procedure.


After boom is raised close to the upper limit and lower the boom slightly and press "LOWER BOOM ANGLE SENSOR".


(2) Touch angle indicating area.

(3) Angle indicating area becomes highlighted and the numeral input becomes possible.









- (4) Measure the actual boom angle with the level gauge and angle meter and input the number with numeric keypad.
- Ex) In case of input "79.5", input (7), (9), (.), (5).

After input, press SET.

(5) Lower the boom for more than 25 degrees and stop.


Then press SET.

▲ CAUTION


Angle of 25 degrees is just a guideline for lowering the boom, and this guideline should not be necessarily observed.

However, remember that the adjustment is more effective if the boom is lowered with an angle as large as possible.


(6) Touch the second angle indicating area.








(7) Angel indicating area becomes highlighted and the numeral input becomes possible.







By pressing [SET], the screen returns to the previous one.







(10) If the adjustment is not properly completed, the message shown right is displayed.

By pressing SET, screen returns to the one during adjusting.

Re-check the procedure and start adjustment again.



- 4. Load detector zero adjustment
- (1) Select "LOAD CELL ZERO OFFSET ADJUSTMENT" in the adjustment menu. The load detectors used in the presently set

attachment become displayed.
Select the required load detector to be adjusted.

* Right screen shows normal crane as an example.

In case of adjusting jib load detector, luffing configuration must be selected.

If plural load detectors are used, plural load detectors become displayed.

Select the required load detector to be adjusted.


(2) Release the tension on the boom hoist rope to "zero" by releasing the boom hoist rope as much as possible or by removing the load detector.

Press SET when prepared.



When the displayed load cell voltage is not in the rage from 0.8 to 1.2 V, the load cell is judged to be faulty and the adjustment is rejected.

In such a case, replace the load cell.







(3) The message shown right becomes indicated when the adjustment is properly completed. By pressing [SET], screen returns to the previous one.

The adjustment is properly completed, press [SET], the screen returns to the previous one. If the adjustment is fail, resetting again from the previous screen.

(4) If the adjustment is not properly completed, the message shown right is displayed.

By pressing [SET], screen returns to the one during adjusting.


Re-check the procedure and start adjustment again.





5. Load less adjustment

Set the load to only the hook installed. Adjust each hook position based on the table below.



8500E-1


Type of attachments	Mode	Weight of hook block to be entered during	Position of hook block when load is adjusted	
		adjustment	Hook of mode selected	Other hooks
Crane	Main lifting	Main hook	Boom foot	-
Crane with auxiliary sheave	Main lifting	Main hook	Boom foot	
	Auxiliary sheave lifting	Auxiliary sheave hook	Boom foot	
Crane with jib	Main lifting	Main hook	Boom foot	
	Jib lifting	Jib hook	Boom foot	
Tower crane	_	Main hook	Boom foot	1/4 of distances from
Luffing crane (with main hook)	Main lifting	Main hook	Boom foot	boom point sheave to
	Jib lifting	Jib hook	Boom foot	ground.
Luffing crane (with aux. sheave hook)	Jib lifting	Jib hook	Boom foot	
	Auxiliary sheave lifting	Auxiliary sheave hook	Boom foot	
Luffing crane (jib hook only)	Jib lifting	Jib hook	Boom foot	

8500-1

Type of attachments	Mode	Weight of hook block to be entered during adjustment	Position of hook block when load is adjusted	
			Hook of mode selected	Other hooks
Crane	Main lifting	Main hook	Boom foot	_
Crane with auxiliary sheave	Main lifting	Main hook + Aux. sheave hook	Boom foot	1/4 of distances from boom point sheave to ground.
	Auxiliary sheave lifting	Main hook + Aux. sheave hook	Boom foot	
Crane with jib	Main lifting	Main hook + Jib hook	Boom foot	
	Jib lifting	Main hook + Jib hook	Boom foot	
Luffing crane (with main hook)	Main lifting	Main hook + Jib hook	Boom foot	
	Jib lifting	Jib hook	Boom foot	
Luffing crane (with aux. sheave hook)	Jib lifting	Jib hook + Aux. sheave hook	Boom foot	
	Auxiliary sheave lifting	Jib hook + Aux. sheave hook	Boom foot	
Luffing crane (jib hook only)	Jib lifting	Jib hook + Aux. sheave hook	Boom foot	

Perform this adjustment by boom lowering motion control.

Adjusting points shall be max. boom (jib) angle point and min. boom (jib) angle point and random selected 5 points between them.



Max. boom (jib) angle and min. boom (jib) angle points are essentially required but points between them can be neglected.


There is no rule on number of points and their interval.

However more precise adjustment becomes possible with more points on wider angle range.

Adjustment would become easier if the adjustment points (angle) are set in advance in the range between the upper limit angle and lower limit angle divided into 6 in the adjustment required configuration.

(1) Select "LOAD-LESS ADJUSTMENT" in the adjustment menu.

Touch load indicating area.





(2) Load indicating area turns highlighting and numeral input becomes possible.

Input hook weight with the numeric keypad. Refer to the table in the previous page for hook weight to be input.

Ex) In case of input "2.0", input (2), (.), (0).


After input, press SET.

After raising the boom to almost the upper limit angle and then lower by about 1 degree and then stop.



There is a some error stopped in boom raising and boom lowering motion.

So ensure to stop in boom lowering.



(3) Press SET.

(4) Lower the boom and stop.

Then press SET.

During boom lowering motion, control the hook raising motion to keep the hook in the same height.

If the points in between are to be skipped, press $_{\mbox{\scriptsize $\mbox{\footnotesize SKIP}$}}.$

If "skip" is selected, all the adjustment points in between are skipped.

(5) By pressing [EI], message memorizing the first point is displayed.

After lowering the boom, press SET.

If the points in between are to be skipped, press [SKIP].

If "skip" is selected, all the adjustment points in between are skipped.







(6) By pressing [SET], message memorizing the second point is displayed.

Second point is memorized.

After lowering the boom further, press [SET].

If the points in between are to be skipped, press $_{\mbox{\scriptsize SKIP}}$

If "skp" is selected, all the adjustment points in between are skipped.

(7) Repeat the adjustment in the same way in sequence.

When 5th point is memorized, message requesting to set the angle to minimum and press [31] is displayed.

Lower the boom to almost minimum angle and press EI.





(8) If the adjustment is properly completed, the message shown right is displayed.

At the same time K1, K2 values are displayed as adjustment result.

By pressing [ST], screen returns to the previous one.

If the adjustment is not properly completed, the message shown right is displayed.

After pressing [SET], start adjustment again.

In the load-less adjustment, if adjustment on more than two boom (jib) length is done, on boom (jib) length which is not adjusted yet, calibration by interpolation by two closest length adjustment values is applied.





6. Some load adjustment

Only the different point to load-less adjustment is the first load value input.

The rest are same.

Different point to load-less adjustment ONLY is explained here.

Firstly lift the weight known load.

Select "SOME LOAD ADJUSTMENT" in the adjustment menu.

By touching load indicating area, display turns highlighting and numeral input becomes possible.

Input load weight actually being lifted with the numeric keypad and press [ET].

* This includes weight of hook and lifting sling.

The procedure afterward is as same as loadless adjustment.

Proceed as same as load-less adjustment.

If adjustment is completed, the screen is displayed as shown right.

At the same time, K3, K4 values are displayed as the adjustment result.

By pressing $\fbox{\ }$, screen returns to the previous one.

If adjustment is not completed, following is displayed.

"Adjustment is in error".


Press set and readjust.


After pressing [SET], start readjustment.

▲ CAUTION

The some load adjustment is likely to receive wind effect.

Therefore if the actual load display changes significantly, wait until the lifting load stops swinging and then press [SET] icon.







7. LVL adjustment

LVL means the load ratio to stop automatically. Normally auto stop load ratio is set at 105% but with this function this load ratio can be changed to 90 to 110%.

A CAUTION


LVL function is only effective when "EFFECTIVE" is set in LVL setting in the setting.

If "NOT EFFECTIVE" is selected, normal 105% is applied even value is changed in this function.

(1) Select "LVL ADJUSTMENT" in the adjustment menu.

Touch the load ratio indicating area.

(2) The indicating area becomes highlighted. Input value with the numeric keypad.





(3) After value input is completed, press [SET].


Setting is completed and screen returns to previous one.



LVL FUNCTION

The following drawings are some examples of LVL function.

(A) When the LVL function is OFF.
If the loading ratio is become 105% while the LVL function is not effective, operation toward the hazardous side is automatically stopped.
Note that hysteresis of 5% must be considered for restoration from the automatic stop status.
When the loading ratio is returned to 100%, the automatic stop status is cancelled.
When the loading ratio is 90% or more, intermittent warning alarm sounds are emitted.
Continuous alarm sounds are emitted when the loading ratio is 100% or more.





The machine is restored from the automatic stop status when the loading ratio is less than 85%.


When the loading ratio becomes 90% with the continuous alarm sounds are emitted.

No forecasting sound (intermittent sound) will be emitted.

(C) When the LVL function is ON and set at 110%. When LVL is set at 110%, the function will be taken as shown in the figure. Please note the following points.







- LVL is also affected by the work area limit parameters. It operates by referencing the smaller value set by the Load Setting switch in "Setting the Work Area Limit Values".
- The LVL operational lag (hysterics) is -5%.
- The load ratio is not affected by LVL function.
- When the loading ratio is 90%, forecasting sounds (intermittent sounds) are emitted.
 Alarm sounds (continuous sounds) are emitted when the loading ratio is 100% (not affected by the LVL function).

8. Work radius adjustment

This is used when difference between the displayed work radius and the actual work radius is large due to the boom deflection etc.




Ensure to check if there is any error in angle display. If error is larger than 0.3 degrees carry out angle adjustment first.

(1) Raise the boom (jib) to almost upper limit angle and then lower by about 1 degree and then stop.


Select "RADIUS ADJUSTMENT" in the adjustment menu.

Touch the radius display area.





(2) Radius display area becomes highlighted and the numeral input becomes possible.



- (3) Input actually measured work radius with the numeric keypad.
- Ex) In case of input "13.9", input (1), (3), (.) (9).

After input, press SET.



(4) Lower the boom (jib) to almost min. angle and stop.

Then press SET.




(5) Touch the radius display area.



- (6) Input actually measured work radius with the numeric keypad.
- Ex) In case of input "16.9", input (1), (6), (.) (9).

After input, press SET.



By pressing $\fbox{}$, screen returns to the previous one.





(8) If the adjustment is not properly completed, the message shown right is displayed.

By pressing [SET], screen returns to the one during adjusting.


Re-check the procedure and start adjustment again.



- 9. Swing angle adjustment
- (1) Select "SWING ANGLE ADJUSTMENT" in the adjustment menu.

Face the crane toward front (idler side of crawler) and fix with the swing lock pin.

Press FR.



LVL ADJUSTMENT

RADIUS ADJUSTMENT

SWING ANGLE SENSOR

BACK

ADJUSTMENT

ANGLE SEMSOR ADJUSTMENT

LOAD CELL ZERO

OFFSET ADJUSTMENT

LOAD-LESS ADJUSTMENT


SOME LOAD ADJUSTM


(2) If the display changes from FR to ®, front side adjustment is properly completed.

Swing the crane by 180 degrees and face it toward rear (travel motor side) and fix with the swing lock pin.

Press RE.

(3) If display changes from RE to ®, rear side adjustment is properly completed.







(4) When either FR or RE is pressed and "NG" is displayed, adjustment is in error.

Check if the crane direction or sensor voltage is correct and start adjustment again.

Right screen indicates "NG" in rear adjustment as an example.

(5) To reset adjusted value, press ."OK" is displayed on both FR, RE and the values are reset.





10.2.11 ML ADJUSTMENT (TEMPORARY)

This adjustment is used to match with the load temporary when error exists in load display due to load detector abnormality etc.

There is no limit in adjustment value and adjustment would become possible even when error occurs in load-less/some load adjustment in "10.2.10 ML ADJUSTMENT (NORMAL)".

However if the crane configuration setting (setting of attachment) is changed, adjusted value would be deleted.

Use this adjustment ONLY for emergency case.


1. Press "ML ADJUSTMENT (TEMPORARY)" in the maintenance menu.

Adjustment possible load detectors become displayed. Select the required one.

Adjustment items become indicated.

Select the required one.

The procedure of "LOAD-LESS ADJUSTMENT", "SOME LOAD ADJUSTMENT" are same as "LOAD-LESS ADJUSTMENT", "SOME LOAD ADJUSTMENT" of "10.2.10 ML ADJUSTMENT (NORMAL)".



10.2.12 OPERATION PROGRESS


 Press "OPERATION PROGRESS" in the maintenance menu.
 Information of internal operation will be displayed.



Symbols	Details			
FOM	Tare weight component during front winch lifting with current radius			
FOA	Tare weight component during rear winch lifting with current radius			
FOR	Tare weight component during third winch lifting with current radius			
δΜ	Load coefficient during front winch lifting with current radius			
δΑ	Load coefficient during rear winch lifting with current radius			
δR	Load coefficient during third winch lifting with current radius			
F00	Tare weight component other than weight of hook block with current radius (during simultaneous lifting only) (Not used)			
F	Raising guy line tension			
FM	Front winch wire rope tension (w/ front winch load cell) (Not used)			
FA	Rear winch wire rope tension (w/ Rear winch load cell) (Not used)			
FR	Third winch wire rope tension (w/ third winch load cell) (Not used)			
WHOLE R.L.	Whole rated load (rated load during selected mode)			
WHOLE A.L.	Whole actual load (actual load during selected mode)			
WHOLE RAT.	Whole moment ratio (value indicated in bar gauge)			
MAIN R.L.	N R.L. Front winch rated load with current radius on the basis of data			
AUX. R.L.	Rear winch rated load with current radius on the basis of data			
THIRD R.L.	Third winch rated load with current radius on the basis of data			
RM	Calculated front winch operating radius before correction by radius adjustment			
RA	Calculated Rear winch operating radius before correction by radius adjustment			
RR	Calculated third winch operating radius before correction by radius adjustment			

EXAMPLE OF USING OPERATION PROGRESS SCREEN

The actual load W can be indicated by the formula shown below.



Suppose the values above are indicated shown below and the indicated actual load is 2 t, when a load weighing 5 t is lifted with the front winch.

$$F = 4.97$$

 $FOM = 2.28$
 $\delta = 1.33$


If neither load-less adjustment nor some load adjustment is carried out, and factors from k1 to k4 are ignored, the theoretical value F required for the actual load of 5 t can be found by the using the formula above, as shown below.

$$F = 5 \times 1.33 + 2.28 = 8.93$$

Where, the actual value F is obviously smaller than the theoretical F.

8500-1 / 8500E-1 10-276 Published 12-16-15, Control #244-01

Next, the F can be found by the formula shown below.



If the load cell zero point adjustment has not been carried out, adjustment value is 1, and the coefficient is 1.02 if the boom lowering stopped.

In such a status, if the load cell voltage is calculated with using the formula above and the value when the F is 4.97, the present load cell voltage is 1.34 V.

In a similar manner, the load cell voltage is 1.61 V, when the theoretical tension F is 8.93.


Then check the load cell voltage on the I/O signal check screen.

If it is close to 1.34 V as stated above, the detected load cell voltage is smaller than the theoretical value. In this case, the load cell may be faulty.

10.2.13 VERSION INFORMATION

1. Press "VERSION INFORMATION" in the maintenance menu.


Each part number and version of ML program, monitor, MC1 program, MC2 program, ML data are displayed.



8500-1 / 8500E-1 10-278 Published 12-16-15, Control #244-01

10.2.14 FAILURE HISTORY

- 1. Press "FAILURE HISTORY" in the maintenance menu.
- 2. Items are displayed.






3. ML failure history

Press "ML FAILURE HISTORY" in the menu.

Past failures become displayed from latest one in order to max. 20 items.

Failure content is displayed by code.

Check the contents by the table in operator's manual refer to the article 3 "MESSAGE TABLE".



DELETING FAILURE HISTORY

When the failure record is to be deleted, press \blacksquare


The message right becomes displayed.


In case of deletion, press .

In case of not deletion, press .

Press for more than 1 second.

By pressing , data is deleted.





4. MC1 failure history

Press "MC1 FAILURE HISTORY" in the menu.

Past failures become displayed from the latest one in order to max. 200 items (10 item × 20 page).

By (a) page can be scrolled up and by (a) page can be scrolled down.

Failure content is displayed by code.

Check the contents by the table in operator's manual refer to the article 3 "MESSAGE TABLE".

DELETING FAILURE HISTORY

When the failure record is to be deleted, press

The message right becomes displayed.

In case of deletion, press .

In case of not deletion, press .

Press for more than 1 second.

By pressing , data is deleted.







5. MC2 failure history


Press "MC2 FAILURE HISTORY" in the menu. Display content and handling procedure are same as MC1.

10.2.15 ADJUSTMENT DATA

Press "ADJUSTMENT DATA" in the maintenance menu.

Adjustment data menu becomes displayed.

- Angle sensor
- (1) Adjustment data display Press "ANGLE SENSOR" in the menu.






(2) Table of adjustment data of angle detector is displayed.


On this machine, No.1 is used for boom angle detector, No.2 is for crane jib angle detector and No.3 is for tower jib angle detector.

span=1.000 is displayed.

If adjustment is not done yet, shift=0.000,

(3) Adjustment data change In case of changing adjustment data, touch the numeral area to be changed. Touched area becomes highlighting and the numeral input becomes possible.





- (4) Input the value with numeric keypad.
- Ex) In case of input "1.103", input (1), (.), (1), (0), (3).

If there is other changing area, change the value in the same way.


After all input is completed, press 🖺.

(5) The message right becomes displayed.

Press 🕮.

(6) Deleting adjustment data Touch the area where to be deleted, be turns highlighting. Press for 3 seconds to execute.





(7) All adjustment data returns to the initial value. Initial value: Shift = 0.000, Span = 1.000

If either shift or span is deleted, the other one also is deleted.

The message right becomes displayed.

This is to complete deletion.

Press 🕮.

- 2. Load detector zero adjustment
- Adjustment data display
 Press "Zero offset value of load cell" in the menu.

Table of zero point adjustment data of load detector is displayed.

They are displayed by load cell voltage value at time of zero adjustment.

On this machine, No.1 of iL1 is used for boom hoist load detector, No.1 of iL3 is for jib hoist load detector.


If adjustment is not done yet, 1.000 is displayed.


Press to return to the previous screen.

- (2) Changing of adjustment data
- (3) Deletion of adjustment data

Adjustment data can be changed or deleted with the same way as that of adjustment data of angle detectors.







- 3. Load-less / some load (temporary)
- Adjustment data display
 Press "F0/d (temporary)" in the menu.

 Table of adjustment datas becomes displayed.


М	Front lifting mode adjustment data		
Α	Rear lifting mode adjustment data		
R	Third lifting mode adjustment data		
No	Load-less load adjustment		
S.	Some load adjustment		

If adjustment is not done yet, shift=0.000, span=1.000 is displayed.

Press to return to the previous screen.

- (2) Changing of adjustment data
- (3) Deletion of adjustment data

Adjustment data can be changed or deleted with the same way as that of adjustment data of angle detectors.





- 4. Load-less / some load (normal)
- Adjustment data display
 Press "F0/d (normal)" in the menu.

 Table of adjustment datas becomes displayed.

On this adjustment, 10 type of boom length adjustment are possible on each group of 1 to 30.

At first, group 1 becomes displayed. On every pressing of ♠, group changes like 2, 3, 4...30. On every pressing of ♠, group changes like 30, 29, 28...2.

No.1 to No.10, adjusted boom length (jib length in case of luffing), shift and span of load-less adjusting become displayed.


If adjustment is not done yet, shift=0.000, span=1.000 is displayed.

When more than two boom (jib) length are adjusted and non adjusted boom (jib) length is used, calibration between closest two length is applied.

- (2) Changing of adjustment data
- (3) Deletion of adjustment data

Adjustment data can be changed or deleted with the same way as that of adjustment data of angle detectors.

* In case of deletion, displayed group data ONLY is deleted.



- 5. Working radius
- (1) Adjustment data display
 Press "RADIUS" in the menu.
 Table of adjustment datas becomes displayed.

This adjustment also consists of group 1 to 30 and the first screen indicates group 1 to 15. By pressing


group 16 to 30 becomes displayed.

Contents of each group is as same as that of "LOAD-LEE/SOME LOAD(NORMAL)".

If adjustment is not done yet, shift=0.000, span=1.000 is displayed.

- (2) Changing of adjustment data
- (3) Deletion of adjustment data


Adjustment data can be changed or deleted with the same way as that of adjustment data of angle detectors.






10.2.16 DOWNLOAD ML PROGRAM

- 1. Take out data CF card from ML controller and insert CF card with new program filed in.
- * It is possible to write in by filing the program to data CF card.
 - 8500E-1 will be need turn on to "H3" position of drum select switch.
- 2. Connect write in permit connector CN- 420M and CN-439F on the right upper of the controller.
- 3. Turn on the key switch.
- 4. Download is started.




During download, 7 segment display of the controller changes as shown below.




- 5. When End is indicated, re-writing is completed.
- 6. Turn OFF the key switch.
- 7. Pull out write in permit connector.
- 8. Return the original CF card back to the ML controller.

10.2.17 DOWNLOAD OF MONITOR PROGRAM

- 1. Insert the CF card with new program filed in to the CF card slot on the back face of the monitor.
- * Ensure to close the cover.



- 2. Turn the key switch ON and wait for screen to start.
- 3. When the screen is started, tap on screen corners diagonally in succession.




8500-1 / 8500E-1 10-290 Published 12-16-15, Control #244-01

4. Menu becomes indicated on the lower part of the screen.


Select "CF/USB".

| SOO min | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO | TOO |


5. Select "CF START".




If the error as shown right is displayed, check for inserted condition of CF card or cover to be closed.




7. Select [DOWNLOAD (CF \rightarrow Display)]



8. Select [Start].



9. Select [Yes].



10. Download starts.

Write in [OS data], [System / Project data] in its order. If properly completed, message as shown right becomes displayed.

Press [Back].

11. Press [Back] to return to the screen before writing in starts.

OS data write completed (4/4).
System/Project data write completed (80/80).
SRAM data write completed (2/2).
Successfully completed.
Please press the Back button.


Download

Warining: Data in the internal memory will be lost.


File Name: //MEM3X00.CML

OS data write completed (4/4).
System/Project data write completed (80/80).
SRAM data write completed (80/80).
SRAM data write completed (7/2).
Successfully completed.
Please push the Back button.

Back



12. Press [Exit] to return to the screen 1 step before.




13. Press [Yes].

Monitor re-starts.

This is to complete re-writing of program.


Turn the key switch OFF and take out the CF card.




10.3 MAIN CONTROLLER

10.3.1 ARRANGEMENT OF MAIN CONTROLLER

1. Installation position (cab) of main controller 1




2. Installation position (left deck) of main controller 2



10.3.2 COMPOSITION OF SYSTEM

1. System composition chart



2. Output relation to controller

Items	Input/Output	Signal types	Outline
M/L (LMI)	Input/Output	Serial communication	The changes in lifting height during boom and jib hoisting, and number of part lines are transmitted from the M/L. The operating direction of the winch operation lever is transmitted to the M/L. The signals referring to automatic stop are input from the M/L in digital form.
Maintenance personal computer	Input/Output	Serial communication	This PC is used for down-loading of programs.
Grip throttle	Input	Analogue 0 to 5 V	The grip signals from the engine throttle are input.
Sensor	Input		The values from the pressure sensor, engine turn sensor, wind speed sensor, etc. are input.
Cab inside switch/ trimmer	Input		The values from the switches and trimmers in the cab are input.
Proportional valve	Output	24 V 100 to 700 mA	PWM output Constant current circuit (Max 1 A) Disconnection detection W/short-circuit protection
Solenoid valve	Output	24 V 1 A	Disconnection detection W/short-circuit protection

10.3.3 FUNCTION OF MAIN CONTROLLER

FUNCTION	CON	CONTROL		
FUNCTION	MC1	MC2		
1. Accelerator control	0			
2. Horse power control	0			
3. Winch motor speed control	0	0		
4. Swing counterforce	0			
5. Swing speed control	0			
6. Swing limit control	0			
7. Winch control	0	0		
8. Boost control		0		
9. Boom stop control		0		
10. Front, rear drum hoisting stop		0		
11. Motor tilt angle control		0		
12. Hook over hoist control		0		
13. Drum rotation detect grip control (option)	0			
14. Front, boom pump control	0			
15. Height meter	0			
16. Lever interlock control	0	0		
17. DPF regeneration control	0	0		
18. G winch control	0	0		
19. G engine control	0			
20. AIS control	0			
21. HYD. oil heat (option)	0	0		

MC1 : MAIN CONTROLLER 1 MC2 : MAIN CONTROLLER 2

Adjustment function

(1)	Model number setting
(2)	Option setting
(3)	Adjustment of grip throttle and foot throttle
(4)	Engine speed adjustment
(5)	Adjustment 5 Proportional solenoid valve output adjustment
(6)	Adjusting of inclination meter
(7)	Supply pump adjustment

1. Accelerator control


(1) Accelerator control

This provides command to ECU (engine control) based on input of grip throttle or foot throttle. In case of both throttles are equipped, throttle having larger amount of command has a priority.

* To make foot throttle effective, option setting and adjustment is required.

In case of receiving command from remote control too, accelerator control by command to ECU shall be done.

In case the remote control is connected, input to remote control has the first priority to control.



If the wire of accelerator control or foot control is broken, output voltage to ECU becomes 0 V. In this case, by turning the aux. accelerator switch to ON, low speed and middle speed becomes operational.


(High speed is not possible)

(2) Power control

Battery relay is energized 1.5 seconds after the key switch is turned ON.

Battery relay is de-energized 4 seconds *after the key switch is turned OFF.

However in case of emergency solenoid being actuated, 90 seconds after.




2. Horse power control


This is to control pump by calculating target speed from grip throttle to meet with engine actual speed.

The actual speed of pump is lower against target speed, the output current is larger.

However in case of low idling, even the difference is small, output current is large. (to prevent engine stall)



3. Winch motor speed control



 Front, Rear, Third (option) drum speed variable Max. current of remo-con prop. valve and motor control prop. valve is controlled as shown above.


Priority order is as follows.

Remo-con prop. valve:

Front, rear, third (option) stop, Lever interlock > Front, rear speed reducing > Free fall > Trimmer control


Motor control prop. valve :

(Refer to "11. Motor tilt angle control" for detail)
Auto-stop > Free fall speed increase > Main
pump inching speed > Trimmer control (during
power lowering)




(2) Boom drum speed control


In case of low engine speed, when engine speed is intended to increase by characteristic (a) becomes closer to characteristic (b). If the trimmer is set to maximum value, the prop. valve becomes full open and the main valve opening becomes maximum.




4. Swing counterforce


A reaction is applied to the lever depending on swing loads.





5. Swing speed control






 When the swing control signal is OFF for 10 seconds, or swing limit function is selected, the current becomes maximum value. (700 mA)

8500-1 / 8500E-1 10-304 Published 12-16-15, Control #244-01

6. Swing limit control



(1) Swing deceleration

Based on swing deceleration signal (R and L) input value (31 \rightarrow 0), right swing / left swing stop prop. valve output current is controlled.


(2) Swing stop

5 seconds after the deceleration signal becomes "0", swing parking output is issued.

Parking action is released when left control pressure is detected when stopped with right deceleration.


Parking action is released when right control pressure is detected when stopped with left deceleration.

Judging point of control pressure is more than 0.539 MPa.



7. Winch control

- (1) Control lever neutral mode selection
- (2) Winch operation solenoid valve control



- (A) When power is supplied The machine always starts running in the neutral brake mode.
- (B) Switching from the brake mode to the free fall mode.

Condition	Output	
The free fall lock switch is set released and function lock lever is in work position.	Free release "ON"	Select the free mode.
The foot brake is depressed (the pressure switch is set to the "ON" position). The free selector switch is set to the "ON" position.		 Light up the free fall indicator lamp. (Monitor indication) Release the main pump control.

- (C) Change from free fall mode to brake mode Depress the foot brake again, and set the free fall mode selector switch to the ON position. Or, when the free fall permission signal is in the "OFF" status.
- (D) Control of solenoid valve in free fall/brake mode The front drum CLM (SOL-22) is controlled as shown in the table below.

Lever control	Mode			
	Neutral free	Neutral brake		
Hoisting	×	×		
Neutral	×	×		
Lowering	0	×		


○: Energized ×: De-energized

 The ON/OFF status of the lever operation is judged by the value from the pressure sensor.
 (Lever operation is judged to be ON if the pressure is 0.343 MPa or more.

It is judged to be OFF if the control pressure is not more than 0.196 MPa or less.)

The rear drum CLA (SOL-23) and the third drum CLT (SOL-24) are controlled in a similar manner.

When the lever is at the neutral position while the free fall mode is selected, output from the front drum (rear drum and third drum) lower remote control proportional valve to be met according to the respective clutch pressure outputs.




- (E) Emergency solenoid valve control For the front drum, when either of the conditions below is realized, ESM (SOL-19) is energized to prevent a drop of a lifted load.
- The clutch pressure is reduced (under 3.73 Mpa) although the brake mode is selected.
- The clutch pressure is reduced (under 3.73 Mpa) although the lever is operated during the free fall mode.

For the rear drum and the third drum, the ESA (SOL-20) and EST (SOL-21) are controlled respectively as same as front drum.


Note

Once the emergency solenoid valve is actuated, the current operation mode cannot be altered to the free fall mode unless power to the controller is shut down.

Even after the main power supply is shut down while the emergency solenoid valve is being actuated, power supply to the controller remains alive for 90 seconds and after the engine is stopped, in this period, the residual clutch pressure is removed.



(3) Free fall acceleration




The falling speed can be increased by idling the motor during the free fall.


The speed is controlled as shown in the table below

Conditions	Procedures	
	C/V free fall acceleration solenoid is energized.	
	Current of motor tilt angle proportional solenoid	
Free fall mode is selected.	Model Gr. : Current (Front/Rear Confluence/Independent)	
The control lever is at the neutral position. The "ERES SALL ORESE NORTH OF SALE OF CONTROLL" on the	FP, GG : 450 mA / 750 mA	
• The "FREE FALL SPEED INCREASE SWITCH" on the left upper of operation seat is ON.	GD, GH, GK : 510 mA / 750 mA	
The foot brake is not depressed.	GN, JD : 535 mA / 750 mA	
(Clutch ≤ pressure 1.96 MPa, when free fall mode)	HF : 527 mA / 750 mA	
	Current (Third)	
	All Models : 750	
One of the above conditions is not realized.	C/V free fall acceleration solenoid is de-energized.	
	Other conditions are restored to those of the normal control.	

The motor control proportional valve is controlled according to the depression of the foot pedal (clutch pressure).



8. Boost control



To prevent a momentary drop of a lifted load, apply a constant boost to the motor while the lever is in the neutral position.


The boost solenoid valves are controlled as shown in the table below.

Lever Boost solenoid valve	
Neutral	Energized.
$\text{Neutral} \rightarrow \text{hoist, lower}$	Immediately de-energized.
Raise, lower → Neutral	Energized a second after the lever is returned to the neutral position. Remained de-energized if the lever is operated within a second after the lever is returned to the neutral position.

When the front drum or rear drum is stopped, the boost solenoid valve is controlled as shown in the table below.


Stop signal	Boost solenoid valve	
Front drum hoist stop	rum hoist stop Front drum boost solenoid is immediately de-energized.	
Rear drum hoist stop Rear drum boost solenoid is immediately de-energized.		
Third drum hoist stop	Third drum boost solenoid is immediately de-energized.	


9. Boom stop control



When boom raise deceleration signals are input (input when the boom reaches 10 degrees before the boom upper limit), the boom raise remote control proportional valve is controlled and the boom raising speed is decelerated according to the boom angle.


When the boom lowering stop signals are input, the current value at the boom lower proportional valve is minimized within 1.5 seconds, and the boom lowering stops gradually.







8500-1 / 8500E-1 10-312 Published 12-16-15, Control #244-01


10. Front, rear drum hoisting stop








11. Motor tilt angle control




- During hoisting or lowering at brake mode or free mode, current of each motor tilt angle prop. valve is controlled as follows. (Trimmer control)
- (A) Current of motor tilt angle prop. valve varies based on lever motion and speed variable trimmer position.
- 1) Front drum and rear drum (At confluence)




At confluence circuit, front, rear tilt angle prop. valve control

2) Front, rear and third drum (At independence)



(B) Maximum current of motor tilt angle prop. valve is controlled by no load engine speed (Command quantity by grip).



(2) When auto-stopped

In case of drum is in auto-stop condition, output current is to be fixed to 200 mA.

But if operated toward safe side (not auto-stop side), it shall return to the value by other control.

(3) Luffing mode speed control

In case luffing mode is selected by ML (by ML transmission) third motor high speed is cut off by output control of third motor tilt angle prop. valve. Prop valve current is cut off to make third tilt angle pressure lower than 2.11 MPa (3.37 V)

(4) Clamshell mode

In case work mode select is ON (= low speed is selected [Heavy load clam], front motor tilt angle and rear motor tilt angle are fixed to low. (prop valve current is fixed to 200 mA)


(In case of luffing specification, this is not done.)

(5) Priority order is as follows.

Auto stop (this section) > free speed increase > main pump inching speed > clamshell mode (this section) > trimmer control (this section) > luffing mode speed control (this section)

Between trimmer lever control value or engine speed control value, smaller value is selected as maximum value.

12. Hook over hoist control



(1) Action at hook over hoist Output of corresponding remo-con. valves shall be 150 mA when hook over hoist notice is received with CAN transmission from ML.

At the same time, stop signal from ML is input and stop action is done.

STOP CORRESPONDING REMO-CON, PROP. VALVE

Front hoist remo-con. prop. valve

Rear hoist remo-con. prop. valve

*But in case of tower configuration, stop action is not executed.

Rear lower remo-con. prop. valve

*But in case of tower configuration only, stop action is executed.

Boom raise lower remo-con. prop. valve

Third hoist remo-con. prop. valve

*But in case of luffing configuration, stop action is not executed.

Third lower remo-con. prop. valve

*But in case of luffing configuration only, stop action is executed.

(2) Action at hook over hoist released When hook over hoist is released at hook over hoist occurs, the following action is made.

Front, rear and third (jib) hoist remo-con. prop. valve command current are set to inching speed level. (375 mA)

If each lever is in operation, each tilt angle prop. valve output is fixed to Low. (310 mA)

Published 12-16-15, Control #244-01

13. Drum rotation detect grip control (option)


Control the grip solenoid based on drum rotation sensor input.


Grip solenoid output becomes OFF when the drum speed exceeds the specified level.

Specified speed. = drum speed:


about $61.5 \text{ min}^{-1} = \text{more than 4 pulses at } 50 \text{ msec.}$

Therefore there is no output from the total controller.





14. Front, boom pump control



(1) Inching control

This is to control the tilt angle proportional (prop.) valve of each pump according to lever motion.


Pump	Drop valvo	Lever motion				
	Prop. valve	Front	Rear	Boom	Travel L	Travel R
Main front	Main pump tilt angle 1	Dologoo	Dologoo	Delegee	Delegee	Dologoo
Main rear		Release	Release	Release	Release	Release

 The corresponding prop. valve is released based on lever motion as shown above.


Release : 150 mA Lever in neutral : 700 mA

- For model with main pump 1, 2 prop valve 1 and 2 are released based on front and rear control motion only at independence mode.
 At confluence mode, they are released at the same time.
- Prop. valve released at third drum is lever controlled.
 Main pump tilt angle prop. valve is released.
- (2) Control at inching switch is ON. When the inching switch is ON, output becomes 700 mA regardless of lever control. At this time, motor tilt angle prop. valve is fixed to low. (310 mA)
- (3) 8500E-1 (CEN conforming) control (Not required for North American models.) When ML is released and switch input is ON, same control as inching switch ON control (2) above is applied.

15. Height meter




- (1) Drum rotation amount is detected by pulse counting with drum rotation sensor.
- (2) When hoist pressure sensor input exists, variation is counted on hoisting side, and on the other case, variation is counted as ⊕ or ⊖ on lowering side.
- (3) The number of wire rope layer adjusted in the main monitor is as a standard layer, calculate the layer during rotation.
- (4) From the factor of each layer and pulse number, rope payout amount is calculated.
- (5) The height is calculated by winding length divided by number of part line.
- (6) With moment limiter, boom point height data is received (jib point height in case of tower). Difference between height of zero reset time and the present height is calculated and the boom or jib height is calculated.
- (7) Distance variation of hook and boom point (jib point) is calculated by angle variation of boom (jib).
- (8) Actual height variation is calculated by adding (5) to (7) and is indicated on main monitor.
- To make this control effective, option setting is required.



8500-1 / 8500E-1

16. Lever interlock control



This is to prevent drum unexpected rotation at engine start when the lever is in operating position and the function lock lever is in work position.

(1) Before engine start

Each prop. valve current is minimum. (150 mA) Pilot cut relay RL-13 is to be output. (pilot cut condition)

Swing parking relay RL-09 is to be output. (Swing parking condition)

(2) After engine started After generation signal is input the


After generation signal is input, the following actions take place.

- (A) In case the function lock lever signal is OFF
- When travel interlock option is equipped:
 Pilot cut relay output becomes ON.
 When travel interlock option is not equipped:
 Pilot cut relay output is not issued.
- 2) Swing parking relay output becomes ON.
- 3) Output to each proportional valves are minimum.
- (B) In case the function lock lever signal is work position (+24 V)
- Output of pilot cut relay becomes OFF.
 If travel control is detected 1 second after pilot cut relay OFF, pilot cut relay becomes ON again. (only when travel interlock option is equipped.)
- 2) Swing parking relay output becomes OFF.
- 3) If 3 seconds is elapsed after pilot cut relay OFF, judge if the pressure is existing on each remocon prop. valve and all hoist and lower motion levers are in neutral, both hoist and lower output becomes minimum value of which used in other control.

Either one of operating motion is detected, all prop. valves output stay minimum as is.

Control stop condition by lever interlock function is to be transmitted to the monitor.

17. DPF regeneration control




Regeneration starts when more than certain amount of soot is accumulated in DPF (Diesel Particulate Filter).

Counting of soot accumulated volume and regeneration start timing etc are all done by engine ECU.

However load valve control and engine speed control to raise exhaust system temperature in order to prevent regeneration starting during crane operation are done by crane side controller.

18. G winch control



(1) G winch mode selecting

This is to make individual select switch, which is set individually for front/rear based on input of G winch select switch effective.

When individual switch is input, G winch condition is selected based on the conditions shown in the table.

	Input condition				
Mode	G winch		Lavaraanditian	Frains aread	
	Main	(Fr)	(Re)	Lever condition	Engine speed
Normal mode	OFF	_	_	Neutral	-
G winch main mode	ON	_	_	Neutral	Idle ±5 %
G winch (Fr) (Re) mode	ON	ON (Ind.)	ON (Ind.)	Neutral	1,000 min ⁻¹ or lower

^{*} Engine speed upper limit value is a value with G engine function OFF.

At G engine function is ON, upper limit 900 min⁻¹.

(2) G winch individual mode When individual mode is selected either front or rear drum, the following action occur.

(A) Hydraulic circuit is changed internally to confluence mode.

In case of independence mode is selected, monitor indication only becomes independence condition.

Mid detent is also ineffective.

- (B) Engine speed is raised to upper limit value.

 If G engine OFF, it becomes 1,000 min⁻¹.

 At G engine, it becomes upper limit 900 min⁻¹.
- (C) Motor tilt angle control is changed to that of individual mode.
- (D) Motor CHP prop. valve is changed to the one same as individual mode.

At luffing configuration, rear individual mode becomes ineffective.


After either front or rear becomes independence, G winch shall be released by one lever control (neutral \rightarrow operation \rightarrow neutral)

In case G winch function is required again, the individual switch is input.

After switched to individual mode and individual switch is pressed again, function is cancelled.

The load limit is to be determined with the displayed load in the monitor, selecting the G winch mode after the selection of the hook which is to be used.

19. G engine control



(1) G engine function select switch After inputting into select switch, check the each levers location and if they are all in neutral, Q max cut solenoid is energized.

Mode	Input		Output	
Mode	G engine function select	Lever condition	Q max cut SOL	Engine speed control
G engine	ON	Neutral	ON	1,725 min ⁻¹
Normal	OFF	Neutral	OFF	2,100 min ⁻¹


- * At G engine mode, engine speed upper limit is changed as shown in the table.
- * Q max cut solenoid becomes de-energized and then Q max cut condition is created. (When energized, pump flow max. value is raised.)

(2) Fail safe

To prevent pump failure, engine speed and Q max cut pressure are always monitored and the following actions are taken at abnormal.

	Abnormal judged value			Action at abnormal	
Mode	Q max cut pressure	Q max cut SOL FB value	Engine speed control	Q max cut SOL	Engine speed control
G engine	3 MPa or more	OFF	1,800 min ⁻¹ or more	OFF output	1.725 min ⁻¹
Normal	Less than 3 MPa	ON	No judgement	* at speed abnormal	1,725 111111

20. AIS control



The above circuit diagram is extract from the main diagram for only related portion of this control.(engine stop/re-start)

When the conditions below are met, engine stops automatically.

Engine stop condition	Effective condition	ML permit condition
ML permit	ML permit condition	
No load engine speed	Low idling ±5 %	
Free fall	Neutral brake mode	
Parking switch	Parking condition	Configuration condition : Other than assembly/ disassembly, stowing mode
Control lever neutral	All neutral incl. swing	Cuter than assembly, also settler, stowing mode
Water temp. condition	40 to 80°C (104 to 176°F)	
Oil temp condition	Lower than 60°C (140°F)	

(1) Engine stop action

If the conditions are met and operator's cancellation does not made, main controller 1 energize engine stop relay. (RL-07)
Key switch signal to engine ECU becomes OPEN condition and engine ECU activate as

(2) Engine restart

Key OFF condition.

At AIS condition, control is only applied at engine stop condition.


Grip accellerator voltage is monitored and when higher than 20% voltage is detected, engine restart relay (RL-21) becomes energized.

However if engine does not start within 3 seconds, engine restart relay becomes deenergized regardless of grip voltage.

(3) Key cut off fail preventing function.


If AIS condition is continued for longer than certain time, battery relay is turned OFF automatically.

21. HYD. oil heat (option)



Control	Relay
When all lever is in neutral	Energized
When any lever is in operation	De-energized


10.3.4 MAIN CONTROLLER 1, 2 (HARDWARE)







MC1 : CN-101F to CN-109F MC2 : CN-111F to CN-119F



13

CN-107F

CN-108F CN-118F

CN-109F

10.3.5 SPECIFICATIONS OF MAIN CONTROLLER INPUT/OUTPUT

1. Specifications of main controller 1 input/output

ANALOGUE INPUT [A]

No.	Name	Range	Input voltage	Judgement
MC1-A01	Reeving winch trimmer			
MC1-A02	A/D Spare			_
MC1-A03	Fr. drum motor speed adjusting trimmer	0 to FULL	0.43 to 5V	
MC1-A04	Re. drum motor speed adjusting trimmer	0 to FULL	0.43 to 5V	- Input voltage InV ≤ 0.2V.
MC1-A05	Third drum motor speed adjusting trimmer	0 to FULL	0.43 to 5V	input voltage inv 3 0.2v.
MC1-A06	Boom drum motor speed adjusting trimmer	0 to FULL	0.43 to 5V	
MC1-A07	A/D Spare			
MC1-A08	Grip throttle	LOW to HIGH	0.7 to 5V	
MC1-A09	Foot throttle (option)	LOW to HIGH	1.0 to 4.4V	Input voltage InV < 0.2V
MC1-A10	Hyd. oil temperature sensor	50 to 130 °C	117.9 Ω to 9.6 Ω	Input voltage InV ≤ 0.2V.
MC1-A11	Tagline trimmer (option)	0 to FULL	0.43 to 5V	
MC1-A12	Control primary pressure	0 to 19.61 MPa	0.5 to 4.5V	
MC1-A13	Swing pump pressure sensor	0 to 49.03 MPa	0.5 to 4.5V	Judge detect among one of
MC1-A14	Swing operation (right) pressures sensor	0 to 2.94 MPa	0.5 to 4.5V	following condition. 1. Input voltage InV ≤ 0.1V.
MC1-A15	Swing operation (left) pressures sensor	0 to 2.94 MPa	0.5 to 4.5V	 Input voltage InV ≤ 4.9V. Input voltage InV ≤ 3.0V with
MC1-A16	Qmax cut solenoid detection pressure	0 to 49.03 MPa	0.5 to 4.5V	engine oil pressure = ON and changing = OFF.
MC1-A17	Power shift pressures sensor	0 to 2.94 MPa	0.5 to 4.5V	
MC1-A18	Supply voltage monitor	19V to 32V	0.5V to 4.8V	Input voltage InV ≤ 2V.
MC1-A19	Inclination detector X	-5 to 5 degrees	0.5 to 4.5V	Innut valtage InV < 0.0V
MC1-A20	Inclination detector Y	-5 to 5 degrees	0.5 to 4.5V	Input voltage InV ≤ 0.2V.
MC1-A21	Fr. drum clutch pressure sensor	0 to 19.61 MPa	0.5 to 4.5V	Judge detect among one of following condition.
MC1-A22	Third drum clutch pressure sensor (option)	0 to 19.61 MPa	0.5 to 4.5V	 Input voltage InV ≤ 0.1V. Input voltage InV ≤ 4.9V. Input voltage InV ≤ 3.0V with engine oil pressure = ON and changing = OFF.
MC1-A23	Re. drum clutch pressure sensor	0 to 19.61 MPa	0.5 to 4.5V	

No.	Name	Status	Signal level	Judgement
MC1-B01	ECU status signal	Power ON/OFF	Ground (15 kΩ) / OPEN	
MC1-B02	Engine hyd. pressure PSW	Engine Stop /Work	Ground (15 kΩ) / OPEN	
MC1-B03	Cooling line filter	Clogging / Normal	Ground (3.3 kΩ) / OPEN	
MC1-B04	Clogging of engine air cleaner	Clogging / Normal	Ground (15 kΩ) / OPEN	
MC1-B05	Vacancy		Ground (3.3 kΩ) / OPEN	
MC1-B06	Fr. drum brake cooling oil temperature	Higher temperature / Normal	Ground (3.3 kΩ) / OPEN	
MC1-B07	Re. drum brake cooling oil temperature	Higher temperature / Normal	Ground (3.3 kΩ) / OPEN	
MC1-B08	Radiator water level	Low level / Normal	Ground (3.3 kΩ) / OPEN	
MC1-B09	Engine oil filer	Clogging / Normal	Ground (3.3 kΩ) / OPEN	
MC1-B10	Fr. drum control signal	ON / OFF	Ground (3.3 kΩ) / OPEN	
MC1-B11	Re. drum control signal	ON / OFF	Ground (3.3 kΩ) / OPEN	
MC1-B12	Third drum control signal	ON / OFF	Ground (3.3 kΩ) / OPEN	
MC1-B13	Fr. drum free fall select. signal	Free / Brake	+24V / OPEN	
MC1-B14	Re. drum free fall select. signal	Free / Brake	+24V / OPEN	
MC1-B15	Third drum free fall select. signal	Free / Brake	+24V / OPEN	
MC1-B16	Fr. drum rotation sensor	0 to 500 min ⁻¹	Ground (3.3 kΩ) / OPEN	
MC1-B17	Re. drum rotation sensor	0 to 500 min ⁻¹	Ground (3.3 kΩ) / OPEN	
MC1-B18	Key switch ON signal	ON / OFF	+24V / OPEN	
MC1-B19	Function lock	Work / Lock	+24V / OPEN	
MC1-B20	Charge signal	Engine Stop /Work	+24V / OPEN	
MC1-B21	Inching select switch	Inching / Normal	+24V / OPEN	
MC1-B22	Aux. accel. signal	ON / OFF	+24V / OPEN	
MC1-B23	Engine emg. stop signal	Stop / Normal	+24V / OPEN	
MC1-B24	Engine restart	Work / Normal	+24V / OPEN	
MC1-B25	Operator certify wait signal	Uncertify / Certify	+24V / OPEN	
MC1-B26	Swing parking switch	Release / Parking	+24V / OPEN	
MC1-B27	Drum rotation detect grip selection	Select / Non-select	+24V / OPEN	

No.	Name	Status	Signal level	Judgement
MC1-B28	Controller ID 1	B28=ON, B29=OFF→ MC1	+24V / OPEN	
MC1-B29	Controller ID 2	B28=OFF, B29=ON → MC2	+24V / OPEN	
MC1-B30	G mode / Normal selection	G mode / Normal	+24V / OPEN	
MC1-B31	G winch (Fr.)	High speed / Normal	+24V / OPEN	
MC1-B32	G winch (Re.)	High speed / Normal	+24V / OPEN	
MC1-B33	Energy saving winch (main)	ON / OFF	+24V / OPEN	
MC1-B34	AIS function ON / OFF switch	ON / OFF	+24V / OPEN	
MC1-B35	Traveling operating pressure switch	Control / Neutral	+24V / OPEN	
MC1-B36	Third drum rotation sensor	0 to 500 min ⁻¹	Ground (3.3 k Ω) / OPEN	
MC1-B37	Boom drum rotation sensor	0 to 500 min ⁻¹	Ground (3.3 kΩ) / OPEN	
MC1-B38	Engine preheat	Preheat / Normal	+24V / OPEN	
MC1-B39	TW latch cylinder (Ex.) signal	Extension / Normal	+24V / OPEN	
MC1-B40	Backup fuse	Normal / Fusion	+24V / OPEN	
MC1-B41	Fr. drum free fall speed increase switch	High / Normal	+24V / OPEN	
MC1-B42	Re. drum free fall speed increase switch	High / Normal	+24V / OPEN	
MC1-B43	Third drum free fall speed increase switch (option)	High / Normal	+24V / OPEN	
MC1-B44	Free fall permit signal	Permit / Lock	+24V / OPEN	
MC1-B45	Fr. drum motor CLM-SOL (FB)	Energized / De-energized	+24V / OPEN	
MC1-B46	Fr. drum motor ESM-SOL (FB)	Energized / De-energized	+24V / OPEN	
MC1-B47	Re. drum motor CLA-SOL (FB)	Energized / De-energized	+24V / OPEN	
MC1-B48	Re. drum motor ESA-SOL (FB)	Energized / De-energized	+24V / OPEN	
MC1-B49	Third drum motor CLT-SOL (FB)	Energized / De-energized	+24V / OPEN	
MC1-B50	Third drum motor EST-SOL (FB)	Energized / De-energized	+24V / OPEN	
MC1-B51	Hyd. oil heat LS (OPT)	Energized / De-energized	+24V / OPEN	
MC1-B52	Pump Qmax cut solenoid (FB)	Energized / De-energized	+24V / OPEN	

No.	Name	Status	Signal level	Judgement
MC1-B53	Remote control connection signal	Connected / Unconnected	+24V / OPEN	
MC1-B54	Swing warning (flasher)	Flasher ON/OFF	+24V / OPEN	
MC1-B55	Swing warning (buzzer and flasher)	Buzzer and flasher ON/OFF	+24V / OPEN	
MC1-B56	DPF regeneration (FB)	Energized / De-energized	+24V / OPEN	
MC1-B57	Accel. signal (DOWN)	Rotate down / Holding	+24V / OPEN	
MC1-B58	Accel. signal (UP)	Rotate up / Holding	+24V / OPEN	

ANALOGUE OUTPUT [H]

No.	Name	Status	Signal level	Judgement
MC1-H01	Accel opening signal 1	800 min ⁻¹ to 2,100 min ⁻¹	1 to 4V	
MC1-H02	Accel opening signal 2	800 min ⁻¹ to 2,100 min ⁻¹	1 to 4V	

PROPORTIONAL VALVE OUTPUT [D]

No.	Name	Output current	Dither	Judgement
MC1-D01	Main pump power reduction prop. valve	100 mA to 700 mA	200 mAp-p 100 Hz	
MC1-D02	Boom pump power reduction prop. valve	100 mA to 700 mA	200 mAp-p 100 Hz	
MC1-D03	Swing low speed prop. valve	100 mA to 700 mA	200 mAp-p 100 Hz	
MC1-D04	Swing counterforce prop. valve	150 mA to 510 mA	200 mAp-p 160 Hz	
MC1-D05	Boom pump tilt angle control prop. valve	150 mA to 700 mA	200 mAp-p 100 Hz	
MC1-D06	Fr. drum middle detent	60 mA to 110 mA	None	When output command value is ≥ 100 mA and feedback current is ≤ 50 mA.
MC1-D07	Re. drum middle detent	60 mA to 110 mA	None	
MC1-D08	Main pump tilt a. control prop. valve 1	150 mA to 700 mA	200 mAp-p 100 Hz	
MC1-D09	Main pump tilt a. control prop. valve 2	150 mA to 700 mA	200 mAp-p 100 Hz	
MC1-D10	Tagline prop. valve	100 mA to 700 mA	200 mAp-p 63 Hz	
MC1-D11	Left swing stop prop. valve	100 mA to 700 mA	200 mAp-p 100 Hz	
MC1-D12	Right swing stop prop. valve	100 mA to 700 mA	200 mAp-p 100 Hz	

No.	Name	Status	Signal level	Judgement
MC1-C01	Fr. drum motor CLM-SOL	Energized / De-energized	GND / OPEN	Judge detect either following condition. 1. Mismatch between output command and actual port condition. 2. Mismatch between output command and MC1-B45 condition.
MC1-C02	Fr. drum motor ESM-SOL	Energized / De-energized	GND / OPEN	Judge detect either following condition. 1. Mismatch between output command and actual port condition. 2. Mismatch between output command and MC1-B46 condition.
MC1-C03	Re. drum motor CLA-SOL	Energized / De-energized	GND / OPEN	Judge detect either following condition. 1. Mismatch between output command and actual port condition. 2. Mismatch between output command and MC1-B47 condition.
MC1-C04	Re. drum motor ESA-SOL	Energized / De-energized	GND / OPEN	Judge detect either following condition. 1. Mismatch between output command and actual port condition. 2. Mismatch between output command and MC1-B48 condition.
MC1-C05	Third drum motor CLT-SOL	Energized / De-energized	GND / OPEN	Judge detect either following condition. 1. Mismatch between output command and actual port condition. 2. Mismatch between output command and MC1-B49 condition.
MC1-C06	Third drum motor EST-SOL	Energized / De-energized	GND / OPEN	Judge detect either following condition. 1. Mismatch between output command and actual port condition. 2. Mismatch between output command and MC1-B50 condition.

No.	Name	Status	Signal level	Judgement
MC1-C07	Sub battery relay energizing	Energized / De-energized	+24V / OPEN	Mismatch between output command and actual port condition. But judged only at output command is ON.
MC1-C08	Swing parking control	Parking / Release	GND / OPEN (300 mA)	Judge detect all of followings realized. • Swing limit device option setting " () ". • Function lock (MC1-B19) is ON condition. • Engine running. • Swing parking input (MC1-B26) has been made even once.
MC1-C09	ML adjust. mode selection	Adjust. Mode / Normal	GND / OPEN (300 mA)	
MC1-C10	Hyd. oil heat SOL	Heat / Normal	GND / OPEN	Mismatch between output command
MC1-C11	Pump Qmax cut solenoid	Energized / De-energized	GND / OPEN	and actual port condition.
MC1-C12	Swing flasher	Lit up / Unlit	GND / OPEN	
MC1-C13	Vacancy		GND / OPEN (PWM)	
MC1-C14	Vacancy		GND / OPEN (PWM)	
MC1-C15	Battery relay energizing	Energized / De-energized	+24V / OPEN	Mismatch between output command and actual port condition. But judged only at output command is ON.
MC1-C16	ML bypass reset	Reset / Bypass possible	GND / OPEN	
MC1-C17	Solenoid cut relay energizing	Solenoid cut / Normal	GND / OPEN	
MC1-C18	Engine warning output	Engine abnormal / Normal	GND / OPEN	Mismatch between output command and actual port condition.
MC1-C19	AIS air con. ON relay energizing	Power ON enabled / Disabled	GND / OPEN	
MC1-C20	Swing neutral brake selection	Neutral brake / Free	GND / OPEN	
MC1-C21	Boom drum rotate detect grip (option)	Energized / De-energized	+24V / OPEN	
MC1-C22	Key return	Resume / Normal	+24V / OPEN	Mismatch hetwoon output command
MC1-C23	TW latch cylinder (retract) output	Retract / Normal	GND / OPEN	Mismatch between output command and actual port condition.
MC1-C24	Camera power		GND / OPEN	and actual port containon.
MC1-C25	Key switch ON signal by AIS	ON / OFF	GND / OPEN (PWM)	

No.	Name	Status	Signal level	Judgement
MC1-C26	DPF regeneration start	Manual regene. start / Normal	GND / OPEN	Judge detect either following condition. 1. Mismatch between output command and actual port condition. 2. Mismatch between output command and MC1-B56 condition.
MC1-C27	Engine restart	Start / Normal	GND / OPEN	Judge detect either following condition. 1. Mismatch between output command and actual port condition. 2. Mismatch between output command and MC1-B24 condition.
MC1-C28	Pilot pressure cut relay	Energized / De-energized	GND / OPEN	
MC1-C29	Fr. drum rotate detect grip (option)	Bumps / dips	+24V / OPEN	
MC1-C30	Re. drum rotate detect grip (option)	Bumps / dips	+24V / OPEN	
MC1-C31	Safety relay operation	Operation / Normal	GND / OPEN	Mismatch between output command and actual port condition.
MC1-C32	Engine stop relay operation	Energized / De-energized	GND / OPEN	and actual port condition.
MC1-C33	Swing voice alarm	ON / OFF	GND / OPEN	
MC1-C34	Re. / 3rd. drum change		GND / OPEN	
MC1-C35	Vacancy		GND / OPEN (CPU error)	
MC1-C36	3rd. drum turn detection grip		+24V / OPEN	Mismatch between output command and actual port condition.

8500-1 / 8500E-1 10-340 Published 12-16-15, Control #244-01

2. Specifications of main controller 2 input/output

ANALOGUE INPUT [A]

No.	Name	Range	Input voltage	Judgement
MC2-A01	A/D Spare			
MC2-A02	A/D Spare			
MC2-A03	Fr. drum motor tilt control press. sensor	0 to 2.94 MPa (30 kg/cm²)	0.5 to 4.5V	 Judge detect among one of following condition. Input voltage InV ≤ 0.1V. Input voltage InV ≤ 4.9V. Input voltage InV ≤ 3.0V with engine oil pressure = ON and changing = OFF. Main hoist lever in neutral with the main hoist neutral brake mode. Main hoist motor swash angle pressure ≥ 2.0 MPa.
MC2-A04	Re. drum motor tilt control press. sensor	0 to 2.94 MPa (30 kg/cm²)	0.5 to 4.5V	 Judge detect among one of following condition. 1. Input voltage InV ≤ 0.1V. 2. Input voltage InV ≤ 4.9V. 3. Input voltage InV ≤ 3.0V with engine oil pressure = ON and changing = OFF. 4. Aux. hoist lever in neutral with the main hoist neutral brake mode. Aux. hoist motor swash angle pressure ≥ 2.0 MPa.
MC2-A05	Third drum motor tilt control press. sensor	0 to 2.94 MPa (30 kg/cm²)	0.5 to 4.5V	Judge detect among one of following condition. 1. Input voltage InV ≤ 0.1V. 2. Input voltage InV ≤ 4.9V. 3. Input voltage InV ≤ 3.0V with engine oil pressure = ON and changing = OFF.
MC2-A06	A/D Spare			
MC2-A07	Fuel level	F to 1/2 to E \rightarrow 10 to 32 to 83 Ω	Grounded input (56 Ω)	Input voltage InV ≤ 0.2V.
MC2-A08	Confluence / Independence select pressure (Fr.)	0 to 49.03 MPa (500 kg/cm²)	0.5 to 4.5V	Judge detect among one of following condition. 1. Input voltage InV ≤ 0.2V. 2. At single oil flow: Input pressure ≥ 3.0 Mpa. 3. At confluence flow: Input pressure < 3.0 Mpa.

ANALOGUE INPUT [A]

No.	Name	Range	Input voltage	Judgement
MC2-A09	Confluence / Independence select pressure (Re.)	0 to 49.03 MPa (500 kg/cm²)	0.5 to 4.5V	Judge detect among one of following condition. 1. Input voltage InV ≤ 0.2V. 2. At single oil flow: Input pressure ≥ 3.0 Mpa. 3. At confluence flow: Input pressure < 3.0 Mpa.
MC2-A10	A/D Spare		Grounded input (56 Ω)	
MC2-A11	Fr., Re. drum CHP start pressure sensor	0 to 2.94 MPa (30 kg/cm²)	0.5 to 4.5V	Judge detect among one of following condition. 1. Input voltage InV ≤ 0.1V. 2. Input voltage InV ≤ 4.9V. 3. Input voltage InV ≤ 3.0V with engine oil pressure = ON and changing = OFF. • At single oil flow: Input pressure ≥ 2.7 Mpa. • At confluence flow: Input pressure < 2.7 Mpa.
MC2-A12	A/D Spare			
MC2-A13	A/D Spare			
MC2-A14	A/D Spare			
MC2-A15	A/D Spare			
MC2-A16	Boom drum raise pressure sensor	0 to 2.94 MPa (30 kg/cm²)	0.5 to 4.5V	
MC2-A17	Boom drum lower pressure sensor	0 to 2.94 MPa (30 kg/cm²)	0.5 to 4.5V	
MC2-A18	Fr. drum hoist pressure sensor	0 to 2.94 MPa (30 kg/cm²)	0.5 to 4.5V	Judge detect among one of following condition.
MC2-A19	Fr. drum lower pressure sensor	0 to 2.94 MPa (30 kg/cm²)	0.5 to 4.5V	 Input voltage InV ≤ 0.1V. Input voltage InV ≥ 4.9V.
MC2-A20	Re. drum hoist pressure sensor	0 to 2.94 MPa (30 kg/cm²)	0.5 to 4.5V	 Input voltage InV ≥ 3.0V with engine oil pressure = ON,
MC2-A21	Re. drum lower pressure sensor	0 to 2.94 MPa (30 kg/cm²)	0.5 to 4.5V	charging = OFF, function lock OFF.
MC2-A22	Third drum hoist pressure sensor	0 to 2.94 MPa (30 kg/cm²)	0.5 to 4.5V	
MC2-A23	Third drum lower pressure sensor	0 to 2.94 MPa (30 kg/cm²)	0.5 to 4.5V	

No.	Name	Range	Input voltage	Judgement
MC2-B01	C/W detect 3		GND (15 kΩ) / OPEN	
MC2-B02	C/W detect 4		GND (15 kΩ) / OPEN	
MC2-B03	C/W detect 5 (C4, C5)		GND (15 kΩ) / OPEN	
MC2-B04	C/W detect 6 (C5)		GND (15 kΩ) / OPEN	
MC2-B05	C/W detect 7 (C5)		GND (15 kΩ) / OPEN	
MC2-B06	CB/W detect	Detection / Non-detection	Ground (15 kΩ) / OPEN	
MC2-B07			GND (15 kΩ) / OPEN	
MC2-B08			GND (15 kΩ) / OPEN	
MC2-B09			GND (15 kΩ) / OPEN	
MC2-B10			GND (15 kΩ) / OPEN	
MC2-B11			GND (15 kΩ) / OPEN	
MC2-B12			GND (15 kΩ) / OPEN	
MC2-B13	Crane boom overhoist signal	Normal / Overhoist	+24V / OPEN	
MC2-B14	Boom B/S No. 1 signal	Normal / Overhoist	+24V / OPEN	
MC2-B15	Boom B/S No. 2 signal	Normal / Overhoist	+24V / OPEN	
MC2-B16			GND (3.3 kΩ) / OPEN	
MC2-B17			GND (3.3 kΩ) / OPEN	
MC2-B18			+24V / OPEN	
MC2-B19	Function lock	Work / stop	+24V / OPEN	
MC2-B20	Charge signal (alternator power generation signal)	With power generation / Without power generation	+24V / OPEN	
MC2-B21	Inching selection switch	Inching / Normal	+24V / OPEN	
MC2-B22			+24V / OPEN	
MC2-B23			+24V / OPEN	
MC2-B24	Crane hook overhoist signal	Normal / Overhoist	+24V / OPEN	
MC2-B25	Jib hook overhoist signal	Normal / Overhoist	+24V / OPEN	
MC2-B26	Hook overhoist release signal	Release / Normal	+24V / OPEN	

No.	Name	Range	Input voltage	Judgement
MC2-B27	Boom hoisting release signal	Release / Normal	+24V / OPEN	3.7.5
MC2-B28	Controller ID 1		+24V / OPEN	
MC2-B29	Controller ID 2		+24V / OPEN	
MC2-B30	Fr. drum hoist stop	Normal / Stop	+24V / OPEN	
MC2-B31	Fr. drum lower stop (CEN)	Normal / Stop	+24V / OPEN	
MC2-B32	Re. drum (tower jib) hoist stop	Normal / Stop	+24V / OPEN	
MC2-B33	Re. drum (tower jib) lower stop	Normal / Stop	+24V / OPEN	
MC2-B34			+24V / OPEN	
MC2-B35	Jib overhoist signal	Normal / Overhoist	+24V / OPEN	
MC2-B36	C/W detect 1		GND (3.3 kΩ) / OPEN	
MC2-B37	C/W detect 2		GND (3.3 kΩ) / OPEN	
MC2-B38	Confluence / independence selection SOL (Fr. drum)		+24V / OPEN	
MC2-B39	Confluence / independence selection SOL (Re. drum)		+24V / OPEN	
MC2-B40	Oil cooler motor relay	ON / OFF	+24V / OPEN	
MC2-B41	Third drum hoist stop	Normal / Stop	+24V / OPEN	
MC2-B42	Third drum lower stop	Normal / Stop	+24V / OPEN	
MC2-B43	Boom drum raise stop	Normal / Stop	+24V / OPEN	
MC2-B44	Boom drum lower stop	Normal / Stop	+24V / OPEN	
MC2-B45	DPF load SOL	Load ON / OFF	+24V / OPEN	
MC2-B46			+24V / OPEN	
MC2-B47			+24V / OPEN	
MC2-B48			+24V / OPEN	
MC2-B49			+24V / OPEN	
MC2-B50			+24V / OPEN	
MC2-B51			+24V / OPEN	
MC2-B52			+24V / OPEN	
MC2-B53	ML bypass (CR)	ON / OFF	+24V / OPEN	
MC2-B54	ML bypass (JIB)	ON / OFF	+24V / OPEN	
MC2-B55			+24V / OPEN	
MC2-B56			+24V / OPEN	
MC2-B57			+24V / OPEN	
MC2-B58			+24V / OPEN	

ANALOGUE OUTPUT [H]

No.	Name	Status	Signal level	Judgement
MC2-H01				
MC2-H02				

PROPORTIONAL VALVE OUTPUT [D]

No.	Name	Output current	Dither	Judgement
MC2-D01	Boom drum raise prop. valve	200 to 625 mA	200 mAp-p 100 Hz	
MC2-D02	Boom drum lower prop. valve	200 to 625 mA	200 mAp-p 100 Hz	
MC2-D03	Fr. drum hoist prop. valve	150 to 620 mA	200 mAp-p 100 Hz	
MC2-D04	Fr. drum lower prop. valve	150 to 620 mA	200 mAp-p 100 Hz	
MC2-D05	Re. drum hoist prop. valve	150 to 620 mA	200 mAp-p 100 Hz	
MC2-D06	Re. drum lower prop. valve	150 to 620 mA	200 mAp-p 100 Hz	
MC2-D07	Third drum hoist prop. valve (option)	150 to 620 mA	200 mAp-p 100 Hz	When output command value is ≥
MC2-D08	Third drum lower prop. valve (option)	150 to 620 mA	200 mAp-p 100 Hz	100 mA and feedback current is ≤
MC2-D09	Motor CHP pressure control prop. valve	100 to 400 mA	200 mAp-p 100 Hz	50 mA.
MC2-D10	Fr. drum motor tilt control prop. valve	200 to 750 mA	200 mAp-p 100 Hz	
MC2-D11	Re. drum motor tilt control prop. valve	200 to 750 mA	200 mAp-p 100 Hz	
MC2-D12	Third drum motor tilt control prop. valve (option)	200 to 750 mA	200 mAp-p 100 Hz	

No.	Name	Output current	Dither	Judgement
MC2-C01			GND / OPEN	
MC2-C02			GND / OPEN	
MC2-C03			GND / OPEN	
MC2-C04			GND / OPEN	
MC2-C05			GND / OPEN	
MC2-C06			GND / OPEN	
MC2-C07			GND / OPEN (300 mA)	
MC2-C08			GND / OPEN (300 mA)	
MC2-C09			GND / OPEN (300 mA)	
MC2-C10			GND / OPEN	
MC2-C11			GND / OPEN	
MC2-C12			GND / OPEN	
MC2-C13			GND / OPEN (PWM)	
MC2-C14			GND / OPEN (PWM)	
MC2-C15	Fr. drum motor boost SOL	Boost / Normal	+24V / OPEN	Mismatch between output command and actual port condition.
MC2-C16	Oil cooler electric motor	ON / OFF	GND / OPEN	Judge detect either following condition. 1. Mismatch between output command and actual port condition. 2. Mismatch between output command and MC2-B40 condition.
MC2-C17	Confluence / independence select SOL (Fr. drum)	Confluence / independence	GND / OPEN	Judge detect either following condition. 1. Mismatch between output command and actual port condition. 2. Mismatch between output command and MC2-B38 condition.
MC2-C18	Confluence/independence select SOL (Re. drum)	Confluence / independence	GND / OPEN	Judge detect either following condition. 1. Mismatch between output command and actual port condition. 2. Mismatch between output command and MC2-B39 condition.

No.	Name	Output current	Dither	Judgement
MC2-C19	DPF load SOL	Load ON / OFF	GND / OPEN	Judge detect either following condition. 1. Mismatch between output command and actual port condition. 2. Mismatch between output command and MC2-B45 condition.
MC2-C20			GND / OPEN	
MC2-C21	Re. drum motor boost SOL	Boost / Normal	+24V / OPEN	Mismatch between output command and actual port condition.
MC2-C22	Third drum motor boost SOL (option)	Boost / Normal	+24V / OPEN	Mismatch between output command and actual port condition.
MC2-C23			GND / OPEN	
MC2-C24			GND / OPEN	
MC2-C25			GND / OPEN (PWM)	
MC2-C26	Fr. drum control signal		GND / OPEN	Mismatch between output command and actual port condition.
MC2-C27	Re. drum control signal		GND / OPEN	Mismatch between output command and actual port condition.
MC2-C28	Third control signal		GND / OPEN	Mismatch between output command and actual port condition.
MC2-C29	Fr. drum C/V-SOL	Energized / De-energized	+24V / OPEN	Mismatch between output command and actual port condition.
MC2-C30	Re. drum C/V-SOL	Energized / De-energized	+24V / OPEN	Mismatch between output command and actual port condition.
MC2-C31			GND / OPEN	
MC2-C32			GND / OPEN	
MC2-C33			GND / OPEN	
MC2-C34			GND / OPEN	
MC2-C35			GND / OPEN (CPU error)	
MC2-C36	Third C / V-SOL (option)	Energized / De-energized	+24V / OPEN	Mismatch between output command and actual port condition.

10.3.6 ARRANGEMENT OF MAIN CONTROLLER CONNECTOR PIN

1. Arrangement of MC1 connector pin

Connector No.	Pin No.	Port name	Function	Specifications	Ref.
CN101	1	+5VA	A1	Spare	
	2	GD2		Spare	
	3	TXD2		Spare	
	4	RXD2		Spare	
	5	CANH1		CAN1_H	
	6	CANL1		CAN1_L	
	7	CAN1 termination		Spare	
	8	CAN1 termination		Spare	
	9	CANH2		CAN2_H	
	10	CANL2		CAN2_L	
	11	A1		Spare	
	12	RTS		Spare	
	13	CTS		Spare	
	14	SHG2		Spare	
	15	CAN2 termination		Spare	
	16	CAN2 termination		Spare	
	17	A2	Resistance input	Spare	
	18	GA	A1	Spare	
	19	TXD1		Spare	
	20	RXD1		Spare	
	21	GD1		Spare	
	22	SHG1		Spare	
	23	TXD3			
	24	RXD3		Program DL serial	
	25	DL		Program DE Senai	
	26	GD3			
	27	GA	A2	Spare	
	28	E1+	Engine turn sensor	Spare	
	29	E1-		Spare	
	30	SHG3		Spare	
	31	H1+		Accel. indicator voltage 1+	
	32	H1-		Accel. indicator voltage 1-	
	33	H2+		Accel. indicator voltage 2+	
	34	H2-		Accel. indicator voltage 2—	

Connector No.	Pin No.	Port name	Function	Specifications	Ref.
CN102	1	+5VA	A3		
	2	А3		Fr. drum motor speed adjusting trimmer	
	3	GA	А3		
	4	+5VA	A4		
	5	A4		Re. drum motor speed adjusting trimmer	
	6	GA	A4		
7	7	+5VA	A5		
	8	A5		Third drum motor speed adjusting trimmer	
	9	GA	A5		
	10	+5VA	A6		
	11	A6		Boom drum motor speed adjusting trimmer	
	12	GA	A6		
	13	A7	Resistance input	Spare	
	14	GA	A7	Spare	
	15	+5VA	A8		
	16	A8		Grip throttle	
	17	GA	A8		
	18	+5VA	A9		
	19	A9		Foot throttle (option)	
	20	GA	A9		
	21	A10	Resistance input	Hydraulic oil temperature sensor	
	22	GA	A10	Hydraulic oil temperature sensor	

Connector No.	Pin No.	Port name	Function	Specifications	Remarks
CN103	1	+5A	A11		
	2	A11		Tagline trimmer (option)	
	3	GA	A11]	
	4	+5A	A12		
	5	A12		Control primary pressure	
	6	GA	A12]	
	7	+5A	A13	Swing pump pressure sensor	
	8	A13			
	9	GA	A13		
	10	+5A	A14	Outro and the Latin Latin Latin	
	11	A14		Swing control (right) pressure sensor	
	12	GA	A22	GND for third clutch pressure sensor (option)	
	13	+5A	A15		
	14	A15		Swing control (left) pressure sensor	
	15	GA	A15		
	16	GA	A14	GND for swing control (right) pressure sensor	

Connector No.	Pin No.	Port name	Function	Specifications	Remarks
CN104	1	B1	Grounded input (15 KΩ)	ECU signal	
	2	+5A	A16		
	3	A16		Qmax cut solenoid detection pressure	
	4	GA	A16		
	5	+5A	A17		
	6	A17		Power shift pressure sensor	
	7	GA	A17		
	8	+5A	A18	+5V for supply voltage monitoring	
	9	B2	Grounded input (15 KΩ)	Engine oil. pressure PSW	
	10	+5A	A19	+5V for Inclination sensor X	
	11	+5A	A20	+5 V for Inclination sensor Y	
	12	A18		Cumulu valta aa manitarina	
	13	GA	A18	Supply voltage monitoring	
	14	В3	Grounded input (15 KΩ)	CB/W detect	
	15	A19		Inclination sensor X	
	16	A20		Inclination concerv	
	17	GA	A20	Inclination sensor Y	
	18	'+5A	A21		
	19	A21		Fr. drum clutch pressure sensor	
	20	GA	A21		
	21	'+5A	A22	+5V for third drum clutch pressure sensor (option)	
	22	B4	Grounded input (15 $K\Omega$)	Clogging of air cleaner	
	23	B5	Grounded input (3.3 K Ω)	Spare	
	24	GA	A19	GND for Inclination sensor X	
	25	'+5A	A23		
	26	A23		Re. drum clutch pressure sensor	
	27	GA	A23		
	28	A22		Third drum clutch pressure sensor (option)	

Connector No.	Pin No.	Port name	Function	Specifications	Remarks
CN105	1	+24 V 1	Battery (+)	Power supply	
	2	+24 V		Power supply	
	3	+24 V		Power supply	
	4	В6	Grounded input (3.3 KΩ)	Fr. drum brake cooling oil temperature	
	5	В7	Grounded input (3.3 KΩ)	Re. drum brake cooling oil temperature	
	6	В8	Grounded input (3.3 KΩ)	Radiator water level	
	7	В9	Grounded input (3.3 KΩ)	Engine oil filter	+
ľ	8	GND	Battery (-)	GND	
	9	GND		GND	
ľ	10	D10+		Tagline tension prop. valve +	
	11	D1+		Main pump horse power control	
ľ	12	D1-		prop. valve	
	13	D2+		Boom pump horse power control)
	14	D2-		prop. valve	
	15	D3+		Swing low speed prop. valve	
	16	D3-			
	17	D4+			
	18	D4-		Swing counterforce prop. valve	
	19	D5+			
	20	D5-		Boom pump tilt control prop. valve	
	21	GND	Battery (-)	GND	
	22	D10-		Tagline tension prop. valve -	
	23	B10	Grounded input (3.3 KΩ)	Fr. drum control signal	
ľ	24	B11	Grounded input (3.3 KΩ)	Re. drum control signal	
	25	B12	Grounded input (3.3 KΩ)	Third drum control signal	
	26	B13	+24 V input	Fr. drum free fall select. signal	
	27	B14	+24 V input	Re. drum free fall select. signal	
	28	B15	+24 V input	Third drum free fall select. signal	
			Grounded input (3.3 KΩ)		
	29	B16	(and pulse input)	Fr. drum rotate sensor	
			Grounded input (3.3 KΩ)		
	30	30 B17	(and pulse input)	Re. drum rotate sensor	
	31	+24 V	For backup power supply RTC		

Connector No.	Pin No.	Port name	Function	Specifications	Remarks
CN106	1	+24 V 1	Battery (+)		
	2	D6+		Fr. drum middle detent	
	3	D6-		Fr. arum middie detent	
	4	D7+		Re. drum middle detent	
	5	D7-		Ne. dram middle detent	
	6	D11+		Left swing stop proportional valve	
	7	D11-		Left swiling stop proportional valve	
	8	D8+		Main pump tilt control prop. valve 1	
	9	D8-		Main pump tilt control prop. valve 1	
	10	D9+		Main pump tilt control prop. valve 2	
	11	D9-			
	12	B18	+24 V input	Key SW ON signal	
	13	B19	+24 V input	Function lock	
	14	B20	+24 V input	Charge signal	
	15	D12+		Right swing stop proportional valve	
	16	D12-		Trigitt swillig stop proportional valve	
	17	GND	Battery (-)	Spare	
	18	B21	+24 V input	Inching selection	
	19	B22	+24 V input	Aux. accel. signal	
	20	B23	+24 V input	Engine emg. stop signal	
	21	B24	+24 V input	Engine restart	
	22	B25	+24 V input	Operator certificate wait signal	
	23	B26	+24 V input	Swing parking switch	
	24	B27	+24 V input	Drum rotate detecting grip selection	

Connector No.	Pin No.	Port name	Function	Specifications	Remarks
CN107	1	B28	D/O FB	Controller ID 1	
	2	B29	D/O FB	Controller ID 2	
	3	B30	+24 V input	G mode/Normal selection	
	4	B31	+24 V input	G winch (Fr.)	
	5	B32	+24 V input	G winch (Re.)	
	6	B33	+24 V input	G winch (main)	
	7	B34	D/O FB	AIS function ON/OFF SW	
	8	B35	+24 V input	Travel control pressure switch	
	9	B36	Grounded input (3.3 KΩ)	Spare	
			(and pulse input)	Spare	
	10	B37	Grounded input (3.3 K Ω)	Cooling line filter	
			(and pulse input)	Cooling line line	
	11	B38	+24 V input	Engine preheat	>
	12	B39	+24 V input	Spare	
	13	B40	D/O FB	Backup fuse	
	14	B41	+24 V input	Fr. drum free fall speed increase SW	
	15	B42	+24 V input	Re. drum free fall speed increase SW	
	16	B43	+24 V input	Third drum free fall speed increase SW (option)	
	17	B44	+24 V input	Free fall permit signal	

Connector No.	Pin No.	Port name	Function	Specifications	Remarks
CN108	1	C1	Grounded output	Fr. drum motor CLM-SOL	
	2	C2	Grounded output	Fr. drum motor ESM-SOL	
	3	C3	Grounded output	Re. drum motor CLA-SOL	
	4	C4	Grounded output	Re. drum motor ESA-SOL	
	5	C5	Grounded output	Third drum motor CLT-SOL	
	6	B45	D/O FB	Fr. drum motor CLM-SOL (FB)	
	7	B46	D/O FB	Fr. drum motor ESM-SOL (FB)	
	8	B47	D/O FB	Re. drum motor CLA-SOL (FB)	
	9	B48	D/O FB	Re. drum motor ESA-SOL (FB)	
	10	C6	Grounded output	Third drum motor EST-SOL	
	11	C7	Grounded output	Spare	
	12	C8	Grounded output	Swing parking control	
	13	C9	Grounded output	ML adjust. mode selection	
	14	C10	Grounded output	Hyd. oil heat SOL	
	15	B49	D/O FB	Third motor CLT-SOL (FB)	
	16	B50	D/O FB	Third motor EST-SOL (FB)	
	17	B51	D/O FB	Hyd. oil heat LS(option)	
	18	B52	D/O FB	Pump Qmax cut solenoid (FB)	
	19	B53	D/O FB	Remote control connection signal	
	20	C11	Grounded output	Pump Qmax cut solenoid	
	21	C12	Grounded output	Swing flasher	
	22	C13	PWM output	Spare	
	23	C14	PWM output	Spare	
	24	B54	D/O FB	Swing warning (flasher)	
	25	B55	D/O FB	Swing warning (Buzzer and flasher)	
	26	B56	D/O FB	DPF regeneration FB)	
	27	B57	D/O FB	Accel. signal (DOWN)	
	28	B58	D/O FB	Accel. signal (UP)	

Connector No.	Pin No.	Port name	Function	Specifications	Remarks
CN109	1	C15	+24 V output	Battery relay energizing	
	2	C16	Grounded output	ML bypass reset	
	3	C17	Grounded output	Solenoid cut relay energizing	
	4	C18	Grounded output	Engine warning output	
	5	C19	Grounded output	AIS air con. ON relay energizing	
	6	C20	Grounded output	Swing neutral brake selection	
	7	C21	+24 V output	Sub battery relay energizing	
	8	C22	+24 V output	Spare	
	9	C23	Grounded output	Spare	
	10	C24	Grounded output	Spare	
	11	C25	PWM output	Spare	
	12	C26	Grounded output	DPF regeneration start	
	13	C27	Grounded output	Engine restart	
	14	C28	Grounded output	Pilot pressure cut relay	
	15	C29	+24 V output	Fr. drum rotate detection grip (option)	
	16	C30	+24 V output	Re. drum rotate detection grip (option)	
	17	C31	Grounded output	Safety relay operation	
	18	C32	Grounded output	Engine stop relay operation	
	19	C33	Grounded output	Swing voice alarm	
	20	C34	Grounded output	Spare	
	21	C35	Grounded output	Spare	
	22	C36	+24 V output	Spare	

2. Arrangement of MC2 connector pin

Connector No.	Pin No.	Port name	Function	Specifications	Ref.
CN111	1	+5VA	A1	Vacancy	
	2	GD2		Vacancy	
	3	TXD2		Vacancy	
	4	RXD2		Vacancy	
	5	CANH1		CAN1_H	
	6	CANL1		CAN1_L	
	7	CAN1 termination		Vacancy	
	8	CAN1 termination		Vacancy	
	9	CANH2		CAN2_H	
	10	CANL2		CAN2_L	
	11	A1		Vacancy	
	12	RTS		Vacancy	
	13	CTS		Vacancy	
	14	SHG2		Vacancy	
	15	CAN2 termination		Vacancy	
	16	CAN2 termination		Vacancy	
	17	A2	Resistance input	Vacancy	
	18	GA	A1	Vacancy	
	19	TXD1		Vacancy	
	20	RXD1		Vacancy	
	21	GD1		Vacancy	
	22	SHG1		Vacancy	
	23	TXD3			
	24	RXD3		Program DL serial	
	25	DL		Program DL Senai	
	26	GD3			
	27	GA	A2	Vacancy	
	28	E1+	Engine rotate sensor	Vacancy	
	29	E1-		Vacancy	
	30	SHG3		Vacancy	
	31	H1+		Vacancy	
	32	H1-		Vacancy	
	33	H2+		Vacancy	
	34	H2-		Vacancy	

Connector No.	Pin No.	Port name	Function	Specifications	
CN112	1	+5VA	A3		
	2	А3		Fr. drum motor tilt control pressure sensor	
	3	GA	A3		
	4	+5VA	A4		
	5	A4		Re. drum motor tilt control pressure sensor	
	6	GA	A4		
	7	+5VA	A5		
	8	A5		Third drum motor tilt control pressure sensor	
	9	GA	A5		
	10	+5VA	A6		
	11	A6		A/D spare	
	12	GA	A6		
	13	A7	Resistance input	Fuel level	
	14	GA	A7	- ruel level	
	15	+5VA	A8		
	16	A8		Confluence/Independence selection pressure (Fr. drum)	
	17	GA	A8		
	18	+5VA	A9		
	19	A9		Confluence/Independence selection pressure (Re. drum)	
	20	GA	A9		
	21	A10	Resistance input	A/D spare	
	22	GA	A10	AVD Spale	

Connector No.	Pin No.	Port name	Function	Specifications
CN113	1	+5A	A11	
	2	A11		Fr./Re. drum CHP start pressure sensor
	2	GA	A11	
	4	+5A	A12	
	5	A12		A/D spare
	6	GA	A12	
	7	+5A	A13	
	8	A13		A/D spare
	9	GA	A13	
	10	+5A	A14	A/D spare
	11	A14		A/D Spare
	12	GA	A22	Third drum raise pressure sensor
	13	+5A	A15	
	14	A15		A/D spare
	15	GA	A15	
	16	GA	A14	A/D spare

Connector No.	Pin No.	Port name	Function	Specifications
CN114	1	B1	Grounded input (15 KΩ)	C/W detect 3
	2	+5A	A16	
	3	A16		Boom drum raise pressure sensor
	4	GA	A16	
	5	+5A	A17	
	6	A17		Boom drum lower pressure sensor
	7	GA	A17	
	8	+5A	A18	Fr. drum hoist pressure sensor
	9	B2	Grounded input (15 KΩ)	C/W detect 4
	10	+5A	A19	Fr. drum lower pressure sensor
	11	+5A	A20	Re. drum hoist pressure sensor
	12	A18		Fr. drum hoist pressure sensor
	13	GA	A18	11. druit hoist pressure sensor
	14	В3	Grounded input (15 KΩ)	C/W detect 5 (C4, C5)
	15	A19		Fr. drum lower pressure sensor
	16	A20		Re. drum hoist pressure sensor
	17	GA	A20	ixe. druin floist pressure sensor
	18	'+5A	A21	
	19	A21		Re. drum lower pressure sensor
	20	GA	A21	
	21	'+5A	A22	Third drum hoist pressure sensor
	22	B4	Grounded input (15 $K\Omega$)	C/W detect 6 (C5)
	23	B5	Grounded input (3.3 K Ω)	C/W detect 7 (C5)
	24	GA	A19	Fr. drum lower pressure sensor
	25	'+5A	A23	
	26	A23		Third drum lower pressure sensor
	27	GA	A23	
	28	A22		Third drum hoist pressure sensor

Connector No.	Pin No.	Port name	Function	Specifications	
CN115	1	+24 V 1	Battery (+)	Power supply	
	2	+24 V		Power supply	
	3	+24 V		Power supply	
	4	В6	Grounded input (3.3 KΩ)	Fr. drum brake cooling oil temperature	
	5	В7	Grounded input (3.3 KΩ)	Re. drum brake cooling oil temperature	
	6	В8	Grounded input (3.3 KΩ)	Radiator water level	
	7	В9	Grounded input (3.3 KΩ)	Engine oil filter	
	8	GND	Battery (-)	GND	
	9	GND		GND	
	10	D10+		Fr. drum motor tilt control prop. valve +	
	11	D1+		Boom drum raise proportional valve	
	12	D1-		Boom drain raise proportional valve	
	13	D2+		Boom drum lower proportional valve	
	14	D2-		Boom aram lower proportional valve	
	15	D3+		Fr. drum hoist proportional valve	
	16	D3-		11. dram moist proportional valvo	
	17	D4+		Fr. drum lower proportional valve	
	18	D4-		11. drum lower proportional valve	
	19	D5+		Re. drum hoist proportional valve	
	20	D5-		rte. dram noist proportional valve	
	21	GND	Battery (-)	GND	
	22	D10-		Fr. drum motor tilt control prop. valve -	
	23	B10	Grounded input (3.3 KΩ)	Spare	
	24	B11	Grounded input (3.3 KΩ)	Spare	
	25	B12	Grounded input (3.3 KΩ)	Spare	
	26	B13	+24 V input	Crane boom overhoist signal	
	27	B14	+24 V input	Boom B/S No.1 signal	
	28	B15	+24 V input	Boom B/S No.2 signal	
	29	B16	Grounded input (3.3 KΩ)	Spare	
	25	V В10	(and pulse input)	Spare	
	30	B17	Grounded input (3.3 KΩ)	Spare	
	30	DII	(and pulse input)	эраге	
	31	+24 V	For backup power supply RTC	Power supply	

Connector No.	Pin No.	Port name	Function	Specifications	Remarks
CN116	1	+24 V 1	Battery (+)	Power supply	
	2	D6+		Re. drum lower proportional valve	
	3	D6-		Re. drum lower proportional valve	
	4	D7+		Third drum hoist proportional valve	
	5	D7-		(option)	
	6	D11+		Re. drum motor tilt control prop. valve	
	7	D11-		Re. druin motor tilt control prop. valve	
	8	D8+		Third drum lower prop. valve (option)	
	9	D8-		Third druit lower prop. valve (option)	
	10	D9+		Motor CHP pressure control prop.	
	11	D9-		valve	
	12	B18	+24 V input	Spare	
	13	B19	+24 V input	Function lock	
	14	B20	+24 V input	Charge signal	
	15	D12+		Third drum motor tilt control prop.	
	16	D12-		valve (option)	
	17	GND	Battery (-)	Spare	
	18	B21	+24 V input	Inching selection	
	19	B22	+24 V input	Spare	
	20	B23	+24 V input	Spare	
	21	B24	+24 V input	Crane hook overhoist signal	
	22	B25	+24 V input	Jib hook overhoist signal	
	23	B26	+24 V input	Hook overhoist release signal	
	24	B27	+24 V input	Boom overhoist release signal	

Connector No.	Pin No.	Port name	Function	Specifications	Remarks	
CN117	1	B28	D/O FB	Controller ID 1		
	2	B29	D/O FB	Controller ID 2		
	3	B30	+24 V input	Fr. drum hoist stop		
	4	B31	+24 V input	Fr. drum lower stop		
	5	B32	+24 V input	Re. drum (tower jib) hoist stop		
	6	B33	+24 V input	Re. drum (tower jib) lower stop		
	7	B34	D/O FB	Spare		
	8	B35	+24 V input	Jib overhoist signal		
	9	9 B36	Grounded input (3.3 KΩ)	C/W detect 1		
	9	9 0	В30	(and pulse input)	C/W detect 1	
	10 B37	Grounded input (3.3 KΩ)	C/W detect 2			
	10	B37	(and pulse input)	O/W detect 2		
	11	B38	+24 V input	Confluence/Independence selection solenoid (Fr.)		
	12	B39	+24 V input	Confluence/Independence selection solenoid (Re.)		
	13	B40	D/O FB	Oil cooler motor relay		
	14	B41	+24 V input	Third drum hoist stop		
	15	B42	+24 V input	Third drum lower stop		
	16	B43	+24 V input	Boom drum raise stop		
	17	B44	+24 V input	Boom drum lower stop		

Connector No.	Pin No.	Port name	Function	Specifications	Remarks
CN118	1	C1	Grounded output	Spare	
	2	C2	Grounded output	Spare	
	3	C3	Grounded output	Spare	
	4	C4	Grounded output	Spare	
	5	C5	Grounded output	Spare	
	6	B45	D/O FB	DPF load solenoid	
	7	B46	D/O FB	Spare	
	8	B47	D/O FB	Spare	
	9	B48	D/O FB	Spare	
	10	C6	Grounded output	Spare	
	11	C7	Grounded output	Spare	
	12	C8	Grounded output	Spare	
	13	C9	Grounded output	Spare	
	14	C10	Grounded output	Spare	
	15	B49	D/O FB	Spare	
	16	B50	D/O FB	Spare	
	17	B51	D/O FB	Spare	
	18	B52	D/O FB	Spare	
	19	B53	D/O FB	ML bypass (CR)	
	20	C11	Grounded output	Spare	
	21	C12	Grounded output	Spare	
	22	C13	PWM output	Spare	
	23	C14	PWM output	Spare	
	24	B54	D/O FB	ML bypass (JIB)	
	25	B55	D/O FB	Spare	
	26	B56	D/O FB	Spare	
	27	B57	D/O FB	Spare	
	28	B58	D/O FB	Spare	

Connector No.	Pin No.	Port name	Function	Specifications	Remarks
CN119	1	C15	+24 V output	Fr. drum motor boost SOL	
	2	C16	Grounded output	Oil cooler electric motor	
	3	C17	Grounded output	Confluence/Independence selection solenoid (Fr. drum)	
	4	C18	Grounded output	Confluence/Independence selection solenoid (Re. drum)	
	5	C19	Grounded output	DPF load solenoid	
	6	C20	Grounded output	Spare	
	7	C21	+24 V output	Re. drum motor boost SOL	
	8	C22	+24 V output	Third motor boost SOL (option)	
	9	C23	Grounded output	Spare	
	10	C24	Grounded output	Spare	
	11	C25	PWM output	Spare	
	12	C26	Grounded output	Fr. drum control signal	
	13	C27	Grounded output	Re. drum control signal	
	14	C28	Grounded output	Third drum control signal	
	15	C29	+24 V output	Fr. drum C/V-SOL	
	16	C30	+24 V output	Re. drum C/V-SOL	
	17	C31	Grounded output	Spare	
	18	C32	Grounded output	Spare	
	19	C33	Grounded output	Spare	
	20	C34	Grounded output	Spare	
	21	C35	Grounded output	Spare	
	22	C36	+24 V output	Third C/V-SOL (option)	

10.3.7 ADJUSTMENT OF MAIN CONTROLLER


1. Model number setting

Perform this setting only when controller is replaced.

If model setting is not properly done, machine does not work properly.

Take extra care.

2. Press the icon in the main screen.



3. Press 🗶 switch.




- 4. Input the password (8 digits) with the keyboard.
- * In case of using capital letter, press switch.


CLR	All clear
DEL	One letter clear
BS	One letter clear and back




5. Press ® switch.




6. Press "ML ADJUSTMENT (TEMPORARY)"



7. Press "ML ADJUSTMENT (TEMPORARY)"



- (1) Select the displayed model group.
- (2) Press ® after model group is selected.
 - * Unless ® is pressed, selection becomes ineffective.



8. Option setting

- (1) Turn the engine key "ON".
- (2) Select the screen as follows. Main screen : \longrightarrow \longrightarrow "Password input" \rightarrow "MC adjustment" \rightarrow "Option setting"
- (3) Select "O (YES)" or "X (NO)" on each function setting.
 - Use icon for page change.
- (4) After setting is completed, press (8) and after page is changed, press (SET) to record.
- * Unless I is pressed, selection becomes ineffective.



- 9. Adjustment of grip throttle and foot throttle.
- (1) Turn the engine key "ON".
- (2) Select the screen as follows.

Main screen : \longrightarrow \longrightarrow "Password input" \rightarrow "MC adjustment" \rightarrow "Grip adjustment"

(3) The screen changes to adjustment screen. Press adjustment start button .

- (4) Throttle low adjustment. Set the grip throttle and foot throttle to low idle position and in case of the joy-stick (8500E-1) to the neutral position.
- (5) If OK, press button .
- (6) Throttle high adjustment. Set the grip throttle and foot throttle to high idle position and in case of the joy-stick (8500E-1) to the idle-up position.
- (7) If OK, press button .
- (8) If adjustment completion becomes displayed, press (and press I after screen has been changed to record.
- * Unless ET is pressed, selection becomes ineffective.

10. Engine speed adjustment

Warm up the engine sufficiently before adjustment.

- (1) Turn the engine key "ON".
- (2) Select the screen as follows.

Main screen : \bigcirc \longrightarrow \bigcirc \longrightarrow "Password input" \longrightarrow "MC adjustment" \longrightarrow "Engine speed adjustment"

- (4) Engine speed is raised to high idle once and then gradually lowered to low idle.
- (5) If adjustment completion becomes displayed, press (and press III) after screen has been changed to record.
- * Unless **SET** is pressed, selection becomes ineffective.
- If adjustment becomes NG,

NG 1:


Engine speed is abnormal.

Check if engine error is output.

NG 2:

Transmission is error.

Check if warning of CAN transmission abnormal is output.





11. Adjusting of inclination meter

Place the main machinery on the horizontal ground before adjustment using the level gauge etc.

- (1) Turn the engine key "ON".
- (2) Select the screen as follows.

Main screen : $\[mu] \to \[mu] \to$ "Password input" \to "MC adjustment" \to "Inclination meter adjustment"

- (3) The screen changes to adjustment screen. Press adjustment start button [SET] if OK.
- (4) If adjustment completion becomes displayed, press (and press I after screen has been changed to record.
- * Unless [SET] is pressed, selection becomes ineffective.

12. Supply pump adjustment


This adjustment is not normally used. Perform this adjustment only when engine supply pump is replaced.


If this is used other than supply pump replacement, it would affect the engine performance.

Take extra care.

- (1) After replacement of supply pump, start the engine and select the screen as follows.
 - Main screen : \longrightarrow \longrightarrow "Password input" \rightarrow "MC adjustment" \rightarrow "Pump learning function"
- (2) Engine speed stays in low idle. Press .
- (3) Progress becomes displayed.

100% is reached after 5 minutes.





10.3.8 CONTROLLER MALFUNCTION EMERGENCY MEASURES

When the controller is malfunctioned, as an emergency measure, set the BYPASS switch for the main controller in the left side stand to the "bypass" position.


The crane operation becomes possible.

Automatic stop is actuated by the load safety device even when the BYPASS switch is actuated.

The variable speed function with the drum speed control knob is unavailable during the crane operation using the BYPASS switch.

Malfunction of the proportional valves (D5, D8, D9, D11, D12 in MC1 and D1 to D8 in MC2) will be displayed in the monitor display.

(excluding the case when H-1 is displayed)





11. AIR CONDITIONER


11.1	NAME OF THE AIR CONDITIONER PARTS	11-1
11.2	ELECTRIC WIRING DIAGRAM	11-7
11.3	PARTS ILLUSTRATION	11-8
11.4	DISASSEMBLY AND ASSEMBLY OF THE UNIT	11-10
11.4.1	REMOVAL OF THE BLOWER UNIT	11-10
11.4.2	REPLACING THE BLOWER MOTOR	
11.4.3	REPLACING THE BLOWER CONTROLLER	
11.4.4	REMOVAL OF THE HEATER CORE	11-11
11.4.5	REMOVAL OF THE AIR CON. UNIT CASE-FRONT, REAR AND LOWER	11-12
11.4.6	REPLACING THE EVAPORATOR AND EXPANSION VALVE	
11.4.7		
11.4.8	REPLACING THE MOTOR ACTUATOR	11-14
11.5	FAULT DETECTION FROM THE CONTROL PANEL INDICATION	
11.5.1	GENERAL	11-15
11.5.2		
	ACTUATOR	11-15
11.5.3		
11.6	BASIC SYSTEM OF HVAC	
11.7	RECHARGING OF THE COOLANT	
11.7.1		
11.7.2		
11.7.3		
11.8	TROUBLESHOOTING	11-32




11. AIR CONDITIONER

11.1 NAME OF THE AIR CONDITIONER PARTS

NAME OF THE AIR CONDITIONER PARTS



NAME OF THE CONTROL PANEL



Published 12-16-15, Control #244-01 11-1 8500E-1

FUNCTION OF EACH CONTROL

1. LCD DISPLAY PANEL

Air volume setting etc. are displayed.

(c)

2. POWER SWITCH (ON/OFF SWITCH)

It turns ON or OFF the air conditioner. When this switch is pushed at the first time, the air conditioner starts on factory set mode. When this switch is pushed, air conditioner starts with previous set mode.



3. AIR CONDITIONER SWITCH (A/C SWITCH)

Every time when this switch is pushed, the air compressor alternates ON/OFF. When the air conditioner is ON, \$\times\$ lights up on the LCD display (a).

4. AIR VOLUME SELECTOR SWITCH (FAN SWITCH)


Air volume can be changed by pushing this switch when air conditioner is running.

⊘	Increase air volume.
⊗	Decrease air volume.

Set air volume is displayed on the LCD display (b).

LCD display		1	7	7
Air volume	Low	Medium	High	Max. high





5. TEMPERATURE CONTROL SWITCH (AIR CONDITIONER TEMP. SET)




Pushing this switch changes temperature setting when the air conditioner is running.

⊘	Rises temperature (blowing air temp.)
⊗	Lowers temperature (blowing air temp.)

Set temperature imi is displayed on LCD display (c).

6. IN-EXT. AIR SELECTOR SWITCH (R/F SWITCH)



	Internal air circulation
<u> </u>	External air take in

Setting is displayed on LCD display (d).

7. AIR VENT SELECTOR SWITCH (MODE SWITCH)

Every time when this switch is pushed, blow out opening changes on in sequence.



DEF

LCD display	نهد	۲۰۰۰	***	ب قم
Blow out opening	Face	Vent	Bi level	Foot
Blow out direction	Front	Front/Upper rear	Front/Upper rear and foot	Foot*

* Air blows from defroster also.

Setting is displayed on LCD display (e).


8. DEFROSTER SWITCH (DEF SWITCH)

Every time when this switch is pushed, blow out opening changes to defroster.

Blow out opening	Defroster
Blow out direction	Front windscreen*

^{*} Air blows from foot too.

(f).



AIR CONDITIONER CONTROL


1. To start or stop air conditioner


Push @ (Power switch).

2. To cool

- (1) Push (Air conditioner switch).
- (2) Push ⊙ (Temperature control switch) to indicate in temperature display.
- (3) Push the air volume selector switch for required air volume setting.
- (4) Push (Air vent selector switch) for (Vent) position.(The above is recommended position and can be chosen as desired.)
- (5) By pushing @RFF (In-ext. air selector switch), set the selector to (Internal air circulation). (The above is recommended position and can be chosen as desired.)

 If the A/C cools down too low, adjust the temp. or air volume by (2), (3).
- (Air conditioner switch) is not pushed, the A/C does not cool but only air flows.
- While defrosting the windows, do not set the temperature too low.
- · Cold air may make windows foggy from outside






3. To warm

- (1) Push (Air conditioner switch).
- (2) Push ⊙™ (Temperature control switch) to indicate temperature display.
- (3) Push the air volume selector switch for required air volume setting.
- (4) Push MODE (Air vent selector switch) for position. (Foot
 - (The above is recommended position and can be chosen as desired.)
- (5) By pushing @R/F (In-ext. air selector switch), set the selector to ② (Internal air circulation). (The above is recommended position and can be chosen as desired.)

 If the A/C warms up too high, adjust the temp. or air volume by (2), (3).
 - If (②A/C) (Air conditioner switch) is pushed, the A/C operates on dry air warming.
- If blow out opening is set to "Foot", small amount for air bows from defroster also.







4. To defrost on the windows

- (1) Push ((Air conditioner switch).
- (2) Push ⊙™ (Temperature control switch) to indicate initial temperature display.
- (3) Push the air volume selector switch for "Max, high" air volume.
- (4) Push [DEF®] (Defroster switch) to change the blow out opening to (TH) (Defroster) position.
- (5) By pushing @R/F (In-ext. air selector switch), set the selector to [1] (Internal air circulation).
 - By pushing MODE (Air vent selector switch) blow out opening return to previous one before (Defroster switch) is pushed.
- When blow out opening is set to "Defroster", small amount of air comes out from foot also.


5. To defog on the windows

- (1) Push (Air conditioner switch).
- (2) Push the air volume selector switch for required air volume setting.
- (3) Push [Defroster switch] to change the blow out opening to (the Defroster) position.
- (4) By pushing @R/F (In-ext. air selector switch), set the selector to (1) (External air take in).
- If quick defogging is required, set the air volume to "Max, high" by (2).
- By pushing [MODE OF (Air vent selector switch) blow out opening return to previous one before [DEF GOD OF (Defroster switch) is pushed.
- When blow out opening is set to "Defroster", small amount of air comes out from foot also.






11.2 ELECTRIC WIRING DIAGRAM



11.3 PARTS ILLUSTRATION



8500-1 / 8500E-1 11-8 Published 12-16-15, Control #244-01

- 3. Heater core assy
- 5. Lower unit case
- 6. Out air intake packing
- 7. Expansion cover
- 9. Expansion valve
- 10. Thermistor
- 11. Unit harness assy
- 12. Lever (MAL1)
- 13. AM rod
- 14. Mode rod
- 15. Lever (MO2)
- 16. Relay
- 17. Evaporator
- 18. Hex. Socket head screw
- 20. Tapping screw
- 21. Cord clamp C
- 22. Rod holder
- 23. Sensor holder
- 24. Cord clamp A
- 25. Duct VE packing


- 26. Duct DE packing
- 27. Duct FO packing
- 28. Pipe clamp
- 29. Plate
- 30. Lever (AM)
- 31. Lever (CM)
- 32. Lever (MO1)
- 33. Mode cam
- 34. Rod AC
- 35. Tapping screw
- 37. Screw
- 101. Upper blower case
- 102. Lower blower case
- 103. Tapping screw
- 104. Fan driver
- 105. Tapping screw
- 106. Unit bracket
- 107. Unit cooling hose
- 108. Blower motor (24V)
- 109. Tapping screw

- 110. Tapping screw
- 201. Intake case (right)
- 202. Intake case (left)
- 204. Damper (IN) assy
- 205. Actuator
- 206. Lever (MAL2)
- 207. Lever (IN)
- 208. Tapping screw
- 209. Internal air filter.
- 401. Rear unit case
- 402. Front unit case
- 403. Damper AM assy
- 404. Damper CM assy
- 405. Damper VE assy
- 406. Damper FA assy
- 407. Damper DE assy
- 408. Damper FO assy
- 409. Tapping screw
- 410. Evaporator F packing


11.4 DISASSEMBLY AND ASSEMBLY OF THE UNIT

11.4.1 REMOVAL OF THE BLOWER UNIT

 Remove the various connectors attached to the in-out air motor actuator, blower motor, blower controller, evaporator sensor and harnesses attached to the blower case.




- Pull out the in air filter from the intake case.
 Remove four of the cross head screw (Phillips)
 T4 × 14 (T1) from the intake case and remove the intake duct.
- 3. Remove four of the cross head screw (Phillips) T5 × 14 (T1) and the remove intake case.
- Remove three of the cross head screw (Phillips)
 T5 × 14 (T1) and separate the blower case and the air con. unit.




11.4.2 REPLACING THE BLOWER MOTOR

- 1. Remove the coolant hose coolant between the blower motor and the blower case.
- Remove three of the cross head screw (Phillips)
 N5 × 16 (W) which are tightened from under the blower unit case and pull the blower unit out.
- 3. Take the reverse way in the foregoing procedure for installation.
- * Do not remove the fan from the blower motor.



11.4.3 REPLACING THE BLOWER CONTROLLER

- Remove two of the cross head screw (Phillips)
 T4 × 14 (T1) which are tightened from under the blower case and pull the blower controller out.
- 2. Installation of the new blower controller is in the reverse way of the foregoing procedure.
- NEVER disassemble the blower controller.




11.4.4 REMOVAL OF THE HEATER CORE

- 1. Drain out the cooling water.
- Remove one of the cross head screw (Phillips)
 N5 × 16 (T2) and pipe clamp which secure the heater core to the unit.

Then pull out the heater core from the unit.


3. Installation is reverse way of the foregoing procedure.




11-11

11.4.5 REMOVAL OF THE AIR CON. UNIT CASE-FRONT, REAR AND LOWER

- 1. Remove the connectors for mode motor actuator and the evaporator sensor.
- Remove the mode rod from the rod holder which is installed on the lever MAL1 of the mode motor actuator.
- 3. Remove three screws N4 × 30 (T1) and remove the mode motor actuator installed on the unit case-lower and the unit case-rear.




- 4. Remove eleven of the cross head screw (Phillips) N5 × 16 (T2) and remove the unit case-lower and the unit case-front. Pull the unit case upward taking care of evaporator sensor cord not to catch the case.
- * In this case make sure that the heater core is removed from the unit case.



8500-1 / 8500E-1 11-12 Published 12-16-15, Control #244-01

11.4.6 REPLACING THE EVAPORATOR AND EXPANSION VALVE


- Pull out the evaporator assy from the caselower with the case insulation material and the expansion valve attached.
- After the evaporator assy is removed, then pull out the evaporator sensor and sensor holder as one piece.
- Remove the HEX. socket head screw M5 × 40 (two) and remove the expansion valve from the evaporator with the hex. wrench (4 mm [0.16 in.]).
- Install the O-ring (NFO ring 5/8 and 1/2, one each) to the new evaporator.
 (Tightening torque 6.9 N·m [5.09 ft·lbs])
- * Be careful not to make the O-ring jammed during the expansion valve installation.



11.4.7 INSTALLATION OF EVAPORATOR SENSOR

Install the evaporator sensor precisely to the original place of the evaporator as shown.

* During the installation work, take care not to make the sensor cord jammed with the case.



11.4.8 REPLACING THE MOTOR ACTUATOR

1. Replacing the mode motor actuator

Remove the connector of the motor actuator.

Remove the mode rod which connects the motor actuator and the mode cam from the rod holder.

Remove three of the cross head screw (Phillips) $N4 \times 30$ (T1) which hold the motor actuator and remove the motor actuator from the unit while the rod holder and lever MAL1 are attached to the motor actuator.

Remove the rod holder and the lever MAL1 from the motor actuator and install the new actuator in the reverse way of this procedure.



Remove the connector connected to the motor actuator.

Remove the AM rod which connect the motor actuator and the lever AM1 from the rod holder. Remove the three of the cross head screw (Phillips) N4 × 30 (T1) holding the motor actuator.

Remove the motor actuator from the unit while the rod holder and lever MAL1 are attached. Remove the rod holder and lever MAL1 from the motor actuator.

Install the new motor actuator to the unit in the reverse way of the foregoing procedure.

3. Replacing the in-out air motor actuator


Remove the connector connected to the motor actuator.


Remove three of the cross head screw (Phillips) N4 × 28 (T1) holding the motor actuator.


Remove the motor actuator from the unit while the lever MAL2 is attached.

Remove the lever MAL2 from the motor actuator.

Install the new motor actuator in the reverse way of the foregoing procedure.







11.5 FAULT DETECTION FROM THE CONTROL PANEL INDICATION

11.5.1 **GENERAL**

When there is any fault in each sensor input circuit of the controller or the motor actuator drive line, fault detection is indicated.

A CAUTION

Once the fault is detected, fault indication is not reset even the fault is recovers to normal condition. In case the fault recovers to normal, the fault indication can be reset by power off the base machine with engine key.

11.5.2 FAULT IN THE INPUT AND OUTPUT CIRCUIT OF THE MOTOR ACTUATOR

1. Open circuit detection

If there is an open circuit or short circuit in the motor actuator line, open circuit detection is indicated.

Open circuit detect indication

Fault location	Fault indication	
Air mix	HOT mark blinking	
(Temperature control)		

2. Motor lock detection

If the motor rotating angle does not reach the target, considered as LOCKED and motor output is ceased and motor lock detection is indicated.

Motor lock detect indication

Fault location	Fault indication
Air mix (Temperature control)	HOT mark blinking
In-out air motor actuator	In-out air mark blinking


11.5.3 FAULT IN THE THERMISTOR SENSOR CIRCUIT

1. Open or short circuit

Open circuit detect is indicated when there is an open or short circuit in the sensor line.

Open circuit detect indication

Fault location	Fault indication
Evaporator sensor	A/C mark blinking



11.6 BASIC SYSTEM OF HVAC

This is the built in type air con. unit with evaporator, heater core and blower as one package and generate cool and warm air.

1. Air cycle

Heater

The unit takes internal air of the cab or open air from the intake port and have them passed through the air filter and send them to the heater core of the air conditioner unit to exchange heat and send the warm air through the duct and blow out from the grill.

Cooler

The unit takes internal air of the cab or open air from the intake port and have it passed through the air filter and send them to the evaporator to exchange the heat (dehumidifying cool) and send the cooled air to the duct and blow out the air from the grill.

· Heater system

The heater unit circulates the engine cooling water. The warm water from the engine is sent to the heater core to exchange heat.

Air sucked in is warmed up and is blown out from the grill inside of the cab.

Temperature of the blow air can be adjusted by temperature adjusting switch.

This air movement is controlled by the air mix damper of the air conditioner unit.


2. Control panel and control unit

The control panel and the control unit is one package.

Micro computer inside of the unit handles the arithmetic processing of input signal from each sensor with the input signal of each switch in the control panel and totally controls the fan motor and compressor and each actuator in the output side of the actuator (in-out blow port selector, air mix).

The unit also has self diagnose function and can perform self diagnose easily.

(For detail refer to the control specification)




3. Fan driver (blower amplifier)


The fan driver receives the control signal from the control unit and control the fan motor speed.


Normal condition

Terminal no.		Continuity		
				\oplus
Tester	Θ	\oplus		No
	\oplus	Θ		Yes (Diode parallel forward direction)

- (1) Remove the connector of the blower amplifier.
- (2) Check the continuity between each terminal of the blower amplifier.
- * The amplifier is located in the left hand of the air conditioner unit.







4. Relay

The blower OFF relay and the compressor relay are four pole relay.

(1) Blower off relay

The blower OFF relay turns ON when the signal from the control amplifier is received.

When the blower OFF relay turns ON, power is supplied to the blower motor and the blower motor starts.

(2) Compressor relay

This relay turns ON-OFF by the compressor control of the control amplifier.

Inspection points of the relay

Identification	Check Method
Relay	
Coil resistance	320 Ω
Voltage*1	DC20 V to 30 V
	between the terminal 3
Inspection	to 4 under the following
	condition.*2


- *1 Note: This relay coil has a polarity.
- *2 Inspection : Check the continuity.

Apply 20 to 30 V between the terminal 1 and


2: Continuity should be YES

Apply no voltage between the terminal 1 and

2: Continuity should be NO







5. Air mix actuator

The air mix actuator is installed in the center of the air conditioner unit and controls OPEN/ CLOSE of the air mix damper.

The air mix actuator has the potentiometer in its inside to be controller by the actuator shaft movement.

When the target position of the air mix door is decided by the temperature control switch, the control system reads the potentiometer indication of the actuator and decides the direction of motor rotation.

The contact moves together with the motor and comes to separate its contact point or reaches to the target position of the potentiometer indication to make output signal OFF from the control unit. Then the motor stops.

(Refer to the inspection of the air mix motor actuator.)

6. In-out air actuator


In-out air actuator is installed in the blower intake unit and opens or closes the in-out air damper through the linkage.


In-out air actuator has the position detect switch in its inside which is controlled by the shaft movement of the actuator.

When the target location of the in-out air damper is decided by the in-out air selector switch of the control unit, the control system reads the potentiometer indication of the actuator and decides the direction of motor rotation.

The contact moves together with motor and stops the motor by reaching to the target position.

(Refer to inspection of the In-out motor actuator.)





7. Blow out mode actuator

The blow out mode actuator is installed in the back side of the air conditioner unit and opens or closes the blow out damper through the linkage.

The bow out mode actuator has the potentiometer in its inside which is controlled by the shaft movement of the actuator.

When the target position of the blow out mode is decided by the temperature control switch, the control system reads the potentiometer indication of the actuator and decides the direction of motor rotation.

The contact moves together with the motor and comes to separate its contact point or reaches to the target position of the potentiometer indication to make output signal OFF from the control unit. Then the motor stops.

(Refer to the inspection of the motor actuator.)

8. Evaporator sensor


This sensor controls ON-OFF of the compressor by detecting the temperature of the bow out air of the evaporator to prevent it from freezing.

Inspection Of The Evaporator (Specification data)

Remove the evaporator sensor connector from the main harness and measure the resistance value between the terminals to the sensor with the multi-tester.

Resistance value between terminal to the sensor

When the sensor detect temp. is 0°C	7.2k Ω
When the sensor detect temp. is 25°C	2.2k Ω






9. Dual pressure switch

The dual pressure switch is installed in the receiver dryer and protect the cooling cycle by opening its contact and cutting the power supply to the compressor when the high pressure side of cooling becomes malfunction (high pressure faulty, low pressure faulty).

- Simple Inspection Of Dual Pressure Switch
- (1) Disconnect the connector from the switch when the cooling cycle is stopped and check the continuity between the terminal to the switch and to the connector with the multi-tester. If the continuity is YES, then it is normal. (When the ambient temperature is above 0°C)
- (2) Connect the high pressure side hose of the gauge manifold to the high pressure side charge port and raise the high side pressure when the cooling cycle is operating. Cover the front face of the condenser with some board or such during this work. If the compressor stops at 3.14 MPa or around then the system if normal.
- (3) Check the continuity between the terminal to the switch and to the connector when the coolant is removed.

If continuity is NO, the system is normal.





Spec. of dual pressure switch

11.7 RECHARGING OF THE COOLANT

11.7.1 CAUTION AT WORK

Make sure that the work is done by the specialist.

Recharging work consist of high pressure gas handling.

Make sure that the work is done with the specialist who is familiar with the work.

MARNING

- Make sure to wear the safety goggles when charging.
 - (If the refrigerant gets into eye may cause the loss of eyesight.)
- Extreme care to handle the liquid refrigerant due to it is extreme low temperature (-26 C°). (If they touch the skin, it may cause the frostbite.)
- 1. Storage and transport
- (1) Store the service bottle (Hereafter called bottle) in the temperature below 40°C.
 - High pressure gas "R134a" is contained inside the bottle in the saturated liquid form. Rapid rise of the temperature may cause burst of the bottle and is very dangerous.
 - Therefore it is NECESSARY to store the bottle in the cold place under minus 40°C temperature.
- (2) Prevent direct sunlight to the bottle and store them in the cool and dark place.
- (3) If the bottle is placed close to the fire, it may raise the temperature due to the heat radiation and may cause to raise the inside pressure and virtually may cause burst of the bottle. Never place the bottle close to the fire.
- (4) Temperature on the closed operator's room will be risen quickly to the dangerous range even at the winter time when the radiant heat from the sun strikes it.

Do not take the bottle into the closed operator's room even at the winder time.

Temperature in the storage box also rises to dangerous range at summer time.

Be careful on this point.

- (5) Flaw, indent mark or deformation may decrease the strength of the bottle.Be careful on this point.
- (A) Do not drop or hit the bottle.
- (B) Take care in loading, transporting and unloading the bottles or packing case containing the bottles.
 - Handle with care and do not drop or throw them.
- (C) Do not store the bottle within the reach of the children.

2. At the recharging time

(1) When the bottle is to be warmed up for recharging, make sure to open the bottle valve, the low pressure side gauge manifold and then warm up the bottle with warm water of about 40°C temperature (Below hand hot temperature!).

Do not put the bottle into the hot water or heat up with direct fire.

- Otherwise the pressure may go up quickly and may burst the bottle.
- (2) When the engine is started to recharge the bottle with the coolant, NEVER open the high pressure valve (HI) of the gauge manifold. Opening the high pressure valve may cause the high pressure gas to backflow and may cause to burst the bottle or the charging hose and is very dangerous.

3. Others

- Reuse of the recharge bottle is prohibited by law. NEVER reuse.
- (2) Do not put any foreign material into the air conditioner piping.
- (3) Cooling cycle hates air, water and dust. Assembling work of the air conditioner must be done quickly and take extra care to prevent water, dust entering into the system.

▲ CAUTION

Pay attention not to overcharge.

Tighten all the pipe fittings with the specified torque.

11.7.2 WORK PROCEDURE

- Recharging work of the coolant into the air conditioner is divided into "Vacuuming work" and "Gas recharging work".
- (1) "Vacuuming work" is to remove the water in the air conditioner piping completely.

Even a slight amount of water is left in the piping, it will be frozen in the small holes in the expansion valve during the operation and may cause piping clogged or rust inside the piping or other trouble.

In order to avoid these troubles the vacuuming work must be done to boil off the water in the piping prior to recharge the coolant into the piping.

(2) "Gas recharging work" is to recharge the system with the coolant after the vacuuming work is completed.

Gas recharging work is the main work and affects not only the cooling performance of the air conditioner but also to the life of the circuit.


Extreme over charging may cause abnormal high pressure in the system and may lower the cooling performance.

On the other hand, extreme low amount of the coolant may cause poor circulation of the lubricant to the compressor and may virtually cause seizure on the sliding area.

Gas recharging work also handle the high pressure gas and wrong handling is very dangerous.

Carry out the coolant recharging by exactly following the procedure mentioned in this manual.

2. Work chart



3. Tool

Name	Shape	Quantity	Use
Gauge manifold		1	
Charging hose	Go or or or or or or or or or or or or or	3	Red : High pressure side Blue : Low pressure side Yellow : Vacuum pump side
Quick joint	27.5 mm dia. (1-3/32" dia.)	1	
Quick joint	23.5 mm (30/32")	1	Low pressure side
T-Joint		1	Service bottle valve
Service bottle valve		2	For service bottle
Vacuum pump adapter		1	For vacuum pump

11.7.3 RECHARGING PROCEDURE

VACUUMING WORK

- 1. Connection of gauge manifold
- (1) Close the high pressure valve (HI) and low pressure valve (LO) of the gauge manifold.
- (2) Connect the charging hose (Red and Blue) to the service valve of the compressor.
 - Red hose
 High pressure side of the gauge manifold
 (HI)→High pressure side of the compressor (DIS)
- Blue hose
 Low pressure side of gauge manifold (LO)→Low pressure side of the compressor (SUC)



Do not mix the high pressure side and low pressure side connection.

Push the hose firmly until "the click" sounds. Connect the charging hose with "L" shaped end to the service valve of the compressor.


The "L" shaped end has a check valve.

If connected in reverse way, check valve of the compressor will not open.

(3) Connect the center valve of the gauge manifold and the vacuum pump with the charging hose.

Note

Some type of the gauge manifold does not have the open/close valve in their center.



(CHECK)

Compressor piping connection

2. Vacuuming

- (1) Open the high pressure valve (HI) and low pressure valve (LO) of the gauge manifold.
- (2) Turn ON the switch of the vacuum pump and continue vacuuming work for more that 30 minutes.
- (3) When the vacuuming for the specified time is completed (Target figure of vacuum: -750 mgHg or lower), close the high pressure valve and the lower pressure valve.
- (4) Then turn off the switch of the vacuum pump.


3. Airtight check

Watch the gauge for more than five minutes while the high pressure valve and the lower pressure valve are closed and confirm that the gauge needle does not move back toward zero direction.

▲ CAUTION

If the gauge moves back toward zero direction, there must be leaking point somewhere. Retighten all of pipe fittings and again repeat the

Retighten all of pipe fittings and again repeat the vacuuming work and check for leak again.



GAS RECHARGING WORK

- 1. Recharge from the high pressure side
- (1) Disconnect the charging hose (yellow) of the gauge manifold from the vacuum pump and reconnect it to the service bottle after the vacuum pump is completed.
- (2) AIR PURGE

Open the service bottle valve. (High pressure side and low pressure side valves must be closed.)

Then push the check valve in the service port of the lower pressure side on the gauge manifold with a screw driver or such to purge the air in the charging hose by the coolant pressure.

(If the air sound "shoo!" comes out, it is completed.)

(3) Open the high pressure valve of the gauge manifold and charge the coolant.

(Charge the coolant gas to 0.098 MPa [1 kgf/cm²] in gauge reading.)

After charging close the high pressure valve in the gauge manifold and the service bottle valve.




Never run the compressor.

(The coolant will flow back and the service bottle or the hose may burst and is very dangerous.)


2. Gas leaking check


Check gas leak in the cooling cycle with the gas leak tester (electric type).

If there is any leaking point, re-tighten.



Make sure that the tester is for R134a coolant. (Tester for flon coolant is not usable due to low sensibility)





Gas charging work (high pressure side)

- 3. Charging from the low pressure side
- Make sure that the valves for high pressure side, low pressure side and service bottle are all closed.
- (2) Start the engine and set the speed to 1400 to 1600 rpm and open the cab door completely.
- (3) Turn ON the air con. switch and set the fan switch to max. and temperature adjusting switch to max. cooling.
- (4) Set the delivery pressure of the compressor to 1.37 to 1.57 MPa [14 to 16 kg/cm²] during charging.
- (5) Open the low pressure valve of the gauge manifold and the service bottle valve and charge the coolant until the bubble in the receiver sight glass disappear.


Full gas charging amount	850 to 950 g
	(1.87 to 2.09 lbs)

(6) When the coolant charging is completed, close the low pressure valve of the manifold and the service bottle valve and stop the engine.

▲ CAUTION

- NEVER open the high pressure side valve of the gauge manifold.
- NEVER place the service bottle upside down

(Liquid form of coolant may be injected into the cooling cycle and may damage the compressor valve.)



Gas charging work (high pressure side)



4. Guidepost of recharging coolant amount

Judgement from sight glass view of the receiver dryer

Judge result	Coolant condition	Coolant change
In case of travel charge	After A/C turned on, bubbles appear a little, hereafter it becomes transparent, and shows milk-white.	$\begin{pmatrix} \hat{\varphi} & \hat{\varphi} \\ \hat{\varphi} & \hat{\varphi} \end{pmatrix} \rightarrow \bigcirc \rightarrow \bigcirc$
In case of overcharge	After A/C turned on, no bubble appears.	$\bigcirc \rightarrow \bigcirc \rightarrow \bigcirc$
In case of insufficient charge	After A/C turned on, bubbles can be seen continuously.	

(%%)	Bubbles exist :Vapor and liquid of refrigerant are mixed.
\bigcirc	No bubbles :All refrigerant becomes liquid and is transparent.
	Impurity :Oil and refrigerant are separated, and show milk-white

▲ CAUTION

The air conditioner is operated when the coolant (R134a) is very low, it may badly affect the compressor.

If the coolant is overcharged, it will rather reduce the cooling performance and the cooling cycle becomes extreme high pressure and is dangerous. Keep the correct amount of coolant.


5. Removal of the gauge manifold

When the inspection of coolant recharging is completed, remove the charging hose from the compressor under the following procedure.


- (1) Push the L shaped fitting of the lower pressure side charging hose (blue) to the service valve of the compressor to prevent coolant leaking and loosen the nut.
 - When the nut is removed, quickly remove the charging hose from the service valve.
- (2) Keep the high pressure side until the high pressure gauge reading becomes lower than 0.98 MPa (10 kg/cm²).
- (3) Remove the high pressure side charging hose (red) in the same procedure as the low pressure side.

11.8 TROUBLESHOOTING


1. Trouble in cooling circuit




2. Magnet clutch does not rotated



3. Mode does not change



4. Blower motor does not rotated



- *1 Measure when the connectors are connected.
- *2 When short circuit test is performed, the air conditioner, base machine key and lighting switches should be turned OFF for safety.



12. TRANSLIFTER SYSTEM

12.1	APPARATUS AND COMPONENTS LOCATION	12-1
12.2	CONSTRUCTION AND FUNCTION	12-2
12.2.	1 HYDRAULIC SCHEMATIC	12-2
12.2.2	2 RAISING THE TRANSLIFTER	12-3
12.2.3	B LOWERING THE TRANSLIFTER	12-4
12 3	REMOTE CONTROL SWITCH BOX	12-5




12. TRANSLIFTER SYSTEM


12.1 APPARATUS AND COMPONENTS LOCATION


The translifter system consists of the vertical cylinder, crawler EXT./RET. cylinder (horizontal cylinder), control valve, remote control switch box.

The pressurized oil discharged from the No.7 pump which is mounted on the main pump is controlled by the hydraulic selector section of the 2 section control valve (gantry control valve), and is led to the translifter control valve through the swivel joint.

The pressurized oil controlled by the remote controller is sent to the respective cylinders.







Published 12-16-15, Control #244-01 8500E-1


12.2 CONSTRUCTION AND FUNCTION

12.2.1 HYDRAULIC SCHEMATIC

The function is common to the four translifter vertical cylinders.

The function of the crawler ext./ret. cylinders is almost identical to that of the vertical cylinders except double pilot check valve.

The function of the translifter cylinders is described below taking the front right vertical cylinder as an example.



8500-1 / 8500E-1 12-2 Published 12-16-15, Control #244-01

12.2.2 RAISING THE TRANSLIFTER

The pressurized oil discharged from the auxiliary unit No.7 pump is led into the hydraulic circuit select section through the gantry section of 2 section control valve.


At this time, if the hydraulic circuit select switch is in "NEUTRAL (GANTRY)" position, the pressurized oil flows through the 2 section control valve, and returns to the tank without any load.

When the remote control switch is connected to the machine, the SOL-44 actuates, causing the pressurized oil to flow through the swivel joint and into the translifter control solenoid valve.

If the translifter control solenoid valve remains unactuated, the pressurized oil flows through the valve, and returns to the tank without any load.

When the "right front" vertical cylinder switch is set to the "EXTEND" side, the solenoid valve (SOL-80) actuates, causing the pressurized oil not only to flow into the head side of the vertical cylinder but also to open the rod side check of the double pilot operated check valve.

As a result, the oil in the rod side returns to the tank, and the right front vertical cylinder is extended.



Published 12-16-15, Control #244-01 12-3 8500-1 / 8500E-1

12.2.3 LOWERING THE TRANSLIFTER

The pressurized oil discharged from the auxiliary unit No.7 pump is led into the gantry and hydraulic selector valve through the gantry section of the 2 section control valve.


At this time, if the hydraulic circuit select switch is in "NEUTRAL (GANTRY)" position, the pressurized oil flows through the 2 section control valve, and returns to the tank without any load.

When the hydraulic circuit select switch is selected to "TRANSLIFTER" position, the SOL-44 actuates, causing the pressurized oil to flow through the swivel joint and into the translifter control solenoid valve.

If the translifter control solenoid valve remains unactuated, the pressurized oil flows through the valve, and returns to the tank without any load.

When the "right front" vertical cylinder switch is set to the "RETRACT" side, the SOL-86 actuates, causing the pressurized oil not only to flow into the rod side of the vertical cylinder but also to open the head side check of the double pilot operated check valve.

As a result, the oil in the head side returns to the tank, and the right front vertical cylinder is retracted.



8500-1 / 8500E-1 12-4 Published 12-16-15, Control #244-01

12.3 REMOTE CONTROL SWITCH BOX


This machine provides the remote control switch box (here after called "remo-con") for operate the machine from outside at the assembling/disassembling.


Note

When a power switch of remote control switch box is ON position, the engine can't be started with the engine key in the operator's cab.


When starting the engine from key switch in the operator's cab, ensure to turn the power switch of remote control box OFF position.

1. Connection with the carbody side






REMOTE CONTROL SWITCH BOX



(1) POWER SWITCH


OFF	Power off. / Engine stop. Turning to this position stops the engine.
ON	Power is supplied to crane portion.
	Engine starts. When released, the switch automatically return to ON position.



Note

The engine can't start from the operator's cab if in case this power switch is on position.

(2) HORN SWITCH
Press this switch to sound the horn.




- * Use only to stop the engine at emergency case.
- (4) ENGINE SPEED CONTROL SWITCH

Increase the engine speed.
Decrease the engine speed.

(5) ABNORMAL INDICATING LAMP This lamp turns ON when the engine abnormality occurs. When this lamp is ON, check the detail of abnormality by the cab monitor and take

appropriate action.










(6) VERTICAL CYLINDER CONTROL SWITCH This switch is used to control the translifter.







(7) CRAWLER EXTEND/RETRACT SWITCH
This switch is used to control the crawler extend/retract cylinder.

#,#	Crawler extend/retract cylinder extends.
;	Crawler extend/retract cylinder retracts.



2. Connection with the self removal device side






REMOTE CONTROL SWITCH BOX

Switches (1) to (5) are same functions when connect the switch box with carbody.


(6) SELF REMOVAL DEVICE CONTROL SWITCH This switch is used to control self-removal cylinders.







3. Construction

When the controller is failed or the cable breakage occurs but the machine still need to be operated, repair upon reviewing the controller circuit or apply voltage directly on the solenoid valve.






4. Schematic



13. TROUBLESHOOTING

13.1	ENGINE	13-1
13.2	WINCH SYSTEM	13-3
13.3	SWING SYSTEM	13-8
13 4	TRAVELING SYSTEM	13-11





13. TROUBLESHOOTING

Grasp the appropriate trouble contents and make the most useful action from this troubleshooting table.

13.1 ENGINE

TROUBLESHOOTING OF ENGINE

Symptom	Possible cause	Check points	Remedy
	Battery is dead.	Check the battery electrolyte for level and specific gravity.	Charge or replace the battery.
		Check the starter relay for operation.	Replace the starter relay.
		Check contents of the error/warning displayed on the main monitor.	Reset the error/warning.
	Starter is not rotating.	Check that the Engine Emergency Stop switch is not pushed.	Release the Engine Emergency Stop switch (inside cabin or via remote controller).
		Check the safety relay for operation.	Replace the safety relay.
		The operator is not authenticated.	Conduct operator authentication work.
		Check whether the fuse (F30) is blown or not.	Replace the fuse (F30).
Engine does not	Air intake is not performed. Engine error signal	Check presence of fuel and flow of fuel in	Supply fuel or replenish fuel in the priming pump.
start.		piping.	Conduct air bleeding.
		Check elements of the fuel filters (main and pre filters) for clogging.	Replace elements of the fuel filters (main and pre filters)
		Check that fuel open/close valve is not closed.	Open the open/close valve.
		Check that air cleaner element is not clogged.	Clean or replace the air cleaner element.
		Check the air intake piping (from air cleaner, turbo intercooler to engine) for clogging.	Eliminate the clogging.
06		Check contents of the error.	Take action after locating the cause in accordance with the Engine Maintenance Manual.
	(P code) is output.		Contact Manitowoc authorized distributor as needed.
Engine does not stop.	Defective electrical system	Key switch in trouble	Replace the key switch.
Engine speed does not increase.	Accelerator grip is in trouble.	Check whether grip trouble error signal is output or not.	The aux. accelerator switch toward "ON" side.
not morease.	iii tioubic.	output of flot.	oluc.

TROUBLESHOOTING OF ENGINE

Symptom	Possible cause	Check points	Remedy
	Malfunctioning of ECU	Check the P code.	Check the Engine Manual.
	Defective electrical system	Defective controller.	Replace the controller. (Conduct the work with aux. accelerator.)
Engine speed does not increase.	Insufficient of DEF/AdBlue®	Check residual amount of DEF/AdBlue®.	Replenishment of DEF/AdBlue®.
not increase.	Engine error signal (P code) is output.		Take action after locating the cause in accordance with the Engine Maintenance Manual.
	(P code) is output.		Contact Manitowoc authorized distributor as needed.
		Check presence of fuel and flow of fuel in	Supply fuel or replenish fuel in the priming pump.
	Fuel is not supplied.	piping.	Conduct air bleeding.
		Check elements of the fuel filters (main and pre filters) for clogging.	Replace elements of the fuel filters (main and pre filters)
Engine revolutions	Air intake is not performed.	Check that air cleaner element is not clogged.	Clean or replace the air cleaner element.
are uneven.		Check the air intake piping (from air cleaner, turbo intercooler to engine) for clogging.	Eliminate the clogging.
		Check contents of the error.	Take action after locating the cause in accordance with the Engine Maintenance Manual.
	(P code) is output.		Contact Manitowoc authorized distributor as needed.
	Cooling water is not enough.	Check the cooling water level.	Replenish cooling water.
	Cooling water is not	Check that the thermostat is not stuck.	Replace the thermostat.
	supplied.	Check water piping for clogging.	Eliminate the clogging.
		Check that the fan is not slipping.	Adjust the V belt tension.
	Cooling air volume	Check that the radiator front face is not blocked with dust and others.	Blow air to clean the radiator.
Overheating	Engine error signal (P code) is output.	Check that there are no obstacles in openings on the air supply and exhaust sides of the guard.	Remove the obstacles.
		Check contents of the error.	Take action after locating the cause in accordance with the Engine Maintenance Manual.
			Contact Manitowoc authorized distributor as needed.

13.2 WINCH SYSTEM

Symptom	Possible cause	Check points	Remedy
	Hydraulic oil is not	Check the hydraulic oil tank oil level.	Replenish hydraulic oil.
	enough.	Check the suction strainer for clogging.	Wash or replace the strainer.
	Clutch is slipping.	Check the positive and negative pressures.	Replace the positive and negative pressure selector valve.
	Malfunctioning of remote control valve	Check whether the secondary pressure generation is normal.	Replace the remote control valve.
	Malford to the	Check the primary pressure.	Adjust the primary pressure or replace the valve.
	Malfunctioning of remote control circuit relief valve	Check the function lock limit switch for operation.	Adjust operation of the limit switch or replace the limit switch.
	on our ronor varyo	Check the function lock solenoid valve for operation.	Replace the solenoid valve.
	Malfunctioning of main pump	Check whether traveling system is functioning.	Replace the main pump.
	Malfunctioning of	Check the main valve relief pressure.	Adjust the relief valve pressure or replace the relief valve.
	main valve	Check the pilot pressure on the main valve.	Check and replace the remote control valve.
Hoisting and lowering	-	Check the counter balance valve spool movement.	Replace the valve.
unable to do.		Check the counter balance valve poppet for deposition of contaminant and flaw on seat surface.	
	Malfunctioning of hoisting motor	Check the motor drain oil amount. 1. Conditions for motor drain measurement (1) Engine rpm: High idle (2) Hyd. oil temp.: 50°C (VG46) (3) Trimmer position: Max. High (For motor swash angle to be minimum) (4) Lifting load: Empty hook only (5) Operate either front or rear drum lever with full stroke. 2. Drain amount: 10 L/min or less.	Replace the motor.
	Malfunctioning of hoisting reduction unit.	Check for unusual noise, temperature and vibration.	Replace the reduction gears/unit.
	Automatic stop, interlock, stop electrically and others.	Check the contents of the stopping condition.	Release the functions (elimination of cause of auto stop and release of interlock)

Symptom	Possible cause	Check points	Remedy
	Hydraulic oil is not	Check the hydraulic oil tank oil level.	Replenish hydraulic oil.
	enough.	Check the suction strainer for clogging.	Wash or replace the strainer.
	Clutch is slipping.	Check the positive and negative pressures.	Replace the positive and negative pressure selector valve.
	Malfunctioning of remote control valve	Check whether the secondary pressure generation is normal.	Replace the remote control valve.
	Malfunctioning of remote control circuit relief valve	Check the primary pressure.	Adjust the primary pressure or replace the valve.
	Malfunctioning of main pump	Check whether traveling system is functioning.	Replace the main pump.
	Malfunctioning of	Check the main valve relief pressure.	Adjust the relief valve pressure or replace the relief valve.
	main valve	Check the pilot pressure on the main valve.	Check and replace the remote control valve.
Intended hoisting and lowering speeds	speeds	Check the counter balance valve spool movement.	Replace the valve.
unable to obtain.		Check the counter balance valve poppet for deposition of contaminant and flaw on seat surface.	
		Check the motor drain oil amount.	Replace the motor.
		Check motor tilt control proportional solenoid valve.	Replace proportional solenoid valve.
	Malfunctioning of hoisting reduction unit.	Check for unusual noise, temperature and vibration.	Replace the reduction gears/unit.
		Check the voltage of the engine rotation grip or rotating speed sensor.	Adjust the rotation grip L/H level or replace the rotation grip.
	Malfunctioning of engine sensing	Check the voltage of the main pump proportional solenoid valve for pressure reducing.	Adjust or replace the proportional solenoid pressure reducing valve.
	Speed trimmer position is minimized.	Check the speed trimmer position.	Maximize the speed trimmer.

Symptom	Possible cause	Check points	Remedy
	Clutch is slipping.	Check the positive and negative pressures.	Replace the positive and negative pressure selector valve.
	Malfunctioning of remote control valve	Check whether the secondary pressure generation is normal.	Replace the remote control valve.
	Malfunctioning of remote control circuit relief valve	Check whether the primary pressure generation is normal.	Adjust the primary pressure or replace the valve.
Hoisting and	Malfunctioning of main pump	Check whether traveling system is functioning.	Replace the main pump.
lowering speeds unable to control.	Malfunctioning of	Check the main valve relief pressure.	Adjust the relief valve pressure or replace the relief valve.
	main valve	Check the pilot pressure on the main valve.	Check and replace the remote control valve.
	Malfunctioning of hoisting motor	Check the counter balance valve spool movement.	Replace the valve.
		Check the motor drain oil amount.	Replace the motor.
	Malfunctioning of hoisting reduction unit.	Check for unusual noise, temperature and vibration.	Replace the reduction gears/unit.
	Clutch is slipping.	Check the positive and negative pressures.	Replace the positive and negative pressure selector valve.
Inching operation	Malfunctioning of remote control valve	Check whether the secondary pressure generation is normal.	Replace the remote control valve.
unable to do.	Malfunctioning of remote control circuit relief valve	Check whether the primary pressure generation is normal.	Adjust the primary pressure or replace the valve.
	Slow reaction of negative brake valve	Check the negative brake release pressure.	Check the negative brake release valve and the slow return valve.
		Check the counter balance valve spool movement.	Replace the valve.
Suspended load unable to hold.	Malfunctioning of hoisting motor	Check the counter balance valve poppet for deposition of contaminant and flaw on seat surface.	Wash or replace the poppet.
		Check the motor drain oil amount.	Replace the motor.

Symptom	Possible cause	Check points	Remedy	
	[Operations on negative brake side]			
	Clutch is slipping.	Check the positive and negative pressures.	Replace the positive and negative pressure selector valve.	
	Negative brake is released.	Check the negative brake release pressure.	Check the negative brake release valve and the slow return valve.	
Suspended load unable to hold.	Malfunctioning of remote control valve	Check the secondary pressure.	Replace the remote control valve.	
	[Operations on positi	ive brake side]		
	Clutch is slipping	Check the brake pedal linkage for loosening and interference.	Adjust or repair the linkage.	
	Clutch is slipping.	Check the positive and negative pressures.	Replace the positive and negative pressure selector valve.	
		Check the positive and negative pressures.	Replace the positive and negative pressure selector valve.	
	Clutch cannot be released. Malfunctioning of remote control circuit relief valve	Check the brake pedal linkage for loosening and interference.	Adjust or repair the linkage.	
		Check the specified brake force is output.	Replace the negative and positive brake units.	
		Check the positive brake control valve spool movement.	Replace the valve.	
		Check whether the primary pressure generation is normal.	Adjust the primary pressure or replace the valve.	
		Check the function lock limit switch works.	Adjust the movement of the limit switch or replace the limit switch.	
Free fall function is unable to do.	Circuit relier valve	Check the function lock solenoid valve function.	Replace the solenoid valve.	
	Malfunctioning of hoisting reduction Check for unusual noise, temperature unusual noise and seiz	Check for unusual noise, temperature	Check the shaft, gear and bearing for unusual noise and seizure.	
		Repair the shaft and bearing or replace parts.		
		Check the fuse (F-38) for blowing as well as wiring.	Replace the fuse (F-38) or repair the wiring.	
	Defective electrical system	Check the free fall selector switch function.	Replace the switch or repair the wiring.	
		Check the relay for switching and the contact for burn mark.	Replace the relay or repair the wiring.	
		Check the free fall selector solenoid valve for function.	Replace the solenoid valve or repair the wiring.	

Symptom	Possible cause	Check points	Remedy
	Hydraulic oil is not	Check the hydraulic oil tank oil level.	Replenish hydraulic oil.
	enough.	Check the suction strainer for clogging.	Wash or replace the strainer.
		Check the counter balance valve spool movement.	Replace the valve.
	Malfunctioning of hoisting motor	Check the counter balance valve poppet for deposition of contaminant and flaw on seat surface.	
		Check the motor drain oil amount.	Replace the motor.
	Malfunctioning of remote control valve	Check whether the secondary pressure generation is normal.	Replace the spool or adjust the valve.
	Malfarationin	Check the primary pressure.	Adjust the primary pressure or replace the valve.
	Malfunctioning of remote control circuit relief valve	Check the function lock limit switch works.	Adjust movement of the limit switch or replace the limit switch.
	circuit relier valve	Check the function lock solenoid valve function.	Replace the solenoid valve.
Hunting	Malfunctioning of main valve Malfunctioning of hoisting motor	Check the main valve relief pressure.	Adjust the relief valve pressure or replace the relief valve.
		Check the pilot pressure on the main valve.	Check the remote control valve.
		Check the counter balance valve spool movement.	Replace the valve.
		Check the counter balance valve poppet for deposition of contaminant and flaw on seat surface.	
		Check the piston for sticking or get out of place.	Check the piston movement and replace the part.
		Check the motor drain oil amount.	Replace the motor.
	Malfunctioning of hoisting reduction unit.	Check for unusual noise, temperature and vibration.	Replace the reduction gears/unit.
06	Malfunctioning of	Check the voltage of the engine rotation grip or rotating speed sensor	Adjust the rotation grip L/H level or replace the rotation grip.
	Malfunctioning of engine sensing	Check the voltage of the main pump proportional solenoid pressure reducing valve.	Adjust or replace the proportional solenoid pressure reducing valve.

13.3 SWING SYSTEM

Symptom	Possible cause	Check points	Remedy
	Hydraulic oil is not	Check the hydraulic oil tank oil level.	Replenish hydraulic oil.
	enough.	Check the suction strainer for clogging.	Wash or replace the strainer.
	Defective swing brake	Check whether the swing brake release pressure is normal or not.	Repair the swing brake valve or replace the valve.
		Check whether the pressure switch function is normal or not.	Repair the pressure switch wiring or replace the switch.
		Check the brake disc for unusual noise and high temperature.	Check the brake disk or replace the disk.
	Malfunctioning of remote control valve	Check whether the secondary pressure generation is normal.	Replace the spool or replace the valve.
	Malfunctioning of remote control circuit relief valve	Check the primary pressure.	Adjust the primary pressure or replace the valve.
		Check the function lock limit switch works.	Adjust movement of the limit switch or replace the limit switch.
Swing is unable to		Check the function lock solenoid valve function.	Replace the solenoid valve.
do.	Defective swing control valve	Check the main valve relief pressure.	Adjust the relief valve pressure or replace the relief valve.
Specified swing speed unable to		Check the valve spool movement.	Lap or replace the spool.
obtain.	Malfunctioning of swing motor	Check the piston for sticking or get out of place.	Check the piston movement and replace the part.
Lack of swing force.		Check the motor drain oil amount.	Replace the motor.
	Malfunctioning of swing reduction unit.	Check for unusual noise, temperature and vibration.	Check the shaft and bearing for unusual noise and seizure.
			Repair the shaft, gear and bearing or replace parts.
		Check the gear oil level in the reduction gears.	Replenish gear oil or replace parts.
	Malfunctioning of swing bearing	Check for unusual noise, temperature and vibration.	Check the bolt for loosening, the bearing for flaking, wearing and seizure.
			Retighten the bolt, replace the ball and replace the bearing.
	Defective electrical system	Check the parking brake and the swing mode selector switch function.	Replace the switch or repair the wiring.
		Check the relay for switching and the point for burning mark.	Replace the relay or repair the wiring.
		Check the swing mode selector solenoid valve works.	Replace the solenoid valve or repair the wiring.

Symptom	Possible cause	Check points	Remedy
	Malfunctioning of swing bearing	Check for unusual noise, temperature and vibration.	Check the bolt for loosening, the ball for problem and bearing for seizure.
			Retighten the bolt, check the bearing for flaking, wearing and if damaged replace the bearing.
		Check the swing pinion for unusual noise	Check the pinion for tooth contact condition, seizure and chipping.
		and vibration.	Apply lubrication, replace the pinion.
	Defective swing brake	Check whether the swing brake release pressure is normal or not.	Repair the swing brake valve or replace the valve.
		Check whether the pressure switch function is normal or not.	Repair the pressure switch wiring or replace the switch.
		Check the brake disk for unusual noise and high temperature.	Check the brake disk or replace the disk.
	Malfunctioning of remote control circuit relief valve	Check the primary pressure.	Adjust the primary pressure or replace the valve.
Shock is observed at stating/stopping		Check the function lock limit switch works.	Adjust movement of the limit switch or replace the limit switch.
of swing motion.		Check the function lock solenoid valve function.	Replace the solenoid valve.
Swing motion is not smooth.	Defective swing control valve	Check the main valve relief pressure.	Adjust the relief valve pressure or replace the relief valve.
		Check the valve spool movement.	Lapping or replace the spool.
	Malfunctioning of swing motor	Check the piston for sticking or get out of place.	Check the piston movement and replace the part.
		Check the motor drain oil amount.	Replace the motor.
	Malfunctioning of swing reduction unit.	Check for unusual noise, temperature and vibration.	Check the shaft, gear and bearing for unusual noise and seizure.
			Repair the shaft and bearing or replace parts.
		Check the gear oil level in the reduction unit.	Replenish gear oil or replace parts.
	Defective electrical system	Check the parking brake and the swing mode selector switch for functioning.	Replace the switch or repair the wiring.
		Check the relay for switching and the contact points for burning mark.	Replace the relay or repair the wiring.
		Check the swing mode selector solenoid valve function.	Replace the solenoid valve or repair the wiring.
			·

Symptom	Possible cause	Check points	Remedy
Swing brake ineffective.		Check whether the swing brake release pressure is normal or not.	Repair the swing brake valve or replace the valve.
	Defective swing brake	Check whether the pressure switch works normal or not.	Repair the pressure switch wiring or replace the switch.
		Check the brake disk for unusual noise and high temperature.	Check the brake disk or replace the disk.
	Defective electrical system	Check the parking brake and the swing mode selector switch function.	Replace the switch or repair the wiring.
		Check the relay for switching and the contact points for burning mark.	Replace the relay or repair the wiring.
		Check the swing mode selector solenoid valve function.	Replace the solenoid valve or repair the wiring.

13.4 TRAVELING SYSTEM

TROUBLESHOOTING OF TRAVELING SYSTEM

Symptom	Possible cause	Check points	Remedy
Traveling unable to do. Specified traveling speed unable to obtain. Lack of traveling force.	Hydraulic oil is not enough.	Check the hydraulic oil tank oil level.	Replenish hydraulic oil.
		Check the suction strainer for clogging.	Wash or replace the strainer.
	Malfunctioning of remote control valve	Check whether the secondary pressure generation is normal.	Replace the valve.
		Adjust the secondary pressure detection switch.	Replace the pressure switch.
	Malfunctioning of remote control circuit relief valve	Check the primary pressure.	Adjust the primary pressure or replace the valve.
		Check the function lock limit switch works.	Adjust movement of the limit switch or replace the limit switch.
		Check the function lock solenoid valve function.	Replace the solenoid valve.
	Defective traveling control valve	Check the main valve relief pressure.	Adjust the relief valve pressure or replace the relief
	Malfunctioning of travel motor	Check the piston for sticking or get out of place.	Check the piston movement and replace the part.
		Check the motor drain oil amount.	Replace the motor.
		Check for unusual noise, temperature	Check the shaft, gear and bearing for unusual noise and seizure.
	Malfunctioning of travel reduction unit	and vibration.	Repair the shaft and bearing or replace parts.
		Check the gear oil level in the reduction unit.	Replenish gear oil or replace parts.

TROUBLESHOOTING OF TRAVELING SYSTEM

Symptom	Possible cause	Check points	Remedy
	Poor engagement of shoe with tumbler	Check engagement of the shoe with the tumbler and shoe overriding the tumbler.	Adjust tension of the shoe, repair the shoe or replace parts.
	Defective travel brake	Check whether the travel brake release pressure is normal or not.	Repair the travel brake valve or replace the valve.
		Check whether the pressure switch function is normal or not.	Repair the pressure switch wiring or replace the switch.
		Check the brake disk for unusual noise and high temperature.	Check the brake disk or replace the disk.
		Check the brake valve.	Replace the brake valve.
Shock is observed at starting/stopping	Malfunctioning of remote control circuit relief valve	Check the primary pressure.	Adjust the primary pressure or replace the valve.
		Check the function lock limit switch works.	Adjust movement of the limit switch or replace the limit switch.
		Check the function lock solenoid valve function.	Replace the solenoid valve.
	Defective travel control valve	Check the main valve relief pressure.	Adjust the relief valve pressure or replace the relief valve.
of traveling motion.		Check the valve spool movement.	Lapping or replace the spool.
Traveling motion is not smooth.	Malfunctioning of travel motor	Check the piston for sticking or get out of place.	Check the piston movement and replace the part.
		Check the motor drain oil amount.	Replace the motor.
	Malfunctioning of travel reduction unit	Check for unusual noise, temperature and vibration.	Check the shaft, gear and bearing for unusual noise and seizure.
			Repair the shaft and bearing or replace parts.
		Check the gear oil level in the reduction unit.	Replenish gear oil or replace parts.
	Defective electrical system	Check the fuse (F-15) for blowing as well as wiring.	Replace the fuse (F-15) or repair the wiring.
		Check the travel brake and low and high speed selector switch function.	Replace the switch or repair the wiring.
		Check the relay for switching and the contact points for burning mark.	Replace the relay or repair the wiring.
		Check the travel brake and low and high speed selector solenoid valve function.	Replace the solenoid valve or repair the wiring.

TROUBLESHOOTING OF TRAVELING SYSTEM

Symptom	Possible cause	Check points	Remedy
Travel brake ineffective.	Defective travel brake	Check whether the travel brake release pressure is normal or not.	Repair the travel brake valve or replace the valve.
		Check whether the pressure switch operation is normal or not.	Repair the pressure switch wiring or replace the switch.
		Check the brake disk for unusual noise and high temperature.	Check the brake disk or replace the disk.
		Check the brake valve.	Replace the brake valve.
	Defective electrical system	Check the travel brake and low and high speed selector switch works.	Replace the switch or repair the wiring.
		Check the relay for switching and the contact points for burning mark.	Replace the relay or repair the wiring.
		Check the travel brake and low and high speed selector solenoid valve function.	Replace the solenoid valve or repair the wiring.

