Grove RT530E-2

Service/Maintenance Manual







SERVICE MANUAL

This Manual has been prepared for and is considered part of -

RT530E-2

Crane Model Number


This Manual is divided into the following Sections:

SECTION 1	INTRODUCTION
SECTION 2	HYDRAULIC SYSTEM
SECTION 3	ELECTRIC SYSTEM
SECTION 4	BOOM
SECTION 5	HOIST AND COUNTERWEIGHT
SECTION 6	SWING SYSTEM
SECTION 7	POWER TRAIN
SECTION 8	UNDERCARRIAGE
SECTION 9	LUBRICATION

NOTICE

The crane serial number is the only method your distributor or the factory has of providing you with correct parts and service information.

The crane serial number is stamped on the top of the outrigger box. *Always furnish crane serial number* when ordering parts or communicating service problems with your distributor or the factory.



© 2016 Manitowoc Published 4-29-16, Control # 584-02 9

CALIFORNIA PROPOSITION 65 WARNING

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

CALIFORNIA PROPOSITION 65 WARNING

Battery posts, terminals, and related accessories contain chemical lead and lead compounds, chemicals known to the State of California to cause cancer, birth defects or other reproductive harm. Wash hands after handling.

The original language of this publication is English.

See back of this manual for Alphabetical Index

SECTION 1	Introduction
Description.	1-1
List of Specifications	1-2
General	1-2
Dimensions	1-2
Capacities	1-2
Torque Converter/Transmission	1-2
Engine	1-2
Axles	
Brakes	
Wheels and Tires	
Swing Gearbox	
Boom	
Swivel Assembly	
Hydraulic Pumps	
General Maintenance	
Cleanliness	
Removal and Installation.	
Disassembly and Assembly	
Pressing Parts.	
Locks.	
Wires and Cables	
Shims	
Bearings	
Gaskets.	
Batteries	
Hydraulic Systems	
Electrical System	
Fatigue of Welded Structures	
Fasteners and Torque Values. Weld Studs.	
Wire Rope	
General	
Environmental Conditions.	
Dynamic Shock Loads	
Precautions and Recommendations During Inspection or Replaceme	
Wire Rope Inspection (Running Ropes and Pendant Cables)	
Wire Rope Inspection (Room Extension and Retraction Cables)	
Wire Rope Inspection/Replacement (All Wire Rope)	
Seizing Wire Rope	
Installing 35x7 Class Wire Rope	
Procedures for Cutting and Preparing 35x7 Class Wire Rope	
SECTION 2 Hydra	aulic System
Description.	
Maintenance	
Hydraulic Oil Recommendations.	
Draining and Flushing.	
Removing Air from the Hydraulic System	
Parts Replacement	
Directional Control Valves.	
Supply Pressure and Return Circuit	

Description
Maintenance
Oil Cooler
Description
Hydraulic Pumps
Description
Maintenance
Pressure Setting Procedures
Procedure A - For Checking/Setting The Main Control Valve For Hoists(s), Boom
Lift and Piston Pump 2-19
Procedure B - For Setting The Outrigger/Rear Steer/Oil Cooler Motor Pressures 2-19
Procedure C - For Checking/Setting The Swing Directional Control Valve Work
Port Relief Valves 2-20
Procedure D - For Checking/Setting The Service Brake Dual Accumulator Charge
Valve Charging Limits
Procedure E - For Checking/Pre-Charging The Service Brake Accumulators 2-20
Procedure F - For Checking/Setting the Front Steer Pressure 2-21
Procedure G - For Checking/Setting the Pilot Supply Pressure 2-21
Procedure H - For Checking/Setting The Swing Brake Release Pressure 2-21
Procedure J - For Setting Threshold on Electronic Controllers
Procedure K - Setting Threshold and Max on Swing Brake Pedal 2-22
Valves
General
Directional Control Valves
Description
Maintenance
Accessory With Swing Directional Control Manifold. 2-33
Description
Maintenance
Steering Control Valve 2-35
Description
Maintenance
Tandem Brake Valve with Treadle Pedal 2-36
Description
Maintenance
Dual Accumulator Charge Valve 2-37
Description
Maintenance
Hydraulic Accumulator Service Brake
Description
Maintenance
Holding Valves 2-40 Description 2-40
Maintenance
Cross Axle Differential Lock Valve
Description
Maintenance
Outrigger Control Manifold
Description
Maintenance
Pilot Operated Check Valve
Description
Maintenance
Integrated Outrigger/Rear Steer Manifold
Description
Maintenance
Check Valves



Description	2-48
Maintenance	2-48
Range Shift/Parking Brake Valve	2-49
Description	
Maintenance	
Axle Oscillation Lockout Valve (Standard Units)	2-50
Description	2-50
Maintenance	2-50
Axle Oscillation Lockout Valve (Optional CE Units).	2-52
Description	2-52
Maintenance	2-52
Cylinders	2-54
General	2-54
Maintenance	2-54
Surface Protection for Cylinder Rods	
Lift Cylinder	
Description	2-57
Maintenance	2-57
Dual Rod Telescope Cylinder	
Description	2-60
Maintenance	
Axle Oscillation Lockout Cylinder	2-64
Description	2-64
Maintenance	
Steer Cylinder	
Description	
Maintenance	
Outrigger Extension Cylinder	
Description	2-71
Maintenance	
Outrigger jack Cylinder	
Description	2-73
Maintenance	2-73

SECTION 3

E	ECTION 3 E	lectric System
	Description	
	General	
	Alternator	
	Batteries	
	Fuse Panel	
	Relays	
	Maintenance	
	General	
	General Troubleshooting	
	Troubleshooting Swivel-Caused Electrical Problems	
	Connector Troubleshooting.	
	Troubleshooting Engine Starting Problems	
	Troubleshooting Engine Charging Problems	
	Troubleshooting Accessories	
	Alternator Replacement	
	Starter Replacement	
	Battery Replacement	
	Relay Panel Component Replacement.	
	Rocker Switch Replacement.	
	Ignition Switch Replacement.	
	Turn Signal Lever and Transmission Shift Lever Replacement	

Windshield Wiper Assembly Replacement 3-1	
Windshield Washer Assembly Replacement	13
Skylight Wiper Assembly Replacement	13
Appendix A: Crane Control System (CCS) Fault Codes	
SECTION 4Boor	m
Description	
Theory Of Operation	
Boom Extension	
Boom Retraction	
Maintenance	
Removal	
Boom Disassembly	
Remove the Base Section	
Disconnect Inner Mid Section	
Remove the Inner Mid Section	
Remove Outer Mid Section	
Remove Telescope Cylinder 4-1	
Boom Nose Sheaves	
Boom Assembly	
Install Telescope Cylinder 4-	
Install Outer Mid Section 4-1	
Install Inner Mid Section 4-1	
Connect Inner Mid Section 4-	
Install Base Section	
Boom Installation	
Functional Check 4-	
Inspection 4-	
Boom Alignment And Servicing 4-	19
Boom Extension And Retraction Cable 4-2	
Maintenance	20
Inspection	20
Extension Cable Adjustment 4-2	20
Retract Cable Adjustment 4-2	21
Telescope Circuit	
Description	
Theory Of Operation	
Maintenance	
Lift Circuit	
Description	
Theory Of Operation	
Maintenance	
Swingaway Boom Extension	
Description	
Maintenance	
Hook Block	
Description	
Maintenance	
	77
SECTION 5	nŧ
•	
Description	
Theory of Operation	
Maintenance	
Warm-up Procedure	
Removal	
Installation	-3



Functional Check	
Servicing	
Fluid Level	
Usage and Inspection	
Preventative Maintenance	
Oil Sampling	
Brake Test Procedure	
Hoist to Boom Alignment	
Preparation .	
Tools Required	
Procedure	
Piston Motor and Control Valve	
Description	
Maintenance	
Description	
Maintenance	
Hoist Drum Rotation Indicator System.	
Description	
Maintenance	
Counterweight Removal	
SECTION 6	Swing System
Description	
Theory of Operation	
Maintenance	
Troubleshooting	
Swing Motor.	
Description	
Maintenance	
Swing Gearbox And Brake	
Description	
Maintenance	
Swing Bearing	
Description	
Maintenance	
Swivels.	
Description	
Hydraulic Swivel	
Electrical Swivel	
SECTION 7	Power Train
Engine	
Description	
Maintenance	7-2
Maintenance	
Fuel System.	7-7
Fuel System Description	
Fuel System. Description Maintenance	
Fuel System Description Maintenance Air Intake System	
Fuel System. Description Maintenance. Air Intake System. Description	
Fuel System. Description Maintenance Air Intake System. Description Air Intake.	
Fuel System. Description Maintenance Air Intake System. Description Air Intake. Charge-Air Cooler System (CAC).	
Fuel System. Description Maintenance Air Intake System Description Air Intake. Charge-Air Cooler System (CAC). Exhaust System.	
Fuel System. Description Maintenance Air Intake System. Description Air Intake. Charge-Air Cooler System (CAC).	

Water Cooling System	
Description	
Maintenance	
Test Equipment	
Antifreeze/Coolant	
Radiator Removal and Installation	
Drive Train	
Description	
Maintenance	
Transmission/Torque Converter	
Description.	
Theory of Operation	
Maintenance	
Servicing Crane After Transmission/Torque Converter Overhaul	
SECTION 8	Undercarriage
Axles.	
Description	
Maintenance	
Wheels and Tires.	
Steering Systems	
Description	
Theory of Operation.	
Rear Steering System	
Hydraulic Pumps	
Front Steering Control Valve	
Integrated Outrigger/Rear Steer Manifold	
Steer Cylinders	
Rear Axle Oscillation Lockout System	
Description	
Axle Oscillation Lockout Cylinders.	
Brake System	
Theory of Operation.	
Service Brakes	
Description	
Maintenance	
Corrosion Protection	
Parking Brake Actuator.	
Description	
Maintenance	
Parking Brake	
Description.	
Park Brake Valve	
Outriggers.	
Outrigger Beam	
Extension Cylinder.	
Outrigger Control Valves	8-35



SECTION 9	Lubrication
General	
Environmental Protection.	
Lubrication Intervals	
Standard Lubricants	
Arctic Conditions Below -9°C (15°F)	
Arctic Conditions Down To -40°C (-40°F)	
Surface Protection For Cylinder Rods	
Wire Rope Lubrication	
Lubrication Points	
CraneLUBE	
Cummins Oil Registration List.	
Safety	
Steering and Suspension	
Axles	
Drive Train	
Drive Train (continued)	
Outriggers	
Turntable	
Boom	
Boom (continued)	9-21
Hoist	
Hydraulic	
Diesel Exhaust Fluid (DEF) Tank	
Carwell® Rust Inhibitor	
Protecting Cranes From Rusting	
Cleaning Procedures	
Inspection and Repair	
Application	
Areas of Application	

THIS PAGE BLANK



SECTION 1 INTRODUCTION

SECTION CONTENTS

	1-1
List of Specifications	
General	
Dimensions	
Capacities	
Torque Converter/Transmission	1-2
Engine	1-2
Axles	1-2
Brakes	1-2
Wheels and Tires	1-2
Swing Gearbox	1-2
Boom	1-2
Swivel Assembly	1-2
Hydraulic Pumps	1-3
General Maintenance	1-8
Cleanliness	1-8
Removal and Installation	1-8
Disassembly and Assembly	1-8
Pressing Parts	1-8
Locks	1-8
Wires and Cables	1-9
Shims	1-9
Bearings	1-9
Gaskets	1-9

Batteries	.9
Hydraulic Systems1-1	0
Electrical System	1
Fatigue of Welded Structures	1
Loctite	2
Fasteners and Torque Values	2
Weld Studs 1-1	6
Wire Rope	7
General	7
Environmental Conditions 1-1	7
Dynamic Shock Loads	7
Lubrication	7
Precautions and Recommendations During	
Inspection or Replacement 1-1	7
Wire Rope Inspection (Running Ropes and	_
Pendant Cables) 1-1	8
Wire Rope Inspection (Boom Extension and	~
Retraction Cables)	9
Wire Rope Inspection/Replacement (All Wire Rope)1-1	0
Seizing Wire Rope	
Installing 35x7 Class Wire Rope	. 1
Procedures for Cutting and Preparing 35x7 Class Wire Rope	1
1110 1000	•••

DESCRIPTION

This Manual provides information for the maintenance of the Model RT530E-2 Series Grove Crane.

The lift capacities are listed on the Load Chart in the cab.

The crane incorporates an all welded parallel box construction steel frame, using planetary drive axles to provide four-wheel drive. Axle steering is accomplished utilizing hydraulic steer cylinders. The engine is mounted at the rear of the crane carrier and provides motive power through a six speed forward and reverse transmission.

The carrier frame incorporates an integral fifth wheel, to which the rear axle is mounted, to provide axle oscillation. Axle oscillation lockout is automatic when the superstructure rotates from the travel position. The superstructure is capable of 360 degree rotation in either direction. All crane functions are controlled from the fullyenclosed cab mounted on the superstructure. The crane is equipped with a four-section, full power, sequenced and synchronized boom. Additional reach is obtained by utilizing an optional swingaway boom extension. Lifting is provided by a main hoist and an optional auxiliary hoist.

- **NOTE:** Throughout this manual, reference is made to left, right, front, and rear when describing locations. When operating the crane, these reference locations are to be considered as those viewed from the operator's seat with the superstructure facing forward over the front of the carrier frame.
- **NOTE:** Transportation and Lifting Decal is shown in (Figure 1-1).

LIST OF SPECIFICATIONS

General

Model	RT530E-2
Rated Capacity	. See Load Chart in cab
Drive	
Gross Weight	See Axle Weight
5	Distribution Table

Dimensions

NOTE: Dimensions listed are for a crane with all components fully retracted in the travel mode with 20.5 x 25-24 Earthmover bias ply tires.

Wheelbase 3.66 m (144 in) Overall Crane Length 12.29 m (483.7 in) Overall Crane Width 2.54 m (100 in) Overall Crane Height 3.24 m (127 in) Tail-Swing 3.66 m (144 in)
Outrigger Spread Retracted 2.39 m (7 ft 10 in) Mid Extend 4.27 m (14 ft) Fully Extended 6.10 m (20 ft)

Capacities

Fuel Tank
Specifications
Engine Lubrication System See Engine
Specifications
Hydraulic Tank (Reservoir Capacity)
Total
at Full Level
at Low Level
Expansion Space
Hoists
Swing Gearbox
Axle Planetary Hubs
Axle Differentials 9.5 I (20 pt)
Transmission (includes Torque Converter)

Torque Converter/Transmission

 Stall Ratio
 2.024:1

 Charge Pump Capacity
 70 I/min (14.5 gpm)

 @ 2000 rpm

Gear Ratios Forward/Rev

ward/Reverse	
Lo 1st	 10.07
Lo 2nd	
Lo 3rd	
Hi 1st	
Hi 2nd	 1.86
Hi 3rd	 0.80

Engine

Cummins QSB6.7

Displacement 6.7 I (409 cu in)
Firing Order
Lube Amount
Coolant System

Axles

Total Ratio.	20.06:1
Carrier Ratio	. 5.57:1
Wheel End Ratio.	. 3.60:1

Brakes

TypeHydraulic/Split system acting on all four wheels

Wheels and Tires

Swing Gearbox

Boom

Length
Retracted
Extended
Power 4 Section, Full Power
Elevation
Extensions
Fixed Offsettable 7.9 meters (26 ft)
Folding* 7.9 - 13.7 meters (26 - 45 ft)
*Extensions are offsettable at 0, 15, or 30
degrees.

Swivel Assembly

Electrical
Hydraulic
Water
Air Conditioning



Hydraulic Pumps

Pump #1

NOTE: Pump output is theoretical @ no-load engine speed.

Pump #2

Type	
Sections	
Output - @ 172.4 bar (2,500 psi) w/no load	
Section 1	

Pump #3

Туре	Gear with priority flow divider
Sections	
Output - @ 199.9 ba	r (2,900 psi) w/no load
Section 1	

Hoists

Drum Dimensions Diameter
Diameter
Length-Main
Length-Aux
Max. Permissible Line Pull (6x36)
Max. Single Line Speed 156.7 m/min (514 fpm)
Hoist Motor Displacement
Low 54.0 cm ³ (3.3 in ³) per revolution
High 39.3 cm ³ (2.4 in ³) per revolution




Table 1-1 Axle Weight Distribution Table


Description	CG From Rear Axle cm (in)	Weight kg (lb)	Front Axle kg (lb)	Rear Axle kg (lb)
	Basic Uni	it		
Maximum Axle Loads Allowed			16783 (37000)	16783 (37000)
Maximum Axle Loads Allowed while Towing			14969 (33000)	14969 (33000)
Maximum Tire Loads Allowed			15604 (34400)	15604 (34400)
Standard Carrier Assy. 4 x 4; Plus all Fluids	158.83 (62.53)	12451 (27449)	5406 (11919)	7044 (15530)
Superstructure w/Cab Plus w/Main Hoist	68.66 (27.03)	3862 (8514)	725 (1598)	3137 (6916)
Pinned on Counterweight	-119.63 (-47.10)	3817 (8416)	-1249 (-2753)	5066 (11169)
Boom Assembly; w/(2/3) Sheaves, RCL, Pivot Pins	427.43 (168.28)	5081 (11202)	5938 (13091)	-857 (-1889)
Lift Cylinder & Lower Shaft	218.29 (85.94)	587 (1293)	350 (772)	236 (521)
Complete Basic Machine				
4 x 4 chassis; Cummins QSB 6.7 Tier 4engine w/ transmission; front and rear axles; 20.5 x 25 tires; main hoist w/137 m (450 ft) of 5/8 in. 6 X 37 cable; full fuel and hydraulic oil	158.37 (62.35)	25798 (56874)	11171 (24627)	14627 (32247)
	Add To Basic Uni	it Weight		
7.9 to 13.7 m (26 to 45 ft)Tele Boom Extension	565.15 (222.50)	794 (1750)	1227 (2704)	-433 (-954)
Boom Ext. Carrier Brackets (Bolt On)	441.96 (174.00)	116 (256)	140 (309)	-24 (-53)
Auxiliary Boom Nose - Installed	916.94 (361.00)	48 (105)	119 (263)	-72 (-158)
30 metric ton (33 ton), CE Hookblock (3 sheave) Stowed in Tray	396.24 (156)	292 (644)	317 (698)	-24 (-54)
27.3 metric ton (30 ton), Hookblock Stowed in Tray	396.24 (156.00)	263 (580)	285 (628)	-22 (-48)
13.5 metric ton (15 ton), Hookblock Stowed in Tray	396.24 (156.00)	193 (425)	209 (460)	-16 (-35)
7 metric ton (7.5 Ton), Headache Ball (Swivel) - Attached to Front O/R Box	581.66 (229.00)	167 (369)	266 (587)	-99 (-218)
Storage Tray Mats	337.82 (133.00)	20 (43)	18 (40)	1 (3)
Rear Mounted Pintle Hook	-162.56 (-64.00)	5 (11)	-2 (-5)	7 (16)
Driver Controlled Differential Locks	177.80 (70.00)	19 (41)	9 (20)	10 (21)
Russian Certification Package	127.00 (50.00)	28 (61)	10 (21)	18 (40)
Air Conditioning - Carrier and superstructure components	38.10 (15.00)	44 (98)	5 (10)	40 (88)
360 Degree Swing Lock	205.74 (81.00)	29 (64)	16 (36)	13 (28)
Driver	187.96 (74.00)	113 (250)	58 (128)	55 (122)
CE Components - w/Main Hoist	10.16 (4.00)	285 (628)	8 (17)	277 (611)
CE Components - w/Main & w/Aux Hoists	15.24 (6.00)	274 (603)	11 (25)	262 (578)



RT530E-2 SERVICE MANUAL

1


Description	CG From Rear Axle cm (in)	Weight kg (lb)	Front Axle kg (lb)	Rear Axle kg (lb)
Remove: Auxiliary Hoist Cable (453 ft) of 5/8 35 x 7	-121.92 (-48.00)	-179 (-394)	59 (131)	-238 (-525)
Remove: Main Hoist Cable (450 ft) of 5/8 6 X 37	-60.96 (-24.00)	-174 (-383)	29 (64)	-203 (-447)
Add: Aux Hoist (Replace IPO Cwt With Aux Hoist and Cable)	-109.22 (-43.00)	174 (383)	-52 (-114)	225 (497)
Sub: Optional Cable on Main Hoist (453 ft of 5/8 inch 35 X 7)	-60.96 (-24.00)	5 (11)	-1 (-2)	6 (13)
Sub: Tier 3 Engine	-157.48 (-62.00)	-17 (-37)	7 (16)	-24 (-53)
Sub: 16.00 X 25 Titan Tires	182.9 (72.00)	-63 (-140)	-32 (-70)	-32 (-70)
Sub: Kessler Axles	175.26 (69.00)	-86 (-190)	-41 (-91)	-45 (-99)






		5			6 7 8514
1	Counterweight	5	Lift Cylinder	9	Front Axle
. –	Auxiliary Hoist	6	Boom Nose Sheaves	10	Hydraulic Tank
2	3				
2	Main Hoist	7	Swingaway	11	Rear Axle

1





GENERAL MAINTENANCE

These general suggestions should be helpful in following the instructions in this manual. In analyzing a system malfunction, use a systematic procedure to locate and correct the problem.

- 1. Determine the problem.
- 2. List possible causes.
- 3. Devise checks.
- 4. Conduct checks in a logical order to determine the cause.
- **5.** Consider the remaining service life of components against the cost of parts and labor necessary to replace them.
- 6. Make the necessary repair.
- 7. Recheck to ensure that nothing has been overlooked.
- 8. Functionally test the failed part in its system.
- **NOTE:** Your safety and that of others is always the number one consideration when working around machines. Safety is a matter of thoroughly understanding the job to be done and the application of good common sense. It is not just a matter of do's and don'ts. Stay clear of all moving parts.

Cleanliness

An important item in preserving the long life of the machine is keeping dirt out of working parts. Enclosed compartments, seals, and filters have been provided to keep the supply of air, fuel, and lubricants clean. It is important that these enclosures be maintained.

Whenever hydraulic, fuel, lubricating oil lines, or air lines are disconnected, clean the adjacent area as well as the point of disconnect. As soon as the disconnection is made, cap, plug, or tape each line or opening to prevent entry of foreign material. The same recommendations for cleaning and covering apply when access covers or inspection plates are removed.

Clean and inspect all parts. Be sure all passages and holes are open. Cover all parts to keep them clean. Be sure parts are clean when they are installed. Leave new parts in their containers until ready for assembly.

Clean the rust preventive compound from all machined surfaces of new parts before installing them.

Removal and Installation

When performing maintenance, do not attempt to manually lift heavy parts when hoisting equipment should be used. Never locate or leave heavy parts in an unstable position. When raising a portion of a crane or a complete crane, ensure the crane is blocked securely and the weight is supported by blocks rather than by lifting equipment.

When using hoisting equipment, follow the hoist manufacturers recommendations and use lifting devices that will allow you to achieve the proper balance of the assemblies being lifted and to ensure safe handling. Unless otherwise specified, all removals requiring hoisting equipment should be accomplished using an adjustable lifting attachment. All supporting members (chains and cables) should be parallel to each other and as near perpendicular as possible to the top of the object being lifted.

CAUTION

The capacity of an eyebolt diminishes as the angle between the supporting members and the object becomes less than 90°. Eyebolts and brackets should never be bent and should only have stress in tension.

Some removals require the use of lifting fixtures to obtain proper balance. The weights of some components are given in their respective sections of the manual.

If a part resists removal, check to be certain all nuts and bolts have been removed and that an adjacent part is not interfering.

Disassembly and Assembly

When assembling or disassembling a component or system, complete each step in turn. Do not partially assemble one part and start assembling some other part. Make all adjustments as recommended. Always check the job after it is completed to see that nothing has been overlooked. Recheck the various adjustments by operating the machine before returning it to the job.

Pressing Parts

When pressing one part into another, use an anti-seize compound or a molybdenum disulfide base compound to lubricate the mating surfaces.

Assemble tapered parts dry. Before assembling parts with tapered splines, be sure the splines are clean, dry, and free from burrs. Position the parts together by hand to mesh the splines before applying pressure.

Parts which are fitted together with tapered splines are always very tight. If they are not tight, inspect the tapered splines and discard the part if the splines are worn.

Locks

Lockwashers, flat metal locks, or cotter pins are used to lock nuts and bolts.



1

Flat metal locks must be installed properly to be effective. Bend one end of the lock around the edge of the part. Bend the other end against one flat surface of the nut or bolt head.

Always use new locking devices on components which have moving parts.

When installing lockwashers on housings made of aluminum, use a flat washer between the lockwasher and the housing.

Wires and Cables

Batteries should always be disconnected prior to working on the electrical system.

When removing or disconnecting a group of wires or cables, tag each one to ensure proper identification during assembly.

Shims

When shims are removed, tie them together and identify them as to location. Keep shims clean and flat until they are reinstalled.

Bearings

Antifriction Bearings

When an antifriction bearing is removed, cover it to keep out dirt and abrasives. Wash bearings in non-flammable cleaning solution and allow them to drain dry. The bearing may be dried with compressed air BUT do not spin the bearing. Discard the bearings if the races and balls or rollers are pitted, scored, or burned. If the bearing is serviceable, coat it with oil and wrap it in clean waxed paper. Do not unwrap new bearings until time of installation. The life of an antifriction bearing will be shortened if not properly lubricated. Dirt in an antifriction bearing can cause the bearing to lock resulting in the shaft turning in the inner race or the outer race turning within the cage.

Double Row, Tapered Roller

Double row, tapered roller bearings are precision fit during manufacture and components are not interchangeable. The cups, cones, and spacers are usually etched with the same serial number and letter designator. If no letter designators are found, wire the components together to assure correct installation. Reusable bearing components should be installed in their original positions.

Heating Bearings

Bearings which require expansion for installation should be heated in oil not to exceed 121 °C (250 °F). When more than one part is heated to aid in assembly, they must be allowed to cool and then pressed together again. Parts often separate as they cool and contract.

Installation

Lubricate new or used bearings before installation. Bearings that are to be preloaded must have a film of oil over the entire assembly to obtain accurate pre-loading. When installing a bearing, spacer, or washer against a shoulder on a shaft, be sure the chamfered side is toward the shoulder.

When pressing bearings into a retainer or bore, uniformly apply pressure to the outer race. If the bearing is pressed on the shaft, uniformly apply pressure on the inner race.

Preload

Preload is an initial load placed on the bearing at the time of assembly. Whether a tapered roller bearing should have preload could depend on any of several conditions: rigidity of the housings and shaft, bearing spread, speed of operation, etc.

To determine whether a bearing requires preload or end clearance, consult the disassembly and assembly instructions pertaining to that bearing.

Care should be exercised in applying preload. Misapplication of preload to bearings requiring end clearance can result in bearing failure.

Sleeve Bearings

Do not install sleeve bearings with a hammer. Use a press and be sure to apply the pressure directly in line with the bore. If it is necessary to drive on a bearing, use a bearing driver or a bar with a smooth flat end. If a sleeve bearing has an oil hole, align it with the oil hole in the mating part.

Gaskets

Be sure the holes in the gaskets correspond with the lubricant passages in the mating parts. If it is necessary to make gaskets, select material of the proper type and thickness. Be sure to cut holes in the right places. Blank gaskets can cause serious damage.

When removed, always install new cylinder head and manifold gaskets using recommended gasket compound on head gaskets to allow uniform sealing.

Batteries

Clean batteries by scrubbing them with a solution of baking soda and water. Rinse with clear water. After cleaning, dry thoroughly and coat terminals and connections with an anti corrosion compound or grease.

If the machine is to be stored or not used for an extended period of time, the batteries should be removed. Store the batteries in a cool (not subfreezing), dry place, preferably on wooden shelves. Never store on concrete. A small charge should be introduced periodically to keep the specific gravity rating at recommended level.

Hydraulic Systems

Exercise extreme care around pressurized hydraulic systems. Do not work on a hydraulic system while it is in operation or until all pressure is released.

Cleanliness

Contaminants in a hydraulic system affect operation and will result in serious damage to the system components. Dirty hydraulic systems are a major cause of component failures.

Keep the System Clean

When removing components of a hydraulic system, cover all openings on both the component and the crane.

If evidence of foreign particles is found in the hydraulic system, flush the system.

Disassemble and assemble hydraulic components on a clean surface.

Clean all metal parts in a nonflammable cleaning fluid. Then lubricate all components to aid in assembly.

Sealing Elements

Inspect all sealing elements (O-ring, gaskets, etc.) when disassembling and assembling the hydraulic system components. Installation of new elements is always recommended.

Hydraulic Lines

When installing metal tubes, tighten all bolts finger-tight. Then, in order, tighten the bolts at the rigid end, the adjustable end, and the mounting brackets. After tubes are mounted, install the hoses. Connect both ends of the hose with all bolts finger-tight. Position the hose so it does not rub the machine or another hose and has a minimum of bending and twisting. Tighten bolts in both couplings.

Due to manufacturing methods there is a natural curvature to a hydraulic hose. The hose should be installed so any bend is with this curvature.

Visual Inspection of Hoses and Fittings

CAUTION

Ensure that the hydraulic hose is depressurized before loosening the connections.

- 1. Visually inspect hoses and fittings once a month or every 250 hours for the following:
 - a. Leaks at hose fitting or in hose
 - b. Damaged, cut, or abraded cover
 - c. Exposed reinforcement
 - d. Kinked, crushed, flattened, or twisted hose
 - e. Hard, stiff, heat cracked, or charred hose
 - f. Blistered, soft, degraded, or loose cover
 - g. Cracked, damaged, or badly corroded fittings
 - h. Fitting slippage on hose
 - i. Other signs of significant deterioration

If any of the above conditions exist, evaluate hose assemblies for correction or replacement. For replacement of hose assemblies, refer to your Manitowoc Crane Care Parts Manual.

- **2.** At the same service interval, visually inspect all other hydraulic components and valves for the following:
 - a. Leaking Ports
 - **b.** Leaking valve sections or manifolds and valves installed into cylinders or onto motors.
 - **c.** Damaged or missing hose clamps, guard, or shields.
 - **d.** Excessive dirt and debris around the hose assemblies.

If any of these conditions exist, address them appropriately.

3. All hydraulic hose assemblies are recommended to be replaced after 8000 hours of service life.



Zone	Classification
А	Tropical Moist: All months average above 18° C. Latitude 15° - 25° North and South
В	Dry or Arid: Deficient precipitation most of the year. Latitude: 20° - 35° North and South
С	Moist Mid-Latitude: Temperature with mild winters. Latitude: 30° - 50° North & South
D	Moist Mid-latitude: Cold winters. Latitude 50° - 70° North & South
Е	Polar: Extremely cold winters and summers. Latitude: 60° - 75° North & South

- Hydraulic hose assemblies operating in a temperature climate zone "C" (Table 1-2) are recommended to be replaced after 8000 hours of service life.
- 5. Hydraulic hose assemblies operating in climate zones "A" and "B" (Table 1-2) with high ambient temperatures, could see hose service life reduced by 40 to 50%, therefore, it is recommended to replace these hoses after 4000 to 5000 hours of service life.
- 6. Hydraulic hose assemblies operating in climate zones "D" and "E" (Table 1-2) cold climates should expect a degrade of mechanical properties such as elasticity, therefore, it is recommended these hoses be inspected and addressed accordingly.

Electrical System

Connectors, Harnesses, Wires, and Connectors

Visually inspect all electrical harnesses, cables, and connectors every month or 250 hours for the following:

- Damaged, cut, blistered, or cracked insulation.
- Exposed bare wires.
- Kinked or crushed wires and cables.
- Cracked or corroded connectors, battery terminals, and ground connections.

If any the above conditions exist, evaluate and replace as necessary.

The climate in which the crane operates affects the service life of the electrical components. The climate zones are defined in Table 1-2. Recommended replacement of harness and cables is as follows:

- Climate zone C after 10,000 hours of service.
- Climate zones A and C with high ambient temperatures and duty cycles after 8000 hours of service.
- Climate zones D and E after 10,000 hours of service.
- Salt water conditions after 8,000 hours of service.

Fatigue of Welded Structures

Experience has shown that highly stressed welded structures when repeatedly subjected to varying stresses caused by twisting, shock, bending, and intentional and/or unintentional overloads, often become subject to weld cracking which may be attributed to fatigue of the welded joint. This condition is not uncommon in construction equipment.

Equipment should be periodically inspected for evidence of weld fatigue. The frequency of these inspections should be commensurate with the age of the equipment, the severity of the application, and the experience of the operators and maintenance personnel. The following are known high stress areas applicable to Manitowoc/Grove machines, and a visual inspection of these areas should be made part of an owner's planned preventive maintenance program:

- 1. Power Telescope Boom wear pad retaining structures, hydraulic cylinder attaching points, boom pivot shaft retaining structures.
- 2. Outrigger pads, beams, boxes and attachment structures.
- 3. Main frames generally in the area of doubler plates and crossmembers; at the junction of front and rear frame members on truck cranes.
- **4.** Turntable bearing connection (where bearing is welded to the crane superstructure or chassis).
- 5. Counterweight support structures.
- 6. Chassis axle and suspension mounting structures.
- 7. Hydraulic cylinder end connections.

The above is provided only as a guide, and your inspection plan should not be limited to the areas listed. A thorough visual inspection of all weldments is good practice.

Anyone requiring more detailed inspection instructions and/ or repair procedures may request them by contacting the local Manitowoc/Grove distributor.

Loctite

Loctite type adhesives contain chemicals that may be harmful if misused. Read and follow the instructions on the container.

Always follow the directions on the Loctite container as not all Loctite types are suitable for all applications.Various types of Loctite are specified throughout the Service Manual.The following types of Loctite brand adhesives are available from the Parts Department of the local Manitowoc/Grove distributor.

Application of Medium Strength Loctite

NOTE: The fastener may be re-used; the adhesive may be re-applied over cured adhesive residue.


The following procedure covers the proper application and curing method for medium strength Loctite adhesive/sealant (Loctite #243) and primer (Locquic Primer T7471).

Primer Application

NOTE: It is not necessary to bathe the threads in primer.

- 1. Ensure the threaded surface, both male and female, is clean and free of dirt and oil. Apply a light spray coating of primer to both male and female parts to be joined to clean and accelerate the curing process.
- **2.** Allow the part to dry prior to adhesive/sealant application.

Adhesive/Sealant Application



- 1. Apply a bead perpendicular to the thread, several threads wide, in the approximate area of threaded engagement (Figure 1-3).
- 2. In a blind hole application, a bead of several drops of adhesive should be applied into the bottom of the hole to be hydraulically forced up during engagement.
- **3.** After application and engagement of mated threads, fixturing will occur within five (5) minutes if primed prior

to engagement. Fixturing may take up to 30 minutes on unprimed parts.

4. Time required to achieve full strength is 24 hours. Maximum ultimate strength is achieved using no primer with this specific threadlocking adhesive.

Fasteners and Torque Values

Use bolts of the correct length. A bolt which is too long may bottom before the head is tight against the part it is to hold. If a bolt is too short, there may not be enough threads engaged to hold the part securely. Threads can be damaged. Inspect them and replace fasteners, as necessary.

Torque values should correspond to the type bolts, studs, and nuts being used.

The torque tables are provided by Manitowoc for reference when performing maintenance.

Use of proper torque values is extremely important. Improper torquing can seriously affect performance and reliability.

Identification of fastener grade is always necessary. When marked as a high strength bolt (grade 5, 8, etc.), the mechanic must be aware that he/she is working with a highly stressed component and the fastener should be torqued accordingly.

NOTE: Some special applications require variation from standard torque values. Reference should always be made to component overhaul procedures for recommendations.

Special attention should be given to the existence of lubricant, plating, or other factors that might require variation from standard torque values.

The use of lubricants on zinc-flake coated parts shall be prohibited since this will change the required torque value.

When maximum recommended torque values have been exceeded, the fastener should be replaced.

Previously installed bolts and nuts of Grade 8 or Class 10.9 and higher may not be reused.

When referring to the applicable torque charts, use values as close as possible to the torque values shown to allow for wrench calibration tolerance.

Torque Wrenches

Flexible beam type wrenches, even though they might have a pre-set feature, must be pulled at right angle and the force must be applied at the center of the handle. Force value readings must be made while the tool is in motion. Rigid handle type, with torque limiting devices that can be pre-set to required values, eliminate dial readings and provide more reliable, less variable readings.



INTRODUCTION

NOTE: If multipliers and/or special tools are used to reach hard to get at areas, ensure torque readings are accurate.

Torque wrenches are precision instruments and must be handled with care. To ensure accuracy, calibrations must be made on a scheduled basis. Whenever there is a possibility that a torque wrench may have been either overstressed or damaged, it should immediately be removed from service until recalibrated. When using a torque wrench, any erratic or jerking motion can result in the application of excessive or improper torque. ALWAYS use a slow, even movement and STOP when the predetermined value has been reached.

When using step wrenches, calculated wrench settings are valid only when the following conditions are met:

• Torque wrenches must be those specified and forces must be applied at the handle grip. The use of handle extensions will change applied torque to the bolt.


- All handles must be parallel to the step wrench during final tightening. Multiplier reaction bars may be misaligned no more than 30 degrees without causing serious error in torque.
- Multiplier bar handles must be propped or supported within the outer 1/4 of the handle length, or serious under or over tightening will occur.

To convert pounds-foot (lb-ft) of torque to newton meters (Nm), multiply the pounds-foot quantity by 1.3558.

To convert pounds-inch (lb-in) of torque to Newton meters (Nm), multiply the pounds-inch quantity by 0.11298.

Torque Values

The following tables list the torque values for both ASME standard and metric fasteners. The tables list the values for grade 5 and grade 8 zinc-flake coated, untreated (black) finish and stainless steel fasteners.: UNC (Coarse) Thread:



Torque Values for Zinc-Flake Coated and Untreated Fasteners

					DOILL	namete		ies						
	Torque Values (Pounds-Foot, Maximum/Minimum)													
	SAE Grade	1/4	5/16	3/8	7/16	1/2	9/16	5/8	3/4	7/8	1	1-1/8	1-1/4	1-1/2
Zinc-Flake	5	7	14	25	40	61	88	121	213	342	512	636	884	1532
Line Take	8	10	20	36	57	86	124	171	301	483	723	1032	1433	2488
	5	9.0	19	32	52	78	114	156	270	416	606	813	1141	2028
Untreated		7.7	17	30	48	72	106	144	249	384	560	751	1053	1865
U and U an	8	12.5	26	48	73	120	161	234	385	615	929	1342	2043	3276
	ð	11.5	24	44	67	110	143	216	355	567	857	1234	1885	3024

Bolt Diamotor - Inchos

NOTE: Studs shall be torqued using capscrew values when grade is known.

Table 1-3: UNF (Fine) Thread: Torque Values for Zinc-Flake Coated and Untreated Fasteners

Bolt Diameter - Inches	5
------------------------	---

Torque Values (Pounds-Foot, Maximum/Minimum)

	SAE Grade	1/4	5/16	3/8	7/16	1/2	9/16	5/8	3/4	7/8	1	1-1/8	1-1/4	1-1/2
Zinc-Flake	5	8	15	28	44	66	95	132	229	364	543	785	944	1654
Zinc-riake	8	11	22	39	61	94	134	186	323	514	766	1109	1530	2682
	5	10	21	36	57	88	126	182	312	458	658	882	1251	2288
Untreated	5	9	19	34	53	81	116	167	287	421	606	814	1155	2105
Untreated	9	14.5	26	53	85	125	177	250	425	672	1009	1500	2092	3640
	8	13.5	24	49	79	115	163	230	393	620	931	1380	1925	3360

NOTE: Studs shall be torqued using capscrew values when grade is known.

Table 1-4: Metric Fasteners, Coarse Thread, Zinc-Flake Coating

Bolt Diameter - Metric

							lorque	e value	S (INIII)							
Class	M4	M5	M6	M8	M10	M12	M14	M16	M18	M20	M22	M24	M27	M30	M33	M36
8.8	2.6	5.2	9.0	21.6	42.4	73.1	116	178	250	349	467	600	877	1195	1608	2072
10.9	3.7	7.5	12.5	31.5	62.0	110	170	265	365	520	700	900	1325	1800	2450	3150
12.9	4.3	9.0	15.0	36.0	75.0	128	205	315	435	615	830	1060	1550	2125	2850	3700

Table 1-5: Metric Fasteners, Coarse Thread, Untreated

Bolt Diameter - Metric

Torque Values (Nm, Maximum/Minimum)

Class	M4	M5	M6	M7	M8	M10	M12	M14	M16	M18	M20	M22	M24	M27	M30
8.8	3.1	6.5	11	19	27	53	93	148	230	319	447	608	774	1134	1538
0.0	2.8	5.9	10	17	25	49	85	136	212	294	413	562	714	1046	1420
10.9	4.5	9.2	16	26	38	75	130	212	322	455	629	856	1089	1591	2163
10.9	4.1	8.5	14	24	35	69	120	195	298	418	581	790	1005	1469	1997
12.9	5.4	11	19	31	45	89	156	248	387	532	756	1029	1306	1910	2595
12.9	4.9	10	17	28	42	83	144	228	357	490	698	949	1206	1763	2395

Table 1-6: Metric Fasteners, Fine Thread, Zinc-Flake Coating

	Bolt Diameter - Metric													
	Torque Values (Nm)													
Class	M8x1	M10x1	M10x1.25	M12x1.5	M14x1.5	M16x1.5	M18x1.5	M20x1.5	M22x1.5	M24x2	M27x2	M30x2	M33x2	M36x3
8.8	23	46	44	75	123	185	270	374	496	635	922	1279	1707	2299
10.9	34	71	66	113	188	285	415	575	770	980	1425	2025	2500	3590
12.9	41	84	79	135	220	335	485	675	900	1145	1675	2375	2900	4200



Table 1-7: Metric Fasteners, Fine Thread, Untreated

	Bolt Diameter - Metric													
	Torque Values (Nm, Maximum/Minimum)													
Class	M8x1	M10x1	M10x1.25	M12x1.5	M14x1.5	M16x1.5	M18x1.5	M20x1.5	M22x1.5	M24x2	M27x2	M30x2	M33x2	M36x3
8.8	29	57	57	100	160	248	345	483	657	836	1225	1661		
0.0	27	53	53	92	147	229	318	446	607	771	1130	1534	—	
10.9	41	81	81	1140	229	348	491	679	924	1176	1718	2336		_
10.9	38	75	75	130	211	322	451	627	853	1085	1587	2157	—	—
12.9	49	96	96	168	268	418	575	816	1111	1410	2063	2800		
12.9	45	90	90	156	246	386	529	754	1025	1302	1904	2590	—	

 Table 1-8: UNC (Coarse) Thread: Torque Values for

 Stainless Steel Fasteners with Oil Lubrication

Size	Torqu	e Value
3126	lb-in	lb-ft
#5 (0.125)	6.9	—
#8 (0.164)	18	—
#10 (0.190)	21	—
1/4	68	—
5/16	120	10
3/8	210	17.5
7/16	340	28
1/2	_	39
5/8	_	74
3/4	_	114

NOTE: Stainless steel fasteners tend to gall while being tightened. To reduce this risk, lubricate the threads with oil or molybdenum disulfide and torque at low speeds without interruptions. Do not use excessive pressure. Impact wrenches are not recommended.

 Table 1-9: Metric Coarse Thread: Torque Values for

 Stainless Steel Fasteners with Oil Lubrication

Size	Torque (Nm)
M2.5	0.4
M3	0.9
M4	1.5
M5	3.1
M6	5.3
M8	13.0
M10	27.0
M12	45.0
M14	71.1
M16	109
M18	157
M20	220

NOTE: Stainless steel fasteners tend to gall while being tightened. To reduce this risk, lubricate the threads with oil or molybdenum disulfide and torque at low speeds without interruptions. Do not use excessive pressure. Impact wrenches are not recommended.

Weld Studs

Unless otherwise specified the following grade 2 torque values (\pm 10%) apply.

Table 1-10: Weld Stud Torque Values

	STUD SIZE	TORQUE
	#10	20 lb in
	1/4"	4 lb ft
	5/16"-18	9 lb ft
	5/16"-24	10 lb ft
	3/8"	14 lb ft
	1/2"	35 Ib ft
T-2-4	5/8"	70 lb ft



General

The following information is a compendium of information from various wire rope manufacturers and includes inspection, replacement, and maintenance guidelines for wire rope as established by ANSI/ASME B30.5, federal regulations, and Manitowoc. The inspection interval shall be determined by a gualified person and shall be based on such factors as expected rope life as determined by experience on the particular installation or similar installations, severity of environment, percentage of capacity lifts, frequency rates of operation, and exposure to shock loads. Periodic Inspections need not be at equal calendar intervals and should be performed at shorter time intervals as the wire rope approaches the end of its useful life. A periodic inspection shall be performed at least once a year. The following provides inspection and maintenance procedures for wire ropes used on Grove products (e.g. wire rope used as load lines [hoisting cables], boom extension and retraction cables, pendant cables, tow winch cables, and hook block tie down cables).

Environmental Conditions

The life expectancy of wire rope may vary due to the degree of environmental hostility and other conditions to which these mechanical devices are subjected. Variation in temperature, continuous excessive moisture levels, exposure to corrosive chemicals or vapors or subjecting the wire rope to abrasive material may shorten normal wire rope life. Frequent/ periodic inspections and maintenance of your wire rope is recommended for preventing premature wear and to insure long-term satisfactory performance.

Dynamic Shock Loads

Subjecting wire rope to abnormal loads beyond the endurance limit will shorten the wire ropes, life expectancy. Examples of this type of loading are listed below.

- 1. High velocity movement e.g.; hoisting or swinging of a load followed by abrupt stops.
- 2. Suspending loads while traveling over irregular surfaces such as railroad tracks, potholes, and rough terrain.
- **3.** Moving a load that is beyond the rated capacity of the lifting mechanism, i.e.; overloading.

Lubrication

A wire rope cannot be lubricated sufficiently during manufacture to last it's entire life. Therefore, new lubricant must be added throughout the life of a rope to replace factory lubricant which is used or lost. It is important that lubricant applied as part of a maintenance program shall be compatible with the original lubricant, and to this end, the rope manufacturer should be consulted. Lubricant applied shall be of the type which does not hinder visual inspection. Those sections of rope which are located over sheaves or otherwise hidden during inspection and maintenance procedures require special attention when lubricating rope. The object of rope lubrication is to reduce internal friction and to prevent corrosion.

During fabrication, ropes receive lubrication; the kind and amount depends on the rope's size, type, and anticipated use. This in-process treatment will provide the finished rope with ample protection for a reasonable time if it is stored under proper conditions. But, when the rope is put into service, the initial lubrication may be less than needed for the full useful life of the rope. Because of this possibility, periodic applications of a suitable rope lubricant are necessary.

The following are important characteristics of a good wire rope lubricant:


- 1. It should be free from acids and alkalis.
- **2.** It should have sufficient adhesive strength to remain on the ropes.
- **3.** It should be of a viscosity capable of penetrating the interstices between wires and strands.
- 4. It should not be soluble in the medium surrounding it under the actual operating conditions (i.e. water).
- 5. It should have a high film strength.
- 6. It should resist oxidation.

Before applying lubrication, accumulations of dirt or other abrasive material should be removed from the rope. Cleaning can be accomplished by using a stiff wire brush and solvent, compressed air, or live steam. Immediately after the wire rope is cleaned, it should be lubricated. Many techniques may be used; these include bath, dripping, pouring, swabbing, painting or pressure spray methods. Whenever possible, the lubricant should be applied at the top of a bend in the rope, because at that point the strands are spread by bending and are more easily penetrated. There should be no load on the rope while it is being lubricated. It should be noted, the service life of wire rope will be directly proportional to the effectiveness of the method used and amount of lubricant reaching the working parts of the rope.


Precautions and Recommendations During Inspection or Replacement

- 1. Always lock out equipment power when removing or installing wire rope assemblies.
- 2. Always use safety glasses for eye protection.
- **3.** Wear protective clothing, gloves, and safety shoes as appropriate.
- **4.** Use supports and clamps to prevent uncontrolled movement of wire rope, parts, and equipment.

- 5. When replacing fixed length cable assemblies (e.g. pendants) having permanently attached end fittings use only pre-assembled lengths of wire rope as supplied from Manitowoc. Do not build lengths from individual components.
- 6. Replace an entire wire rope assembly. Do not attempt to rework damaged wire rope or wire rope ends.
- 7. Never electroplate wire rope assemblies.
- 8. Do not weld any wire rope assembly or component unless welding is recommended by the wire rope manufacturer. Welding spatter shall never be allowed to come in contact with the wire rope or wire rope ends. In addition, be sure that the wire rope is not an electrical path during other welding operations.
- **9.** Wire ropes are manufactured from special steels. If heating a wire rope assembly is absolutely necessary for removal, the entire wire rope assembly shall be discarded.
- **10.** On systems equipped with two or more wire rope assemblies operating as a matched set, they shall be replaced as an entire set.
- **11.** Do not paint or coat wire ropes with any substance except approved lubricants.
- **12.** Measure the rope's diameter across crowns (1) of the strands when determining if rope has become damaged (Figure 1-5).



13. When checking for broken wires (5) (Figure 1-6) relax the rope, move it off "pick-up points", and flex it as much as possible. Use a sharp awl to pick and probe between wires and strands, lifting any wire which appears loose or moves excessively. Defect in the rope is spoke of in relations to "Lay Length" (2) which is the distance measured along rope in which one strand (3) makes one complete revolution around core (4).



Wire Rope Inspection (Running Ropes and Pendant Cables)

Wire rope should be inspected frequently/dally and periodically/yearly in accordance with the following information excerpted from a National Consensus Standard as referenced by Federal Government Agencies. Recommended inspection intervals may vary from machine to machine and may vary based on environmental conditions, frequency of lifts, and exposure to shock loads. The inspection time intervals may also be predetermined by state and local regulatory agencies.

NOTE: Wire rope may be purchased through Manitowoc Crane Care.

Any deterioration observed in the wire rope should be noted in the equipment inspection log and an assessment concerning wire rope replacement should be made by a qualified person.

Keeping Records

A signed and dated report of the wire rope's condition at each periodic inspection must be kept on file at all times. The report must cover all inspection points listed in this section. The information in the records can then be used to establish data which can be used to determine when a wire rope should be replaced.

It is recommended that the wire rope inspection program include reports on the examination of wire rope removed from service. This information can be used to establish a relationship between visual inspection and the rope's actual internal condition at the time of removal from service.

Frequent Inspection

A frequent daily visual inspection is recommended for all running ropes in service. This inspection should be made on all wire rope which can be expected to be in use during the day's operation. This inspection should be used to monitor progressive degradation and to discover severe damages necessitating wire rope replacement such as:

Distortion, Kinking, Crushing, Un-stranding, Bird caging, Reduction of diameter, etc.



1

- General corrosion.
- Broken or cut strands.
- Number, distribution and type of broken wires.
- Evidence of core failure.
- End fitting wear/abrasion.

Pay particular attention to areas of the rope where wear and other damage is likely to occur:

- Pick-up Points: Sections of wire rope that are repeatedly stressed during each lift, such as those sections in contact with sheaves.
- End Attachments: The point where a fitting is attached to the wire rope or the point where the wire rope is attached to the drum.
- Abuse Points: The point where the wire rope is subjected to abnormal scuffing and scraping.

Periodic Inspection

Wire rope should be inspected periodically/annually or at a shorter time interval if necessitated by environmental or other adverse conditions, and shall cover the entire length of the wire rope. Only the outer surface of the wire rope need be inspected, and no attempt should be made to open the rope. Periodic inspection should include all items listed under frequent inspection plus the following:

- 1. Inspect for reduction of rope diameter below nominal diameter.
- **2.** Inspect for severely corroded or broken wires at end connections.
- **3.** Inspect for severely corroded, cracked, bent, worn, or improperly applied end connections.
- **4.** Inspect wire rope in areas subjected to rapid deterioration such as:
 - Sections in contact with saddles, equalizer sheaves, or other sheaves where wire rope travel is limited.
 - Sections of wire rope at or near terminal ends where corroded or broken wires may protrude.
- 5. Inspect boom nose sheaves, hook block sheaves, boom extension/jib sheaves, auxiliary boom nose sheaves, and hoist drums for wear. Damaged sheaves or hoist drums can accelerate wear and cause rapid deterioration of the wire rope.

Wire Rope Inspection (Boom Extension and Retraction Cables)

Periodic Inspection

It is recommended that a periodic inspection of all boom extension and retraction cables be performed using the

following guidelines. This inspection shall cover the entire length of the extension and retraction cables. This inspection should be used to monitor progressive degradation and to discover severe damages necessitating wire rope replacement or equipment repair. Inspection criteria are as follows:

- 1. Inspect for reduction of rope diameter below nominal diameter.
- 2. Inspect for severely corroded or broken wires at end connections.
- **3.** Inspect for severely corroded, cracked, bent, worn, or improperly applied end connections.
- **4.** Inspect wire rope in areas subjected to rapid deterioration such as:
 - Sections in contact with saddles, equalizer sheaves, or other sheaves where wire rope travel is limited.
 - Sections of wire rope at or near terminal ends where corroded or broken wires may protrude.
 - Sections of wire rope in contact with stationary surfaces where abrasion or chafing may take place as a result of equipment vibration.
- Inspect for damaged or wobbly boom extension and retraction sheaves that may cause rapid deterioration of the wire rope.
- 6. Inspect for unusual cable sag/stretch and be sure cables used in sets all have an equal tension applied. Repeated need for adjustment of an individual cable is evidence of cable stretch and indicates the need for additional and more thorough inspection in order to determine and correct the cause.

Wire Rope Inspection/Replacement (All Wire Rope)

No precise rules can be given for determination of the exact time for replacement of wire rope since many variable factors are involved. Determination regarding continued use or replacement of wire rope depends largely upon the good judgement of an appointed and qualified person who evaluates the remaining strength in a used rope after allowance for any deterioration disclosed by inspection.

Wire rope replacement should be determined by the following information excerpted from a National Consensus Standard as referenced by Federal Government Agencies and as recommended by Grove Worldwide. All wire rope will eventually deteriorate to a point where it is no longer usable. Wire rope shall be taken out of service when any of the following conditions exist:

- **1.** Kinking, crushing, bird caging, or any other damage resulting in distortion of the rope structure.
- 2. Evidence of any heat damage from any cause.

- 3. Reductions from nominal diameter of more than 5%.
- 4. In running rope, six randomly distributed broken wires in one lay or three broken wires in one strand in one lay.
- 5. In standing ropes, more than two broken wires in one lay in sections beyond end connections or more than one broken wire at an end connection.
- 6. In rotation resistant rope, two randomly distributed broken wires in six rope diameters or four randomly distributed broken wires in 30 rope diameters.
- 7. Severe corrosion as evidenced by pitting.
- **8.** Manitowoc recommends that for cable extended booms, a single damaged wire rope assembly shall require replacement of the entire set of extension cables.
- **9.** Manitowoc recommends for cable extended booms, that boom extension cables be replaced every seven (7) years.

Seizing Wire Rope


It is important to seize the ends of rotation resistant wire ropes to prevent the displacement and unraveling of the individual wires and strands at the ends. All preformed and non-preformed styles of wire rope should be seized prior to cutting. Seizings must be placed on both sides of the point where the wire rope is to be cut.

The two preferred methods for seizing wire ropes are:


Method 1

Using a length of soft annealed wire (Figure 1-7), place one end in the groove between two strands of the wire rope. Turn the long end of the annealed wire at right angles to the wire and wrap it tightly over the portion in the groove.

The two ends of the annealed wire should be twisted together tightly. Cut off the excess wire and pound the twist flat against the wire rope.




Method 2



Wind a length of soft annealed wire (Figure 1-8) around the wire rope at least seven times. The two ends should be twisted together in the center of the seizing. Tighten the seizing by alternately prying and twisting. Cut off both ends of the wire and pound the twist flat against the rope.

NOTE: Non-preformed wire rope (1) (Figure 1-9) should have three seizings (3) located on each side of the cut (4) as compared to performed wire rope (2).





Installing 35x7 Class Wire Rope

CAUTION

Any cutting of this specific wire rope is not recommended. If 35x7class wire rope must be cut for any reason, it is necessary to follow the attached instructions. Also, unlike other types of wire rope, the ends on this wire rope must be welded to retain the rotation resistant characteristics.

- 1. Unload properly and relieve any twists. Pull the rope off the shipping reel or unroll it from a shipping coil. (If done improperly, you may kink the rope, which will result in permanent damage to the rope.) Then lay the rope on the ground in direct line with the boom. This helps release any twist in the rope.
- 2. Attach rope's end to drum. Pull the rope over the point sheave and attach the end to the drum. Be sure not to remove the welded end.
- **3.** Wind rope onto drum slowly and carefully. At this point, it isn't necessary to provide additional load other than the weight of the rope being pulled across the ground.
- 4. Spool first layer tightly. It is essential on smooth-faced drums that the first layer is spooled with wraps tight and close together since the first layer forms the foundation for succeeding layers. If need be, use a rubber, lead or brass mallet (but never a steel hammer) to tap the rope in place.
- 5. Spool multiple layers with sufficient tension. It's very important to apply a tensioning load to the ropes during the rope breaking-in process. (If not, the lower layers may be loose enough that the upper layers become wedged into the lower layers under load, which can seriously damage the rope.) The tensioning load should range from 1 to 2% of the rope's minimum breaking force.
- 6. For ropes in multi-part systems: Reeve the traveling block and boom tip sheaves so the rope spacing is maximized and the traveling (hook) block hangs straight and level to help assure block stability.
- 7. Breaking in your new 35x7 class rope: After installation, you should properly break in your rope, which allows the rope's component parts to adjust themselves to your operating conditions.

With the boom fully raised and fully extended, attach a light load at the hook and raise it a few inches off the ground. Allow to stand for several minutes. Then cycle the load between the full "up" and "down" positions several times. Stand back and watch the drum winding and rope travel for any potential problems.

After making the lifts with a light load, increase the load and cycle it up and down a few times. This procedure will


train the rope and help assure smooth operation during its useful life.

Ideally, you should run these loads with reeving that lets you place the loads on the block with all rope off the drum except the last three wraps. If this is not possible, alternate methods must be used to assure proper tensioning of the rope on the drum.

Procedures for Cutting and Preparing 35x7 Class Wire Rope

35x7 class rope is a special wire rope that must be handled differently than any other rope we manufacture. One characteristic that makes this rope special is that the outer strands are not preformed. It is because of this that the following procedures for cutting and preparing 35x7 class rope must be followed:

- 1. The welded ends prepared by the manufacturer are not to be removed.
- 2. Before cutting the rope, make three separate bands with seizing strand on each side of where the cut is to be made (total of six bands for each cut). Each band is to have a minimum length of one and one half times the rope diameter. The two bands closest to the cut should be located at a distance equal to one rope diameter away from the cut. The four remaining bands should be evenly spaced at a distance equal to three rope diameters.
 - a. If a welder is available, the cut should be made with an abrasive saw. Immediately after the cut, both ends of the rope are to be cap welded so that all inner and outer strands are welded together, preventing any movement between them.
- **NOTE:** The outer strands must not be able to move with respect to the inner strands. The weld must not exceed the diameter of the rope.
 - **b.** If a welder is not available, the cut is to be made with an acetylene torch. The cut is to be made in such a way that both ends of the rope are completely fused so that all inner and outer strands are bonded together, preventing any movement between strands.
- **NOTE:** The outer strands must not be allowed to move with respect to the inner strands. The fused end must not exceed the diameter of the rope.
- **3.** Once the cuts have been completed, the seizing bands are to be left in place for shipment of the rope.
- **4.** Attach a "Do not remove welded ends" tag on each reel flange.





SECTION 2 HYDRAULIC SYSTEM

SECTION CONTENTS

Description	. 2-2
Maintenance	. 2-5
Hydraulic Oil Recommendations	. 2-5
Draining and Flushing	
Removing Air from the Hydraulic System	. 2-6
Parts Replacement	
Directional Control Valves	. 2-6
Supply Pressure and Return Circuit	. 2-8
Description	
Maintenance	. 2-9
Oil Cooler	2-13
Description	2-13
Hydraulic Pumps	2-14
Description	2-14
Maintenance	2-14
Pressure Setting Procedures	2-17
Procedure A - For Checking/Setting The Main	
Control Valve For Hoists(s), Boom Lift and Pisto	
	2-19
Procedure B - For Setting The Outrigger/Rear Steer/Oil Cooler Motor Pressures	2-10
Procedure C - For Checking/Setting The Swing	2-13
Directional Control Valve Work Port Relief Valve	s. 2-
20	
Procedure D - For Checking/Setting The Service	
Brake Dual Accumulator Charge Valve Charging	
Limits	2-20
Procedure E - For Checking/Pre-Charging the Service Brake Accumulators	2 20
Procedure F - For Checking/Setting the Front	2-20
Steer Pressure	2-21
Procedure G - For Checking/Setting the Pilot	
Supply Pressure	2-21
Procedure H - For Checking/Setting The Swing	
Brake Release Pressure	
Procedure J - For Setting Threshold on Electron	
Controllers	2-21
Procedure K - Setting Threshold and Max on	0.00
Swing Brake Pedal	
Valves	
General	
Directional Control Valves	
	2-30
Accessory With Swing Directional Control	

Manifold 2	
Description2	
Maintenance 2	
Steering Control Valve 2	
Description2	
Maintenance 2	-35
Tandem Brake Valve with Treadle Pedal 2	-36
Description	
Maintenance 2	-36
Dual Accumulator Charge Valve 2	-37
Description2	
Maintenance 2	-37
Hydraulic Accumulator Service Brake 2	
Description2	-39
Maintenance 2	-39
Holding Valves 2	-40
Description2	-40
Maintenance 2	-40
Cross Axle Differential Lock Valve 2	-41
Description2	-41
Maintenance 2	-41
Outrigger Control Manifold 2	-43
Description2	
Maintenance 2	-43
Pilot Operated Check Valve 2	
Description2	
Maintenance 2	-44
Integrated Outrigger/Rear Steer Manifold 2	
Description2	
Maintenance 2	
Check Valves 2	
Description2	
Maintenance 2	
Range Shift/Parking Brake Valve 2	
Description2	
Maintenance 2	-49
Axle Oscillation Lockout Valve	
(Standard Units)	
Description	
Maintenance	-50
Axle Oscillation Lockout Valve	
(Optional CE Units)	
Description2	-52


Maintenance 2-52	2
Cylinders 2-54	4
General	1
Maintenance 2-54	1
Surface Protection for Cylinder Rods 2-54	1
Lift Cylinder 2-57	7
Description 2-57	7
Maintenance 2-5	7
Dual Rod Telescope Cylinder 2-60)
Description 2-60)
Maintenance 2-60)

Axle Oscillation Lockout Cylinder	-64
Maintenance2	-64
Steer Cylinder	-68
Outrigger Extension Cylinder	
Description	

DESCRIPTION

This section describes the hydraulic system, the components which make up the hydraulic system, and the components dependent upon the hydraulic system for their operation. This includes descriptions of the supply pressure and return hydraulic circuit, hydraulic pumps, all hydraulic valves, and all hydraulic cylinders. Detailed descriptions and operation of individual hydraulic circuits are discussed within their individual sections as applicable. A complete hydraulic system schematic showing all options is at the back of this manual and a figure titled A.N.S.I. Graphical Symbols provides hydraulic symbol information for this section (Figure 2-1) and (Figure 2-2).





ETHOD OF OPERATION	MISCELLANEOUS		
SPRING	\sim	ROTATING SHAFT	-(
MANUAL		ENCLOSURE	
PUSH BUTTON		RESERVOIR VENTED	
PUSH – PULL LEVER	Ê_	PRESSURIZED	
PEDAL OR TREADLE	と	PRESSURE GAUGE	\mathbf{k}
MECHANICAL	Œ	ELECTRIC MOTOR	M
DETENT		ACCUMULATOR, SPRING LOADED	₹ ,
PRESSURE COMPENSATED		ACCUMULATOR, GAS CHARGED	P
SOLENOID, SINGLE WINDING		HEATER	
REVERSING MOTOR	@ {	COOLER	\rightarrow
PILOT PRESSURE REMOTE SUPPLY		TEMPERATURE CONTROLLER	
INTERNAL SUPPLY		FILTER, STRAINER	



MAINTENANCE

Hydraulic Oil Recommendations.

For the hydraulic oil specifications, refer to Section 9 - LUBRICATION.

Draining and Flushing

If a component has been changed because of a failure that might allow metal or abrasive particles to enter the system, all systems must be thoroughly checked, drained, and flushed.

- 1. Remove the reservoir drain plug. Allow about three minutes after hydraulic oil stops flowing from the drain port for the side walls to drain.
- 2. Clean and install the reservoir plug and fill the reservoir with a 50/50 mixture of fuel oil and clean hydraulic oil.
- **3.** Cycle the crane through all functions several times. Then return the crane to its stowed position and turn the front and rear wheels to the extreme left. Shut down the engine.
- 4. Remove the reservoir drain plug and drain the reservoir. Clean and install the drain plug and fill the reservoir with clean hydraulic oil.

CAUTION

Hydraulic oil supply lines must be connected to the cylinders when flushing the system.

- **NOTE:** Draining the various components will be aided by connecting a drain line in place of the disconnected return line.
- 5. Disconnect the return line from the lift cylinder and raise the boom to maximum elevation.
- 6. Connect the cylinder return line and lower the boom to its stowed position. Replenish the reservoir hydraulic oil level as required.
- **7.** Disconnect the return line from an outrigger extension cylinder and fully extend the outrigger.
- 8. Connect the outrigger return line and retract the outrigger. Replenish the reservoir hydraulic oil level as necessary.
- 9. Repeat Steps 7 and 8 for the remaining outriggers.

CAUTION

When draining the outrigger cylinders, always operate either both front or both rear cylinders together to prevent twisting the crane.

- **10.** Disconnect the return lines from a pair of outrigger jack cylinders and activate the cylinders to their maximum down positions.
- **11.** Connect the return lines and raise the outrigger jack cylinders to the stowed position. Replenish the reservoir hydraulic oil level as necessary.
- **12.** Repeat Steps 10 and 11 for the remaining two outrigger cylinders.
- **13.** Disconnect the return line from the telescope cylinder and fully extend the boom.
- **14.** Connect the return line and retract the boom. Replenish the reservoir hydraulic oil level as necessary.
- **15.** Disconnect the return lines from both front steer cylinders and turn the front wheels to the extreme right.
- **16.** Connect the return lines and turn the front wheels to the extreme left and then back to center. Replenish the reservoir hydraulic oil level as necessary.
- 17. Repeat Steps 15 and 16 for the rear steering cylinders.
- **18.** Raise the crane on outriggers.
- **19.** Disconnect the line from port A of the axle lockout valve.
- **20.** Using a jack under the rear wheel on one side of the crane, jack up the wheel to maximum travel.
- **21.** Connect the line to port A of the axle lockout valve and disconnect the line from Port B.
- 22. Repeat step 19 using the other rear wheel.
- **23.** Connect the line to port B of the axle lockout valve. Energize the axle lockout valve. Replenish the reservoir hydraulic oil level as necessary.
- **24.** Disconnect the return line from the main hoist motor and fully hoist up the hoist.
- **25.** Connect the return line to the main hoist motor and fully hoist down the hoist, then hoist up again. Replenish the reservoir hydraulic oil level as necessary.
- **26.** Repeat Steps 24 and 25 for the auxiliary hoist as necessary.
- **27.** Disconnect one of the lines from the swing motor and drive the motor in the direction it will go.
- **28.** Connect the line to the swing motor, then drive the swing motor in the opposite direction until the boom is centered and forward. Replenish the reservoir hydraulic oil level as necessary.

CAUTION

When hydraulic oils are changed or added, ensure that hydraulic oils of different manufacturers are of the same specifications. Discoloration may occur.

When hydraulic oils are changed, recheck the reservoir hydraulic oil level after brief system operation and add hydraulic oil as required. Ensure the crane is level and in the travel mode of operation when the hydraulic system is being filled. The system must be filled with all cylinders retracted. Fill the reservoir to the full mark on the reservoir sight gauge. After the reservoir is filled, operate all circuits and recheck the reservoir sight gauge. Add hydraulic oil as required.

Removing Air from the Hydraulic System

Air entering the hydraulic oil will normally be removed automatically by passage of the hydraulic oil over the baffles in the hydraulic reservoir. If a component has been replaced, the reservoir level is too low, or a leak develops in the suction lines to the pumps, air can enter the system. If air becomes entrapped in the hydraulic oil, it may be detectable in pumps and motor operated components such as the swing mechanism and hoist(s), because it can cause these units to become noisy during operation. If noisy operation occurs, first check the level of the hydraulic reservoir and replenish as necessary. Then inspect for leaks in the suction lines leading to the pumps.

Minute leaks may be hard to locate. If a leak is not readily detectable, use the following way to check for it:

- Seal all normal openings in the hydraulic system and the reservoir. Using a positive means to control the pressure (like a regulator), pressurize the hydraulic system to 13.8 to 27.6 kPa (0.14 to 0.28 bar) (2 to 4 psi) and inspect all joints and fittings for evidence of leaks. A soap solution applied to the fittings and joints may also prove helpful in detecting minute leaks while the system is pressurized. Remove the pressure, repair any leaks found, and reopen any openings (such as a vent) closed for inspection. Refill the reservoir after completing any repairs or service. Operate all hydraulic circuits several times in both directions.
- This action should return any entrapped air to the reservoir where it can be removed from the hydraulic oil by the baffles.



To avoid death or serious injury, locate the machine on a firm supporting surface and position the boom over the front on outriggers when extending the boom at low angles.

• To remove entrapped air from telescope cylinders, lower the boom to below horizontal and fully telescope the boom in and out several times.

If the air is not readily removed, lower the boom to below horizontal, extend the telescope cylinders as far as practicable, and allow the boom to remain in this position overnight. This should allow entrapped air to find its way to the holding valve so that telescoping the boom IN the next morning should force the air back to the reservoir. Ensure the boom is first telescoped IN (not OUT) in the morning. Telescoping OUT may cause air to be forced back into a cylinder.



Pressurized fluid can cause serious injury or death. Extreme care must be used when removing any plugs or restrictions from a hydraulic system suspected to have entrapped air that may be pressurized.

 Entrapped air may be removed from cylinders having wet rods by cycling. On certain cylinders, a plugged port is provided on the rod end to bleed off entrapped air.



Pressurized fluid can cause serious injury or death. Do not attempt to loosen fittings in pressurized lines or while the hydraulic pumps are in operation.

- In the event that air entrapment should persist, bleeding of air by loosening various clamp and screw type fittings may become necessary.
- If the above procedures fail to eliminate air entrapment, contact your authorized Grove Distributor.

Parts Replacement

Parts found damaged or out of tolerance when maintenance is being performed should be replaced. Refer to the Manitowoc Crane Care Parts Catalog for proper replacement parts.

Directional Control Valves

The control valves that control the crane functions are installed on the right side on the outside of the superstructure side plate, and between the left and right superstructure side plates under the main hoist.

Inspection

Inspect the control valves for visible damage, binding spools, and evidence of leakage. If excessive internal leakage is suspected during operation with a spool in its center position, it is possible that the area between the spool and working section bore of the valve body is worn beyond serviceable



limits. If this condition exists, the spool and body must be replaced as an assembly.

Valve Leakage

Dripping hydraulic oil indicates some type of external leakage. The machine should be removed from service for immediate repairs. External leaks sometimes develop at fittings and seals. Seals may be damaged by temperatures that are too high, or by dirt or paint accumulation on the spool. Damaged or torn seals must be replaced.

A component functioning at reduced efficiency may indicate that the control valve for that component is leaking internally. If preliminary check-out reveals that adequate volume is being supplied to the affected valve bank, relief valves are properly adjusted, and the component is not at fault, check the valve for scored or worn parts. Scoring is a sign of the number one problem in hydraulics - contamination (external contamination by dust or internal contamination by debris from deteriorating components or oxidized hydraulic oil). Scored or severely worn valve components must be replaced.

Check valves in the control valves are designed to permit a flow of hydraulic oil in one direction only. If a piece of dirt or rust has worked its way into the check valve and lodges between the poppet and seat, it will keep the valve open and allow a return flow of hydraulic oil. The remedy is to clean the valve, but it is also a good idea to follow through and ensure the hydraulic system filter is still serviceable.

Binding Spools

Some of the most common causes for stiff spool movement or jammed spool action are system overheating, excessive pressure, contaminated or deteriorated hydraulic oil, or warped mountings. When scorched, deteriorated hydraulic oil or contamination is the cause, flushing the system and replenishing with clean hydraulic oil may solve the problem. If the spool bores are badly scored or galled, the valve must be removed for servicing.

Warping occurs when mounting plates are not level or they become distorted from machine damage. As mentioned previously, the valve can be shimmed level.

Also, check the valve for rust. Rust or dirt collecting on the valves can prevent free movement of the spool, and keep it from the true center position. Excessive system pressure can create both internal and external leaks in valves that are otherwise sound. Only qualified technicians using the correct equipment should make pressure adjustments when pressure adjustments are needed.

SUPPLY PRESSURE AND RETURN CIRCUIT

Description

The supply pressure and return circuit is made up of several circuits which route hydraulic oil from the hydraulic pumps to the directional control valves for the individual operating circuits. The supply pressure and return circuit consists of the reservoir and integral filter, three hydraulic pumps, a hydraulic oil cooler, and a 12-port hydraulic swivel. Refer to HYDRAULIC PUMPS in this section for descriptions and maintenance instructions for each hydraulic pump. Refer to Section 6 - SWING for description and maintenance instructions for the 12-port hydraulic swivel.

The supply pressure and return circuit uses Ports 5 and 6 for pump supply and the dual Port 4 for return. Each operating circuit's description and components begin with the circuit's directional control valve.

Hydraulic Reservoir and Filter

The reservoir (Figure 2-3), attached to the right side of the carrier frame, has a capacity of 442.3 I (116.8 gal) total, 395.9 I (104.6 gal) to the full mark. The all-steel reservoir has an internally mounted full-flow filter and integral baffles that help cool the hydraulic oil and prevent hydraulic oil foaming.

Hydraulic oil flows through two tubes at the rear of the reservoir to the two hydraulic pumps. Almost all of the return flow goes through the filter at the top of the reservoir. The return line that goes directly into the reservoir (instead of through the filter) is from the No. 10 port (drain) of the 12-port swivel.

A magnetized drain plug in the bottom of the reservoir collects metal particles from the hydraulic oil if it becomes contaminated.

A sight gauge is located on the front of the reservoir to indicate hydraulic oil level.

1. A breather/fill cap located on the top of the reservoir allows air to enter or exhaust the reservoir. It consists of a breather, fill neck, gaskets and strainer. It is important that the breather be kept clean to prevent damage to the reservoir. The breather/fill cap also provides for filling the reservoir.

A large access cover on top of the reservoir provides for cleaning. The access cover can also be used to fill the reservoir after it has been completely drained. An oil temperature gauge is located on the lower front of the reservoir to indicate oil temperature.

The hydraulic oil filter (Figure 2-4) is located in the top of the reservoir. The filter housing contains a replaceable filter element. Returning hydraulic oil flows through the filter head, through the filter element and into the reservoir.

An element condition indicator on the filter head indicates when to change the filter element. When back pressure caused by a dirty filter element exceeds 172.3 kPa/1.72 bar (25 psid), the filter head's bypass feature functions to allow the hydraulic oil to bypass the filter element and flow into the reservoir through the bypass outlet instead. A bypass filter screen prevents gross contamination from passing through the filter even during bypass. Refer to Return Hydraulic Filter for filter changing instructions.

Pump Distribution

Pump No. 1 is mounted off drive pads of the torque converter. Pump No. 2 is mounted on the left front side of the engine.

Pump No. 1

Pump No. 1 is a variable displacement axial piston pump with a maximum displacement of $112 \text{ cm}^3/\text{rev}$ (6.83 in³/rev). The pump differential or standby pressure is 2413 kPa/24 bar (350 psi). Pump No. 1 supplies oil to the integrated outrigger/rear steer valve, boom lift, telescope, hoist, brakes and pilot functions.

Pump No. 2

Pump No. 2 is a single positive displacement gear pump with a displacement of $39 \text{ cm}^3/\text{rev}$ (2.40 in³/rev) delivering a theoretic flow of 84 lpm (21.9 gpm). Pump No. 2 supplies oil to the front steer and swing circuits.

Pump No. 3


Pump No. 3 is a single positive displacement gear pump with a displacement of 19 cm³/rev (1.16 in³/rev) delivering a theoretic flow of 57.2 lpm (10.6 gpm). Pump No. 3 supplies oil to the transmission oil cooler fan motor.



Maintenance


Troubleshooting

Symptom	Probable Cause	Solution
1. No hydraulic o	a. Low hydraulic oil level.	a. Fill reservoir.
flows in systems.	 b. Reservoir-to-pump suction lines broken or restricted. Air entering at suction lines. Pump not priming. 	b. Clean, repair, or replace lines as necessary. Check lines for security, absence of cracks, and proper attachment. Tighten, repair, or replace parts as necessary.
	c. Pump shaft sheared or disengaged.	c. If drive shaft is damaged or sheared, remove and repair or replace as necessary
	d. Internal contamination.	d. Drain, flush with recommended oil mixture, then drain and refill system with recommended hydraulic oil.
2. Slow response.	a. Low hydraulic oil level.	a. Fill reservoir.
	b. Hydraulic oil temperature too high (watery thin oil) or too low (thick sluggish oil).	 b. If too low, warm up system. As needed, troubleshoot cooler circuit. If too high, troubleshoot cooler circuit. Likely suspects are in-line check valve and related hydraulic circuits.
	c. Faulty pump section(s).	c. Repair or replace pump section(s) or entire pump.
3. Pump noise	a. Low hydraulic oil level.	a. Fill reservoir.
accompanied by hydraulic oil	b. Excessive engine speed.	b. Regulate engine speed.
foaming in reservoir.	c. Air entering at suction lines.	c. Check all lines for security and proper repair. Tighten, repair, or replace as needed.
4. Excessive pressure buildup.	a. System relief valve set too high.	 a. Using adequate pressure gauge, adjust system relief valve as necessary.
	b. Restricted pump-to-control valve supply line.	 b. Clean, repair, or replace line as necessary.
5. Specific hydraulic	a. Leak in system.	a. Repair leak.
system (lift, hoist, telescope, swing)	b. Faulty electric controls/signals.	b. Adjust or replace controls signals.
not working.	c. Faulty directional control valve.	c. Replace valve.
	d. Poorly adjusted control in circuit.	 d. Troubleshoot circuit with schematic. Adjust hydraulic component per schematic.
	e. Faulty hydraulic cylinder, motor, or valve.	e. Replace faulty component.



1	Access Cover	7	Hex Locknut
2	Breather/Fill Cap	8	Flatwasher
3	Return Line Filter	9	Thermometer (Temperature Gauge)
4	Reservoir	10	Ladder
5	Sight Gauge	11	Magnetic Plug
6	Capscrew		





1	Capscrew	8	Filter Head
2	Washer	9	Gauge
3	Сар	10	O-ring
4	O-ring	11	Element
5	Bypass Valve	12	Bowl
6	Spacer	13	Gasket
7	Capscrew		

Return Hydraulic Filter Assembly

Element Removal



Ensure that all hydraulic systems are shut down and the pressure is relieved.

- 1. Shut down all hydraulic systems.
- 2. Wipe any dirt from the filter head and cap assembly.
- **NOTE:** The bypass valve assembly is installed to the cap and is removed with the cap.
- **3.** Remove the four bolts securing the cap assembly to the filter head. Remove the cap and bypass valve assembly.
- 4. Remove the filter element from the filter bowl (housing).
- 5. Ensure the new filter element is correct by comparing their part numbers with the part numbers of the used element.
- 6. Discard the element.

Element Installation

- 1. Place a new element into the filter bowl (housing).
- 2. Install new O-ring in the cap assembly.
- **3.** If by-pass valve was removed from cap, install by-pass capscrews to cap.
- 4. Install cap assembly on filter head and secure with the four bolts. Torque bolts 14.9 Nm ±2.7 (11.00 lb-ft ±2.0) until the gasket starts to bulge slightly. Do not over torque. Torque bolt in a criss-cross pattern.
- 5. Activate the hydraulic system and check for leaks. make repairs as necessary.

Hydraulic Reservoir Removal

1. Remove the capscrews, flatwashers, lockwashers and hex nuts securing the reservoir to the fame. Using a suitable lifting device, remove the reservoir.

Hydraulic Reservoir Installation

1. Using a suitable lifting device, install the reservoir to the frame and secure with the capscrews, flatwashers, lockwashers and hex nuts. Torque the capscrews. Refer to *Fasteners and Torque Values*, page 1-12.



OIL COOLER

Description


An air cooled hydraulic oil cooler (Figure 2-5) is installed on the rear of the superstructure behind the hoists.

When the oil temperature reaches 48.8° C (120° F), the normally closed temperature switch opens to turn on the oil cooler electric motor which drives the oil cooler fan.

The oil cooler fan pulls cool air through the cooling fins on the cooler. Normally, most hydraulic oil from components is routed through the oil cooler by way of a return line and on to

the filter in the reservoir. When several hydraulic functions are being used at one time (i.e., hoisting, lifting, and telescoping), more oil has to flow through this return line, causing a pressure buildup. When this pressure reaches 206.8 kPa/2.0 bar (30 psi), the normally closed check valve in the return line (in parallel with the return line through the hydraulic oil cooler) will open, letting some hydraulic oil bypass the hydraulic oil cooler and flow directly into the reservoir filter.

When fewer functions are being used, the pressure in the system will decrease below 206.8 kPa/2.0 bar (30 psi) and the check valve will close again.



ltem	Description
1	Flatwasher
2	Lockwasher
3	Capscrew
4	Hex Nut

ltem	Description	
5	Mounting Bracket	
6	Mounting Bracket	
7	Shield Plate	
8	Oil Cooler	

2

HYDRAULIC PUMPS

Description

Pump No. 1 is mounted off drive pads of the torque converter. Pump No. 2 is mounted on the left front side of the engine (Figure 2-6).

Pump No. 1

Pump No. 1 is a variable displacement axial piston pump with a maximum displacement of 112 cm³/rev. (6.83 in³/rev). The pump differential or standby pressure is 2413 kPa/24 bar (350 psi). Pump No. 1 supplies oil to the integrated outrigger/rear steer valve, boom lift, telescope, hoist, brakes and pilot functions.

Pump No. 2

Pump No. 2 is a single positive displacement gear pump with a displacement of $39 \text{ cm}^3/\text{rev}$. (2.40 in $^3/\text{rev}$) delivering a theoretic flow of 84 lpm (21.9 gpm). Pump No. 2 supplies oil to the front steer and swing circuits.

Pump No. 3

Pump No. 3 is a single positive displacement gear pump with a displacement of $19 \text{ cm}^3/\text{rev}$. (1.16 in $^3/\text{rev}$) delivering a theoretic flow of 57.2 lpm (10.6 gpm). Pump No. 3 supplies oil to the transmission oil cooler fan motor.

Maintenance

No. 1 Pump Removal

CAUTION

Absolute cleanliness is essential when working on the hydraulic pumps. Always work in a clean area. The presence of dirt and foreign materials in the system can result in serious damage or inadequate operation.

- 1. For ease of removal, gain access to the pump by removing the engine hood. The pump is bolted to the engine's torque converter.
- **2.** Tag and disconnect the supply line from the pump. Cap or plug the line and port.
- **3.** Tag and disconnect the pump distribution lines from the pump. Cap or plug the lines and ports.

CAUTION

When removing the pump, keep the pump as level as possible to avoid damaging the input spline.

- **NOTE:** Charge pump and two studs must be removed for wrench access to piston pump mounting bolts.
- 4. Remove the capscrews and washers attaching the pump to the drive pad on the torque converter. Remove the pump.
- 5. Clean the gasket material from the drive pad on the torque converter.
- 6. Cover the drive pad's opening to prevent dirt from entering.

No. 1 Pump Installation

- 1. Install new gasket material to the pump mounting flange.
- 2. Install pump on torque converter drive pad with capscrews and washers. Make sure the splines mesh properly. Torque capscrews 292 to 317.2 Nm (216 to 234 ft-lb).
- 3. Replace the charge pump and studs.
- 4. Connect the distribution and supply lines as tagged during removal.

No. 2 Pump Removal

CAUTION

Absolute cleanliness is essential when working on the hydraulic pumps. Always work in a clean area. The presence of dirt and foreign materials in the system can result in serious damage or inadequate operation.

- **1.** For ease of removal, gain access to the pump by removing the engine hood.
- 2. Tag and disconnect the supply line from the pump. Cap or plug the line and port.
- **3.** Tag and disconnect the pump distribution line(s) from the pump. Cap or plug the line(s) and port.

CAUTION

When removing the pump, keep the pump as level as possible to avoid damaging the input spline.

- 4. Remove the capscrews and washers attaching the No. 2 pump to the drive pad on the torque converter. Remove the pump.
- **5.** Remove the gasket material from the drive pad on the torque converter.
- 6. Cover the drive pad's opening to prevent dirt from entering.



No. 2 Pump Installation

- 1. Install new gasket material to the pump mounting flange.
- 2. Install pump on to left front of engine with capscrews and washers. Make sure gear teeth mesh properly. Torque capscrews to 85 to 93 Nm (63 to 69 pounds-foot).
- **3.** Connect the distribution and supply lines as tagged during removal.

CAUTION

Do not feed hot hydraulic oil into a cold pump. This may cause the pump to seize.

No. 3 Pump Removal

CAUTION

Absolute cleanliness is essential when working on the hydraulic pumps. Always work in a clean area. The presence of dirt and foreign materials in the system can result in serious damage or inadequate operation.

- 1. For ease of removal, gain access to the pump by removing the engine hood.
- 2. Tag and disconnect the supply line from the pump. Cap or plug the line and port.
- **3.** Tag and disconnect the pump distribution line(s) from the pump. Cap or plug the line(s) and port.

CAUTION

When removing the pump, keep the pump as level as possible to avoid damaging the input spline.

- 4. Remove the capscrews and washers attaching the No. 3 pump to the No. 1 pump. Remove the pump.
- 5. Remove the gasket material from the drive pad on the No. 1 pump.
- 6. Cover the drive pad's opening to prevent dirt from entering.

No. 3 Pump Installation

- 1. Clean and prime the mounting surfaces with Loctite 7649 primer.
- **2.** Apply Loctite 518 sealant to the pump mounting flange.
- **3.** Install pump on to pump No. 1 with capscrews and washers. Make sure gear teeth mesh properly. Torque capscrews to spec listed in *Fasteners and Torque Values*, page 1-12.

4. Connect the distribution and supply lines as tagged during removal.

CAUTION

Do not feed hot hydraulic oil into a cold pump. This may cause the pump to seize.

Testing After Rebuild or Replacement

1. Operate the pump for at least two minutes at zero pressure and moderate speed (not over 1500 rpm).

CAUTION

If the pump becomes hot to the touch, it is binding and may seize. Stop engine, disassemble pump, and repair it so it will not bind.

- 2. Touch pump to verify it has not become hot from binding. Listen for abnormal noises indicating low hydraulic oil level or internal pump problems. If the pump appears to be operating satisfactorily, increase the rpm by steps, until reaching governed rpm. Operate pump about five minutes while checking for proper operation and leakage. Fix leaks; make repairs as needed.
- **3.** Cycle the components the pump powers to verify the pump drives them all properly.

Hydraulic Gear Pump Start-up Procedure

- 1. Ensure the reservoir is filled with the proper hydraulic fluid to the high level mark on the reservoir sight gauge.
- 2. Ensure no air is entering the pump inlet, and that the pump suction or inlet fluid is not bleeding back to the reservoir when the engine is stopped, by making sure all suction or inlet lines are air tight.
- **NOTE:** The following step can be done before the pump is installed by removing the plastic cap from "T1" port, and checking to ensure "T2" port on the opposite side of the pump is plugged. Fill housing full of hydraulic oil through "T1" port. Re-install the plastic cap and then install the pump.
- Remove adapter and hose from "T1" port, and check to ensure "T2" port on the opposite side of the pump is plugged. Fill housing full of hydraulic oil through "T1" port. Re-install the adapter and hose into the "T1" port.
- 4. Start the engine.
 - a. Idle engine for two to three minutes with no functions actuated. Check for leaks and repair if required. Lay hand on pump to check for excessive heat build-up. If the pump section is too hot to keep your hand on, stop immediately. If the pump makes excessive noise, air is probably entering the pump

keeping it from priming. If this occurs, stop engine, and inspect all connections of the suction hose/tube for a loose connection, or a missing or damaged Oring. Re-start the engine and run until the pump takes prime for a maximum of 30 seconds. If the pump does not prime in 30 seconds, stop the engine and repeat until the pump primes.


- **b.** Increase the RPM to 1500-1800 for 1 to 2 minutes with no functions actuated and make checks again as outlined in step a. Incrementally increase throttle to full RPM and then cycle the functions that the pump supples to verify proper speed. Verify pump flow.
- **5.** Check pressure settings. Refer to PRESSURE SETTING PROCEDURES in this section.

Piston Pump Start-up Procedure

- **1.** Ensure the reservoir is filled with the proper hydraulic fluid to the high level mark on the reservoir sight gauge.
- 2. Ensure no air is entering the pump inlet, and that the pump suction or inlet fluid is not bleeding back to the reservoir when the engine is stopped, by making sure all suction or inlet lines are air tight.
- 3. Remove the case drain hose and adapter from port DR on the pump (Figure 2-7), and fill housing with the same


hydraulic oil that was used to fill the hydraulic reservoir to the bottom of the O-ring case drain port. Install the case drain adapter and hose.

- 4. Start the engine.
 - a. Idle engine for two to three minutes with no functions actuated. Check for leaks and repair if required. Lay hand on pump to check for excessive heat build-up. If the pump section is too hot to keep your hand on, stop immediately. If the pump makes excessive noise, air is probably entering the pump keeping it from priming. If this occurs, stop engine, and inspect all connections of the suction hose/tube for a loose connection, or a missing or damaged O-ring. Re-start the engine and run until the pump takes prime for a maximum of 30 seconds. If the pump does not prime in 30 seconds, stop the engine and repeat until the pump primes.
 - Increase the RPM to 1500-1800 for 1 to 2 minutes with no functions actuated and make checks again as outlined in step a. Incrementally increase throttle to full RPM and then cycle the functions that the pump supples to verify proper speed. Verify pump flow.
- 5. Check pressure settings. Refer to Pressure Setting Procedures (pg 2- 17) in this section.



1	Pump No. 1 - Piston Pump	4	Transmission
2	Pump No. 2 - Gear Pump	5	Engine
3	Pump No. 3 - Gear Pump		





PRESSURE SETTING PROCEDURES

The following procedures should be used to properly check, adjust and set the hydraulic system pressures.

NOTE: A Digital Pressure Gauge and accessories may be purchased through Manitowoc Crane Care.

The following equipment is required for checking the hydraulic pressure settings.

- Pressure Gauge
- Three dial gauge 0-34.5 MPa (0-5000 psi)
- Pressure check diagnostic quick disconnect Grove P/N 9999101806 and straight adapter fitting 7447040401
- ORFS reducers as required to attach work port hoses to the gauge.

NOTE: When checking the directional control valve relief settings, unless otherwise specified, start with the engine at idle RPM and move the controller to its fully stroked position. Then slowly accelerate the engine to the specified RPM. Read gauge and make adjustments to specified setting.

When checking the outrigger relief valve setting, start with the engine at idle RPM and activate and hold the extend switch. Then slowly accelerate the engine to the specified RPM. Read gauge and make adjustment as required.

NOTE: GP (gauge Port) and number corresponds to gauge ports on the valve and on the hydraulic schematic.

Table 2-1Valve Pressure Setting Table

Valve To Be Set	Pressure Setting PSI (MPa)	Tolerance PSI (MPa)	Adjustment Location
Hoist (s), and Lift Pressure Setting	4000 (27.6)	± 50 (0.4)	GP2 - Superstructure mounted main directional control valve load sense relief valve (Figure 2-9)
Telescope Extend Pressure Setting	3500 (24.1)	± 50 (0.4)	GP7 - Superstructure mounted main directional control valve port relief valve (Figure 2-10)
Telescope Retract Pressure Setting	3250 (22.4)	± 50 (0.4)	GP7 - Superstructure mounted main directional control valve port relief valve (Figure 2-10)
Outrigger Extend/Retract/Rear Steer/Oil Cooler Motor Pressure	2500 (17.3)	± 50 (0.4)	GP2 - Carrier mounted outrigger control manifold (Figure 2-11)
Swing Left and Right Work Port Relief Pressures	2100-2450 (14.5 - 16.9)	See Range	GP1 - Superstructure mounted accessory manifold with swing directional control valve (Figure 2-9)
Front Steer Pressure Setting	2500 (17.3)	± 50 (0.4)	GP5 - Superstructure mounted accessory manifold with swing directional control valve (Figure 2-9)
Swing Brake Supply Pressure Setting	250 - 275 (1.7 - 2.1)	See Range	GP4 - Superstructure mounted accessory manifold with swing directional control valve (Figure 2-9)
Pilot Supply Pressure Setting	2500 - 2550 (17.3 - 17.6)	See Range	GP3 - Superstructure mounted accessory manifold with swing directional control valve (Figure 2-9)
Non-CE Cranes Piston Pump ΔP Pressure Setting	325 - 400 (2.2 - 2.8)	See Range	GP2 - Carrier mounted piston pump (Figure 2-13)
CE Cranes Piston Pump Δ P Pressure Setting	525 - 550 (3.6 - 3.8)		(Figure 2-13)
Service Brake High Charge Limit	2320 (16.0)	+72, -145 (0.5) (1.00)	GP7 (Figure 2-10) Non-adjustable
Service Brake Low Charge Limit	1950 (13.5)	±145 PSI (1.00)	GP7 - (Figure 2-10) Non-adjustable
Service Brake Accumulator Pre-charge	800 - 850 (5.5 - 5.8)	See Range	Accumulator (Figure 2-12)



NOTE: Procedures A through H in the following text correlate with Figures 2-6 through 2-10.

Procedure A - For Checking/Setting The Main Control Valve For Hoists(s), Boom Lift and Piston Pump

NOTE: Procedure A for max. and Δ P settings.

Set hoist(s) and boom lift as follows:

- Install pressure check diagnostic quick disconnect with gauge onto test nipple @ the G2 Port of the accessory manifold with swing directional control valve (Figure 2-9).
- 2. Assure piston pump cut-off max.(Figure 2-13) factory setting is correct. Loosen the jam nut on the cut-off max adjusting screw and turn it in until it softly seats or bottoms out. Then back the adjusting screw out 1/4 to 1/2 turn and lock in place with jam nut. This will ensure that full system pressure of 27.6 MPa (4000 psi) can be obtained in step #4.
- 3. Assure piston pump △P (stand-by) factory setting is correct. With diagnostic quick disconnect still installed @ the GP2 port of the accessory manifold with swing directional control valve (Figure 2-9), start engine and @ idle RPM adjust the piston pump differential setting screw "in" to increase or "out" to decrease so that a gauge reading of 2.2 2.8 MPa (325 400 psi) (Figure 2-13). For CE machines, this pressure is 3.6-3.8 MPa (525-550 psi)
- 4. If the lift cylinder is not installed, plug the extend hose (the larger of the two). If lift cylinder is installed, omit this step and continue to step #5.
- 5. With diagnostic quick disconnect still installed @ the GP2 port of the accessory manifold with swing directional control valve (Figure 2-9), start engine and throttle up to full RPM. Feather into the boom lift controller to full controller stroke (up or down) and hold. If the boom is installed, boom up to max elevation and hold or boom down to minimum elevation and hold. Adjust the load sense relief valve "in" to increase or "out" to decrease so that a gauge pressure reading of 27.6± 0.4 MPa (4000 ± 50 psi) is achieved (Figure 2-10).
- **6.** Stop engine and remove the diagnostic couplers from the test nipples

Set telescope extend and retract as follows:

Extend

 If boom is not installed, install a pressure check diagnostic quick disconnect with gauge onto test nipple
 @ the GP7 port of the main directional control valve (Figure 2-10).

- **8.** Cap hose (the larger of the two) running from port A, telescope section of the main directional control valve to the cylinder port block at the back of the base section.
- 9. Start engine and throttle up to full RPM. Attempt to telescope OUT by feathering into the controller to full controller stroke. Adjust the work port relief "in" to increase or "out" to decrease so that a gauge pressure of 24.2 ±0.4 MPa (2700 ±50 psi) is achieved (Figure 2-10).
- If the boom is installed, start engine and throttle up to full RPM. Telescope out to fully extend the boom and hold. Adjust the work port relief valve "in" to increase or "out" to decrease so that a gauge pressure reading of 24.2 ±0.4 MPa (2700 ±50 psi) is achieved (Figure 2-10).
- **11.** Stop engine and remove pressure gauge and re-connect plumbing.

Retract

- 12. If the boom is not installed, install a pressure check diagnostic quick disconnect with gauge onto test nipple@ the GP7 port of the main directional control valve (Figure 2-10).
- **13.** Cap hose (the smaller of the two) running from port B, telescope section of the main directional control valve to the cylinder port block at the back of the base section.
- 14. Start engine and throttle up to full RPM. Attempt to telescope IN by feathering into the controller to full controller stroke. Adjust the work port relief valve "in" to increase or "out" to decrease so that a gauge pressure reading of 22.5 ±0.4 MPa (3000 ±50 psi) is achieved (Figure 2-10).
- **15.** If the boom is installed, start engine and throttle up to full RPM. Telescope in to fully retract the boom and hold. Adjust the work port relief valve "in" to increase or "out" to decrease so that a gauge pressure reading of 22.5 ± 0.4 MPa (3000 ± 50 psi) is achieved (Figure 2-10).
- **16.** Stop the engine and remove pressure gauge and reconnect plumbing.

Procedure B - For Setting The Outrigger/ Rear Steer/Oil Cooler Motor Pressures

- 1. Install a pressure check diagnostic quick disconnect with gauge onto test nipple at G2 port of the outrigger control manifold (Figure 2-11).
- 2. Start engine and throttle up to full RPM. Select and activate the outrigger "extend or retract" switch on the cab dash. Adjust the pressure reducing valve integrated in the outrigger control manifold "in" to increase or "out" to decrease so that a gauge pressure of 17.3 MPa \pm 0.4 (2500 \pm 50 PSI) is achieved (Figure 2-11).
- 3. Stop engine. Remove the diagnostic coupler.

Procedure C - For Checking/Setting The Swing Directional Control Valve Work Port Relief Valves

- 1. With engine off, Install a pressure check diagnostic coupler with gauge onto test nipple at GP1 port of the accessory manifold with swing directional control valve (Figure 2-9).
- Start engine, throttle up to full RPM. With the swing house lock engaged, swing full right and hold controller. Adjust the "B" port work port relief "in" to increase or "out" to decrease so that a gauge pressure reading of 14.5 16.9 MPa (2100 2450 psi) is achieved.
- 3. Repeat step #2 for swing left adjusting the "A" port relief.

Procedure D - For Checking/Setting The Service Brake Dual Accumulator Charge Valve Charging Limits

- 1. With engine off, discharge all of the pressurized fluid stored in the accumulators by depressing the service brake pedal on the cab floor 8 10 times.
- 2. Install a pressure check diagnostic quick disconnects with gauge onto test nipple at GP7 port of the main directional control valve (Figure 2-10).
- **3.** Start engine and idle. The charging valve will immediately start to charge the accumulators. Watch the pressure gauge. The high charge limit should read 17.4 MPa +0.5- 1.00 (2320 +72, -145 psi) when the pressure stops rising. This accumulator charge valve is non-adjustable.
- 4. With the engine still at idle, repeatedly depress the service brake pedal on the cab floor until the gauge pressure reads approximately 13.5 ±1.00 MPa (1950 ±145 psi) when it starts to recharge. This accumulator charge valve is non-adjustable.
- 5. Stop engine. Remove pressure gauge.

Procedure E - For Checking/Pre-Charging The Service Brake Accumulators

- With the engine off, discharge all of the pressurized oil stored in the accumulators by depressing the service brake pedal on the cab floor 4-6 times. Remove the gas valve guard and cap on the accumulator (Figure 2-13)
- Before attaching the gas charging assembly (Figure 2-13) onto the gas valve, back out the gas chuck "T" handle all the way our (counterclockwise).

- **3.** Close the charging assembly bleed valve. Attach the swivel nut onto the gas valve and tighten 1.1 1.6 Nm (10-15 pounds-inch).
- **4.** Turn the gas chuck "T" handle all the way down (clockwise) which will depress the core in the gas valve
- 5. Check the pre-charge pressure. The gauge should read 5.5 +0.4, -0 MPa (800 +50, -0 psi).
- 6. If the pressure is 5.5 +0.4, -0 MPa (800 +50, -0 psi), remove the charging valve assembly by turning the "T" handle all the way out on the gas chuck and then opening the bleed valve (Figure 2-13).
- **7.** Secure the gas valve, loosen the swivel nut and remove the charging assembly. Replace the gas valve cap and guard.

Procedure For Pre-charging the Accumulator, If required

- With the engine off, discharge all of the pressurized oil stored in the accumulators by depressing the service brake pedal on the cab floor 4 - 6 times. Remove the gas valve and cap on the accumulator (Figure 2-12).
- **2.** Ensure the nitrogen supply bottle is shut off, then attach the charging valve assembly to it.
- **3.** Before attaching the charging assembly to the accumulator gas valve, back the gas chuck "T" handle all the way out (counterclockwise).
- 4. Close the charging assembly bleed valve. Without looping or twisting the hose, attach the swivel nut to the accumulator gas valve and tighten 1.1 1.6 Nm (10-15 pounds-inch).
- **5.** Turn the gas check "T" handle al the way down (clockwise) which will depress the core in the gas valve.
- **6.** Slowly open the nitrogen bottle valve and fill the accumulator. Close the valve when the pre-charge is 5.5 +0.4, -0 MPa (800 +50, -0 psi).
- 7. If the precharge is higher than specified in step #6, close the nitrogen bottle and slowly open the bleed valve on the charging assembly (Figure 2-12) until the pressure is to specification.
- 8. Remove the charging valve assembly by turning the "T" handle all the way out (counterclockwise) on the gas check and then open the bleed valve.
- **9.** Secure the gas valve, loosen the swivel nut and remove the charging assembly. Replace the gas valve cap and guard.



Procedure F - For Checking/Setting the Front Steer Pressure

- Install pressure check diagnostic quick disconnect with gauge onto test nipple @ GP5 port of the accessory manifold with swing directional control valve (Figure 2-9).
- 2. Start engine and throttle up to full RPM. Fully turn the steering wheel left or right against the axle stop. Adjust the steering load sense relief valve in the accessory manifold with swing directional control "in" to increase or "out" to decrease so that a gauge pressure of 17.3 MPa (2500 psi) is achieved (Figure 2-9).
- 3. Stop engine. Remove diagnostic couplers.

Procedure G - For Checking/Setting the Pilot Supply Pressure

- Install pressure check diagnostic quick disconnect with gauge onto test nipple @ GP3 port of the accessory manifold with swing directional control valve (Figure 2-9).
- 2. Start engine and @ idle RPM, lower left armrest, fully stroke and hold the boom lift raise or lower joystick. Adjust the pilot pressure reducing valve of the accessory manifold with swing directional control valve "in" to increase or "out" to decrease so that the gauge pressure of 17.3 17.6 MPa (2500 2550 psi) is achieved (Figure 2-9).
- 3. Stop engine. remove diagnostic couplers.

Procedure H - For Checking/Setting The Swing Brake Release Pressure


- Install pressure check diagnostic quick disconnect with gauge onto test nipple @ GP6 port of the accessory manifold with swing directional control valve (Figure 2-9).
- Start engine and idle, select and depress the swing brake release switch and adjust the swing brake pressure reducing valve "in" to increase or "out" to decrease so that a gauge pressure of 1.7 - 2.1 MPa (250 - 275 psi) (Figure 2-9).
- 3. Stop engine. Remove diagnostic couplers.

Procedure J - For Setting Threshold on Electronic Controllers

- Attach laptop to diagnostic connector in cab and make sure CAN C is selected (position 3 on CAN selector knob) (Figure 2-8).
- 2. Open the CCS Crane Service Tool. From the menu bar, select Settings->Crane Model->Auto Detect. The auto

detection procedure should detect RT->RT540i/RT530i->Superstructure.

- 3. Start engine and run at @ idle rpm's, make sure to lower left armrest.
- 4. For each function, attach a test fitting and pressure gauge in the Pilot End Caps one at a time: GPA for Main Hoist Up, GPB for Aux Hoist Up, GPC Tele Retract, GPD Lift Down (Figure 2-10).
- 5. Current range settings for each function can be found in the Crane Service Tool in the menu bar under View->Superstructure. Select the function and a child window will open. Select the Speed Control solenoid icon, normally located in the lower left of the window. An example is shown for Main Hoist.
- 6. Adjust the max current for Main Hoist Up (Figure 2-10). Move the joystick to the full on position and monitor the pressure gauge and adjust the Imax [mA] to reach 295psi then adjust to 300psi +0/–5psi. Note that you will need to press the Set button at the bottom of the window before it will take effect.
- 7. Next set the current threshold of Main Hoist Up. Monitor the pressure gauge and move the joystick just off center for Main Hoist in the up position. Watch the pressure gauge, move until it reaches approx 100 PSI. Hold the joystick at this position and note the value for MH Solenoid Current in the Main Hoist Data window. Enter this setting for Imin [mA] and press the green Set button at the bottom of the window.
- 8. Repeat this process for Aux Hoist Up (GPB,) Tele Retract (GPC,) and Boom Down (GPD) (Figure 2-10)
- 9. Next adjust the slew brake current range. Attach test fitting and pressure gauge GP4 (Figure 2-9)port with engine running at idle. Fully depress swing brake pedal. Monitor the press gauge and adjust the swing brake solenoid Imax [mA] setting to reach to reach 250psi. Next slowly depress swing brake pedal down until you reach 25psi on the gauge. Note the swing brake current value, and set Imin [mA] to this value.
- 10. After setting all of the functions, save the EE configuration to the controller's Factory and Customer settings area. This is done by selecting Tools->Calibration and Adjustment->EEPROM and pressing the Save active to Customer and Save active to Factory buttons.
- Next save the configuration to a file by right clicking on the 'Active' column and Write->Write column to file from the context menu. Save the file in a folder under the model designation (In this case RT530E-2). Name the file as follows: (*Sales order number_Date*). Sample: (123456_2006aug17)



Procedure K - Setting Threshold and Max on Swing Brake Pedal


- Install pressure check diagnostic quick disconnect (Parker PD240) with gauge onto test nipple @ GP6 port of the accessory manifold with swing directional control valve (Figure 2-9).
- 2. Start engine and idle, enable swing (left armrest switch) and adjust the swing brake pressure reducing valve "in" to increase or "out" to decrease so that a gauge

pressure of 1.7-1.9 MPa (250-275 PSI) is achieved (Figure 2-9).

- 3. If adjustment can't obtain the setting in step #2, stop engine and install a pressure check diagnostic quick disconnect (Parker PD240) with gauge onto the test nipple @ the GP2 at the accessory manifold valve (Figure 2-9). Follow procedure A step 3 to set pump stand-by and then repeat this step.
- 4. Stop engine. Remove diagnostic couplers.





ltem	Description
1	Procedure G- Pilot Supply PSI Reducing Valve
2	Procedure H - Swing Brake PSI Reducing Valve
3	Procedure C - Swing Left Port Relief Valve
4	Procedure F - Front Steer Load Sense Relief Valve
5	Procedure C - Swing Right Port Relief Valve
6	Gauge Port 2
7	Gauge Port 3
8	Gauge Port 6
9	Pilot End Cap GP8 - Swing Left
10	Pilot End Cap GP9 - Swing Right




ltem	Description	
1	Procedure A - Telescope Extend Port Relief	
2	Procedure A - Load Sense Relief Valve	
3	Procedure A - Telescope Retract Port Relief	
4	Gauge Port 7	
5	Pilot End Cap GPD Lift Down	
6	Pilot End Cap GPC Telescope Retract	
7	Pilot End Cap GPA Main Hoist Up	
8	Pilot End Cap GPB Aux Hoist Up	
8102		
		FIGURE 2-10







GROVE





VALVES

General


This subsection provides descriptive information for all the hydraulic valves used on this crane. For a listing of all valves, the circuit they are used in, and their physical location, refer to (Table 2-2). Refer to (Figure 2-14) for valve locations. The

Table 2-2 Valve Usage Table

description of each valve given here is for the valve itself. For information on how each valve functions in the individual circuits, refer to the description and operation procedures of that circuit.


NOTE: On each valve illustration in this section, each item number in table correlates to location on the valve, and to the valve hydraulic schematic.

Valve Name	Circuit Used In	Physical Location
Directional Control Valvas	Boom Lift/Telescope(s)/Hoist(s)	Superstructure Right Side Plate
Directional Control Valves	Swing/Steer	Superstructure Right Side Plate
Steering Control Valve	Front Axle Steer Control	Cab Steering Column
Front Steer/Swing/Accessory Manifold Front Steer/Swing/Accessory Manifold Front Steer/Swing/Accessory Manifold Swing Brake Release Pilot Supply		Superstructure Right Side Plate
Tandem Brake Valve with Treadle	Service Brakes	Cab Floor
Dual Accumulator Charging Valve	Service Brakes	Superstructure Left Side Plate
Accumulator(s)	Service Brake	Rear Superstructure
Holding Valves	Boom Lift Telescope (3) Counterweight Removal (2)	Lift Cylinder (Bolt on Manifold) Cylinder Port Blocks (Cartridge style) Cylinder Port Blocks (Cartridge style)
Axle Lockout, Rear Steer and Oil Cooler Fan Motor Control Manifold	Axle Lockout Control Rear Steer Control Oil Cooler Motor Control	Left Hand Carrier Frame Rail
Solenoid Valves:		
Cross Axle Differential Lock	Differential Lock (Optional)	Carrier Inside Right Side Rail
Hoist Motor Control Valve	Hoist(s)	Both Hoists (see Hoist section)
Check Valves	Return Circuit	One in Parallel With Oil Cooler
Outrigger Control Manifold	Outrigger	On Front and Rear Face of Carrier Frame Front and Rear Cross Member
Pilot Operated Check Valve	Outrigger	Port Block of each Jack Cylinder (4)
Cross Axle Differential Lock Valve	Differential Lock (Optional)	Carrier Bulkhead Plate Forward Of The Engine
Range Shift and Parking Brake Valve	Parking Brake Axle Disconnect	Center of Rear Frame



ltem	Description	ltem	Description
1	Hoist/Telescope/Lift Directional Valve	4	Secondary Steer Valve (CE Option)
2	Swing/Steer Directional Valve	5	Accumulator
3	Service Brake Dual Accumulator Charge Valve	6	Superstructure





ltem	Description	
1	Front Outrigger Control Manifold	
2	Outrigger/Rear Steer Valve	
3	Differential Lock Valve	
4	Park Brake Range Shift Valve	

ltem	Description
5	Axle Lockout Valve
6	Rear Outrigger Control manifold
7	Frame

DIRECTIONAL CONTROL VALVES

Description

The directional control valves direct and control hydraulic oil flow from the pumps to the boom lift and telescope cylinders, each hoist motor, the swing motor, and the front steer cylinders from the front steer control valve. The boom lift/ telescope/hoist directional control valve (Figure 2-15) is located on the outside of the right superstructure side plate. The valve bank is removed and installed as an assembly.

The boom lift/telescope/hoist control valve is a three position four way pressure compensated, closed center directional valve. It receives pump flow from hydraulic swivel port 6 and pump No. 1. Lift, telescope and hoist (s) functions are controlled by proportional two position two way solenoid cartridges installed into the valve's casting under each spool. These valves receive an electrical signal from the controllers on the cab armrest.

RCL lockout is achieved by de-energizing the proportional solenoids.

The inlet section of the boom lift/telescope/hoist directional control valve contains a load sense relief valve set at 27,579 kPa/275.7 bar (4000 psi) protecting the main and auxiliary hoist and boom lift sections. The boom lift retract has a thermal port relief set of 29,647.4kPa/296.4 bar (4300 psi). The telescope section has port reliefs set at 18,616 kPa/186.2 bar (2700 psi) and 20,684 kPa/207 bar (3000 psi).

The swing directional control valve is installed on the outside of the right superstructure side plate. Refer to Accessory With Swing Directional Control Manifold, page 2-33.

Maintenance

Boom Lift/Telescope/Hoist Valve Bank Removal

- **1.** Tag and disconnect all of the electrical connectors from the valve.
- Tag and disconnect the hydraulic lines from the valves. Cap or plug the lines and ports.

- **NOTE:** The lift/telescope/hoist valve bank weighs approximately 81.30 kg (179.2 pounds).
- **3.** Remove the capscrews, washers and nuts securing the valve bank and remove the valve bank.

Boom Lift/Telescope/Hoist Valve Bank Installation

- 1. Place the valve bank on the superstructure side plate and secure it with the capscrews, washers and nuts. Torque the capscrews see *Fasteners and Torque Values*, page 1-12.
- 2. Connect the hydraulic lines to the valves as tagged during removal.
- **3.** Connect the electrical connectors as tagged during removal.


Functional Check (All Valve Banks)

- 1. Start the engine and run it at normal speed.
- **2.** Operate the control levers of the valve bank(s). Check for smooth operation of cylinders and motors.
- **3.** Check the valve bank(s) and lines for leakage. Make repairs as needed.

Function Check - RCL Lockout Valves


- 1. Remove circuit breaker F11 from the power panel in the cab. This cuts off power to the RCL.
- 2. Start the engine.
- **3.** Try to telescope the boom out, lower the boom, hoist up the main hoist, and hoist the auxiliary hoist up (if installed). Verify none of these functions work.
- 4. Shut down the engine. Reinstall F11.
- Telescope the boom out, lower the boom, hoist up the main hoist, and hoist the auxiliary hoist up (if installed). Verify all of these functions work.
- 6. Check for leaks. Make repairs as needed.





ltem	Description
1	Port 1A -Main Hoist Up
2	Port 1B - Main Hoist Down
3	Port 2A - Aux Hoist Up
4	Port 2B - Aux Hoist Down
5	Port 3A - Telescope Extend
6	Port 3B - Telescope Retract
7	Port 4A - Lift Up
8	Port 4B - Lift Down
9	Load Sense - Outlet Port
10	Port P1 - From Swivel Port 6

ltem	Description
11	Load Sense - Inlet Port
12	Port PS - Pilot Supply
13	Gauge Port
14	Relief Valve - Telescope Extend
15	Relief Valve - Telescope Retract
16	Relief Valve - Lift
17	Relief Valve - Load Sense





ACCESSORY WITH SWING DIRECTIONAL CONTROL MANIFOLD

Description

The accessory manifold with swing directional valve (Figure 2-16) is located on the right side of the turntable. The manifold contains two adjustable pressure reducing valves, five 3-way two position solenoid valves, 3-way four position swing directional valve, and a check valve.

One pressure reducing valve provides 1.72 MPa (250 psi) for operation of the swing brake. The other provides 17.2 MPa (2500 psi) for the pilot circuit.

Each solenoid valve is held in its normally closed position by a spring. When the solenoid is energized, the plunger assembly forces the spool to shift, causing the valve to shift. De-energizing the solenoid causes spring pressure to shift the spool to its normally closed position.

One two position, three way solenoid valve serves as the swing brake release valve. This normally closed valve, when de-energized, prevents hydraulic oil pressure from releasing the swing brake. When the swing brake switch is off, this valve opens to allow hydraulic oil pressure to release the swing brake.

One proportional two position, three way solenoid valve actuated by the cab swing foot brake proportionally supplies pressurized oil to the swing drive brake.

The three position four-way swing directional valve is installed onto the manifold. Both swing working ports have check valves that are flooded by a.41 MPa (60 psi)


resistance check valve providing make-up oil to the swing motor for motor over-run when the valve is centered. It receives oil from pump #1 through swivel port 5. This section is controlled by two proportional two position, three way solenoid valves. These valves receive an electrical signal from the cab armrest controllers.


Maintenance

Removal

- 1. Tag and disconnect all of the electrical connectors or manual control levers.
- **2.** Tag and disconnect the hydraulic lines from the valves. Cap or plug the lines and ports.
- **NOTE:** The swing/steer/brake valve manifold weighs approximately 10.0 kg (22.0 lb).
- **3.** Remove the capscrews, lockwashers and flatwashers securing the manifold. Remove the manifold.

- 1. Place the manifold on the superstructure side plate and secure with the capscrews, lockwashers and flatwashers. Torque the capscrews see *Fasteners and Torque Values*, page 1-12.
- **2.** Connect the hydraulic lines to the valves as tagged during removal.
- **3.** Connect the electrical connectors to the valve as tagged during removal.





ltem	Description
1	Pilot Supply Relief Valve
2	Gauge Port- GP4
3	Swing Brake Relief Valve
4	Solenoid Valve - Swing Brake
5	Solenoid Valve - Swing Brake Release
6	Solenoid Valve - Pilot Supply
7	Gauge Port - GP1
8	Pilot Supply Port - PS
9	Drain - D2
10	Port 2B - Swing Left
11	Port 2A - Swing Right
12	Swing Directional Valve
13	Drain Port - D4 (Swing Motor Pilot Supply)
14	Drain Port - D6 (Hoist/Tele/Lift valve Pilot Supply)

ltem	Description
15	Drain Port - D7 (Swing Brake/Lift Cylinder Pilot)
16	Drain Port - D3 (Plugged)
17	Gauge Port - GP2
18	Gauge Port - GP5
19	Drain Port - D1
20	Gauge Port - GP3
21	Swing Brake Release Port - SBR
22	Drain Port - D5
23	Swing Brake Supply Port -SBS
24	Tank Port
25	Gauge Port - GP6 (Plugged)
26	Gauge Port - GP8 (Plugged)
27	Proportional Two Position Two Way Solenoid
28	Steering Priority Valve
29	Steer Circuit Load Sense Relief



STEERING CONTROL VALVE

Description

The steering control unit (Figure 2-17) controls hydraulic flow to the front steering cylinders. It is located on the steering column of the cab.

Both work ports are connected to the rod side of one steer cylinder and to the piston side of the other steer cylinder. A steering wheel input will connect the load sense port #5 to the steering cylinder load demand by way of the steer priority valve located in the swing/steer manifold.

Displacement of the valve is 315 cm³ (19.22 in³).


Maintenance

Removal

- 1. Tag and disconnect the electrical connector to the valve.
- **2.** Tag and disconnect the hydraulic hoses from the valve. Cap or plug the lines and ports.

3. Remove the capscrews and washers and remove the valve from the steering column.

- 1. Secure the valve to the steering column and secure with the capscrews and washers. Torque the capscrews 40.6 to 43.3 Nm (30 to 32 pounds-foot).
- 2. Connect the hydraulic hoses to the ports on the valve as tagged during removal.
- **3.** Connect the electrical connector to the valve as tagged during removal.
- 4. Verify proper operation of the valve.
- **5.** Check valve and hydraulic connections for leaks. Make repairs as needed.



TANDEM BRAKE VALVE WITH TREADLE PEDAL

Description

The tandem brake valve with treadle pedal (Figure 2-18) is located on the floor of the cab. The tandem brake valve provides split system braking for the primary (front) brakes and the secondary (rear) brakes.

The valve modulates the output pressure 10,342 kPa/103.4 bar (1500 psi) to the brake actuators. The valve is mechanically actuated by a treadle pedal (Figure 2-18). The direct acting spool provides a pedal feel which accurately represents the brake pressure, similar to automotive style pedal feedback as the brake pedal pressure increases, the pedal effort increases proportionally. As the pedal is initially actuated, the tank ports are closed off from the brake ports. With further application of the pedal, the pressure ports are opened to the brake ports until the pedal actuation force and the hydraulic pressure force are balanced.


Also when the pedal is actuated, a pressure switch located off a tee in port F2 provides an electrical signal for brake lights. When the pedal is released, the valve and the pedal return to the non-applied position. In normal operation, the secondary system is piloted from the primary section providing pressure to both systems. The tandem brake valve consists of a tandem valve body, a closed center spool, a treadle pedal and a mechanical spring assembly to limit the output pressure to the brake actuators to 10,342 kPa/103.4 bar (1500 psi).

Maintenance

Removal

- 1. Tag and disconnect the electrical connector to the valve.
- **2.** Tag and disconnect the hydraulic hoses from the valve. Cap or plug the lines and ports.
- **3.** Remove the capscrews, lockwashers, flatwashers and nuts securing the valve to the cab Floor. Remove the valve.

- 1. Secure the valve to the cab floor with the capscrews, lockwashers, flatwashers and nuts. Torque the capscrews 10 to 11 Nm (7.4 to 8.1 pounds-foot).
- 2. Connect the hydraulic hoses to the ports on the valve as tagged during removal.
- **3.** Connect the electrical connector to the valve as tagged during removal.
- **4.** Start the engine and check valve and hoses for leaks. Make repairs as needed.





DUAL ACCUMULATOR CHARGE VALVE

Description

The load sensing dual accumulator charging valve is located on the inside of the left superstructure side plate. The purpose of the valve is to provide pressure regulation to the service brake circuit.

The dual accumulator charge valve consists of an inlet main check valve, a load sense control section with a pilot spool that controls the pump stroke and an inverted shuttle that controls the accumulator charging (Figure 2-19).

When the valve is charging the accumulators, the load sense control section is in neutral position, connecting the load to the pump by way of the load sense line. This brings the piston pump No. 1 on stroke to supply fluid for charging. Fluid passes through the main check valve connecting to the pilot end and through the spool onward to the inverted shuttle that connects the accumulators.

When the control pilot spool bias spring senses the low limit pressure of 13,445 kPa/134 bar (1950 psi), the spool shifts to the neutral position, allowing the pump to charge the accumulators to a maximum of 16,000 kPa/160 bar (2320 psi). The inverted shuttle cartridge senses the pressure in the accumulators to pilot the cartridge closed when maximum charge pressure is reached. Maximum charge pressure also pilots the control pilot spool to open the load sense line to tank, destroking the piston pump No. 1.


Maintenance

Removal

- 1. Tag and disconnect the hydraulic hoses from the valve. Cap or plug the lines and ports.
- 2. Remove the capscrews, flatwashers and lockwashers securing the valve to the turntable. Remove the valve.

- 1. Position the valve on the turntable and secure with the capscrews, flatwashers, and lockwashers. Torque capscrews see *Fasteners and Torque Values*, page 1-12.
- 2. Connect the hydraulic hoses to the valve ports as tagged during removal.
- **3.** Start the engine and check for leaks. Make repairs as needed.
- 4. Depress the brake pedal several times to cause the brake valve to charge. Make several turns with the steering wheel, and swing the superstructure left and right. Verify the brakes, swing, and front steering work properly.

HYDRAULIC SYSTEM





HYDRAULIC ACCUMULATOR SERVICE BRAKE

Description

The service brake hydraulic accumulators are located on the outside of the left superstructure side plate behind the cab. The purpose of each accumulator is to provide stored energy, an oil volume of 1.23 I (75.1 cu in) at a maximum pressure of 27,579 kPa/275 bar (4000 psi), to actuate the service brake circuits. The dual accumulator charge valve regulates flow to the hydraulic accumulators to provide fully powered independently separate, primary (front) and secondary (rear), service brake circuits.

Each accumulator has two chambers divided by a piston. One side is pre-charged to 5,515.8 kPa/55.1 bar (800 psi) with high purity nitrogen. This maintains a constant pressure in the other chamber which is connected to the modulating brake valve. After the accumulators are fully charged, they will provide the necessary brake system flow and pressure to actuate the brakes.

The accumulator consists of a tube, piston, seals, gas charging valve, and a gas valve guard.

Maintenance

Removal

- 1. With the engine shutdown, deplete the hydraulic pressure in the accumulators by depressing the service brake pedal several times.
- **2.** Tag and disconnect the hydraulic hose from the accumulator. Cap or plug the line and port.

3. Remove the two nuts securing each clamp half. Remove the each clamp half and accumulator from the turntable.

Installation

- 1. Position the accumulator in the clamps and secure with the removable clamp halves and nuts.
- **2.** Connect the hydraulic hose to the port on the accumulator as tagged during removal.
- **3.** Pre-charge the accumulator. Refer to paragraph titled Pre-Charging Accumulator in Sub-Section titled Pressure Setting Procedures.
- **4.** Start the engine and check accumulator and hoses for leaks. Make repairs as needed.
- 5. Depress the brake pedal several times, make several turns with the steering wheel, and swing the superstructure left and right. Verify the brakes, swing, and front steering work properly.

Servicing

The pre-charge nitrogen pressure should be checked every 200 hours or once a month, whichever comes first. Refer to Pressure Setting Procedures in this section.

HOLDING VALVES

Description

A bolt-on manifold style holding valve is installed on the boom lift cylinder. A cartridge style holding valve is used on the telescope cylinder installed in the piston side of the cylinder.

The holding valve provides meter out control, will lock the cylinder in place, prevent a load from running ahead of the oil supply, and will relieve excess pressure caused by thermal expansion.

Maintenance



Boom must be fully lowered and fully retracted before removing lift cylinder and telescope cylinder holding valves.

Removal

1. Unscrew holding valve from its port block or manifold.

Installation

- 1. Check the inside of the port block or manifold for any sharp edges or burrs and remove as necessary with emery cloth.
- 2. Install new O-rings onto the holding valve.
- **3.** Lubricate the holding valve and O-rings with clean hydraulic oil.

CAUTION

Do not damage the O-rings during installation of the holding valve. If the holding valve turns freely then gets hard to turn, then easy to turn, remove the holding valve and check the O-rings. They have probably been damaged by a sharp edge of a port.

- **NOTE:** The holding valve should turn by hand until compression of the O-rings begins.
- 4. Carefully install the holding valve into the port block or manifold until fully seated.
- 5. Test the holding valve and port block or manifold by operating the lift cylinder and/or the telescope cylinder, as applicable. Verify lift cylinder and/or telescope cylinder works without problems; verify there is no leaking. Make repairs as needed.



CROSS AXLE DIFFERENTIAL LOCK VALVE

Description

The optional cross axle differential lock valve is mounted on the right side of the aft center frame cross member. The valve consists of a three way, two position valve without a reducing valve (Figure 2-21). The valve is used to control the application of the crane's hydraulically applied and released cross axle differential lock actuators.

Pressing the top of the cross axle differential lock switch on the front console shifts the three-way, two-position solenoid valve so hydraulic oil can flow to the engage port of the cross axle differential lock actuators, extending them. When the actuators extend, they engage the splines on the differential case and the axle shafts to lock the differential assemblies together.

Releasing the cross axle differential lock switch unlocks the three-way, two-position solenoid valve to apply hydraulic pressure to the spring release of the actuators, retracting them. As the actuators retract, they unlock the axles.


Maintenance

Removal

- 1. Tag and disconnect the electrical connector from the valve.
- **2.** Tag and disconnect the hydraulic lines attached to the valve. Cap or plug lines and ports.
- **3.** Remove the capscrews, flatwashers, lockwashers and nuts securing the valve to the frame. Remove the valve.

Installation

- 1. Secure the valve to the frame with the capscrews flatwashers, lockwashers and nuts. Torque the capscrews 10 to 11 Nm (7.4 to 8.1 pounds-foot).
- 2. Connect the hydraulic lines to the valve as tagged during removal.
- **3.** Connect the electrical connector to the valve as tagged during removal.
- 4. Apply and release the cross axle differential lock several times. Verify the cross axle differential lock holds the axle from moving when applied so there is no differential action between the wheels.
- 5. Check for leaks. Make repairs as needed.





OUTRIGGER CONTROL MANIFOLD

Description

There are two outrigger control manifolds utilized on the crane, one for the front outriggers and one for the rear outriggers. The manifold consists of four normally closed two position two way solenoid valves (Figure 2-22). They are mounted inside the frame of their respective outrigger box.

When energized, the solenoid shifts the spool to open allowing extension or retraction of the outrigger cylinders.

Maintenance

Removal

- **1.** Tag and disconnect the hydraulic lines to the solenoid valves; cap all lines and openings.
- **2.** Tag and disconnect the electrical connectors.
- **3.** Remove the capscrews, nuts, lockwashers and flatwashers securing the manifold to the outrigger box; remove the manifold.

Inspection


Visually inspect the valves and hydraulic connections for any evidence of leaks or other damage. Check security of the electrical connections. Inspect the wiring for any evidence of cracks or breaks.

Installation

- 1. Position the manifold on the mounting and secure with the lockwashers, flatwashers, nuts and capscrews. Torque capscrews see *Fasteners and Torque Values*, page 1-12.
- **2.** Connect the electrical connectors to the solenoids as marked during removal.
- **3.** Connect the hydraulic lines to the valves as marked during removal.

Functional Check

Activate the hydraulic system and cycle the affected cylinder(s) several times. Observe for proper functioning of the affected cylinder(s). Ensure the solenoid valve hydraulic connections are secure.



ltem	n Description		Description	
1	Solenoid Valve - Left Front or Rear Extension Cyl	6	Outlet Port Left Front or Rear Jack Cyl	
2	Solenoid Valve - Left Front or Rear Jack Cyl	7	Outlet Port Right Front or Rear Jack Cyl	
3	Solenoid Valve Right Front or Rear Jack Cyl	8	Outlet Port Right Front or Rear Extension Cyl	
4	Solenoid Valve Right Front or Rear Extension Cyl	9	In Port (Far Side) - From Port B of Outrigger	
5	Outlet Port - Left Front or Rear Extension Cyl		Selector Valve	

PILOT OPERATED CHECK VALVE

Description

A pilot operated (PO) check valve is located in each outrigger jack cylinder port block. The check valve functions as a holding valve for the jack cylinder. Oil flow is directed from the "V" port to the "C" ports, while blocking flow in the opposite direction. Flow is reversed from "C" to "V" when pressure pilot oil is applied to the opposite side "V" port (Figure 2-23)

Maintenance

Removal

1. Unscrew the check valve from the jack cylinder port block.

Installation


- 1. Check the inside of the port block for any sharp edges or burrs and remove as necessary with emery cloth.
- 2. Install new O-rings onto the check valve.

3. Lubricate the check valve and O-rings with clean hydraulic oil.

CAUTION

Do not damage the O-rings during installation of the check valve. If the check valve turns freely then gets hard to turn, then easy to turn, remove the check valve and check the O-rings. They have probably been damaged by a sharp edge of a port.

- **NOTE:** The check valve should turn by hand until compression of the O-rings begins.
- **4.** Carefully install the check valve into the port block until fully seated.
- 5. Test the check valve and port block by operating the affected outrigger's jack cylinder. Verify it extends and retracts without problems; verify there is no leaking. Make repairs as needed.





INTEGRATED OUTRIGGER/REAR STEER MANIFOLD

Description

The integrated outrigger/rear steer manifold (Figure 2-24) controls the outrigger and rear steer circuit. The valve is mounted on the frame center section to the rear of the front axle.

The manifold is made up of two sections; an inlet section and a working section.

The inlet section contains a 17,200 kPa/172 bar (2500 psi) pressure reducing valve and a load sense shuttle valve. The solenoid valve is a normally closed two position two way valve. It unloads the load sense line to the pump to ensure the pump is de-stroked during engine start.

The rear steer section contains a three position four way solenoid controlled directional valve that controls left and right rear steer. The rear steer cylinders are positive locked by the double pilot operated check valves integral to the work ports.

The outrigger section contains a three position four way pilot controlled directional valve, two check valves, two load sense shuttle valves, and two, two position three way solenoids for pilot control of the outrigger extend and retract function.


Maintenance

Removal


- 1. Tag and disconnect the electrical connectors to the valve.
- **2.** Tag and disconnect the hydraulic hoses from the valve. Cap or plug the lines and ports.
- **3.** Remove the capscrews and washers securing the valve to the frame bracket. Remove the valve.

Installation

- 1. Secure the valve to the frame bracket with the washers and capscrews. Torque the capscrews see *Fasteners* and *Torque Values*, page 1-12.
- 2. Connect the hydraulic hoses to the ports on the valve as tagged during removal.
- **3.** Connect the electrical connectors to the valve as tagged during removal.
- 4. Verify operation as follows:
- Operate the rear steer left and right to verify smooth operation.
- On outriggers, swing over the front outriggers to ensure the oscillation cylinders lockout.
- Remove the electrical connection from the oil cooler motor two position three-way solenoid valve to verify that it operation.
- 5. Check valve and hoses for leaks. Make repairs as needed.







Item	Description
1	Pressure Reducing Valve - PR1
2	Check Valve - CV1
3	Orifice - ORF1
4	Solenoid Valve - Rear Steer S1
5	Solenoid Valve - Rear Steer S2
6	Solenoid Valve - SV2
7	Solenoid Valve - SV1
8	Gauge Port - G2
9	Orifice - ORF2
10	Solenoid - SF1
11	Check Valve - CV4

Item	Description
12	Load Sense - LS0
13	Load Sense - LS1
14	Port ALO - To Axle Lockout Valve
15	Port T - Tank
16	Port G1 - Gauge Port
17	Port P - Pressure From Pump #1
18	Port A - Outrigger Retract
19	Port B - Outrigger Extend
20	Port RSA - Left Rear Steer
21	Port RSB - Right Rear Steer
22	Load Sense Shuttle valve
23	Pressure Reducing Valve - PR2

CHECK VALVES

Description

Check valves are used in the crane hydraulic system to block flow in one direction and allow free flow in the opposite direction.

A check valve is plumbed in-line at the inlet of the front steer control valve. It prevents steering wheel kick-back if the steer cylinder pressure rises above the inlet port pressure.

Maintenance

Removal

1. Tag and disconnect hydraulic lines from the valve and cap or plug all openings and remove valve.

Installation

- 1. Connect the hydraulic lines as tagged during removal.
- **2.** Check valve and hydraulic connections for leaks. Make repairs as needed.



RANGE SHIFT/PARKING BRAKE VALVE

Description

The range shift/parking brake valve controls the flow of oil to the parking brake, hi-low range and axle disconnect actuators by the use of two solenoid valves (Figure 2-25). The valve is located on the center of the frame. Pressure is supplied to the valve from the transmission charge pump.

The parking brake solenoid valve is a two position three-way valve. In its de-energized position, the inlet port is blocked and the parking brake actuator is drained to the reservoir. When the solenoid is energized, the reservoir port is blocked and pressurized oil is directed to the actuator, releasing the parking brake.

The range shift solenoid valve is a two position four-way valve. In its de-energized position, pressurized oil flows to the "B" port of the range shift actuator, while the "A" port is drained to the reservoir along with the axle disconnect actuator for two wheel drive/high range. When the solenoid is energized, pressurized oil is directed to the "A" port of the range shift actuator hydraulic spring release while port "B" of the range shift actuator is drained to the reservoir for four wheel drive/low range.

Maintenance

Removal


- 1. Tag and disconnect the electrical connectors to the valve.
- **2.** Tag and disconnect the hydraulic hoses from the valve. Cap or plug the lines and ports.
- **3.** Remove the capscrews, lockwashers, flatwashers and nuts securing the valve to the frame. Remove the valve.

Installation

- 1. Secure the valve to the frame with the nuts, flatwashers, lockwashers and capscrews. Torque the capscrews see *Fasteners and Torque Values*, page 1-12.
- 2. Connect the hydraulic hoses to the ports on the valve as tagged during removal.
- **3.** Connect the electrical connectors to the valve as tagged during removal.

Functional Tests

- 1. Start and idle engine.
- 2. With units on outriggers, check for proper two/four wheel operation.



AXLE OSCILLATION LOCKOUT VALVE (STANDARD UNITS)

Description

The axle oscillation lockout valve is used in the rear axle oscillation lockout circuit. The valve is located on the left inner center frame rail. It consists of a valve body and two normally-closed, three way, two position solenoid valves. It keeps the lockout cylinders from oscillating unless the turntable is centered forward.

The area definition potentiometer in the electrical swivel energizes and deenergizes the axle oscillation relay. When the superstructure is more than 6 degrees left or right of directly over the front, the axle oscillation relay is deenergized.

When the axle oscillation lockout valve is open, the normally closed solenoid valves are deenergized and isolate the lockout cylinders from hydraulic oil supply. This keeps the cylinders from oscillating (moving up and down) because hydraulic oil cannot leave the cylinders. Instead, the cylinders remain full of hydraulic oil and rigid.

When the axle oscillation lockout valve is closed, the solenoid valves are energized and open. This allows hydraulic oil in and out of the cylinders, allowing them to oscillate.

Maintenance


Removal

- 1. Tag and disconnect the electrical connectors to the valve.
- **2.** Tag and disconnect the hydraulic hoses from the valve. Cap or plug the lines and ports.
- **3.** Remove the capscrews, hex nuts, flatwashers and lockwashers securing the valve to the frame. Remove the valve.

Installation

- 1. Secure the valve to the crane with the capscrews, hex nuts, flatwashers and lockwashers. Torque the capscrews see *Fasteners and Torque Values*, page 1-12.
- 2. Connect the hydraulic hoses to the ports on the valve as tagged during removal.
- **3.** Connect the electrical connectors to the valve as tagged during removal.
- 4. Check valve and hoses for leaks. Make repairs as needed.





ltem	Description	Item	Description
1	Port C- Pressure From Axle Lockout Port On	3	Port B - To Left Hand Lockout Cylinder
·	Outrigger Selector Valve	4	Solenoid Valve
2	Port A - To Right Hand Lockout Cylinder		

AXLE OSCILLATION LOCKOUT VALVE (OPTIONAL CE UNITS)

Description

The axle oscillation lockout valve is used in the rear axle oscillation lockout circuit. The valve is located on the left inner center frame rail. It consists of a valve body, a normallyclosed three-way, two position solenoid valve and a pressure reducing valve. It keeps the lockout cylinders from oscillating unless the turntable is centered forward.

The area definition potentiometer in the electrical swivel energizes and deenergizes the axle oscillation relay. When the superstructure is more than 6 degrees left or right of directly over the front, the axle oscillation relay is deenergized.

When the axle oscillation lockout valve is open, the normally closed solenoid valves are deenergized and isolate the lockout cylinders from hydraulic oil supply. This keeps the cylinders from oscillating (moving up and down) because hydraulic oil cannot leave the cylinders. Instead, the cylinders remain full of hydraulic oil and rigid.

When the axle oscillation lockout valve is closed, the solenoid valves are energized and open. This allows hydraulic oil in and out of the cylinders, allowing them to oscillate.

Maintenance


Removal

- 1. Tag and disconnect the electrical connectors to the valve.
- **2.** Tag and disconnect the hydraulic hoses from the valve. Cap or plug the lines and ports.
- **3.** Remove the capscrews, hex nuts, flatwashers and lockwashers securing the valve to the frame. Remove the valve.

Installation

- 1. Secure the valve to the crane with the capscrews, hex nuts, flatwashers and lockwashers. Torque the capscrews see *Fasteners and Torque Values*, page 1-12.
- 2. Connect the hydraulic hoses to the ports on the valve as tagged during removal.
- **3.** Connect the electrical connectors to the valve as tagged during removal.
- 4. Check valve and hoses for leaks. Make repairs as needed.





	Item	Description	
Description	4	Solenoid Valve	
Port P - Pressure From Axle Lockout Port On	5	Port B - To Lockout Cylinder Pilot	
Port T - Tank	6	Port P1 - To Lockout Cylinder	
Pressure Reducing Valve			
	Port P - Pressure From Axle Lockout Port On Outrigger Selector Valve Port T - Tank	Description4Port P - Pressure From Axle Lockout Port On Outrigger Selector Valve5Port T - Tank6	Description4Solenoid ValvePort P - Pressure From Axle Lockout Port On Outrigger Selector Valve5Port B - To Lockout Cylinder PilotPort T - Tank6Port P1 - To Lockout Cylinder

CYLINDERS

General

Table 2-3 Wear Ring Gap

This subsection provides descriptive information for all the hydraulic cylinders used on this crane. The description of the cylinder given here is for the cylinder itself. For information on how the cylinder functions in the individual circuits, refer to the Description and Operation of that circuit.

Maintenance

General

There must be a gap between the ends of each wear ring when it is installed onto the piston (as applicable) or head. In addition, each wear ring gap is to be located as follows: Divide 360 degrees by the number of wear rings on the component. The resulting value is the number of degrees each wear ring gap is to be located with respect to each other.

The approximate wear ring gaps are as follows:

Head (or F	Piston) Size	Wear Rin	ng Gap
Inch	mm	Inch	mm
1 to 4.75	25.4 to 120.7	0.125	3.18
5 to 10.0	127.0 to 254.0	0.187	4.75
greater than 10.0	greater than 254.0	0.250	6.35

Surface Protection for Cylinder Rods

Steel cylinder rods include a thin layer of chrome plating on their surfaces to protect them from corroding. However, chrome plating inherently has cracks in its structure which can allow moisture to corrode the underlying steel. At typical ambient temperatures, hydraulic oil is too thick to penetrate these cracks. Normal machine operating temperatures will allow hydraulic oil to warm sufficiently to penetrate these cracks and if machines are operated daily, protect the rods. Machines that are stored, transported, or used in a corrosive environment (high moisture, rain, snow, or coastline conditions) need to have the exposed rods protected more frequently by applying a protectant. Unless the machine is operated daily, exposed rod surfaces will corrode. Some cylinders will have rods exposed even when completely retracted. Assume all cylinders have exposed rods, as corrosion on the end of the rod can ruin the cylinder.

It is recommended that all exposed cylinder rods be protected using Boeshield® T-9 Premium Metal Protectant. Manitowoc Crane Care has Boeshield® T-9 Premium Metal Protectant available in 12 oz. cans that can be ordered through the Parts Department.

NOTE: Cylinder operation and inclement weather will remove the Boeshield® protectant; therefore, inspect machines once a week and reapply Boeshield® to unprotected rods.

Leakage Check

A hydraulic cylinder should not be disassembled unless it is essential. The following checks will provide a means of determining if a cylinder has a faulty or leaking piston seal.

1. Extend the rod to its maximum stroke. Remove the retract hose from the cylinder. Cap the retract hose.

Ensure pressure is applied to the piston side of the cylinder only and the retract hose is capped.

- Apply hydraulic pressure to the piston side of the cylinder and observe the open cylinder port for leakage. If leakage is observed, the seals in the cylinder must be replaced.
- **3.** Fully retract the cylinder rod (except the telescope cylinder). Remove the extend hose from the cylinder. Cap the extend hose.



Ensure pressure is applied to the retract (rod) side of the cylinder only and that the extend hose is capped.

4. Apply hydraulic pressure to the retract (rod) side of the cylinder and observe the open cylinder port for leakage.



If leakage is observed, the seals in the cylinder must be replaced.

5. Reconnect all cylinder ports.

Temperature Effects on Hydraulic Cylinders

Hydraulic oil expands when heated and contracts when cooled. This is a natural phenomena that happens to all liquids. The coefficient of expansion for API Group 1 hydraulic oil is approximately 0.00043 cubic inches per cubic inch of volume for 1°F of temperature change. Thermal contraction will allow a cylinder to retract as the hydraulic fluid which is trapped in the cylinder cools. The change in the length of a cylinder is proportional to the extended length of the cylinder and to the change in temperature of the oil in the cylinder. For example, a cylinder extended 25 feet in which the oil cools 60°F would retract approximately 7 3/4 inches (see chart below). A cylinder extended 5 feet in which the oil cools 60°F would only retract approximately 1 1/2 inches. The rate at which the oil cools depends on many factors and will be more noticeable with a larger difference in oil temperature verses the ambient temperature.

Thermal contraction coupled with improper lubrication or improper wear pad adjustments may, under certain conditions, cause a "stick-slip" condition in the boom. This "stick-slip" condition could result in the load not moving smoothly. Proper boom lubrication and wear pad adjustment is important to permit the boom sections to slide freely. Slow movement, of the boom may be undetected by the operator unless a load is suspended for a long period of time. To

minimize the effects of thermal contraction or "Stick-slip" it is recommended that the telescope control lever is activated periodically in the extend position to mitigate the effects of cooling oil.

If a load and the boom is allowed to remain stationary for a period of time and the ambient temperature is cooler than the trapped oil temperature, the trapped oil in the cylinders will cool. The load will lower as the telescope cylinder(s) retracts allowing the boom to come in. Also, the boom angle will decrease as the lift cylinder(s) retracts causing an increase in radius and a decrease in load height.

This situation will also occur in reverse. If a crane is set up in the morning with cool oil and the daytime ambient temperature heats the oil, the cylinders will extend in similar proportions.

The charts below have been prepared to assist you in determining the approximate amount of retraction/extension that may be expected from a hydraulic cylinder as a result of change in the temperature of the hydraulic oil inside the cylinder. The chart is for dry rod cylinders. If the cylinder rod is filled with hydraulic oil, the contraction rate is somewhat greater.

NOTE: Operators and service personnel must be aware that load movement, as a result of this phenomena, can be easily mistaken as leaking cylinder seals or faulty holding valves. If leaking seals or faulty holding valves are suspected to be the problem, refer to Service Bulletin 98-036 dealing with testing telescope cylinders.

Table 2-4 Boom Drift Chart (Cylinder length change in inches)

Coeff. =	0.00043	(in ³ /in ³ / °F)								
STROKE				Temper	ature Char	nge (°F)				
(FT.)	10	20	30	40	50	60	70	80	90	100
5	0.26	0.52	0.77	1.03	1.29	1.55	1.81	2.06	2.32	2.58
10	0.52	1.03	1.55	2.06	2.58	3.10	3.61	4.13	4.64	5.16
15	0.77	1.55	2.32	3.10	3.87	4.64	5.42	6.19	6.97	7.74
20	1.03	2.06	3.10	4.13	5.16	6.19	7.22	8.26	9.29	10.32
25	1.29	2.58	3.87	5.16	6.45	7.74	9.03	10.32	11.61	12.90
30	1.55	3.10	4.64	6.19	7.74	9.29	10.84	12.38	13.93	15.48
35	1.81	3.61	5.42	7.22	9.03	10.84	12.64	14.45	16.25	18.06
40	2.06	4.13	6.19	8.26	10.32	12.38	14.45	16.51	18.58	20.64
45	2.32	4.64	6.97	9.29	11.61	13.93	16.25	18.58	20.90	23.22
50	2.58	5.16	7.74	10.32	12.90	15.48	18.06	20.64	23.22	25.80
55	2.84	5.68	8.51	11.35	14.19	17.03	19.87	22.70	25.54	28.38
60	3.10	6.19	9.29	12.38	15.48	18.58	21.67	24.77	27.86	30.96

Table 2-5 Boom Drift Chart (Cylinder length change in millimeters)

Coeff. =	0.000774	(1/ °C)									
STROKE				Temper	ature Chan	ge (°C)					
(m)	5	10	15	20	25	30	35	40	45	50	55
1.5	5.81	11.61	17.42	23.22	29.03	34.83	40.64	46.44	52.25	58.05	63.86
3	11.61	23.22	34.83	46.44	58.05	69.66	81.27	92.88	104.49	116.10	127.71
4.5	17.42	34.83	52.25	69.66	87.08	104.49	121.91	139.32	156.74	174.15	191.57
6	23.22	46.44	69.66	92.88	116.10	139.32	162.54	185.76	208.98	232.20	255.42
7.5	29.03	58.05	87.08	116.10	145.13	174.15	203.18	232.20	261.23	290.25	319.28
9	34.83	69.66	104.49	139.32	174.15	208.98	243.81	278.64	313.47	348.30	383.13
10.5	40.64	81.27	121.91	162.54	203.18	243.81	284.45	325.08	365.72	406.35	446.99
12	46.44	92.88	139.32	185.76	232.20	278.64	325.08	371.52	417.96	464.40	510.84
13.5	52.25	104.49	156.74	208.98	261.23	313.47	365.72	417.96	470.21	522.45	574.70
15	58.05	116.10	174.15	232.20	290.25	348.30	406.35	464.40	522.45	580.50	638.55
16.5	63.86	127.71	191.57	255.42	319.28	383.13	446.99	510.84	574.70	638.55	702.41
18	69.66	139.32	208.98	278.64	348.30	417.96	487.62	557.28	626.94	696.60	766.26

Length change in mm = Stroke (m) X Temperature Change (°C) X Coeff. (1/ °C) X 1000 mm/m



LIFT CYLINDER

Description

The lift cylinder (Figure 2-28) has a bore of 22.8 cm (9.0 inches). The retracted length of the cylinder from the center of the barrel bushing to the center of the rod bushing is 265.1cm (104.4 inches). The extended length of the cylinder from the center of the barrel bushing to the center of the rod bushing is 464.5 cm (182.9 inches). Its stroke is 199.3 cm (78.5 inches). A wiper ring prevents foreign material from entering the cylinder. O-rings and other seals prevent internal and external leakage.

The cylinder weighs approximately 521 kg (1149 lb).

Maintenance

Disassembly

- **NOTE:** Any maintenance requiring disassembly of the cylinders should include replacement of all seals and rings. A seal kit will supply the required items.
- 1. Disconnect the tube assembly from the holding valve.
- 2. Remove the capscrews and washers securing the holding valve and remove the holding valve from the cylinder barrel.
- **3.** Using a spanner wrench or chain wrench, unscrew the head from the barrel.

Do not use air pressure to remove the rod. Use only a source of controlled hydraulic oil pressure if the rod is hard to move.

CAUTION

Exercise extreme care when handling or setting down the rod. Damage to the rod surface may cause unnecessary maintenance and expense.

- 4. Remove the rod and attached parts from the barrel.
- **NOTE:** Cover the barrel opening to avoid contamination.

CAUTION

When removing seals and rings, avoid scratching the grooved and gland surfaces.

5. Remove the two hydrolock seals and guidelock ring from the outside of the piston.

- **NOTE:** Arranging discarded seals and rings in the order of disassembly will aid in installation of new seals and rings. Pay attention to how each seal and ring is installed to avoid installing replacement seals and rings improperly.
- 6. Remove the set screw securing the piston to the rod.
- 7. Unscrew the piston from the rod.
- **8.** Remove the O-ring and two backup rings from the inside of the piston.
- 9. Remove the head from the rod.
- **10.** Remove the O-ring and the backup ring from the outside of the head and the wear rings, buffer seal, rod seal, and wiper ring from the inside of the head.

Inspection

- 1. Clean all parts with solvent and dry with compressed air. Inspect all parts for serviceability.
- 2. Inspect the barrel carefully for scoring. If barrel is scored, it must be repaired or replaced.
- **3.** Check piston for damage. If piston is damaged, determine if it can be repaired or must be replaced.
- **4.** Inspect rod for straightness. Determine if it can be straightened or must be replaced.

CAUTION

Before installing new seals and rings, clean all surfaces and carefully remove burrs and nicks. Parts displaying excessive wear or damage should be replaced.


- 5. Stone out minor blemishes and polish with a fine crocus cloth.
- 6. Clean with solvent and dry with compressed air any parts that have been stoned and polished.

Assembly

CAUTION

When installing new seals and rings, avoid stretching seals or scratching the grooved or gland surfaces. Make sure parts are clean before and during assembly. Make sure seals and rings are installed in the proper order.


NOTE: Lubricate seals and rings with clean hydraulic oil.




1	Grease Fitting	13	Wear Ring
2	Rod	14	Buffer Seal
3	Setscrew	15	Rod Seal
4	Piston	16	Wiper Ring
5	Seal Assembly	17	Barrel
6	Guidelock Ring	18	Washer
7	Capscrew	19	Plug
8	Backup Ring	20	Holding Valve
9	O-ring	21	Tube Assembly
10	Head	22	Nut
11	Backup Ring	23	Capscrew
12	O-ring	24	Pipe Clamp



 Install the replacement wear rings, buffer seal, rod seal and wiper ring in the inside of the head. Make sure the buffer seal's step is closer to the rod seal. Make sure the rod seal's rim groove is closer to the buffer seal (Figure 2-29).



- **2.** Install the replacement O-ring and the backup ring on the outside of the head.
- **3.** Install the replacement O-ring and backup rings in the inside of the piston.
- 4. Lubricate the rod with clean hydraulic oil.
- 5. Slide the head, wiper ring end first, onto the rod.
- 6. Screw the piston onto the rod until tight. Secure the piston with the set screw.



- Install the replacement hydrolock seals on the outside of the piston. Make sure the "vees" on the two hydrolock seals point at each other (Figure 2-30).
- 8. Lubricate all parts freely with clean hydraulic oil.

CAUTION

Exercise extreme care when handling the rod. Damage to the rod surface may cause unnecessary maintenance and expense. Also, take care to avoid damaging grooved or gland surfaces or rings or seals during rod insertion.

- **9.** Remove the cover from the barrel. Insert the rod and attached parts into the barrel with a slight twisting motion.
- **10.** Using a spanner wrench or chain wrench, screw the head into place in the barrel.

CAUTION

Do not use air pressure to cycle or pressurize the cylinder.

- **11.** Position the holding valve on the cylinder barrel and secure with four capscrews and washers. Torque capscrews 97.6 to 105.7 Nm (72 to 78 pounds-foot). Connect tubing to holding valve.
- **12.** Pressurize and cycle the cylinder with hydraulic oil pressure. Test the cylinder at 41,368 kPa/413.6 bar (6000 psi). Check for proper operation and any leakage. Make repairs as needed.

DUAL ROD TELESCOPE CYLINDER

Description

The boom dual rod telescope cylinder has a 16.0 cm (6.31 inch) bore. The cylinder is internally ported (rod ported). Oil from the telescope control valve is routed to the cylinder by external lines. Foreign material is prevented from entering the cylinder rod during retraction by a wiper ring in the head. O-ring seals prevent internal and external leakage (Figure 2-31).

The cylinder incorporates two cylinder rods with separate strokes. One rod has a stroke of 674.8 cm (265.7 in), and one rod has a stroke of 687.7 cm (270.75 in), which provides a combined overall stroke of 1362.7 cm (536.5 in).

CAUTION

Do not retract the cylinder completely if it is not attached to the boom. Maintain a spacer that is split or hinged 6.88" long to prevent cylinder from retracting completely.

The cylinder weighs approximately 907 kg (1995.5 lb) wet.

Maintenance

Disassembly

- **NOTE:** Any maintenance requiring disassembly of the cylinder should include replacement of all cylinder seals and O-rings.
- 1. Using a spanner wrench, unscrew the outer cylinder head from the cylinder barrel.

Do not use air pressure to remove the cylinder rod assembly. Use only a source of controlled hydraulic oil pressure if the rod is hard to remove.

CAUTION

Exercise extreme care when handling or setting down the cylinder rod. Do not damage the chrome surface.

2. Remove the cylinder rod assembly from the cylinder barrel and cover the barrel to avoid contamination.

CAUTION

When removing seals and rings, avoid scratching grooved and gland surfaces.

- **NOTE:** Aligning discarded seals and rings in the order of disassembly will facilitate installation of new seals and rings.
- **3.** Remove the hydrolock piston seal to gain access to the setscrew securing the piston to the outer cylinder rod.
- **4.** Remove the setscrew and unscrew the piston from the cylinder rod.
- 5. Remove the remaining hydrolock seal and wear ring from the outside of the piston and the O-ring and two backup rings from the inside of the piston.
- 6. Remove the spacer from the rod.
- 7. Remove the O-ring from the rod.
- 8. Remove the cylinder head from the outer rod.
- **9.** Remove the O-ring and backup ring from the outside of the head and the wear ring, buffer seal, rod seal and wiper ring from the inside of the head.
- **10.** Using a spanner wrench, unscrew the inner cylinder head from the outer cylinder rod.

CAUTION


Do not use air pressure to remove the cylinder rod assembly. Use only a source of controlled hydraulic oil pressure if the rod is hard to remove.

CAUTION

Exercise extreme care when handling or setting down the cylinder rod. Do not damage the chrome surface.

- **11.** Remove the inner cylinder rod assembly from the outer cylinder rod and cover the opening to avoid contamination.
- **12.** Remove the hydrolock piston seal to gain access to the setscrew securing the piston to the inner cylinder rod.
- **13.** Remove the setscrew and unscrew the piston from the cylinder rod.
- **14.** Remove the remaining hydrolock seal from the outside of the piston and the O-ring and two backup rings from the cylinder rod.
- 15. Remove the O-ring from the rod.
- **16.** Remove the spacer from the rod and remove the wear ring from the spacer.
- 17. Remove the cylinder head from the inner rod.
- **18.** Remove the O-ring and backup ring from the outside of the head and the wear rings, buffer seal, rod seal and wiper ring from the inside of the head.
- **19.** If necessary, remove the socket head capscrews and remove the counterbalance valve.





1	Barrel	17	Setscrew
2	Piston	18	Seal Assembly
3	Seal Assembly	19	O-ring
4	O-ring		Backup Ring
5	Backup Ring	21	Spacer
6	Spacer	22	O-ring
7	O-ring	23	Head
8	Head	24	Backup Ring
9	Backup Ring	25	O-ring
10	O-ring	26	Wiper Ring
11	Wiper Ring	27	Rod Seal
12	Rod Seal	28	Buffer Seal
13	Buffer Seal	29	Wear Ring
14	Wear Ring	30	Rod
15	Rod	31	plug
16	Piston	32	Counterbalance Valve

Inspection

1. Clean all parts with solvent and dry with compressed air. Inspect for damaged or worn parts and replace as required.

CAUTION

Clean all surfaces and remove all burrs and nicks before installing new seals and rings. Replace all damaged or worn parts.

- 2. Stone out minor blemishes and polish with fine crocus cloth.
- **3.** Clean all with solvent and dry with compressed air any parts that have been stoned and polished.
- 4. Inspect the barrel for scoring.

Assembly

1. If removed, install the counterbalance valve with the socket head capscrews.


CAUTION

When installing new seals and rings, clean all surfaces and carefully remove burrs and nicks. Parts displaying excessive wear or damage should be replaced.


- **NOTE:** Lubricate new seals and rings with clean hydraulic oil.
- **NOTE:** Locate the gap of wear ring 180 degrees with respect to each other.
- 2. Install the wiper ring, wear rings, buffer seal, rod seal and wiper ring in the inner cylinder head ensuring the seals are assembled properly and installed in the correct direction (Figure 2-32).
- **3.** Install the O-ring and backup ring onto the outside of the head.

CAUTION

Improper seal installation can cause faulty cylinder operation.



- 4. Install the inner cylinder head onto the inner cylinder rod.
- 5. Install the spacer onto the rod.
- 6. Install the O-rings onto the rod. Secure the piston in place with the setscrew.



7. Install the hydrolock seals onto the piston (Figure 2-33).

CAUTION

Avoid scratching or damaging the grooved and gland surfaces or the seals and rings.


- **8.** Lubricate the inner cylinder rod assembly with clean hydraulic oil and install the rod assembly into the outer cylinder rod with a slight twisting motion.
- **9.** Using a spanner wrench, secure the inner cylinder head to the outer cylinder rod.




10. Install the wiper ring, wear ring, buffer seal and rod seal into the head ensuring the seals are assembled properly and installed in the correct direction (Figure 2-34).

CAUTION

Improper installation of seals could cause faulty cylinder operation.



- 11. Install the O-ring and backup ring onto the outside of the outer cylinder head.
- 12. Install the outer cylinder head onto the outer cylinder rod.
- 13. Install the spacer onto the rod.
- 14. Install the O-ring and backup rings into the inside of the piston. Install the piston onto the outer cylinder rod. Secure the piston in place with the setscrew.



CAUTION

Avoid scratching or damaging the grooved or gland surfaces or the ring and seals.

- 16. Lubricate the outer cylinder rod assembly with clean hydraulic oil and install the rod assembly into the cylinder barrel with a slight twisting motion.
- 17. Using a spanner wrench, secure the outer cylinder head to the cylinder barrel.



Do not use air pressure to cycle or pressurize the cylinder.

18. Pressurize and cycle the cylinder with hydraulic oil pressure. Test the cylinder at 24,132 kPa/241 bar (3500 psi). Check for proper operation and any leakage.

AXLE OSCILLATION LOCKOUT CYLINDER

Description

The two oscillation lockout cylinders (Figure 2-36) standard or (Figure 2-37) (CE Option) each have 12.7 cm (5 inch) diameter bores. The retracted length of each cylinder is 48.8 cm (19.25 inches) from the center of the lug holes to the center of the barrel bushing. The extended length of each cylinder from the center of the lug holes to the center of the barrel bushing is 65.5 cm (25.8 inches). Its stroke is 16.8 cm (6.62 inches). A wiper ring prevents foreign material from entering each cylinder. O-rings and other seals prevent internal and external leakage.

The cylinder weighs approximately 38.8 kg (85.5 pounds).

Maintenance

Disassembly

- **NOTE:** Any maintenance requiring disassembly of the cylinder should include replacement of all cylinder seals.
- 1. Clean away all dirt from the head. Place protective padding around the rod near the head to prevent damaging the chrome. Using a spanner wrench, unscrew the head from the barrel.



Do not use air pressure to remove the rod. Use only a source of controlled hydraulic oil pressure if the rod is hard to remove.

CAUTION

Exercise extreme care when handling or setting down the rod. Do not damage the chrome surface.

- 2. Open both ports on the side of the cylinder barrel and drain the oil from the cylinder.
- **3.** Secure cylinder barrel in a chain vise without putting pressure on the side feeder tube preferably in the vertical position with the rod assembly up.
- **4.** Using a screwdriver, or 1/4 inch wrench, remove the screw from the head.
- 5. Remove the grease fitting from the rod
- **6.** Turn the head counterclockwise with a fitted spanner wrench until the threads disengage.
- **NOTE:** Residual oil will spill over the end of the barrel when the rod assembly is extended. Make provisions to contain the oil.

- **7.** Using a hoist, extend the rod assembly slowly until the piston is free of the barrel.
- 8. Remove the rod and attached parts from the barrel.
- **NOTE:** Cover the barrel opening to avoid contamination.

CAUTION

When removing seals and rings, avoid scratching the grooved and gland surfaces.

- **9.** Remove the lip seals and wear ring from the outside of the piston.
- **NOTE:** Arranging discarded seals and rings in the order of disassembly will aid in installation of new seals and rings. Pay attention to how each seal and ring is installed to avoid installing replacement seals and rings improperly.
- **10.** Remove the retaining ring from the rod.
- **11.** Remove the head from the rod. Remove the O-ring and backup ring from the outside of the head. Remove the wear ring, buffer seal, lip seal and wiper ring from the inside of the head.


Inspection

- 1. Inspect the rod. There should be no scratches or pits deep enough to catch the fingernail. Pits that go to the base metal are unacceptable. Chrome should be present over the entire surface of the rod. If lack of chrome on rod, the rod should be replaced.
- **2.** Inspect rod for straightness. Determine if it can be straightened or must be replaced.
- **3.** Inspect the head. Visually inspect the inside bore for scratching or polishing. Deep scratches are unacceptable. Polishing indicates uneven loading, and the bore should be checked for out-of-roundness.
- 4. Inspect the piston. Visually inspect the outside surface for scratches or polishing, Deep scratches are unacceptable. Polishing indicates uneven loading, and the diameter should be checked for out-of roundness.
- 5. Inspect the barrel carefully for scoring. If barrel is scored, it must be repaired or replaced.
- 6. Thoroughly rinse parts, allow to drain, and wipe with a lint-free rag. Inspect all parts for serviceability.

CAUTION


Before installing new seals and rings, clean all surfaces and carefully remove burrs and nicks. Parts displaying excessive wear or damage should be replaced.





ltem	Description	
1	Barrel	
2	Rod	
3	Head	
4	Lip Seal Ring	
5	Wear Ring	
6	O-ring	
7	Backup Ring	
8	Buffer Ring	
9	Wear Ring	

_	ltem	Description
	10	Lip Seal Ring
-	11	Wiper Ring
-	12	Retainer Ring
-	13	Bleeder Plug
-	14	Grease Fitting
-	15	Grease Fitting
-	16	Screw
-	17	O-ring
-	18	Cap Assembly



Item	Description	ltem	Description
1	Barrel	11	Wiper Ring
2	Rod Assembly	12	Retainer Ring
3	Head	13	Bleeder Plug
4	Lip Seal	14	Grease Fitting
5	Wear Ring	15	Grease Fitting
6	O-ring	16	Screw
7	Backup Ring	17	O-ring
8	Wear Ring	18	Plug
9	Buffer Ring	19	Plug
10	Lip Seal	20	Check Valve



2

- **7.** Stone out minor blemishes and polish with a fine crocus cloth.
- **8.** Clean with solvent and dry with compressed air any parts that have been stoned and polished.

Assembly

CAUTION

When installing new seals and rings, avoid stretching seals or scratching the grooved or gland surfaces. Make sure parts are clean before and during assembly. Make sure seals and rings are installed in the proper order.

NOTE: Lubricate seals and rings with clean hydraulic oil.

- 1. Install the replacement wiper ring, lip seal, buffer seal and wear ring in the inside of the head.
- **2.** Install the replacement O-rings and backup ring on the outside of the head.
- **3.** Install the lip seals and wear ring onto the outside of the piston.
- 4. Lubricate the rod with clean hydraulic oil.
- 5. Slide the head, onto the rod. Tap the head with a rubber mallet to engage the seals. Push the head about half way down the length of the rod assembly.
- 6. Remove the cover from the barrel.

CAUTION

Exercise extreme care when handling the rod. Damage to the rod surface may cause unnecessary maintenance and expense. Also, take care to avoid damaging grooved or gland surfaces or rings or seals during rod insertion.

- 7. With a hoist, raise the rod assembly back into a vertical position taking care not to damage the OD seals on the head and piston.
- 8. Lubricate the OD seals on the piston and head with clean light oil and lower the assembly into the barrel. Stop just before the head enters the barrel.
- **9.** Place a spanner wrench on the head and turn counterclockwise until the thread clicks, then reverse direction to clockwise and thread in until there is no gap between the head shoulder and top of barrel.
- **10.** Install the retaining ring onto the rod.
- **11.** Install the setscrew into the head.

CAUTION

Do not use air pressure to cycle or pressurize the cylinder.

12. Pressurize and cycle the cylinder with hydraulic oil pressure. Test the cylinder at 25,856 kPa/259 bar (3750 psi). Check for proper operation and any leakage. Make repairs as needed.

STEER CYLINDER

Description

The steer cylinders (Figure 2-38) are mounted on the axles, two cylinders on each axle. The front and rear steer cylinders each have 6.3 cm (2.5 inch) diameter bores. The front and rear steer cylinders each have a retracted length of 53.1cm (20.94 inches) from bushing center to bushing center. The front and rear steer cylinders each have an extended length of 74.1cm (29.19 inches) from bushing center to bushing center to bushing center. Each cylinder has a stroke of 20.9 cm (8.25 inches). A wiper ring prevents foreign material from entering each cylinder. O-rings and other seals prevent internal and external leakage.

The cylinder weighs approximately 9.07 kg (19.9 pounds).

Maintenance

Disassembly

- **NOTE:** Any maintenance requiring disassembly of the cylinders should include replacement of all seals and rings. A seal kit will supply the required items.
- 1. Secure the cylinder in a clean work area by use of clamps or a chain vise to prevent rolling.
- 2. Retract the cylinder fully to avoid damaging the rod during removal.
- **NOTE:** Mark or note the piston and head relationship to the rod and barrel.
- 3. Clean away all dirt from the head. Place protective padding around the rod near the head to prevent damaging the chrome during head removal.

Do not use air pressure to remove the rod. Use only a source of controlled hydraulic oil pressure if the rod is hard to move.

CAUTION

Exercise extreme care when handling or setting down the rod. Damage to the rod surface may cause unnecessary maintenance and expense.

- 4. Position the rod mount with the ports facing down.
- **5.** Using a means of collecting the oil, remove the port plugs and allow cylinder to drain.
- 6. Rapidly pull the rod against the head to free it. Remove rod and attached parts from the barrel. Place the rod on a surface that will not damage the chrome or allow the rod assembly to drop.

NOTE: Cover the barrel opening to avoid contamination.

CAUTION

When removing seals and rings, avoid scratching the grooved and gland surfaces.

- 7. Remove the seal from the outside of the piston.
- **NOTE:** Arranging discarded seals and rings in the order of disassembly will aid in installation of new seals and rings. Pay attention to how each seal and ring is installed to avoid installing replacement seals and rings improperly.
- **8.** Loosen and remove the nut securing the piston. Remove the piston from the rod.
- 9. Remove the O-ring from the inside of the piston.
- **10.** Remove the head from the rod. Remove the O-ring and backup ring from the outside of the head. Remove the wiper ring and the rod seal from the inside of the head.

Inspection

Clean all parts with solvent and dry with compressed air.
 Inspect for damaged or worn parts and replace as required.

CAUTION

Clean all surfaces and remove all burrs and nicks before installing new seals and rings. Replace all damaged or worn parts.

- 2. Stone out minor blemishes and polish with fine crocus cloth.
- **3.** Clean all with solvent and dry with compressed air any parts that have been stoned and polished.
- 4. Inspect the barrel for scoring.


Assembly

CAUTION

When installing new seals and rings, clean all surfaces and carefully remove burrs and nicks. Parts displaying excessive wear or damage should be replaced.

- **NOTE:** Lubricate new seals and rings with clean hydraulic oil.
- 1. Install the replacement wiper ring into the head.
- **2.** Install the rod seal in the inside of the head. Make sure the lips of the seal face the piston.





ltem	Description	ltem	Description
1	Barrel	7	Piston Seal Ring
2	Rod	8	O-ring
3	Head	9	Back-up Ring
4	Piston	10	Rod Seal Ring
5	Nut	11	Wiper Ring
6	O-ring		

HYDRAULIC SYSTEM

- **3.** Install the O-ring and backup ring onto the outside of the head.
- 4. Install the O-ring in the inside of the piston.
- **5.** Lubricate the rod with clean hydraulic oil.
- 6. Slide the head, larger OD end first, onto the rod.
- 7. Install the piston onto the rod. Secure the piston with the nut. Lubricate the threads and torque the nut to 176.2 ± 6.7 Nm (130 ± 5 pounds-foot).
- 8. Install the seal on the outside of the piston.
- 9. Lubricate all parts freely with clean hydraulic oil.

CAUTION

Exercise extreme care when handling the rod. Damage to the rod surface may cause unnecessary maintenance and expense. Also, take care to avoid damaging grooved or gland surfaces or rings or seals during rod insertion.

- **10.** Remove the cover from the barrel. Insert the rod and attached parts into the barrel with a slight twisting motion.
- **11.** Push the head into the barrel. Torque the head 27.1 Nm (20 pounds-foot).

CAUTION

Do not use air pressure to cycle or pressurize the cylinder.

 Pressurize and cycle the cylinder with hydraulic oil pressure. Test the cylinder at 20,684 kPa/206.8 bar (3000 psi). Check for proper operation and any leakage. Make repairs as needed.



OUTRIGGER EXTENSION CYLINDER

Description

The four extension cylinders (Figure 2-39) have 6.4 cm (2.5inch) diameter bores. Each cylinder has a retracted length of 218.1 \pm 0.30 cm (85.88 \pm 0.12 inches) from the center of the rod bushing to the center of the barrel bushing. Each cylinder's extended length is 403.5 cm (157.87 inches). The stroke of each cylinder is 185.4 cm (73.0 inches). A wiper ring prevents foreign material from entering each cylinder. Orings and other seals prevent internal and external leakage.

The cylinder weighs approximately 42 kg (112.5 pounds).

Maintenance

Disassembly

- **NOTE:** Any maintenance requiring disassembly of the cylinders should include replacement of all seals and rings. A seal kit will supply the required items.
- 1. Remove all dirt, grease and other contaminants from around the ports and the head

Do not use air pressure to remove the rod. Use only a source of controlled hydraulic oil pressure if the rod is hard to move.

CAUTION

Exercise extreme care when handling or setting down the rod. Damage to the rod surface may cause unnecessary maintenance and expense.

- 2. Using a spanner wrench, unscrew the cylinder head.
- 3. Remove rod and attached parts from the barrel.

NOTE: Cover the barrel opening to avoid contamination.

CAUTION

When removing the seals and rings, avoid scratching the grooved and gland surfaces.

- **4.** Remove the wear rings and piston seal from the outside of the piston.
- **NOTE:** Arranging discarded seals and rings in the order of disassembly will aid in installation of new seals and rings. Pay attention to how each seal and ring is installed to avoid installing replacement seals and rings improperly.
- 5. Remove the nut from the rod.

- 6. Remove the piston and spacer from the rod.
- **7.** Remove the O-ring and the backup ring from the outside of the head.
- **8.** Remove the rod seal, wear ring and wiper ring from the inside of the head.
- 9. Remove the O-ring from the rod.

Inspection

- 1. Clean all parts with solvent and dry with compressed air. Inspect all parts for serviceability.
- **2.** Inspect the barrel carefully for scoring. If barrel is scored, it must be repaired or replaced.
- **3.** Check rod's piston area for damage. If it is damaged, determine if it can be repaired or must be replaced.
- **4.** Inspect rod for straightness. Determine if it can be straightened or must be replaced.

CAUTION

Before installing new seals and rings, clean all surfaces and carefully remove burrs and nicks. Parts displaying excessive wear or damage should be replaced.

- 5. Stone out minor blemishes and polish with a fine crocus cloth.
- **6.** Clean with solvent and dry with compressed air any parts that have been stoned and polished.


Assembly

CAUTION

When installing new seals and rings, avoid stretching seals or scratching the grooved or gland surfaces. Make sure parts are clean before and during assembly. Make sure seals and rings are installed in the proper order.

NOTE: Lubricate seals and rings with clean hydraulic oil.

- 1. Install the replacement wear ring, rod seal and wiper ring in the inside of the head.
- **2.** Install the replacement O-ring and the backup ring on the outside of the head.
- 3. Install the O-ring onto the rod.
- 4. Lubricate the rod with clean hydraulic oil.
- 5. Slide the head onto the rod.
- 6. Install the spacer and piston on the rod.
- 7. Install the locknut onto the rod.



ltem	Description	Item	Description
1	Barrel	8	Wear Ring
2	Rod	9	O-ring
3	Piston	10	O-ring
4	Head	11	Backup Ring
5	Spacer	12	Seal
6	Nut	13	Wiper
7	Piston Seal	14	Wear Ring



RT530E-2 SERVICE MANUAL

- **8.** Install the replacement piston seal and wear rings on the outside of the piston.
- 9. Lubricate all parts freely with clean hydraulic oil.

CAUTION

Exercise extreme care when handling the rod. Damage to the rod surface may cause unnecessary maintenance and expense. Also, take care to avoid damaging grooved or gland surfaces, rings or seals during rod insertion.

- **10.** Remove the cover from the barrel. Insert the rod and attached parts into the barrel with a slight twisting motion.
- **11.** Push the head into the barrel.

CAUTION

Do not use air pressure to cycle or pressurize the cylinder.

Pressurize and cycle the cylinder with hydraulic oil pressure. Test the cylinder at 20,700 kPa (270 bar) (3000 psi). Check for proper operation and any leakage. Make repairs as needed.

OUTRIGGER JACK CYLINDER

Description

The four outrigger jack cylinders (Figure 2-40) each have a hollow rod for internal porting. Each cylinder has a 10.1 cm (4.0 inch) diameter bore. A port block is welded to the rod of each cylinder and a pilot operated check valve is threaded into each port block. The retracted length of the cylinder from the end of the barrel to the center of the rod's port block rod bushing is 122.2 ± 30.8 cm ($48.12 \pm .12$ in). The extended length of the cylinder from the end of the cylinder from the end of the barrel to the center of the barrel to the center of the rod's port block rod bushing is 185.7 cm (73.12 in). Its stroke is 63.5 cm (25 in). A wiper ring prevents foreign material from entering the cylinder. O-rings and other seals prevent internal and external leakage

The cylinder weighs approximately 64.6 kg (142.52 lb).

Maintenance

Disassembly

- **NOTE:** Any maintenance requiring disassembly of the cylinder should include replacement of all cylinder seals.
- 1. Clean away all dirt from the head. Place protective padding around the rod near the head to prevent

damaging the chrome. Using a spanner wrench, unscrew the head from the barrel.

Do not use air pressure to remove the rod. Use only a source of controlled hydraulic oil pressure if the rod is hard to remove.

CAUTION

Exercise extreme care when handling or setting down the rod. Do not damage the chrome surface.

- 2. Open ports on the side of the cylinder barrel and drain the oil from the cylinder.
- **3.** Secure cylinder barrel in a chain vise without putting pressure on the side feeder tube in the vertical position with the rod assembly up.
- **4.** Using a 5/32 inch Allen wrench, remove the setscrew on the barrel OD at the head.
- **NOTE:** Oil or oil/air mixture may rapidly exit out of the ports during rod extension. Shield the work area from the exiting oil.
- 5. With the ports open, extend the rod assembly with a hoist enough to access the top of the head with spanner wrench. Do not extend completely.
- **6.** Turn the head counterclockwise with a fitted spanner wrench until the threads disengage.
- 7. Extend the rod assembly slowly until the piston is free of the barrel assembly. Place the rod assembly horizontally on a workbench taking care not to damage the surface of the rod.

NOTE: Cover the barrel opening to avoid contamination.


- **8.** Remove the piston seal to gain access to the piston setscrew Using a 3/16 inch Allen wrench, remove the setscrew from the piston.
- **9.** Remove the piston by turning counterclockwise with a fitted spanner wrench.
- **10.** Remove the spacer and head from the rod.

CAUTION

When removing seals and rings, avoid scratching the grooved and gland surfaces.

11. Remove the seal assembly from the outside of the piston and the O-ring and backup rings from he inside of the piston.

- **NOTE:** Arranging discarded seals and rings in the order of disassembly will aid in installation of new seals and rings. Pay attention to how each seal and ring is installed to avoid installing replacement seals and rings improperly.
- **12.** Remove the O-ring and backup ring from the outside of the head. Remove the wear rings, buffer seal, rod seal and wiper ring from the inside of the head.



1	Barrel	11	Rod Seal
2	Rod	12	Buffer Seal
3	Head	13	Wear Ring
4	Piston	14	O-ring
5	Spacer	15	Backup Ring
6	Check Valve	16	Seal Assembly
7	Setscrew	17	Backup Ring
8	Insert	18	O-ring
9	Plug	19	Setscrew
10	Wiper Ring	20	Insert



2

Inspection

- Inspect the rod. There should be no scratches or pits deep enough to catch the fingernail. Pits that go to the base metal are unacceptable. Chrome should be present over the entire surface of the rod. If lack of chrome on rod, the rod should be replaced.
- **2.** Inspect rod for straightness. Determine if it can be straightened or must be replaced.
- **3.** Inspect the head. Visually inspect the inside bore for scratching or polishing. Deep scratches are unacceptable. Polishing indicates uneven loading, and the bore should be checked for out-of-roundness.
- 4. Inspect the piston. Visually inspect the outside surface for scratches or polishing, Deep scratches are unacceptable. Polishing indicates uneven loading, and the diameter should be checked for out-of roundness.
- **5.** Inspect the barrel carefully for scoring. If barrel is scored, it must be repaired or replaced.
- 6. Thoroughly rinse parts, allow to drain, and wipe with a lint-free rag. Inspect all parts for serviceability.

CAUTION

Before installing new seals and rings, clean all surfaces and carefully remove burrs and nicks. Parts displaying excessive wear or damage should be replaced.

- **7.** Stone out minor blemishes and polish with a fine crocus cloth.
- 8. Clean with solvent and dry with compressed air any parts that have been stoned and polished.

Assembly

CAUTION

When installing new seals and rings, avoid stretching seals or scratching the grooved or gland surfaces. Make sure parts are clean before and during assembly. Make sure seals and rings are installed in the proper order.

NOTE: Lubricate seals and rings with clean hydraulic oil.

- 1. Install the replacement wiper ring, rod seal, buffer seal and wear rings in the inside of the head.
- **2.** Install the replacement O-ring and backup ring on the outside of the head.
- **3.** Lubricate the rod with clean hydraulic oil.
- 4. Slide the head, onto the rod. Tap the head with a rubber mallet to engage the seals. Push the head about half way down the length of the rod assembly.
- 5. Install the spacer onto the rod with the ID lip at the piston end.
- **6.** Install the setscrew in the piston with a 3/16 inch Allen wrench until hand tight. Install the seal assemblies onto the piston.
- 7. Remove the cover from the barrel.

CAUTION

Exercise extreme care when handling the rod. Damage to the rod surface may cause unnecessary maintenance and expense. Also, take care to avoid damaging grooved or gland surfaces or rings or seals during rod insertion.

- **8.** With a hoist, raise the rod assembly back into a vertical position taking care not to damage the OD seals on the head and piston.
- **9.** Lubricate the OD seals on the piston and head with clean light oil and lower the assembly into the barrel. Stop just before the head enters the barrel.
- **10.** Place a spanner wrench on the head and turn counterclockwise until the thread clicks, then reverse direction to clockwise and thread in until there is no gap between the head shoulder and top of barrel.
- **11.** Using a 5/32 inch Allen wrench install the setscrew into the head until hand tight.
- **12.** Slowly lower the rod down to the fully retracted position.

CAUTION

Do not use air pressure to cycle or pressurize the cylinder.

 Pressurize and cycle the cylinder with hydraulic oil pressure. Test the cylinder at 31,026 kPa/310.2 bar (4500 psi). Check for proper operation and any leakage. Make repairs as needed. THIS PAGE BLANK



SECTION 3 ELECTRIC SYSTEM

SECTION CONTENTS

Description	3-1
General	3-1
Alternator	3-1
Batteries	3-1
Fuse Panel	3-2
Relays	3-3
Maintenance	3-4
General	3-4
General Troubleshooting	3-4
Troubleshooting Swivel-Caused Electrical	
Problems	3-4
Connector Troubleshooting	3-4
Troubleshooting Engine Starting Problems	3-5
Troubleshooting Engine Charging Problems	3-5

Troubleshooting Accessories
Alternator Replacement
Starter Replacement 3-7
Battery Replacement 3-8
Relay Panel Component Replacement 3-8
Rocker Switch Replacement
Ignition Switch Replacement
Turn Signal Lever and Transmission Shift Lever
Replacement
Windshield Wiper Assembly Replacement 3-12
Windshield Washer Assembly Replacement 3-13
Skylight Wiper Assembly Replacement 3-13
Appendix A: Crane Control System (CCS) Fault
Codes

DESCRIPTION

General

The electrical system is 24-volt operation with 24-volt starting, consisting of an alternator and two lead-acid batteries. The system is the single wire ground return type, using the machine's structure as ground

Alternator


The alternator is mounted on the engine and is belt driven. It is a 70 ampere alternator with an integral transformer rectifier unit. When the engine is running, and the alternator is turning, the alternator's 24-volt output terminal supplies the crane's electrical circuits. The output terminal also supplies current to recharge the batteries and maintains them at a full state of charge.

Batteries

The batteries (1) (Figure 3-1) are located in a box on the left side of the crane. The batteries are the maintenance free type and completely sealed except for a small vent hole in the side. The vent hole allows what small amount of gases that are produced in the battery to escape. On some batteries, a test indicator located on the top of the battery is used to determine if the battery can be tested in case of a starting problem.


There is a battery disconnect switch (1) (Figure 3-2) located on the right of the battery box. To disconnect the batteries, turn the battery disconnect switch to OFF. Turn the switch to ON to connect the batteries.





Fuse Panel

Fuses are located behind the seat in the cab (Figure 3-3) and in the battery box fuse panel (3) (Figure 3-4) in the battery box.



The following fuse assignments apply:

Table 3-1: Superstructure Cab Power Panel

Fuse	Protects	Amps	Location	
F1	Dome Light	5	(Figure 3-3)	
F2	ACC Power Outlet/ Heater Motor	10	(Figure 3-3)	
F3	Work Lights	10	(Figure 3-3)	
F4	Steering Column Power	5	(Figure 3-3)	
F5	Key Switch Power	10	(Figure 3-3)	
F6	Turntable Module Battery Power	15	(Figure 3-3)	
F7	Master/Cab Slave Module Battery Power	15	(Figure 3-3)	
F8	Skylight Wiper	10	(Figure 3-3)	
F9	Turntable Option Module Battery Power	15	(Figure 3-3)	
F10	Turntable Option Module Battery Power	15	(Figure 3-3)	
F11	Turntable Module Battery Power	15	(Figure 3-3)	
F12	Diagnostic Tool Power	15	(Figure 3-3)	
F13	Accessory Lights Power	15	(Figure 3-3)	
F14	Oil Cooler	25	(Figure 3-3)	
F15	Heater/AC Panel	10	(Figure 3-3)	
F16	Circulating Fan	5	(Figure 3-3)	
F17	Joystick/Jogdial/ Operator Display Power	5	(Figure 3-3)	
F18	Master/Cab Slave Module PCB Power	5	(Figure 3-3)	
F19	Turntable Module PCB Power	5	(Figure 3-3)	
F20	Spare		(Figure 3-3)	



Table 3-2: Superstructure Cab Fuse Box

Fuse	Protects	Amps	Location
F1	Keyswitch Ignition Relay	3	(Figure 3-3)
F2	Open		(Figure 3-3)
F3	Ignition On Signal	3	(Figure 3-3)
D1	Keyswitch Ignition On Signal		(Figure 3-3)
D2	Brake Pedal Press Switch Signal		(Figure 3-3)
D3	Hazard Lights On Switch Signal		(Figure 3-3)
D4	Marker Lights On Switch Signal		(Figure 3-3)
D5	Horn On Signal		(Figure 3-3)

Table 3-3: Carrier Fuses and Relays


Fuse	Protects	Amps	Location
F1	Superstructure Module 20 (Fi		(Figure 3-4)
F2	CraneStar Power	5	(Figure 3-4)
F3	Diagnostic Tool Power	5	(Figure 3-4)
F4	Carrier Module Battery Power	15	(Figure 3-4)
F5	Carrier Module Battery Power	15	(Figure 3-4)
F6	Engine ECM Power	30	(Figure 3-4)
F7	Relay Power	10	(Figure 3-4)
F8	Reverse Power	15	(Figure 3-4)
F9	Carrier Module PCB Power	15	(Figure 3-4)
KC1	Headlight Relay		(Figure 3-4)
KC2	Starter Lockout Relay		(Figure 3-4)
KC3	Reverse Relay		(Figure 3-4)
KC4	Ignition On Relay		(Figure 3-4)

Table 3-4: Carrier Fuses and Relays

Fuse	Protects	Amps	Location
F51	Alternator	100	(Figure 3-4)
F52	Swivel	100	(Figure 3-4)
F53	Swivel	100	(Figure 3-4)
F54	Swivel	100	(Figure 3-4)
F55	Main Power	125	(Figure 3-4)
F56	Grid Heater Power	100	(Figure 3-4)

Relays

The relays are located at the back of the battery box (Figure 3-4): Includes K-301 start relay (1) and K-302 grid heater relay (2).



3

MAINTENANCE

General

Electrical system maintenance includes troubleshooting and replacement of damaged components. Observe standard wiring practices when replacing components.

If it is necessary to perform electrical maintenance on live or hot circuits, remove all rings, watches, and other jewelry before performing maintenance as serious burns result from accidental grounding or shorting circuits.

CAUTION

Ensure the batteries are disconnected before performing any maintenance on an electrical circuit which is not fused or when performing continuity checks.

Never replace original wiring with wiring of a smaller size (gauge).

General Troubleshooting



Many steps in the troubleshooting procedures require testing live (energized) components. Perform these steps observing good safety practices to avoid electrical shock injury.

- NOTE: Make voltage checks at terminations when components are installed and operating. Make continuity checks (with batteries disconnected) when components are isolated or removed. Troubleshoot per the following guidelines:
- **1.** First, use reported symptoms to identify a problem or a suspect component.
- 2. Test the suspect component per instructions in this section. The instructions identify the circuit breakers and components and guide you from the easiest and most likely problems to the hardest and least likely problems.
- **3.** Using a multimeter, test the circuit for continuity if you suspect a broken circuit or for voltage if you suspect a power problem. Check the electrical schematic and wiring diagram for most accurate wiring information.
- **4.** If the component proves faulty, replace it with a known working component.

- 5. If wiring proves faulty, this is typically the result of another failure within the electrical system. Identify and investigate the root cause of failure. Make necessary component repairs as outlined in the following sections. Proceed to make appropriate wiring fault repair. Wiring repairs must be made using Manitowoc approved materials.
- 6. Splicing sections of broken wire must have terminations that meet minimum pull test requirements listed in table 3-5. Splices must be completely covered with adhesive lined shrink tubing. Tubing must extend beyond any bar conductors by at least ¼".

Table 3-5 Minimum Pull Values (In Ibs)

Wire Gauge	Single Wire	Two Wire Termination
24	10	8
22	15	10
20	20	17
18	30	20
16	40	30
14	60	50
12	70	60
10	80	70
8	90	80
6	100	90
4	140	120

7. After troubleshooting, test the repaired harness. Verify the circuit works properly.

Troubleshooting Swivel-Caused Electrical Problems

Many crane component electrical troubles can be traced to the electrical swivel. Troubles common to the swivel are improper mounting, foreign material between the brushes and slip rings, incorrect wiring from the swivel to the components, incorrect wire size, worn brushes, improper spring tension on the brush assembly, and loose setscrews on the slip ring assembly. Refer to the electrical schematic and wiring diagram for slip ring connections and amperages.

Connector Troubleshooting

The cause of an electrical problem may be a loose or corroded connection in the pin or socket connectors. Check the connectors to ensure that the pins and sockets are properly seated and engaged. If the pins and sockets show any signs of corrosion, use a good quality electrical contact cleaner or fine sandpaper to clean them. When the pins or sockets show signs of arcing or burning, it indicates another failure within the electrical system that might cause the condition. Identify and investigate the root cause of the failure, make necessary component repairs and then proceed to make the necessary wire terminal repairs.



When replacing wire terminals, use the proper crimp tool to ensure the proper crimping method. Refer to the tables at the end of this section listing tools necessary for connector maintenance. These tables list common tools; however, contact Manitowoc CraneCare to ensure the proper crimp tool is available.

Because the pins and sockets are crimped to the wires, it is not possible to remove them. Using the proper extraction tool, remove the pin(s) or socket(s) from the plug or receptacle. Cut the wire as close to the pin or socket as possible. After cutting the pin or socket off, the wire will most likely be too short. Using a wire that is too short will allow pressure to be applied to the pin or socket and wire where they are crimped when the pin or socket is inserted in the plug or receptacle. Splice a short length of wire to the short wire according to the guidelines in the General Troubleshooting section.

Troubleshooting Engine Starting Problems

- 1. Verify the battery terminals are connected and clean, none of the fuses are blown, the transmission is in neutral, and the machine is fueled.
- 2. Try to turn on the head lights, tails lights, marker lights, dome light, work light, or gauge lights and panel lights to verify the battery has at least some charge. If none of these lights comes on, suspect the battery. Charge battery as needed, jump-start the crane or replace the battery when possible.
- **NOTE:** The crane is a 24V machine which requires a 24V source for jump starting.
- 3. If you hear the starter relay clicking repeatedly, power is reaching the starter, but not enough; suspect the battery. Charge battery as needed, jump-start the crane or replace the battery when possible.
- 4. If the problem remains, troubleshoot the starter lockout relay. Use service tool for starter lockout input signal to CCM11. Also, check starter lockout relay to ensure it is energized.
- 5. Using the service tool (see "Using Service Tool Section"), check for proper Keyswitch input signals and Start output signals. With the Service Tool connected to the crane A channel, Select View, Cab, Steering Column. Watch the Keystate value for each position of the Keyswitch:

0=OFF

1=ON

2=START

6. If the battery, fuses, secondary circuit, ignition switch, and power circuit to the ignition switch check out, do one of the following:

- a. If you hear no noise when you try to turn the starter, troubleshoot the start circuit (ignition switch, electric shifter, and wiring from ignition switch to starter relay). Make repairs as needed.
- **b.** If the engine still won't start, and you hear no noise or just a single click, suspect the starter. Troubleshoot the starter circuit from the starter relay through the starter solenoid to the starter motor and ground. Make repairs as needed. If the starter solenoid or the starter motor is faulty, replace the starter.
- c. If the starter engages but can't turn the engine (and the lights dim, signaling power drain during start attempt), check the starter's feed circuit from the batteries for resistance. If the resistance is high, greater than 002Ω , make repairs. If the circuit checks out, replace the starter. If the engine still won't start, suspect a seized engine.
- **d.** If the starter turns the engine, but it still won't start, suspect a fuel problem. Ensure fuel system can draw fuel from the tank and pump it to the engine; make repairs as needed.
- e. If the engine starts, then shuts down, suspect a fuel problem. Ensure fuel system can draw fuel from the tank and pump it to the engine; make repairs as needed.
- 7. Refer to the engine manual for further instructions.
- **NOTE:** If the starter won't disengage during running, verify the starter is mounted properly so its gear won't mesh with the engine's flywheel when not trying to start engine. Troubleshoot the starter relay and ignition switch for closed contacts. If these components check out, replace the starter.

Troubleshooting Engine Charging Problems

- 1. Verify battery terminals are connected and clean and all wires in the charging system are in good repair and are connected properly.
- **2.** Verify the alternator belt is properly installed and is under proper tension.
- **3.** Verify the battery puts out 24 volts minimum. Charge battery as needed so the battery can supply a minimum excitation voltage to the engine's charging system.
- **4.** Verify when the crane is running that the alternator is putting out a minimum of 24 volts DC on the voltmeter.
- 5. Replace the alternator if the other conditions check out.
- 6. Refer to the engine manual for further instructions.
- **NOTE:** If the alternator runs noisily, check belt tension. If problem persists, replace alternator.

NOTE: If the alternator overcharges (voltmeter reads high, light bulbs turn out quickly), look for a ground where one shouldn't exist. If external wiring checks out, replace alternator. (The alternator probably has an internal ground or a faulty internal voltage regulator.)

Troubleshooting Accessories

If the crane's engine starts and charges properly, but none of its components except the horn or lights work, the accessory circuitry may be faulty. Check as follows:

- 1. Turn the ignition switch to ON (Position 1). Try to turn on the cab circulating fan, the heater fan, the defroster fan, or the windshield wipers or washer. If none of these come on (but the head lights, tail lights, marker lights, dome light or work light will come on), there is accessory circuitry problem.
- 2. Check the primary power circuit to the accessory relay K101 in the Cab fuse & relay panel. Make circuit repairs as needed.

- 3. If the problem remains, check the ignition switch and the accessory control circuit from the ignition switch through the coil of the accessory relay (KS1) to ground. Turn the ignition switch to ON (Position 1) and shift the electric shifter to reverse; if the backup lights and backup alarm do not turn on, then there is no power through the switch when it is on (Position 1). Replace ignition switch if there is no power through it when it is ON (Position 1). Replace accessory relay if there is no continuity through it's coil. Make circuit repairs to accessory control circuit as needed.
- If the problem remains, check the accessory relay (K101) contacts and the accessory power circuit. Replace relay if its contacts stay open when the coil is energized. Make circuit repairs as needed.



Alternator Replacement

Removal

- 1. Ensure that the key switch has been in the OFF position for 2 minutes.
- 2. Turn the battery disconnect switch to the OFF position.
- 3. Remove the ECM power fuse.
- 4. Remove and isolate the negative battery cables.
- 5. Open the engine compartment.
- **6.** Tag and disconnect the electrical leads from the terminals on the alternator.
- 7. Turn the tensioner below the alternator clockwise to remove tension from the belt. Slip the belt off of the alternator pulley, then let the tensioner return to its normal position.
- 8. Remove and tag all wires. Remove the alternator link capscrew and the mounting capscrew. Remove the alternator.

Installation

- 1. Inspect the belt. Verify it has no cracks or other damage. Replace damaged belt as needed.
- **2.** To assemble the alternator, the mounting components must be tightened in the following sequence.
 - a. Alternator-to-alternator bracket capscrew.
 - b. Lower brace-to-alternator capscrew.
 - c. Lower alternator brace-to-water pump capscrew.
 - **d.** Torque brace-to-alternator bolt, see *Fasteners and Torque Values*, page 1-12.
 - e. Torque alternator-to-alternator bracket, see Fasteners and Torque Values, page 1-12.
- **3.** Install the belt on all engine pulleys except the alternator pulley for now.
- 4. Turn the tensioner clockwise. Slip the belt onto the alternator pulley, then carefully return the tensioner to its normal position so it puts tension on the belt. Make sure the belt is centered on the tensioner.
- 5. Check belt tension at the belt's longest span (longest distance between pulleys). At the center point of the longest span, push in on the belt with your thumb. Verify you can deflect the belt no more than 10 to 13 mm (3/8 to 1/2 inch) with your thumb. (Or, using a belt tension gauge, verify there is 267 to 578 N (60 to 130 lb) of tension on the belt in the middle of its longest span.) Replace belt if it is too loose (overstretched).
- 6. Verify tensioner bolt is torqued to 43 Nm (32 lb-ft).

- **7.** Connect the electrical leads to the terminals as tagged during removal.
- 8. Close the engine compartment.
- 9. Reconnect the ground cables to the battery.
- **10.** Install the ECM power fuse.
- **11.** Turn the battery disconnect switch to the ON position.

Check

- 1. Run engine. Verify reading of voltmeter on front console is 24 volts or greater. Make repairs as needed.
- 2. Continue troubleshooting charging system as needed if replacement of alternator did not correct problem in charging system.

Starter Replacement

Removal

- 1. Ensure that the key switch has been in the OFF position for 2 minutes.
- 2. Turn the battery disconnect switch to the OFF position.
- 3. Remove the ECM power fuse.
- 4. Remove and isolate the negative battery cables.
- 5. Open the engine compartment.
- **6.** Tag and disconnect the electrical leads from the terminals on the starter.
- **7.** Remove the bolts holding the starter to the mounting pad. Remove the starter.

Installation

- 1. Place the starter on its mounting pad. Secure the starter with the bolts. Torque the bolts to 43 Nm (32 lb-ft).
- **2.** Connect the electrical leads to the terminals as tagged during removal.
- 3. Connect the batteries.
- 4. Install the ECM power fuse.
- 5. Turn the battery disconnect switch to the ON position.
- 6. Close the engine compartment.

Check

- **1.** Try to start the engine. Verify the starter starts the engine.
- 2. Start engine again, and listen for starter noises. Verify there is no abnormal noise indicating the starter's gear is meshing improperly with the flywheel, that the starter's gear hasn't disengaged from the flywheel after the ignition switch is in the ignition (run) position, or some other problem. Install starter properly as needed.

Battery Replacement

Removal

CAUTION

To avoid possible engine fault codes and undesirable operation, ensure the keyswitch has been off 2 minutes before disconnecting batteries.

Disconnect batteries, if machine will be inactive for over 24 hours.

	A CAUTION
Í	To avoid possible engine fault codes and undesirable operation, ensure the keyswitch has been off 2 minutes before disconnecting batteries.
	Disconnect batteries, if machine will be inactive for over 24 hours.
	FIGURE 3-

- 1. Ensure that the key switch has been in the OFF position for 2 minutes.
- 2. Turn the battery disconnect switch to the OFF position.
- 3. Remove the ECM power fuse.
- 4. Remove the negative battery cables.
- 5. Remove the positive battery cables.
- **6.** Tag and disconnect leads from the battery terminals starting with the positive terminals.
- **7.** Remove the nuts and washers from the bracket hold down rods. Remove the hold down bracket.
- 8. Remove the batteries.

Installation

- 1. Place the batteries in the battery box.
- 2. Install the hold down brackets so they can hold down the batteries. Secure the brackets (and batteries) to the bracket hold down rods with nuts and washers.
- **3.** Connect leads to the battery terminals starting with the negative terminals (Figure 3-5)
- 4. Install the ECM power fuse.
- 5. Close the battery box cover.
- 6. Turn the battery disconnect switch to ON.
- **7.** Verify replacement batteries work by starting crane's engine and operating various crane components.

Relay Panel Component Replacement

Accessory Relay

- 1. Ensure that the key switch has been in the OFF position for 2 minutes.
- 2. Turn the battery disconnect switch to the OFF position.
- **3.** Remove the hardware securing the console front cover and remove the cover.
- **4.** Tag and disconnect the electrical leads from the suspect relay.
- 5. Remove the hardware securing the suspect relay to the relay panel assembly. Remove suspect relay.
- **6.** Install replacement relay on relay panel and secure it with attaching hardware.
- **7.** Connect the electrical leads to the relay as tagged during removal.
- **8.** Position the console front cover on the console and secure with the attaching hardware.
- 9. Connect the batteries.
- 10. Turn the battery disconnect switch to the ON position.
- **11.** Verify proper installation by operating all components involved with the replacement relay verifying they all work.

Rocker Switch Replacement

Use the following procedures and refer to Figure 3-6 when removing/installing a switch.

Removal

- 1. Ensure that the key switch has been in the OFF position for 2 minutes.
- 2. Turn the battery disconnect switch to the OFF position.



- **3.** Pull the rubber boot (11) off the bottom of the left and right side covers (8, 9).
- **4.** Remove the lever (12) and spacer that locks/unlocks the steering column tilt/telescope function.
- 5. Remove the four screws (13) securing the left and right side covers (8, 9) together.
- **6.** Remove the six screws (14) securing the left and right side covers (8, 9) to the switch cover (6).
- 7. Remove the left side cover (8) from the steering column.
- **8.** Disconnect the wire harness from the back of the ignition switch (10).
- 9. Remove the right side cover (9) from the steering column.
- **10.** Disconnect the wire harness from the bottom of the switch (4) that must be replaced. Remove the switch by squeezing the retaining clips on each side of switch and pushing upwards until switch is free of cover.

Inspection

- 1. Visually check the switch for evidence of cracks, damaged connections, or other damage. Replace damaged switch as needed.
- **2.** Check wiring for damaged insulation or damaged connectors. Repair as needed.
- **3.** Check all connectors for corrosion. Replace corroded components as needed.
- 4. Perform the following check to determine switch serviceability.
 - **a.** Using an ohmmeter, check for continuity between the switch terminals with switch at ON or activated position(s). Ohmmeter should register zero ohms (continuity).
 - **b.** Place switch at OFF or deactivated position. Ohmmeter should register infinity (no continuity).
 - c. Replace switch if it fails either part of the check.

Installation

- 1. Remove the rocker (3) from the old switch by holding the switch by its sides in one hand and then squeezing the left and right sides of the rocker with the other hand and pulling up.
- Orient the rocker (3) correctly relative to the new switch (4), then install rocker in switch.
- Install the switch (4) in the switch cover (6) by pushing the switch (4) down through the top of the switch cover (6) until the switch's retaining clips click in place.

- 4. Connect the wire harness to the bottom of the switch (4).
- 5. Install the right side cover (9) on the steering column.
- 6. Connect the wire harness to the ignition switch (10).
- 7. Install the left side cover (8) on the steering column.
- **8.** Secure the switch cover (6) to the left and right side covers (8, 9) using six screws (14).
- **9.** Secure the left and right side covers (8, 9) together using four screws (13).
- **10.** Install the lever (12) and spacer that locks/unlocks the steering column tilt/telescope function.
- **11.** Pull the rubber boot (11) up and over the bottom of the left and right side covers (8, 9).
- 12. Turn the battery disconnect switch to the ON position.

Check

- 1. Operate the switch per the Operator's Manual. Verify each of its functions works.
- 2. As needed, troubleshoot further any system or circuit malfunction not corrected by repair or replacement of the switch or associated wiring.

Ignition Switch Replacement

Use the following procedures and refer to Figure 3-6 when removing/installing the ignition switch.

Removal

- 1. Ensure that the key switch has been in the OFF position for 2 minutes.
- 2. Turn the battery disconnect switch to the OFF position.
- **3.** Pull the rubber boot (11) off the bottom of the left and right side covers (8, 9).
- **4.** Remove the lever (12) and spacer that locks/unlocks the steering column tilt/telescope function.
- 5. Remove the four screws (13) securing the left and right side covers (8, 9) together.
- **6.** Remove the six screws (14) securing the left and right side covers (8, 9) to the switch cover (6).
- 7. Remove the left side cover (8) from the steering column.
- **8.** Disconnect the wire harness from the back of the ignition switch (10).
- 9. Remove the right side cover (9) from the steering column.
- 10. Remove the locking nut that secures the ignition switch (10) to the right cover (9) and remove the ignition switch (10).

Inspection

- 1. Visually check the ignition switch for evidence of cracks, damaged connections, or other damage. Replace damaged ignition switch as needed.
- 2. Check wiring for damaged insulation or damaged connectors. Repair as needed.
- **3.** Check all connectors for corrosion. Replace corroded components as needed.
- **4.** Perform the following check to determine ignition switch serviceability.
 - **a.** Using an ohmmeter, check for continuity between the switch terminals with switch at ON or activated position(s). Ohmmeter should register zero ohms (continuity).
 - **b.** Place switch at OFF or deactivated position. Ohmmeter should register infinity (no continuity).
 - c. Replace switch if it fails either part of the check.

Installation

- 1. Install the ignition switch (10) in the right side cover (9) and secure with the locking nut.
- 2. Install the right side cover (9) on the steering column.
- 3. Connect the wire harness to the ignition switch (10).
- 4. Install the left side cover (8) on the steering column.
- 5. Secure the switch cover (6) to the left and right side covers (8, 9) using six screws (14).
- 6. Secure the left and right side covers (8, 9) together using four screws (13).
- **7.** Install the lever (12) and spacer that locks/unlocks the steering column tilt/telescope function.
- **8.** Pull the rubber boot (11) up and over the bottom of the left and right side covers (8, 9).
- 9. Turn the battery disconnect switch to the ON position.

Check

- 1. Operate the ignition switch per the Operator's Manual. Verify each of its functions works.
- 2. As needed, troubleshoot further any system or circuit malfunction not corrected by repair or replacement of the switch or associated wiring.

Turn Signal Lever and Transmission Shift Lever Replacement

Use the following procedures and refer to Figure 3-6 when removing/installing the turn signal lever or transmission shift lever.

Removal

- 1. Ensure that the key switch has been in the OFF position for 2 minutes.
- 2. Turn the battery disconnect switch to the OFF position.
- **3.** Pull the rubber boot (11) off the bottom of the left and right side covers (8, 9).
- **4.** Remove the lever (12) and spacer that locks/unlocks the steering column tilt/telescope function.
- 5. Remove the steering wheel by doing the following:
 - a. Remove the steering wheel cap (1) using a twisting motion by pushing on the side of the cap closest to you with your thumbs while simultaneously pulling on the side of the cap farthest from you with your fingers.
 - **b.** Remove the securing nut from the steering column shaft and remove the steering wheel (2).
- 6. Remove the four screws (13) securing the left and right side covers (8, 9) together.
- **7.** Remove the six screws (14) securing the left and right side covers (8, 9) to the switch cover (6).
- 8. Remove the left side cover (8) from the steering column.
- **9.** Disconnect the wire harness from the back of the ignition switch (10).
- **10.** Remove the right side cover (9) from the steering column.
- **11.** Tag and disconnect the wire harness from the bottom of each switch (4).
- 12. Remove the switch cover (6) from the steering column.
- **13.** Disconnect the wire harnesses from the bottom of the turn signal and transmission shift levers (7).
- 14. Remove the two bolts and nuts securing the two levers (7) together.

Installation

- 1. Align the location pins of the turn signal and transmission shift levers (7) with the holes in the steering column.
- **2.** Secure the two levers (7) together using the two bolts and nuts.
- 3. Connect the wire harnesses to the levers (7).
- 4. Install the switch cover (6) on the steering column.
- **5.** Install the wire harnesses on the switches (4) as tagged during removal.
- 6. Install the right side cover (9) on the steering column.
- 7. Connect the wire harness to the ignition switch (10).


RT530E-2 SERVICE MANUAL

- 8. Install the left side cover (8) on the steering column.
- **9.** Secure the switch cover (6) to the left and right side covers (8, 9) using six screws (14).
- **10.** Secure the left and right side covers (8, 9) together using four screws (13).
- Install the steering wheel (2); torque the securing nut to 40 Nm ±5 (30 lb-ft ±4).
- 12. Install the steering wheel cap (1).
- **13.** Install the lever (12) and spacer that locks/unlocks the steering column tilt/telescope function.

- **14.** Pull the rubber boot (11) up and over the bottom of the left and right side covers (8, 9).
- **15.** Turn the battery disconnect switch to the ON position.

Check

- 1. Operate the turn signal lever or transmission shift lever per the Operator's Manual. Verify each of its functions work.
- 2. As needed, troubleshoot further any system or circuit malfunction not corrected by repair or replacement of the switch or associated wiring.



Windshield Wiper Assembly Replacement


Removal

- 1. Ensure that the key switch has been in the OFF position for 2 minutes.
- 2. Turn the battery disconnect switch to the OFF position.
- 3. Tag and disconnect the electrical leads from the motor.
- Disconnect the washer hose on the wiper arm (also called the pantograph arm assembly) from the washer nozzle fitting assembly.
- 5. Remove the cap nut and washer securing the wiper arm to the pantograph adapter kit. (The nut and washer are part of the pantograph adapter kit.) Remove the cap nut, washer, and tapered sleeve securing the wiper arm to the pivot shaft kit. (The nut, washer, and sleeve are part of the pivot shaft kit.)
- 6. Remove the wiper arm from the pantograph adapter kit and the pivot shaft kit.
- 7. Remove the flanged sleeve, nut, and two flat washers from the pivot shaft kit. (The sleeve, nut, and washers are part of the pivot shaft kit.)
- 8. Remove the two capscrews and lockwashers securing the pantograph adapter kit's adapter to the cab exterior. Remove the pantograph adapter kit's adapter and gasket.
- **9.** Remove attaching hardware to free the windshield wiper motor bracket from the cab interior. Remove the bracket, with motor and pivot shaft connected, from the cab.
- **NOTE:** You may have to remove or move other parts to get the bracket and attached parts around the steering column. Take care not to damage any parts.
- **10.** Remove the nut to free the wiper motor's shaft from the wiper motor kit crank. Remove the three screws and washers to free the wiper motor from its bracket. Remove the wiper motor from its bracket. Leave the other parts attached to the bracket for now.

Inspection

- 1. Visually check the motor housing for evidence of cracks or other damage. Check for excessive shaft end play indicating worn or damaged bearings. Replace motor if damaged.
- 2. Inspect the wiper blade for serviceability. Replace wiper blade when worn.
- 3. Inspect the wiper arm and parts of the linking component kits (pantograph adapter kit, pivot shaft kit, wiper motor kit link and crank, wiper motor bracket) for damage. Replace as needed.

Installation



- 1. Verify the pivot shaft and the wiper motor kit link and crank are in place on the motor bracket. (Washers and clip springs fasten the link to the pivot pins on the crank and the pivot shaft. The pivot shaft's pivot pin mounts in the hole nearest the end of the pivot shaft's lever.)
- 2. Connect the wiper motor to the motor bracket with screws and washers. Connect the wiper motor's shaft to the wiper motor kit crank with the nut and washer.
- 3. Secure the adapter and the gasket of the pantograph adapter kit to the cab exterior with capscrews and lockwashers.
- 4. Install the motor bracket and attached parts in the cab interior with attaching hardware. Ensure the pivot shaft sticks through the hole in the pantograph adapter kit.
- **NOTE:** Take care not to damage any parts while moving the bracket and attached parts around the steering column.
- 5. Secure the pivot shaft to the pantograph adapter with the pivot shaft kit's nut and washers. Install the flanged sleeve on the pivot shaft.
- 6. Install the wiper arm on the shafts of the pantograph adapter kit and the pivot shaft kit. Secure the wiper arm to the pantograph adapter kit shaft with the kit's own washer and cap nut. Secure the wiper arm to the pivot shaft with the pivot shaft kit's own tapered sleeve, washer, and cap nut.
- **7.** Connect the wiper arm's washer hose to the washer nozzle fitting assembly.



RT530E-2 SERVICE MANUAL

- **8.** Connect the electrical leads to the wiper motor as marked before removal.
- 9. Turn the battery disconnect switch to the ON position.

Check

- 1. Squirt some cleaning fluid onto the windshield with the windshield washer.
- 2. Operate the windshield wiper. Verify it works. (Replace wiper blade as needed if it streaks or otherwise wipes poorly.)

Windshield Washer Assembly Replacement

Removal

- 1. Ensure that the key switch has been in the OFF position for 2 minutes.
- 2. Turn the battery disconnect switch to the OFF position.
- **3.** Locate the windshield washer container and pump on the left rear side of the cab.
- 4. Tag and disconnect the pump's electrical lead and ground wire.
- 5. Disconnect the hose from the windshield washer pump. Point it so it won't spill cleaning fluid. Catch cleaning fluid from the windshield washer container with a suitable container.
- 6. Remove four self tapping screws securing the windshield washer container to the cab. Remove the windshield washer container and pump.
- 7. Remove pump and pump seal from container.

Inspection

- 1. Visually check the pump for evidence of cracks, leaks, or other damage. Replace pump if damaged.
- 2. Inspect the container for leaking. Replace pump seal if it is leaking. Replace container if it is damaged and leaking.
- 3. Inspect spray nozzle on the wiper arm. As needed, clean the nozzle with a fine piece of wire and compressed air.

Installation

- 1. Install pump and pump seal on container.
- 2. Install windshield washer container on the cab. Secure the container with four self tapping screws.
- 3. Attach the hose to the windshield washer pump.
- 4. Connect the pump's electrical lead and ground wire as tagged during removal.

- 5. Turn the battery disconnect switch to the ON position.
- 6. Fill the container with cleaning fluid.

Check

- 1. Squirt some cleaning fluid onto the windshield with the windshield washer.
- 2. Make repairs if windshield washer doesn't work.

Skylight Wiper Assembly Replacement

Removal

- 1. Ensure that the key switch has been in the OFF position for 2 minutes.
- 2. Turn the battery disconnect switch to the OFF position.
- 3. Tag and disconnect the electrical leads from the motor.
- 4. Remove the wiper arm from the motor shaft.
- 5. Remove the nut, spacer, leather washer, and nylon flat washer from the motor shaft outside the cab roof.
- 6. Remove the nut and lockwasher securing the motor bracket to the cab roof and remove the motor from the cab roof. Remove large nylon flat washer from motor shaft and flat washer and smaller nylon flat washer from mounting screw.
- **7.** Remove mounting screw and nylon flat washer from outside cab roof.
- 8. Clean any sealing material from around holes in cab roof.

Inspection

- Visually check the motor housing for evidence of cracks or other damage. Check for excessive shaft end play indicating worn or damaged bearings. Replace motor if damaged.
- **2.** Inspect the wiper blade for serviceability. Replace wiper blade when worn.
- **3.** Inspect the wiper arm and parts for damage. Replace as needed.

Installation

- 1. Install sealant material around both holes in cab roof, both inside and outside.
- **2.** Install screw with nylon flat washer (from outside) through mounting hole in cab roof.
- Install flat nylon washer on motor shaft and insert motor shaft through hole in cab roof. Position small nylon washer and flat washer on screw between mounting bracket and cab roof. Secure with lockwasher and nut.

ELECTRIC SYSTEM

- **4.** Install nylon flat washer, leather washer, spacer, and nut on motor shaft. Tighten nut.
- 5. Install wiper arm and blade on motor shaft.
- 6. Connect the electrical leads to the wiper motor as marked before removal.
- 7. Turn the battery disconnect switch to the ON position.

Check

1. Operate the skylight wiper. Verify it works. (Replace wiper blade as needed if it streaks or otherwise wipes poorly.)

Table 3-6Amp Extraction Tool Table

Description	Amp Part Number	Grove Part Number
14 gauge wire (connectors)	305183	9999100176
12 to 8 gauge wire (connectors)	91019-3	9999100175
4 to 9 circuit (in-line connectors)	453300-1	N/A
15 circuit (in-line connectors)	458944-1	N/A

Table 3-7

Amp Crimping Tool Table

Description	Amp Par	t Number	Grove Pa	art Number
	ΤοοΙ	Die	Tool	Die
14 to 12 gauge wire	69710-1	90145-1	9999100177	N/A
10 to 8 gauge wire	69710-1	90140-1	9999100177	9999100178
4 to 9 circuit (in-line connectors	69710-1	90306-1	9999100177	N/A
15 circuit (in-line connectors	90299-1	-	N/A	

Table 3-8Deutsch Extraction Tool Table

Description	Deutsch Part Number	Grove Part Number
12 gauge wire	114010	9999100194
16 gauge wire	0411-204-1605	9999100195
8-10 gauge wire	114008	7902000012
4-6 gauge wire	114009	790200009

Table 3-9 Deutsch Crimping Tool Table

Description	Deutsch Part Number	Grove Part Number
12, 14, 16, 18, 20 gauge wire	HDT48-00	9999100808
4, 6, 8, 10 gauge wire	HDT 04-08	9999100842



Appendix A: Crane Control System (CCS) Fault Codes

There are four codes for every fault in the Crane Control System (CCS) diagnostic. The Component Code number informs the operator which component is in fault mode; the Condition Code explains the actual malfunction; the Device Code indicates which module contains the fault; and the Index Code reveals the type of fault. For example, a code reading "7111. 2. 0. 129" correlates to "RCL Display", "Cable Break", "SCMO", "CANbus 1". This means the RCL display CANbus cable to the SCMO module is broken.

Component Codes

Fault Code	Component Description	
5000	Key switch On input	
5001	Key switch Accessory input	
5002	Key switch Start input	
5003	Horn switch input	
5005	Transmission Forward input	
5006	Transmission Neutral input	
5007	Transmission Reverse input	
5008	Transmission 1st gear input	
5009	Transmission 2nd gear input	
5010	Transmission 3rd gear input	
5011	Transmission 4th gear input	
5012	Transmission 5th gear input	
5013	Transmission speed gears (all)	
5014	Transmission direction gears (all)	
5015	Turn Signal left input	
5016	Turn Signal right input	
5017	Headlights input	
5018	Marker lights input	
5019	Hazard lights input	
5020	Parking light switch	
5021	Fog tail light switch	
5022	Fog light switch	
5023	Low beam headlight switch	
5024	High beam headlight switch	
5025	Windshield wiper low speed input	
5026	Windshield wiper high speed input	
5027	Windshield washer spray input	
5028	Windshield wiper intermittent input	
5030	Engine speed increment switch input	
5031	Engine speed decrement switch input	
5032	Rear steer left switch input	

Fault Code	Component Description		
5033	Rear steer right switch input		
5034	Park brake release switch input		
5035	2 wheel drive switch input		
5036	Differential lock switch input		
5037	Brake pedal switch input		
5038	Retarder / Thelma brake switch		
5040	Outrigger extend switch input		
5041	Outrigger retract switch input		
5042	Cabin lower switch input		
5043	Cabin raise switch input		
5050	Crane functions switch input		
5051	Boom lights switch input		
5052	Bypass hoist limiter switch input		
5053	Bypass RCL inside switch input		
5054	Bypass RCL outside switch input		
5055	Bypass Derricking switch input		
5056	Aircraft warning light switch input		
5057	Working light switch input		
5058	Rotating flashing light switch		
5059	High beam flasher switch		
5060	Air Condition Switch (Carrier)		
5061	Air Condition Switch (Superstructure)		
5100	Enable Extend switch input		
5101	Enable Retract switch input		
5102	Enable Aux Hoist switch input		
5103	Enable Main Hoist switch input		
5104	Enable Derricking switch input		
5105	Enable Slewing switch input		
5106	Enable Telescoping switch input		
5107	Enable Freeswing switch input		
5108	Enable Jib switch input		
5109	Jib Identity		
5110	Jib Remote Control down switch input		
5111	Jib Remote Control up switch input		
5112	Cab Tilt Down switch input		
5113	Cab Tilt Up switch input		
5150	Left Joystick Deadman input		



3

Fault Code	Component Description
5152	Seat Switch deadman input
5153	Armrest deadman switch input
5154	Both Deadman switches input
5160	Carrier Emergency Off Switch
5161	Carrier Emergency Off Relay input
5162	Carrier Emergency Operation input
5163	AMOT active input
5170	Exhaust System Cleaning Init switch input
5171	Exhaust System Cleaning Inhibit switch input
5300	Gas Pedal PWM input
5301	Slew Brake pedal PWM input
5302	Telescoping pedal PWM input
5303	Gas Pedal ANA input
5304	Service brake pedal ANA input
5305	Slewing brake pedal ANA input
5500	Cold Weather switch input
5501	Rear Wheels Not Centered switch input
5502	Differential Lock Front switch input
5503	Differential Lock Rear switch input
5504	Oil Temperature switch input
5505	Hydraulic oil temperature switch input
5506	Slewing system temperature switch input
5507	Starter Lockout
5509	All wheel drive active input switch
5510	Axle locking input switch
5511	Cross Diff Lock switch input Axle 1
5512	Cross Diff Lock switch input Axle 2
5513	Cross Diff Lock switch input Axle 3
5514	Cross Diff Lock switch input Axle 4
5515	Cross Diff Lock switch input Axle 5
5516	Cross Diff Lock switch input Axle 6
5517	Cross Diff Lock switch input Axle 7
5518	Cross Diff Lock switch input Axle 8
5519	Cross Diff Lock switch input Axle 9
5522	Long Diff Lock switch input Axle 2
5523	Long Diff Lock switch input Axle 3
5524	Long Diff Lock switch input Axle 4
5525	Long Diff Lock switch input Axle 5

3-17

Fault Code	Component Description		
5526	Long Diff Lock switch input Axle 6		
5527	Long Diff Lock switch input Axle 7		
5528	Long Diff Lock switch input Axle 8		
5529	Long Diff Lock switch input Axle 9		
5530	Drag link unlocked		
5531	Drag link locked		
5533	Steering Rod Lock switch input Axle 3		
5534	Steering Rod Lock switch input Axle 4		
5535	Steering Rod Lock switch input Axle 5		
5536	Steering Rod Lock switch input Axle 6		
5537	Steering Rod Lock switch input Axle 7		
5538	Steering Rod Lock switch input Axle 8		
5539	Steering Rod Lock switch input Axle 9		
5600	Park Brake Pressure switch input		
5601	ABS Trolley input		
5602	Suspension group too high (front left) input		
5603	Suspension group too high (front right) input		
5604	Suspension group too high (rear left) input		
5605	Suspension group too high (rear right) input		
5606	Suspension group too low (front left) input		
5607	Suspension group too low (front right) input		
5608	Suspension group too low (rear left) input		
5609	Suspension group too low (rear right) input		
5700	Cab Sensor for Humidity		
5800	Outrigger length left front analog input		
5801	Outrigger length left rear analog input		
5802	Outrigger length right front analog input		
5803	Outrigger length right rear analog input		
5804	Hoist limiter analog input		
5805	Telescoping cylinder length analog input		
5806	Stabilizer pressure sensor input, front left		
5807	Stabilizer pressure sensor input, rear left		
5808	Stabilizer pressure sensor input, front right		
5809	Stabilizer pressure sensor input, rear right		
5810	Anemometer analog input		
5811	Angle sensor axle 1		
5812	Angle sensor axle 2		
5813	Angle sensor axle 3		



3

Fault Code	Component Description
5814	Angle sensor axle 4
5815	Angle sensor axle 5
5816	Angle sensor axle 6
5817	Angle sensor axle 7
5818	Angle sensor axle 8
5819	Angle sensor axle 9
5820	Fuel Level analog input
5821	Sensor Supply Voltage analog input
5822	Pressure Sensor Axle 1 Left
5823	Pressure Sensor Axle 1 Right
5824	Pressure Sensor Axle 2-3 Left
5825	Pressure Sensor Axle 2-3 Right
5826	Pressure Sensor Axle 4-5 Left
5827	Pressure Sensor Axle 4-5 Right
5828	Pressure Sensor Axle 6-7 Left
5829	Pressure Sensor Axle 6-7 Right
5830	Pressure Sensor Axle 8-9 Left
5831	Pressure Sensor Axle 8-9 Right
5833	Cabin Temperature Sensor Head
5834	Cabin Temperature Sensor Feet
5835	Cabin Temperature Sensor Back
5836	Cabin Sensor Humidity
5840	Service Brake Circle 1
5841	Service Brake Circle 2
5845	Transmission Temperature
5850	LIM override simulated output
5900	Main Hoist Counter / encoder
5901	Main Hoist direction input
5902	Aux Hoist Counter / encoder
5903	Aux Hoist direction input
5904	Main hoist 3rd wrap input
5905	Aux hoist 3rd wrap input
5906	System Release input (signal from SCM0)
5907	Emergency Stop input
5908	Main Hoist Lower pressure switch
5909	Main Hoist Raise pressure switch
5910	Aux Hoist Lower pressure switch
5911	Aux Hoist Raise pressure switch

Fault Code	Component Description	
5912	Derricking Down pressure switch	
5913	Derricking Up pressure switch	
5914	Telescoping Extend pressure switch	
5915	Telescoping Retract pressure switch	
5916	Hydraulic Oil Temp switch	
5917	Brake Pressure switch	
5918	AC Clutch Required switch	
5919	Swing Right pressure switch	
5920	Swing Left pressure switch	
5921	Swing Brake pressure switch	
5922	Hydraulic Oil Filter pressure switch	
5923	Steering Pressure low switch	
5924	Boom Section Locked redundant switch	
5925	Left Tele Cylinder Locked redundant switch	
5926	Right Tele Cylinder Locked redundant switch	
5927	Left Tele Cylinder Pins Low switch	
5928	Left Tele Cylinder Pins High switch	
5929	Boom Section Locked switch	
5930	Boom Section Unlocked switch	
5931	Left Tele Cylinder Pin Unlocked switch	
5932	Right Tele Cylinder Pin Unlocked switch	
5933	Left Tele Cylinder Pin Locked switch	
5934	Right Tele Cylinder Pin Locked switch	
5935	Right Tele Cylinder Pins Low switch	
5936	Right Tele Cylinder Pins High switch	
5937	Jib mounted & folded switch	
5938	Turntable Locked switch	
5939	Turntable Unlocked switch	
5940	Pump 1 Pressure analog input	
5941	Telescoping Pressure analog input	
5942	Slewing Pressure analog input	
5943	Hoist Limiter (A2B) analog input	
5944	Piston Length Sensor analog input	
5945	8.5V External Feedback analog input	
5946	Accumulator pressure sensor analog input	
5947	Mechanical locking head TUSL switch	
5948	Mechanical locking head TLSL switch	
5949	Mechanical locking head TLSU switch	



Fault Code	Component Description
5950	Auxiliary Hoist Identifier input
5951	New York House Lock Pin Bolted input
5952	New York House Lock Locked input
5953	New York House Lock Unlocked input
5954	Counterweight Left Unlock input
5955	Counterweight Right Unlock input
5956	Counterweight Left Lock input
5957	Counterweight Right Lock input
5958	Counterweight Left Bottom Proximity Switch input
5959	Counterweight Right Bottom Proximity Switch input
5960	Counterweight Left Top Proximity Switch input
5961	Counterweight Right Top Proximity Switch input
5962	Hoist Limiter (A2B) Switch input - Stop
5963	Steering Filter switch input
5964	Flow indicator steering circle 1
5965	Flow indicator steering circle 2
5966	Air Filter switch input
5967	Cabin locked left switch input
5968	Cabin locked right switch input
5969	Bridge collision switch input
5970	Filter backpressure switch input 1
5971	Filter backpressure switch input 2
5972	Length Hydraulic pivot cylinder
5973	Auxhoist right locked
5974	Auxhoist left locked
5975	Auxhoist right unlocked
5976	Auxhoist left unlocked
5977	Auxhoist carrier retracted
5978	Counterweight installed input
5979	Counterweight in position input
5980	Counterweight position left analog input
5981	Counterweight position right analog input
5982	Derricking valve spool position analog input
5983	Slew left pressure analog input
5984	Slew right pressure analog input
5985	Hoist Limiter (A2B) Switch input - Slow
6000	PERM 24V voltage output
6001	Release LMI output

6002 Gearshift power supply output	
6002 SCM0 ignition to CCM40 autout	
6003 SCM0 ignition to CCM10 output	
6004 SCM0 ignition to CCM11 output	
6005 Oil Cooler Off relay output	_
6006 SCM0 ignition to IOS modules output	_
6007 SCM0 ignition to displays output	
6008 Accessory output	
6010 Turn signal left output	
6011 Turn signal right output	
6020 Left armrest lamps output	
6021 Right armrest lamps output	
6030 Perm VCC output	
6031 Boom Lights 1 output	
6032 Boom Lights 2 output	
6033 IOL30 Sensor supply output	
6034 Aircraft Warning Light output	
6035 Horn output	
6036 AC Condenser Motor output	
6037 Windshield Washer output	
6038 Beacon Lights output	
6039 IOS20 Sensor Supply output	
6040 Lamp Main hoist output	
6041 Lamp Derricking output	
6042 Lamp Telescoping output	
6043 Lamp Jib output	
6044 Lamp Park Brake output	
6045 Lamp Slewing output	
6046 Lamp Aux Hoist output	
6047 Flight traffic light output	
6048 Release hoist limiter	
6049 IOL34 Sensor supply output	
6050 New York House Lock change direction ou	tput
6051 New York House Lock release direction ou	tput
6060 Windshield Wash front Wiper	
6061 Windshield Wash top Wiper	
6062 Delay Front Wiper	
6063 Delay Top Wiper	
6064 Windshield Wash front Wiper low speed	



Fault Code	Component Description
6065	Windshield Wash front Wiper high speed
6066	Windshield Wash front Wiper park
6100	Headlight Low Beam Left output
6101	Headlight Low Beam Right output
6102	Brake Lights output
6103	Engine Start output
6104	AC Clutch output
6105	Marker Lights output
6106	Reverse Lights output
6107	Derricking Release output
6108	Daytime Driving Light output
6109	Fuel Heater Relay output
6110	Enable Cross (Transverse) Differential Locks Output
6111	Enable Longitudinal Differential Locks Output
6112	Enable Axle Blocking Output
6113	Unlock Axle 3 Steering Output
6114	Unlock Axle 4 Steering Output
6115	Unlock Axle 5 Steering Output
6116	Unlock Axle 6 Steering Output
6117	Unlock Axle 7 Steering Output
6118	Unlock Axle 8Steering Output
6119	Unlock Axle 9 Steering Output
6120	Superstructure Maneuvering Enable Output (EDM)
6121	Select Gear D Output (EDM)
6122	Select Gear N Output (EDM)
6123	Select Gear R Output (EDM)
6124	PTO Request Output (EDM)
6125	Inhibit Upshift Output (EDM)
6126	Inhibit Engine Start Output
6127	Switch carrier/super cabin
6128	Central lubrication
6130	Air Conditioning ON output
6131	Air Conditioning (Superstructure) output
6132	Air Conditioning (Carrier) output
6133	Retarder (Telma brake) output
6134	Fog tail lights output
6135	Fog lights output
6136	High beam headlight

Fault Code	Component Description		
6137	Outrigger Light Front Left Output		
6138	Outrigger Light Front Right Output		
6139	Outrigger Light Rear Left Output		
6140	Outrigger Light Rear Right Output		
6200	Four Wheel Drive output		
6201	Rear Axle Oscillation output		
6202	Rear Steer Right output		
6203	Rear Steer Left output		
6204	Park Brake Release output		
6205	Differential Lock output		
6206	Load Sense output		
6210	Stabilizer Left Front solenoid		
6211	Stabilizer Right Front solenoid		
6212	Stabilizer Left Rear solenoid		
6213	Stabilizer Right Rear solenoid		
6215	Beam Left Front solenoid		
6216	Beam Right Front solenoid		
6217	Beam Left Rear solenoid		
6218	Beam Right Rear solenoid		
6220	Outrigger Extend solenoid		
6221	Outrigger Retract solenoid		
6225	Transmission Forward solenoid		
6226	Transmission Reverse solenoid		
6227	Transmission First Gear solenoid		
6228	Transmission Second Gear solenoid		
6229	Transmission Third Gear solenoid		
6230	Transmission Fourth Gear solenoid		
6231	Transmission Fifth Gear solenoid		
6240	Pressure buildup solenoid		
6241	Release All Wheel steering solenoid		
6244	Steering Control Valve 1 solenoid		
6245	Steering Control Valve 2 solenoid		
6246	Steering Control Valve 3 solenoid		
6247	Slewing System Release solenoid		
	Block Steering Circuit 1 solenoid		
6248			
6248 6249	Service Brake solenoid		
	-		



Ī	Fault Code	Component Description
-	6252	Steer Left solenoid Axle 2
=	6253	Steer Left solenoid Axle 3
-	6254	Steer Left solenoid Axle 4
-	6255	Steer Left solenoid Axle 5
-	6256	Steer Left solenoid Axle 6
-	6257	Steer Left solenoid Axle 7
-	6258	Steer Left solenoid Axle 8
-	6259	Steer Left solenoid Axle 9
-	6261	Steer Right solenoid Axle 1
-	6262	Steer Right solenoid Axle 2
-	6263	Steer Right solenoid Axle 3
-	6264	Steer Right solenoid Axle 4
-	6265	Steer Right solenoid Axle 5
-	6266	Steer Right solenoid Axle 6
-	6267	Steer Right solenoid Axle 7
-	6268	Steer Right solenoid Axle 8
-	6269	Steer Right solenoid Axle 9
-	6270	Stabilizer Left Front extend solenoid
-	6271	Stabilizer Right Front extend solenoid
-	6272	Stabilizer Left Rear extend solenoid
-	6273	Stabilizer Right Rear extend solenoid
_	6274	Stabilizer Left Front retract solenoid
_	6275	Stabilizer Right Front retract solenoid
	6276	Stabilizer Left Rear retract solenoid
	6277	Stabilizer Right Rear retract solenoid
	6278	Extension Beam Left Front extend solenoid
	6279	Extension Beam Right Front extend solenoid
	6280	Extension Beam Left Rear extend solenoid
	6281	Extension Beam Right Rear extend solenoid
	6282	Extension Beam Left Front retract solenoid
_	6283	Extension Beam Right Front retract solenoid
_	6284	Extension Beam Left Rear retract solenoid
-	6285	Extension Beam Right Rear retract solenoid
-	6286	Suspension Group Left Front solenoid
-	6287	Suspension Group Right Front solenoid
-	6288	Suspension Group Left Rear solenoid
_	6289	Suspension Group Right Rear solenoid
-	6290	Axle Lifting Front Left solenoid

Fault Code	Component Description		
6291	Axle Lifting Front Right solenoid		
6292	Axle Lifting Rear Left solenoid		
6293	Axle Lifting Rear Right solenoid		
6294	Pressure Axle Lifting Front Left solenoid		
6295	Pressure Axle Lifting Front Right solenoid		
6296	Pressure Axle Lifting Rear Left solenoid		
6297	Pressure Axle Lifting Rear Right solenoid		
6298	Drive out cylinder, Jib moves ahead from boom		
6299	Retract cylinder, jib moves to boom		
6400	Main Hoist Down solenoid		
6401	Main Hoist Up solenoid		
6402	Aux Hoist Down solenoid		
6403	Aux Hoist Up solenoid		
6404	Derricking Down solenoid		
6405	Derricking Up solenoid		
6406	Tele Cylinder Extend solenoid		
6407	Tele Cylinder Retract solenoid		
6408	Slewing Right solenoid		
6409	Slewing Left solenoid		
6410	Lower Brake Main Hoist solenoid		
6411	Raise Lower Brake Main Hoist solenoid		
6412	Lower Brake Aux Hoist solenoid		
6413	Raise Lower Brake Aux Hoist solenoid		
6414	Pilot Supply solenoid		
6415	Slew Brake Release solenoid		
6416	Enable high Speed Tele solenoid		
6417	Lock Telecylinder Boom Section solenoid		
6418	Charge Cylinder Tube solenoid		
6419	Release Boom Down solenoid		
6420	Hold Unlock Position solenoid		
6421	Select Boom Section Telecylinder solenoid		
6422	Jib Down solenoid		
6423	Jib Up solenoid		
6424	Cabin Down solenoid		
6425	Cabin Up solenoid		
6426	Turntable Lock solenoid		
6427	Turntable Unlock solenoid		
6428	Counterweight Lower solenoid		



Fault Code	Component Description
6429	Counterweight Raise solenoid
6430	Counterweight Unlock solenoid
6431	Counterweight Lock solenoid
6432	Aux hoist carrier raise
6433	Aux hoist carrier lower
6434	Aux hoist lock
6435	Aux hoist unlock
6436	Main hoist Fast Moving
6437	Aux hoist Fast Moving
6438	Pressure Limiter Valve
6600	Main Hoist Speed Control PWM output
6601	Aux Hoist Speed Control PWM output
6602	Derricking Speed Control PWM output
6603	Telescoping Speed Control PWM output
6604	Slewing Speed Control PMW output
6605	Boom Down Release PWM output
6606	Tele Pressure Extend PWM output
6607	Slew Brake PWM output
6608	Aux Drives Speed Control PWM output
6609	Oil Cooler 1A PWM output
6610	Oil Cooler 1B PWM output
6611	Oil Cooler 2A PWM output
6612	Oil Cooler 2B PWM output
6614	Oil heater cooler
7001	Hydac Pressure Sensor (default node ID)
7002	SCM0
7003	SCM1
7004	SCM2
7005	SCM3
7013	Pressure sensor lower chamber 0
7014	Pressure sensor lower chamber 1
7015	Pressure sensor upper chamber
7017	Length sensor BOOM length
7018	Length sensor telecylinder length
7019	Telescoping Cylinder CAN length sensor
7020	Boom angle sensor 0
7021	Boom angle sensor 1
7022	Jib angle sensor

Fault Code	Component Description
7025	CCM10
7026	CCM11
7027	CCM12
7028	CCM13
7032	IOL30
7033	IOL31
7034	IOL32
7035	IOL33
7036	IOL34
7037	IOL35
7038	IOL36
7039	IOL37
7040	IOL38
7041	IOL39
7042	IOL40
7043	IOL41
7044	IOL42
7045	IOL43
7046	IOL44
7047	IOL45
7048	Slew Angle Sensor
7052	IOS20
7053	IOS21
7054	IOS22
7055	IOS23
7056	IOS24
7057	IOS25
7058	IOS26
7059	IOS27
7065	Slew angle sensor
7066	Boom angle sensor 0 GMK
7067	Boom angle sensor 1 GMK
7068	Boom length sensor
7075	Machine Display Extended
7081	Boom Handset
7082	Turntable Handset
7084	Carrier Left Handset
7085	Carrier Right Handset



Fault Code	Component Description
7090	Simulated Joystick
7091	Left joystick
7092	Right joystick
7093	Left joystick
7100	Remote Control -or- Slew Angle Sensor (default node ID)
7101	MMI Left
7102	MI Right
7106	External Light Tower
7108	Service Software
7109	Outside Light bar
7111	RCL display
7112	Operating display
7113	Carrier Display
7119	Jogdial
7123	Inside Light bar
7124	Cranestar
7129	J1939 Communications
7400	Engine RPM speed sensor
7401	Alternator Charge Frequency input
8000	RCL software
8001	Error List
8002	Operating system task 1
8003	Operating system task 2
8004	Operating system task 3
8005	Operating system task 4
8006	Operating system task 5
8007	Speed limit software
8008	RCL load charts
8009	AddReadSDO software function
8010	AddWriteSDO software function
8011	Telescoping software
8012	Interpolator / CCM closed loop current control
8013	Pinning program
8014	Slewing control system
8015	Derricking control system
8016	Main Hoist control system
8017	Aux Hoist control system
8100	Main Software Program

Fault Code	Component Description
8400	Eeprom
8401	CPU watchdog
8402	Data Flash
8600	RCL Boom Length
8601	RCL Slewing Range
8602	RCL Outrigger
8603	RCL Jib
8700	Telescoping Length Sensor Comparison
8701	Pinning Proxy Switches Left
8702	Pinning Proxy Switches Right
8900	Engine Type Selection (eeprom setting)
10100	Proximity Sensor Drum 0 (A)
10101	Proximity Sensor Drum 0 (B)
10102	Proximity Sensor Drum 1 (A)
10103	Proximity Sensor Drum 1 (B)
10104	Proximity Sensor Drum 2 (A)
10105	Proximity Sensor Drum 2 (B)
10106	Proximity Sensor Drum 3 (A)
10107	Proximity Sensor Drum 3 (B)
10108	Proximity Sensor Drum 4 (A)
10109	Proximity Sensor Drum 4 (B)
10110	Proximity Sensor Drum 5 (A)
10111	Proximity Sensor Drum 5 (B)
10112	Proximity Sensor Drum 6 (A)
10113	Proximity Sensor Drum 6 (B)
10114	Proximity Sensor Drum 7 (A)
10115	Proximity Sensor Drum 7 (B)
10116	Proximity Sensor Drum 8 (A)
10117	Proximity Sensor Drum 8 (B)
10118	Proximity Sensor Drum 9 (A)
10119	Proximity Sensor Drum 9 (B)
10120	Luffing Jib Min
10121	Luffing Jib Max
10123	Fixed Jib Confirm
10125	Boom Strap Load Cell Right
10126	Boom Strap Load Cell Left
10130	Proximity Sensor Output (V+) Drum 0
10131	Proximity Sensor Output (V+) Drum 1



Fault Code	Component Description
10132	Proximity Sensor Output (V+) Drum 2
10133	Proximity Sensor Output (V+) Drum 3
10134	Proximity Sensor Output (V+) Drum 4
10135	Proximity Sensor Output (V+) Drum 5
10136	Proximity Sensor Output (V+) Drum 6
10137	Proximity Sensor Output (V+) Drum 7
10138	Proximity Sensor Output (V+) Drum 8
10139	Proximity Sensor Output (V+) Drum 9
10140	Boom Strap Load Cell Output (V+)
10141	Lower/Upper Boom Point A2B Slow Output (V+)
10142	Lower/Upper Boom Point A2B Stop Output (V+)
10143	Luffing Jib Max Output (V+)
10144	Luffing Jib Min Output (V+)

Condition Codes

Fault Code	Condition Description	
0	No Error	
1	Over Current	
2	Cable Break	
3	Short to Battery	
4	Short to Ground	
5	Resistor Low	
6	Resistor High	
7	Below minimum level	
8	Above maximum level	
10	Undefined Area	
11	Initialization failed	
12	System	
13	Function Error	
14	Logic	
15	Fuse	
16	PWM Signal	
17	8.5V supply below the minimum allowed voltage	
18	8.5V supply above the maximum allowed voltage	
19	Relay failure	
20	The total current of all outputs is too high	
21	Out of tolerance	
22	Too many write SDOs for this device	
23	Too many read SDOs for this device	
24	Component is not calibrated	
25	A sensor with redundant inputs has both at the same state: They must be opposite to each other	
26	Two opposite input switches are both active. Example: Outrigger Extend & Retract	
27	Joystick X axis fault	
28	Joystick Y axis fault	
29	Calibration invalid: The calibration points are too close to each other.	
30	The power supply voltage is too low	
31	The internal supply voltage UE is too low	
32	The internal supply voltage UB1 is too low	
33	The internal supply voltage UB2 is too low	
34	The internal supply voltage UC1 is too low	



Fault Code	Condition Description	
35	The internal supply voltage UC2 is too low	
36	Analog Input error	
37	Digital Input error	
38	Digital Output error	
39	PWM Output error	
40	Task Time too long	
41	Data is not valid	
42	Device is not operational	
43	Could not get semaphore	
44	Data does not match required data	
45	The counter from a connected CAN device is no longer being updated. The data is considered no longer valid.	
46	A CAN device is reporting a self-detected error	
47	The pinning system could not unlock within the required time limit	
48	The current operating mode is invalid	
49	Movement in opposite direction	
50	Unintentional Lock	
52	The internal supply voltage UF is too low	
53	The internal supply voltage UE is too low	
54	The internal supply voltage UF is out of range	
55	The internal supply voltage UB1 is out of range	
56	The internal supply voltage UB2 is out of range	
57	The internal supply voltage UC1 is out of range	
58	The internal supply voltage UC2 is out of range	
59	The external supply voltage EXT is out of range	
60	Outrigger base too small	
61	Jib angle tolerance	
128	The last reset was because the watchdog detected that Ue was above the maximum allowed value	
129	The last reset was because the watchdog detected that Ue was below the minimum allowed value	
130	The last reset was because the watchdog detected that the system voltage was above the maximum allowed value	
131	The last reset was because the watchdog detected that the system voltage was below the minimum allowed value	
132	The last reset was because the watchdog detected an error as defined by the user	
133	The last reset was because the watchdog detected a system error	

Fault Code	Condition Description
134	The last reset was because the watchdog detected a configuration error
137	Unexpected NULL pointer
140	Command not zero. The joystick or tele pedal command must be zero to enable a function.
150	Pressure negative and positive
151	Pressure negative at positive
152	Pressure positive at negative
153	Pressure positive at stop
154	Pressure negative at stop



Device Codes

Fault Code	Device Description
	SCM0
1	SCM1
2	SCM2
3	SCM3
10	CCM10
11	CCM11
12	CCM12
13	CCM13
20	IOS20
21	IOS21
22	IOS22
23	IOS23
24	IOS24
25	IOS25
26	IOS26
27	IOS27
30	IOL30
31	IOL31
32	IOL32
33	IOL33
34	IOL34
35	IOL35
36	IOL36
37	IOL37
38	IOL38
39	IOL39
40	IOL40
41	IOL41
42	IOL42
43	IOL43
44	IOL44
45	IOL45
50	Joystick Left
51	Joystick Right

Index Codes

	Index Description
0-29	Digital Inputs
48-95	Digital Outputs
96-110	Analog Inputs
128	Internal measurement
129	CAN bus 1
130	CAN bus 2
131	CAN bus 3
132	CAN bus 4
140	Eeprom Read - backup area
141	Eeprom Read - customer area
142	Eeprom Write - backup area
143	Eeprom Write - customer area
144	Not Applicable
145	Internal Software
150	Pressure logic
150	Pressure logic



SECTION 4 BOOM

SECTION CONTENTS

Description 4-	1
Theory of Operation 4- Boom Extension 4- Boom Retraction 4-	1
Maintenance 4- Removal 4-	-
Boom Disassembly. 4- Remove the Base Section 4- Disconnect Inner Mid Section 4- Remove the Inner Mid Section 4- Remove Outer Mid Section 4-1 Remove Telescope Cylinder 4-1 Boom Nose Sheaves 4-1	6 8 9 0 2
Boom Assembly4-1Install Telescope Cylinder4-1Install Outer Mid Section4-1Install Inner Mid Section4-1Connect Inner Mid Section4-1Install Base Section4-1Boom Installation4-1Functional Check4-1	3 4 6 7 8 9

	Inspection	4-19
	Boom Alignment and Servicing	
В	oom Extension and Retraction Cable	4-20
	Maintenance	4-20
	Inspection	4-20
	Extension Cable Adjustment	4-20
	Retract Cable Adjustment	4-21
T	elescope Circuit	4-21
	Description	4-21
	Theory of Operation	4-21
	Maintenance	4-22
Li	ift Circuit	4-25
	Description	4-25
	Theory of Operation	4-25
	Maintenance	4-25
S	wingaway Boom Extension	4-29
	Description	4-29
	Maintenance	4-29
Η	ook Block	4-34
	Description	4-34
	Maintenance	4-34

DESCRIPTION

A four section 8.81 to 29.0 m (28.7 to 95.0 ft), synchronized full power, cable extended boom is installed on this crane.

The boom is rectangular in design and utilizes one twostage double-acting, rod ported telescope cylinder. The telescoping sections are supported on graphite impregnated nylatron wear pads. Adjustable side wear pads prevent metal to metal contact between the sections.

Boom assembly lift is provided by one lift cylinder. Boom elevation is from -3 to 76 degrees.

An optional auxiliary boom nose (rooster sheave) is available for the boom to simplify single part cable usage. The rooster sheave is installed on the main boom nose and is secured by pins that pass through the rooster sheave and bolt on adapter plates on the main boom nose.

A 7.92 m (26 ft) offsetable or a 7.92 to 13.7 m (26 to 45 ft) telescoping offsetable swingaway boom extension is provided to obtain additional boom reach. The boom

extension mounts directly to the boom nose utilizing a four point attachment. The boom extensions may be offset at 0 to 30 degrees. In addition, the swingaway can be stowed on the right side of the boom base section.

THEORY OF OPERATION

Boom Extension


The outer rod end of the telescope cylinder is secured to the boom base section, the inner rod end is secured to the inner mid section, and the cylinder barrel is secured to the outer mid section. The five fly section extension cables secured to the inner mid section are routed around a five groove sheave assembly at the barrel end of the telescope cylinder and are secured at the opposite end to the fly section. The long extend synchronizing cable is routed around two sheaves on the top front of the inner mid, around a half sheave at the top rear of the outer mid, and secured to the rear of the base section. The four retraction cables are secured at the outside front of the inner mid section, are routed around sheaves mounted on the end of the outer mid section and are secured at the opposite end to the fly section. The six retraction cables are secured at the outside front of the base section, are routed around sheaves mounted on the end of the inner mid section and are secured at the opposite end to the outer mid section.

As the telescope cylinder extends, the cylinder barrel, which is attached to the outer mid section and the inner cylinder rod which is attached to the inner mid section, pulls the mid sections out along with it. At the same time, the five groove sheave assembly at the end of the telescope cylinder pulls on the five fly extension cables around it. This causes the fly extension cables to pull the fly section out at the same time and rate that the telescope cylinder is pulling out the mid sections. The long extend synchronizing cable ensures the mid sections and the telescope cylinder remain in synchronization.

Boom Retraction

The four fly retraction cables are secured at the outside front of the inner mid section, are routed around sheaves mounted on the end of the outer mid section and are secured at the rear end to the fly section. The six outer mid retraction cables are secured at the outside front of the base section, are routed around sheaves mounted on the end of the inner mid section and are secured at the rear end to the outer mid section. As the telescope cylinder is retracted, the outer mid section, which is secured to the cylinder barrel and the inner mid section, which is secured to the inner cylinder rod, are pulled in. At the same time, the sheaves at the rear of the mid sections pull on the four fly and six outer mid retraction cables around the sheaves. This causes the retraction cables to pull the fly section and the outer mid section in at the same time and rate the telescope cylinder is pulling in the mid sections and the telescope cylinder stages remain in synchronization.






ltem	Description	Item	
1	Fly Section	15	Uppe
2	Outer Mid Section	16	Lowe
3	Inner Mid Section	17	Kicke
4	Base Section	18	Front
5	Telescope Cylinder Barrel	19	Botto
6	Sheave Mounting Assembly	20	Greas
7	Extend Cable Sheave Assembly	21	Exter
8	Extend Sheave Shaft	22	Fly R
9	Cable Retainer	23	Outer
10	Fly Extend Cables	24	Kicke
11	Support Foot Weldment	25	Exter
12	Wear Pads	26	A2B F
13	Cable Retainer Pin	27	Retra
14	End Cap		

Item	Description
15	Upper Boom Nose Sheaves
16	Lower Boom Nose Sheaves
17	Kicker Plate
18	Front Top and Bottom Side Wear Pads
19	Bottom Front Wear Pads
20	Grease Fittings
21	Extend Synchronizing Cable
22	Fly Retract Cables
23	Outer Mid Retract Cables
24	Kicker Plates
25	Extend Synchronizing Cable Sheave Assembles
26	A2B Roller Guide Mounting Angle
27	Retract Cable Anchor Plates





ltem	Description	ltem	Description
28	Telescope Cylinder Inner Rod	37	Retract Cable Sheaves, Shaft, Thrust Washers
29	Telescope Cylinder Outer Rod	01	and Spacers
30	Lower Rear Side Wear Pads	38	Cable Retainer Bushings and Bolts
31	Bottom Wear Pads	39	Fly Extend Cable Sled
32	Pins	40	Fly Extend Cable Sled Adjusting Bolt
33	Fly Extend Cables Keeper Plate	41	Holding valve Port Block
34	Adjustable Wear Pads	42	Keeper Bolts
35	Keeper Plates	43	Pivot Shaft
36	Offset Washers	44	Pin
00		45	Cotter Pin

4

MAINTENANCE

Removal

- **NOTE:** The boom may be disassembled with the base section left on the crane if repair of the base section is not necessary.
- **NOTE:** The boom weighs approximately 4978 kg (10,974 lb). Removal of the boom extension will simplify boom removal, therefore, the above weight is for the boom without the swingaway boom extension attached.
- 1. Extend and set the outriggers to level the crane and ensure the boom is fully retracted and in a horizontal position over the front of the crane.
- **2.** If equipped, remove the boom extension according to the removal procedures in this section.



Wear gloves when handling wire rope.

- **3.** Remove the hook block or headache ball and wind all the wire rope onto the hoist drum.
- 4. Elevate the boom slightly so that the lift cylinder is extended approximately 30.48 cm (12 in) to allow for withdrawal of the lift cylinder rod end from the lift cylinder attach fitting on the bottom of the boom.



Ensure all blocking and lifting devices are capable of supporting the boom assembly.

- **5.** Attach a lifting device to the boom to provide for equal weight distribution.
- 6. Disconnect any electrical wiring from the boom.
- **7.** Tag and disconnect the hydraulic lines to the telescope cylinder. Cap or plug the lines and openings.

Ensure the boom lift cylinder is properly supported before disconnecting it from the boom.

- 8. Block the lift cylinder.
- **9.** Remove the bolt and washer securing the upper lift cylinder shaft to the side of the attach fitting on the boom.
- **10.** Remove the upper lift cylinder shaft.
- **11.** Activate the hydraulic system and withdraw the lift cylinder rod enough to clear the attach fitting. For removal of the lift cylinder from the crane refer to the removal procedures outlined in LIFT CIRCUIT Removal in this section.



Shut down the crane before proceeding.

- 12. Take up the slack on the boom lifting device.
- **13.** Remove the clip pin and retaining pin securing the boom pivot shaft on the boom to the superstructure assembly. Remove the grease fittings from the pivot shaft. Remove the boom pivot shaft.
- **14.** Raise the boom clear of the crane and lower to blocking or cribbing for service.


BOOM DISASSEMBLY

- **NOTE:** The complete boom assembly without the swingaway boom extension attached weighs approximately 4978 kg (10,974 lb).
- 1. Remove the boom in accordance with the REMOVAL procedures outlined in this section.
- 2. Remove the bolts and washers securing the telescope cylinder outer rod to the rear of the base section.
- **3.** Remove the nuts and washers securing the synchronizing cable ends to the base section.

Remove the Base Section


- **NOTE:** The combined weight of the boom inner mid, outer mid, and fly sections, including the telescope cylinder, is approximately 3680 kg (8110 lb).
- 1. Remove the access cover on the top rear of the base section. Slide the assembly out of the base section enough to gain access to the top rear adjustable wear pads on the inner mid.






ltem	Description
1	Telescope Cylinder - Rod End
2	Base Section
3	Telescope Cylinder - Inner Rod
4	Inner Mid Section
5	Telescope Cylinder Barrel
6	Outer Mid Section
7	Extension Cables
8	Inner Mid Section
9	Sheave Assembly
10	Telescope Cylinder
11	Fly Section Base End
12	Synchronizing Cables
13	Base Section - Rear
14	Retraction Cables
15	Sheave
16	Retraction Cable to Fly Section
17	Fly Section
18	Retraction Cables to Outside Front of Base Section
19	Sheave
20	Retract Cables to Outer Mid Section
21	Base Section Top and Bottom Wear Pads

 Remove the capscrews, washers, and offset washers (1) (Figure 4-3) securing each top rear adjustable wear pad and remove the wear pads, keeper plates and capscrews from the top of the inner mid. Note location of wear pads and shims for installation.



 On the top front of the base section, remove the two capscrews securing each kicker plate and remove the plates.


- 4. Remove the capscrews securing the outer mid retract cable anchor plates to the lower front of the base section. Remove the cable locknuts and the anchor plates from the cables.
- Remove the capscrews and washers securing each top (1) and bottom (2) side wear pads at the front of the base section (Figure 4-4). Remove wear pads, shims, and mounting angle (top left side only).



- 6. Lift up on the front of the assembly and remove the wear pads from the pockets in the bottom of the base section.
- 7. Continue to pull the assembly from the base section.


Disconnect Inner Mid Section

1. At the rear of the inner mid, remove the capscrew and cable retainer bushing (1) from the rear of each retract cable sheave assembly (2)(Figure 4-5).






 On both sides, remove the capscrews (1) securing each retract sheave assembly shaft weldment. Remove the shaft, spacer bushing, sheave assembly, and two thrust washers (3) (Figure 4-6). If necessary, remove the grease fitting from the shaft weldment.




- Remove the two capscrews and washers (1) securing the cylinder inner rod (2) to the rear of the inner mid (3) (Figure 4-7).
- **4.** Remove the nuts (4) from the extend cable sled weldment adjusting bolts Figure 4-7.




5. Pull the retract cables up through the holes in the bottom of the inner mid and lay them out to the rear.

Remove the Inner Mid Section


- **NOTE:** Together the boom outer mid and fly sections, and telescope cylinder weigh approximately 2550 kg (5610 lb).
- 6. Slide the assembly out of the inner mid enough to gain access to the top rear adjustable wear pads on the outer mid through the hole in the top of the inner mid.
- Remove the capscrews, washers, and offset washers (1) securing each top rear adjustable wear pad (2). Remove the wear pads, keeper plates (3) and capscrews from the top of the outer mid (4) (Figure 4-8).




8. At the top front of the inner mid, remove the four bolts and washers (1) securing the synchronizing cable (2) sheave assembly (3). Lay the assembly with cables on top of the outer mid (4) (Figure 4-9).




9. Remove the capscrews and washers (1) securing the fly retract cable anchor plates (2) to the lower front of the inner mid section. Remove the cable locknuts and the anchor plates (3) from the cables (Figure 4-10).



- **10.** Remove the capscrews and washers (4) securing each top (5) and bottom (6) side wear pad at the front of the inner mid (Figure 4-10). Remove wear pads, shims, and mounting angle (top left side only) (7).
- **11.** Lift up on the front of the assembly and remove the wear pads from the pockets in the bottom of the inner mid.
- **12.** Continue to pull the assembly from the inner mid section until access to the rear of the outer mid is gained to disconnect the six retract cables.
- **13.** Remove the cotter pins and pins (1) securing the retract cables (2) to the rear of the outer mid (Figure 4-11).



14. Remove the two adjusting bolts (1) from the extend cable sled weldment (2) (Figure 4-12).




- **15.** Remove the two bolts securing the keeper plate (3) to the bottom of the sled and remove it from the cable ends (Figure 4-12).
- **16.** If necessary, remove the retract cables from the inside of the inner mid.
- **17.** If necessary, remove the two bolts securing the bottom wear pad to the inner mid. Remove wear pad.
- **18.** If necessary, remove the two bolts securing each lower rear side wear pad to the inner mid. Remove wear pads and shims. Note location of shims for installation.

Remove Outer Mid Section


- 1. At the rear of the outer mid, remove the capscrew and cable retainer bushing from above each retract cable sheave assembly (1) (Figure 4-13).
- On both sides, remove the capscrews securing each retract sheave assembly shaft weldment (2) (Figure 4-13). Remove the shaft, spacer bushing, sheave assembly, and two thrust washers. If necessary, remove the grease fitting (3) from the shaft weldment.




4




3. Place blocking (1) under cylinder (2) (Figure 4-14) and remove the two bolts and washers securing the cylinder barrel to the rear of the outer mid.




- 4. Pull the retract cables up through the holes in the bottom of the outer mid and lay them out to the rear.
- **NOTE:** Together the boom fly section and telescope cylinder weigh approximately 1690 kg (3720 pounds).
- **5.** Turn cylinder rod mounting lugs so they are vertical to clear mounting bracket in the outer mid.
- 6. Slide the fly assembly out of the outer mid enough to gain access to the top rear adjustable wear pads on the fly through the hole in the top of the outer mid.
- Remove the capscrews washers, and offset washers (1) securing each top rear adjustable wear pad (2). Remove the wear pads and wear pad holder from the top of the fly (3) (Figure 4-15).




8. At the top front of the outer mid, remove the capscrews securing the kickback plate (1) (Figure 4-16). Remove the kickback plate.



9. Remove the capscrews securing each top (1) and bottom (2) (Figure 4-17) side wear pads at the front of the outer mid. Remove wear pads, shims, and mounting angle (3) (top left side only).




- **10.** Lift up on the front of the fly assembly and remove the wear pads (4) (Figure 4-17) from the pockets in the bottom of the outer mid.
- **11.** Continue to pull the assembly from the outer mid section until access to the rear of the fly is gained to disconnect the four retract cables.
- **12.** Remove the clip pins and pins (1) securing the four fly retract cables (2) to the rear of the fly (Figure 4-18).




- **13.** If necessary, remove the synchronizing cable and sheave assembly from the top of the outer mid.
- **14.** If necessary, remove the four fly retract cables from the inside of the outer mid.
- **15.** If necessary, remove the two bolts securing the bottom wear pad to the outer mid. Remove wear pad.
- **16.** If necessary, remove the two bolts securing each lower rear side wear pad to the outer mid. Remove wear pads and shims. Note location of shims for installation.

Remove Telescope Cylinder

- 1. Attach a suitable lifting device to the telescope cylinder. Raise the cylinder and remove the blocking device from under the cylinder
- 2. Slide the cylinder out the rear of the fly until the extend cable sheave assembly is aligned with the side access hole in the fly section.
- **NOTE:** The telescope cylinder weighs approximately 899 kg (1980 lb).
- **3.** Remove the capscrews and washers (1) securing the extend cable keeper plate (2) to the rear of the fly (Figure 4-19). Remove the keeper plate and remove the five extend cable ends from the slots in the fly.



- 4. Lift up on the sheave end of the cylinder and remove the two lower capscrews securing the support foot weldment and sheave mounting assembly to the cylinder barrel. Remove the support foot weldment.
- If necessary, remove the capscrews securing each wear pad to the support foot weldment. Remove the wear pads.
- 6. Continue to pull the cylinder from the fly section until access to the rear of the fly is gained to disconnect the five extend cables.
- 7. If necessary, remove the screws securing the bottom rear wear pad to the fly. Remove wear pad.
- 8. If necessary, remove the capscrews (1) securing each lower rear side wear pad (2) to the fly section (3) (Figure 4-20). Remove wear pads and shims. Note location of shims for installation.



- **9.** If new cylinder is to be installed, remove the cable retainer, cables, extend sheave assembly, and sheave mounting assembly from the barrel end of the cylinder.
- **10.** If removal of the boom nose sheaves are required, refer to BOOM NOSE SHEAVES Removal in this section.



RT530E-2 SERVICE MANUAL

 Refer to BOOM EXTENSION AND RETRACTION CABLE MAINTENANCE in this section for cable inspection.

Boom Nose Sheaves

NOTE: Refer to BOOM NOSE SHEAVES in this section.

BOOM ASSEMBLY

CAUTION

When adjusting cables, hold the cable end and turn the nut. do not turn cable. Turning cable while adjusting will result in damage or failure of cable.


CAUTION

Install cables in their natural untwisted condition. Do not twist cable. Twisting of cable will result in damage or failure of cable.


- **NOTE:** Apply Loctite 243 to the threads of all attaching hardware except cable ends and cable lock nuts.
- **NOTE:** Apply multipurpose grease (MPG) to all wear pads and the surfaces the wear pads slide on.
- **NOTE:** Use standard torque values specified in Section 1-INTRODUCTION of this Manual unless otherwise specified.
- **NOTE:** When installing upper and lower side wear pad, use shims as necessary so wear pad is within 1.5 mm (0.06 inch) from side plate of next inner section. Use equal number of shims on each side.

Install Telescope Cylinder

- 1. Measure and mark the center line of the fly section. This mark will be used to set the adjustable wear pads after the section is installed in the outer mid section.
- 2. If removed from the telescope cylinder (3) assembly, install the sheave mounting assembly (1) with four capscrews and washers (2). Do not tighten lower two capscrews at this time. They will be torqued later.



- **3.** Install the telescope sheave assembly to the telescope cylinder as follows:
 - a. Using the extend sheave shaft, install the extend cable sheave assembly with spacer on each side, on the sheave mounting assembly.
 - **b.** Install grease fitting (4) (Figure 4-21) in shaft.
 - c. Lubricate sheave.
- 4. Route the five extension cables (5) (Figure 4-21) up and around the extend cable sheave assembly about one foot on to cylinder. To aid in assembly, secure the cables to the top end of the cylinder by wrapping tape around the cylinder.
- 5. Position the cable retainer (6) (Figure 4-21) over the sheave shaft and secure it to the sheave mounting assembly with four capscrews and washers. The retainer secures the sheave shaft.
- 6. Install the lower rear side wear pads and shims (1) on the fly section with two capscrews (2) each (Figure 4-22).



7. Install the bottom rear wear pad on the fly section with two screws.

CAUTION

The five extend cables must be marked at both ends prior to installation. If the cables are not marked, they will be difficult to install in the correct order.


Do not allow the cables to become entangled or overlap. Cable or boom failure could result.

When adjusting cables, hold the cable end and turn the nut. do not turn cable.

Turning or twisting of the cable while adjusting will result in damage or failure of cable.

Install cables in their natural untwisted condition.

8. Position the sheave end of the telescope cylinder (with port block up) at the rear of the fly section. Place the five extend cable dead ends in the slots at the top of the fly section and secure them with keeper plate (2), capscrews and washers (1) (Figure 4-23).




- **9.** Install the telescope cylinder into the fly section until the sheave end is aligned with the side access hole in the fly.
- **10.** Install the two wear pads on the support foot weldment with two capscrews each.
- **11.** Lift up on the sheave end of the telescope cylinder and remove the two lower capscrews securing the sheave mounting assembly.
- **12.** Install the support foot weldment through the side access hole and secure with the two removed

capscrews. Torque all four capscrews at this time to standard torque. A 1-1/8" box x 3/4 drive 6" step wrench will be required. It can be ordered from Grove using part number 9-999-100122. Lower cylinder so it rests on support foot weldment wear pads.

- **13.** Slide cylinder all the way in. Place blocking under the rear of the telescope cylinder to aid in assembly.
- **14.** Turn rod ends so they are aligned vertically to clear mounting brackets in outer mid.


Install Outer Mid Section

- **NOTE:** When installing upper and lower side wear pad, use shims as necessary so wear pad is within 1.5 mm (0.06 inch) from side plate of next inner section. Use equal number of shims on each side.
- Install the lower rear side wear pads and shims (1) on the outer mid section with two screws (2) each (Figure 4-24).




- 2. Install the bottom rear wear pad on the outer mid section with two screws.
- **3.** Lay four fly retract cables inside the bottom of the outer mid section, threaded ends out the back.
- 4. Install two extend synchronizing cable sheaves (1) on the shafts of the sheave mount weld (2). Install a grease fitting (3) in each shaft. Lay this assembly on top front of outer mid section (Figure 4-25).






- 5. Lay out the extend synchronizing cable on top of the outer mid with both threaded ends at the rear and the loop at the front. Route the looped end through the inside of the sheaves installed in step 4. Place the looped end around the fixed half sheave at rear of the outer mid. Be careful to not twist cable.
- 6. Install a socket head keeper bolt on each side of the half sheave to retain the cable.
- **7.** Position the front end of the outer mid at the rear of the fly/telescope cylinder assembly.
- 8. Using pins, cotter pins, and safety clip (1) attach the four fly retract cables (2) laying in the bottom of the outer mid to the lugs in the rear of the fly (3) (Figure 4-26).




9. Slide the fly/telescope cylinder into the outer mid being careful not to damage any of the cables. As the sections slide together pull the retract cables out the rear of the outer mid. Do not fully slide together.

 Lift up on the front of the fly and install the bottom front wear pads (1) (Figure 4-27) in the pockets of the outer mid.



- **11.** Install outer mid front top (4) and bottom (2) side wear pads with two screws each. On top left side attach mounting angle (3) with top wear pad screw (Figure 4-27). Shim as noted during disassembly.
- **12.** Install kicker plate in top of outer mid with capscrews.
- 13. Completely slide assembly together.
- **14.** Turn cylinder rod mounting lugs so they are horizontal with port block holding valve being at the top.
- **15.** Loosen plugs in cylinder port block and manually extend the inner rod approximately 15 to 20 cm (6 to 8 in). Tighten plugs.
- **16.** Lift up on end of cylinder to align barrel mounting holes with tabs and holes in lugs of outer mid. Secure with two bolts and washers.
- 17. Remove any blocking under cylinder.
- 18. Through the top access hole in the outer mid, position the two adjustable wear pads (4) on the top rear of the fly. Install each wear pad holder (5) and loosely install each with two capscrews and washers (6) (Figure 4-26). Install offset washers, capscrews and washers (7). Using the offset washers, adjust the wear pads such that the wear pads are within 1 mm (0.03 in) from each side plate of the next outer section. Tighten the offset washer and capscrews.
- **19.** Route the four fly retract cables through the holes in the bottom of the outer mid and pull them toward the front of the assembly. Install the anchor plates on the cables with cable locknuts. Be careful not to tangle cables.
- **20.** Apply grease to four thrust washers and place one on each side of the two groove retract cable sheave assemblies. Grease will keep the thrust washer in place during installation.




- 21. Install grease fitting (1) in two shaft weldments. Position retract cables (2) around sheave assemblies (3) (Figure 4-28). Install spacer bushing and install shaft weldment through mounting lugs in outer mid and the sheave assembly and spacer bushing (4). Secure each shaft weldment with a bolt. Apply grease to fittings.
- **22.** Position cable retainer bushing (5) (Figure 4-28) on top of each sheave assembly and secure with a capscrew.

Install Inner Mid Section

- 1. Install the lower rear side wear pads and shims on the inner mid section with two screws each.
- 2. Install the bottom rear wear pad on the inner mid section with two screws.


3. Lay outer mid retract cables inside the bottom of the inner mid section, threaded ends out the back.




- 4. Position the extend cable sled weldment (1) on the five large extend cables (2), slots down, and secure the cables to the sled with keeper plate and two bolts (3) (Figure 4-29). Be careful not to tangle cables.
- **5.** Install two long adjusting bolts (4) through holes in sled, heads from the front (Figure 4-29).
- **6.** Temporarily fasten the sled up under the cylinder so it does not interfere with installation.
- **7.** Position the front of the inner mid at the rear of the assembly.




8. Using pins and cotter pins (1) (Figure 4-30), attach the outer mid retract cables (2) laying in the bottom of the inner mid to the lugs in the rear of the outer mid.



- 9. Slide the assembly into the inner mid being careful not to damage any of the cables. As the sections slide together pull the retract cables out the rear of the inner mid. Do not fully slide together.
- **10.** Lift up on the front of the assembly and install the bottom front wear pads (1) in the pockets of the inner mid (Figure 4-31).




- **11.** Install inner mid front top (2) and bottom (3) side wear pads with two screws each. On top left side attach mounting angle (4) with bottom wear pad screw (Figure 4-31).
- **12.** Attach fly retract cable anchor plates (5) to front of inner mid with two bolts each (6) (Figure 4-31).
- **13.** Using four bolts and washers, attach the extend synchronizing cable sheave assembly laying on top of the outer mid to top front inside of the inner mid.
- 14. Through the top access hole in the inner mid, position the two adjustable wear pads (2) on the top rear of the outer mid (4). Install each wear pad holder (3) and loosely install each with two capscrews and washers. Install offset washers, capscrews, and washers (1) (Figure 4-32). Using the offset washers, adjust the wear pads such that the wear pads are within 1 mm (0.03 in) from each side plate of the next outer section. Tighten the offset washer and capscrews.



Connect Inner Mid Section


- 1. Route outer mid retract cables through the holes in the bottom of the inner mid and pull them toward the front of the assembly. Install the anchor plates on the cables with cable locknuts. Be careful not to tangle cables.
- 2. While continuing to slide together, route extend cable sled adjusting bolts through mounting holes in rear of inner mid. Install nuts on the bolts.
- **3.** Align the cylinder inner rod (1) mounting holes with the tabs and holes in the rear of the inner mid and secure with two capscrews and washers (2) (Figure 4-33).



- 4. Apply grease to four thrust washers and place one on each side of the three groove retract cable sheave assemblies. Grease will keep the thrust washer in place during installation.
- 5. Install grease fitting in two shaft weldments. Position retract cables around sheave assemblies, install spacer bushing, and install shaft weldment through mounting lugs in inner mid and the sheave assembly and spacer bushing. Secure each shaft weldment with a capscrew. Apply grease to fittings.
- 6. Position cable retainer bushing to the rear of each sheave assembly and secure with a capscrew
- Loosen plugs in cylinder port block and manually extend the outer rod approximately 15 to 20 cm (6 to 8 in). Tighten plugs.
- 8. Position the front of the base section at the rear of the assembly and slide together being careful not to damage any cables.

Install Base Section

- 1. Lift up on the front of the assembly and install the bottom front wear pads in the pockets of the base section.
- 2. Install base section front top (1) and bottom (2) side wear pads with two screws each (Figure 4-34). On top left side attach mounting angle (3) with both wear pad screws.



- **3.** Attach outer mid retract cable anchor plates (4) to front of base section with two capscrews (5) each (Figure 4-34).
- 4. Install kicker plate on top of each side of base section with two capscrews each.
- **5.** Through the top access hole in the base section, position the two adjustable wear pads on the top rear of the inner mid. Install each wear pad holder and loosely install each with two capscrews and washers. Install offset washers, capscrews, and washers. Using the offset washers, adjust the wear pads such that the wear pads are within 1mm (0.03 in) from each side plate of the next outer section. Tighten the offset washer and capscrews. Install top access hole cover.
- 6. Continue to slide together and route synchronizing cable threaded ends through holes in rear of base section. Install locknuts on cable ends.
- **7.** Align cylinder outer rod mounting holes with mounting holes in rear of base section and secure with two bolts and washers.
- 8. Reattach the RCL, A2B/ Length cable to the boom nose.
- **9.** Refer to Section 9 LUBRICATION section for lubrication of wear pads and other plates on boom.
- **10.** Install the boom in accordance with the INSTALLATION procedures outlined in this section.



Boom Installation

- **NOTE:** The following procedure applies to a boom totally removed from the crane.
- If the lift cylinder was removed from the crane, refer to installation procedures in LIFT CYLINDER INSTALLATION in this section.



Ensure blocking and lifting devices are capable of supporting the boom assembly.

- **2.** Extend and set the outriggers to level the crane and position superstructure toward front of crane.
- **3.** Attach an adequate lifting device to the boom and suspend the boom over the machine.
- 4. Lower the boom into position and align the boom pivot shaft mounting holes for installation of the pivot shaft to the superstructure assembly.
- 5. Lubricate and install the boom pivot shaft. Secure in place with the retaining pin and clip pin Install the grease fitting in each end of the shaft.



Block the boom before doing any work under the boom.

- 6. Block the boom in place.
- 7. Attach a suitable lifting device to the lift cylinder.

Failure to properly support the boom lift cylinder may result in death or injury to personnel.

8. Using the lifting device attached to the boom, lower the boom onto the lift cylinder rod end and extend the lift cylinder as necessary to align rod with attach fitting on boom.

If the hydraulic system must be activated to extend or retract the lift cylinder, ensure the rod end is properly aligned with the lift cylinder attach fitting.

- **9.** Lubricate and install the upper lift cylinder shaft. Secure in place with the bolt and washer. Refer to LIFT CIRCUIT INSTALLATION in this section.
- **10.** Remove the boom lifting device.
- **11.** Activate the hydraulic system to remove the boom and lift cylinder blocking devices. Lower the boom to horizontal. Shut down the crane.
- **12.** Connect the hydraulic lines to the telescope cylinder as tagged prior to removal.
- **13.** Connect any electrical wires as tagged prior to removal.
- Refer to BOOM EXTENSION AND RETRACTION CABLE ADJUSTMENT in this section for cable adjustments.

Functional Check

- Activate the hydraulic system and check for proper operation and any leaks.
 - 4
- 2. Ensure the boom will extend and retract properly.
- **3.** Ensure the lift cylinder will not allow the boom to drift down until the operator lowers it.
- 4. Ensure all electrical components disconnected during removal are operating properly.

Inspection

Visually inspect telescoping sections for adequate lubrication of all wear surfaces. Observe extended sections for evidence of cracks, warping, or other damage. Periodically check security of boom wear pads. Check boom nose sheaves for security and freedom of movement.


Boom Alignment And Servicing

Boom alignment is achieved by adjustment of the wear pads located at various points in the boom assembly. Adjustment of the wear pads is as follows:

- 1. Fully extend the boom horizontally.
- 2. Lubricate the boom bottom plates (sides and bottom).
- 3. Shim the front lower side wear pads to within 1.52 mm (0.06 in) from side plate of next inner boom section, then shim the front upper wear pads in the same manner. Use equal number of shims on each side.

CAUTION

When extending and retracting the boom during alignment, movement should be stopped if a restriction is encountered, and wear pads re-shimmed as necessary to provide free travel of the affected boom section(s).



- 4. Retract and extend the boom; check for the high point where the boom has brushed the wear pads at the widest point.
- 5. Retract the boom sections to align the high point on the boom section with the adjacent wear pads.
- 6. Add or subtract shims as necessary.
- **7.** Attach a weight and extend the boom full length. Check for side deflection.

Example: If the boom deflects to the left, the forward left wear pad would be shimmed in and the rear left adjustable wear pad would be adjusted out, away from the internal boom section in a similar manner. The forward right wear pad will be shimmed out and the right rear adjustable pad adjusted in.

BOOM EXTENSION AND RETRACTION CABLE

Maintenance

NOTE: For more detailed information concerning maintenance of the extension and retraction cables, refer to Wire Rope (pg 1- 17).

Inspection



Never handle wire rope with bare hands.

The following information is taken from a National Consensus standard as referenced by Federal Government Agencies.

All wire rope will eventually deteriorate to a point where it is no longer usable. Wire rope shall betaken out of service when any of the following conditions exist.

- 1. In running ropes, six randomly distributed broken wires in one lay or three broken wires in one strand in one lay.
- 2. Wear of one-third the original diameter of outside individual wires. Kinking, crushing, bird caging, or any

other damage resulting in distortion of the rope structure.

- 3. Evidence of any heat damage from any cause.
- 4. Reductions from nominal diameter of more than:
 - 0.4 mm (0.016-in) for diameters up to and including 8 mm (0.3125-in).
 - 0.79 mm (0.031-in) for diameters 10 and 13 mm (0.375 and 0.5-in) inclusive.
 - 1.19 mm (0.047-in) for diameters 14 to 19 mm (0.5625 to 0.75-in) inclusive.
 - 1.59 mm (0.063-in) for diameters 22 to 29 mm (0.875 to 1.125 in) inclusive.
 - 2.38 mm (0.094-in) for diameters 32 to 38 mm (1.25 to 1.5 in) inclusive.
- 5. In standing ropes, more than two broken wires in one lay in sections beyond end connections or more than one broken wire at an end connection.

Extension Cable Adjustment

CAUTION

When adjusting cables, hold the cable end and turn the nut. Do not turn cable. Turning cable while adjusting will result in damage or failure of cable.

- **NOTE:** The extension cables must be adjusted properly before the retract cables can be adjusted.
- 1. Extend and set the outriggers, ensuring the crane is level.
- **2.** Ensure the boom is over the front and at a horizontal position (boom angle elevation 0 degrees).
- **3.** There needs to be some initial tension on the retract cables before the extension cables can be adjusted. At any boom length, extend the boom 15 cm (6 in). This will cause a slack condition in the retract cables. Torque nuts on retract cables at front of inner and base sections to approximately 1.4Nm (1.0 lb-ft)



4

- 4. Fully extend the boom and then retract it approximately 15 cm (6 in). This will create the loosest condition for synchronizing and extension cables. Adjust the two extend synchronizing cables at the top rear of the base section. Adjust until 9 cm (3.5 in) of threaded cable end is exposed and lock with jam nuts.
- 5. To adjust the five fly extend cables, fully retract the boom to have access to the two extend cable sled adjusting bolts at the back of the inner mid section through the rear of the base section. Adjust these bolts to have 5 cm (23 in) of bolt thread exposed from the sled.
- 6. Check through the side access holes in the boom, that the fly extension cables have approximately 12 mm (0.5 in) slack and lock with jam nuts.

Retract Cable Adjustment

- 1. Extend each boom section approximately 900 mm (35.4 inches).
- 2. Adjust the outer mid retract cables at the front of the base section to have approximately 65 mm (2.5 inches) of threaded cable end exposed from the retract cable mounting plate.
- **3.** Adjust the fly retract cables at the front of the inner mid section to have approximately 76 mm (2.9 inches) of threaded cable exposed from the retract cable anchor plate.
- **4.** Fully retract the boom. All sections should bottom out on the next inner section at the same time.
- 5. If one or more sections do not fully retract, tighten the adjusting nut of the retraction cables for the section until the section bottoms out. Repeat until al sections bottom out at the same time.
- 6. Check through the side access holes in the boom, that the tension is the same for all retract cables for a given section. Lock all adjustments with jam nuts.

TELESCOPE CIRCUIT

Description

The boom telescope circuit consists of the telescope hydraulic remote controller, telescope directional control valve, holding valve, and the telescope cylinder. **NOTE:** If the crane is equipped with an auxiliary hoist, the telescope function is controlled by a foot pedal instead of a controller.

The telescope control valve is the closed spool type and is described under VALVES in Section 8.

Refer to VALVES in Section 8 for a complete description of the hydraulic remote controller.

The boom telescope cylinder is a two stage double acting, rod ported cylinder. Foreign material is prevented from entering the cylinder by a wiper seal during rod retraction. Oring seals prevent internal and external leakage. Refer to CYLINDERS in Section 8 for a complete description of the telescope cylinder.

The holding valve is threaded into a port block on the inner rod end of the telescope cylinder. The holding valve functions during the retraction, extension, or holding operation. When holding the boom section at a given length, oil is trapped in the cylinder by the holding valve. Refer to VALVES in Section 8 for a complete description of the holding valve.

Theory Of Operation

Flow from the pump travels to the telescope directional control valve. Movement of the control lever for telescope functions from neutral sends a pilot pressure signal to the directional control valve to shift the spool in the directional control valve. This aligns the appropriate passages in the control valve to route oil to the telescope cylinder holding valve. The holding valve, with its' internal make-up of valves and springs, passes oil to and from the telescope cylinder. During extension, oil unseats the poppet (check) valve in the holding valve. This oil is routed to the piston sides of the cylinder which forces the rods out of the cylinder, causing the boom section to extend.

During retraction, oil enters the retract port and flows to the rod sides of the cylinder. When pilot pressure reaches a predetermined value, the main poppet unseats, and oil flows from the piston sides of the cylinder to the reservoir causing the boom section to retract. All return flow from the directional control valve goes to the reservoir.

Maintenance

Telescope Circuit Troubleshooting

Table 4-1

SYMPTOM	PROBABLE CAUSE	SOLUTION	
1. Erratic operation of	a. Low hydraulic oil level.	a. Replenish hydraulic oil to proper level.	
extending telescoping	b. Damaged relief valves.	b. Repair or replace relief valves.	
cylinder.	c. Air in telescope cylinder.	c. Bleed by lowering telescope cylinder below horizontal.	
-	d. Low engine rpm.	d. Increase engine rpm to recommended setting.	
_	e. Lack of lubrication on boom sections.	e. Properly lubricate all boom sections.	
-	 f. Extremely tight boom extension sheaves. 	f. Inspect and properly lubricate boom extension sheaves.	
-	 Improper boom alignment caused from side loading. 	g. Reduce and properly hoist load.	
_	h. Worn boom wear pads.	 h. Replace wear pads and properly lubricate. 	
_	i. Distorted boom section.	i. Replace distorted section.	
_	j. Damaged telescope cylinder.	j. Repair or replace cylinder.	
	 k. Clogged, broken, or loose hydraulic lines or fittings. 	 k. Clean, tighten, or replace lines or fittings. 	
	I. Damaged control valve.	I. Repair or replace control valve.	



	SYMPTOM	PROBABLE CAUSE	SOLUTION
2.	Erratic operation of	a. Low hydraulic oil level.	a. Replenish hydraulic oil to proper level.
	retracting telescoping	b. Damaged relief valve.	b. Repair or replace relief valve.
	cylinder.	c. Air in cylinder.	c. Bleed by lowering telescoping cylinder below horizontal and cycle telescope cylinder.
		d. Low engine rpm.	d. Increase engine rpm to recommended setting.
		e. Lack of lubrication.	e. Properly lubricate all boom sections.
	-	f. Check valve malfunctioning.	f. Repair or replace check valve.
	-	g. Improper boom alignment caused from side loading.	g. Reduce and properly hoist load.
	-	h. Extremely tight boom retraction sheave.	h. Inspect and properly lubricate.
	-	i. Distorted boom section.	i. Replace distorted section.
	-	j. Worn boom wear pads.	j. Replace wear pads and properly lubricate.
	-	k. Bent cylinder rod(s).	 Replace cylinder rod(s) and all cylinder seals.
	-	I. Scored cylinder barrel.	I. Repair or replace cylinder barrel.
	-	m. Damaged piston seals.	m. Replace all cylinder seals.
		n. Loose or damaged piston(s).	 Replace all seals and re-torque or replace piston(s).
3.	Telescope cylinder	a. Low hydraulic oil level.	a. Replenish oil to proper level.
	will not extend.	b. Relief valve malfunctioning.	b. Repair or replace relief valve.
	_	c. Excessive load.	c. Reduce load.
		d. Clogged hose and fittings.	 Replace hose or fittings. (Refer to Manitowoc Crane Care Parts Manual).
		e. Broken valve spool.	e. Replace valve.
		f. Damaged piston seals.	f. Replace all cylinder seals.
	24	g. Damaged piston(s).	g. Replace piston(s) and all cylinder seals.
		h. Bent boom section(s).	h. Replace damaged boom section(s).
		i. Broken hydraulic pump coupling.	 Replace broken hydraulic pump coupling.
		j. Worn or damaged hydraulic pump section.	j. Repair or replace pump section.

	SYMPTOM	PROBABLE CAUSE	SOLUTION
4.	Telescope cylinder	a. Low hydraulic oil level.	a. Replenish oil to proper level.
	will not retract.	b. Relief valve damaged.	b. Repair or replace relief valve.
		c. Excessive load.	c. Reduce load. (Refer to load chart).
		d. Inoperative check valve.	d. Replace check valve.
	_	e. Clogged hose and fittings.	e. Replace hose or fittings. (Refer to Manitowoc Crane Care Parts Manual).
		f. Broken valve spool.	f. Replace valve section.
	_	g. Broken piston(s).	g. Replace piston(s) and all cylinder seals.
		h. Damaged piston seals.	h. Replace all cylinder seals.
		i. Bent boom section(s).	i. Replace damaged boom section(s).
	_	j. Broken hydraulic pump coupling.	j. Replace broken hydraulic pump coupling.
		k. Worn or damaged hydraulic pump.	k. Repair or replace pump.
		I. Broken hydraulic pump shaft.	I. Replace pump shaft.

Removal And Installation

Removal and installation of the telescope cylinder from the boom is described under disassembly and assembly of the boom. Refer to BOOM MAINTENANCE in this Section.

Disassembly And Assembly

Disassembly and assembly procedures of the telescope cylinder and control valve are provided in Section 2 under CYLINDERS and VALVES respectively.



Description

The boom lift circuit consists of the lift hydraulic remote controller, lift directional control valve, holding valve, and the lift cylinder. These components enable the boom to be raised or lowered to various degrees of elevation ranging from -3 to +76 degrees from horizontal.

The lift directional control valve is the closed spool type and is described under VALVES in Section 8 - HYDRAULIC SYSTEM.

Refer to VALVES in Section 8 for a complete description of the hydraulic remote controller.

The lift cylinder is the double acting type. Dirt and other foreign material is prevented from entering the cylinder and causing internal damage by a wiper seal during rod retraction. Oil Seals on both the piston and cylinder head prevent internal and external hydraulic oil leakage. Refer to CYLINDERS in Section 8 for a complete description of the lift cylinder.

Maintenance

Lift Circuit Troubleshooting

Table 4	4-2
---------	-----

Theory Of Operation

The directional control valve bank housing the lift control valve is supplied by flow from the hydraulic pump.

When booming up, oil unseats the poppet (check) valve in the holding valve, letting oil flow to the piston side of the cylinder. Pressure is applied to the piston, forcing the rod to extend, raising the boom.

When booming down, oil enters the retract port of the port block and flows to the cylinder rod side. When pilot pressure reaches a pre-determined value, the main poppet unseats and oil flows from the piston side of the cylinder to the reservoir.

All return flow from the control valve goes to the reservoir.

Symptom		Probable Cause		Solution	
1.	Boom raises erratically.	a. Low hydraulic oil.	a.	Replenish hydraulic oil to proper level.	
		b. Low engine rpm.	b.	Increase engine rpm to recommended setting.	
		c. Main relief valve damaged.	C.	Replace relief valve.	
		d. Air in cylinder rod.	d.	Bleed cylinder rod.	
		e. Bent boom pivot shaft.	е.	Replace pivot shaft.	
2.	Boom lowers erratically.	a. Low hydraulic oil.	a.	Replenish hydraulic oil to proper oil level.	
		b. Low engine rpm.	b.	Increase engine rpm to recommended level.	
		c. Circuit and/or relief valve inoperative.	C.	Repair or replace relief valve.	
		d. Air in hydraulic cylinder.	d.	Bleed air from cylinder.	
		e. Damaged hydraulic pump section.	е.	Repair or replace pump section.	

	Symptom		Probable Cause		Solution
3.	Boom raises slowly.	a.	Low hydraulic oil level.	a.	Replenish hydraulic oil to proper level.
		b.	Low engine rpm.	b.	Increase and maintain engine rpm.
		c.	Damaged relief valve.	c.	Repair or replace relief valve.
		d.	Extremely cold hydraulic oil.	d.	Operate unit to bring oil to operating temperature.
		e.	Improper hose or fittings, installed.	e.	Replace hose or fittings. (Refer to Manitowoc Crane Care Parts Manual).
		f.	Operating two functions with in the same control valve bank assembly.	f.	Feather controls to obtain desired speed of both functions.
		g.	Restriction in return hose.	g.	Replace return hose.
		h.	Cylinder piston seals leaking.	h.	Replace all cylinder seals.
		i.	Scored cylinder barrel.	i.	Hone or replace barrel.
		j.	Worn hydraulic pump section.	j.	Repair or replace pump section.
4.	Boom lowers	a.	Low hydraulic oil level.	a.	Replenish hydraulic oil to proper level.
	slowly.	b.	Low engine rpm.	b.	Increase rpm to recommended level.
		C.	Damaged relief valve.	c.	Repair or replace relief valve.
		d.	Operating two functions within the same control valve bank assembly.	d.	Feather controls to obtain desired speed of both functions.
		e.	Extremely cold hydraulic oil.	e.	Operate unit to bring oil to operating temperature.
		f.	Improper hose or fittings installed.	f.	Replace hose or fittings. (Refer to Manitowoc Crane Care Parts Manual).
		g.	Restriction in return hose.	g.	Replace return hose.
		h.	Cylinder piston seals worn.	h.	Replace all cylinder seals.
		i.	Scored cylinder barrel.	i.	Hone or replace barrel.
		j .	Worn hydraulic pump section.	j.	Repair or replace pump section.
		k.	Piston rod broken (loose from piston).	k.	Replace piston rod and all cylinder seals.
5.	Boom will not raise.	a.	Low hydraulic oil.	a.	Replenish hydraulic oil to proper level.
	G	b.	Main relief valve or circuit relief valve damaged.	b.	Repair or replace relief valve.
		C.	Excessive load.	c.	Reduce load as required.
		d.	Worn or damaged hydraulic pump section.	d.	Repair or replace pump section.
		e.	Broken pump shaft.	e.	Replace pump shaft and seals.
		f.	Broken pump drive coupling.	f.	Replace drive coupling.
		g.	Broken control valve spool.	g.	Replace control valve.



Symptom Probable Cause		Solution	
6. Boom will not	a. Low hydraulic oil.	a. Replenish hydraulic oil to proper level.	
lower.	 b. Main relief valve or circuit relief valve damaged. 	b. Repair or replace relief valve.	
	c. Worn or damaged hydraulic pump section.	c. Repair or replace pump section.	
	d. Broken pump shaft.	d. Replace pump shaft and seals.	
	e. Broken pump drive coupling.	e. Replace drive coupling.	
	f. Broken control valve spool.	f. Replace control valve.	

NOTE: Refer to Section 2 - HYDRAULIC AND PRESSURE SETTINGS for lift cylinder disassembly and assembly procedures. Maintenance not requiring removal of the cylinder barrels, such as packing, may be performed without removing the cylinders from the turntable. However, all disassembly and assembly should be conducted in a clean dust-free area.

Removal

- 1. Extend and set the outriggers and level the crane.
- Elevate the boom slightly so that the lift cylinder is extended approximately 0.3 m (1 ft). The lift cylinder is 521 kg (1149 lb).



Ensure any blocking or cribbing used is capable of supporting the boom.

- **3.** Ensure the boom is fully supported by placing blocking or cribbing under the boom. Rest the boom on the blocking or cribbing.
- 4. Remove the bolt and washer securing the lift cylinder upper pivot shaft to the boom.
- 5. Remove the bolt and locknut securing the lift cylinder lower pivot shaft to the turntable.



Ensure the lifting/supporting device is capable of supporting the lift cylinder.

- **6.** Attach an adequate lifting/supporting device to the lift cylinder being removed.
- **7.** Remove the upper pivot shaft. Activate the hydraulic system and retract the lift cylinder enough to clear the upper attach point.


- **8.** Tag and disconnect all the hydraulic lines to the cylinder. Cap or plug all openings with high pressure fittings.
- **9.** Pull the lower lift cylinder pivot shaft out far enough to remove the cylinder.
- 10. Move the lift cylinder to a clean work area.

Disassembly And Assembly

Disassembly and assembly procedures of the lift cylinder holding valve, and control valve are provided in Section 2 under CYLINDERS and VALVES respectively.

Installation

- 1. Attach an adequate lifting device to the lift cylinder and position the cylinder over the attach fitting on the turntable.
- **2.** Lower the lift cylinder into the attach fittings on the turntable and align the lift cylinder bushing with the attach fitting holes.
- **NOTE:** Install lower pivot shaft (Figure 4-35) (Detail B) with tapped hole on the right side, side opposite the cab.
- **3.** Install the lift cylinder lower pivot shaft and secure with the bolt and locknut.
- 4. Connect the extend and retract hoses to the lift cylinder.
- 5. Activate the crane's hydraulic system and align the lift cylinder rod end with the attach point on the boom. Install the upper pivot shaft through the cylinder and boom attach points. Shut down the engine.
- 6. Secure the upper pivot shaft with the bolt and washer.
- 7. Remove the lifting and supporting devices from the boom and lift cylinders. Activate the hydraulic system and check the lift cylinders for proper operation and any leaks.
- 8. Lubricate the pivot shafts using grease fittings.





SWINGAWAY BOOM EXTENSION

Description

A 7.92 m (26 ft) 0 or 30 degrees offsetable or a 7.92 to 13.7 m (26 to 45 ft) telescoping, 0 or 30 degrees offsetable swingaway boom extension is provided to obtain additional boom reach.

The boom extension mounts directly to the boom nose utilizing a four point attachment. In addition, the swingaway can be stowed on the right side of the boom base section.

Removing the attach pins from the attach points on the left side of the boom nose allows the swingaway to be rotated and stowed on the right side of the boom base section.

The fixed swingaway weighs approximately 588 kg (1296 lb) and the telescoping swingaway weighs approximately 810 kg (1790 lb).

Maintenance



Before attempting to erect or stow the swingaway, read and strictly adhere to all danger decals installed on the swingaway and stowage brackets.


Removal

- **NOTE:** If an adequate lifting device is available, the swingaway boom extension can be dismounted directly from the side
- 1. Fully extend and set the outriggers and level the crane.
- 2. Position the boom over the front.
- **3.** If extended, fully retract all the boom sections and lower the boom to minimum elevation to permit ease of installation of pins and access to the boom nose.

- **NOTE:** The auxiliary boom nose (rooster sheave) does not have to be removed. However, if reeved, the hoist cable must be removed from the sheave.
- 4. On the rear stowage bracket, remove the retainer pin securing the sliding support in the "IN" position (Figure 4-36). Pull out on the handle to pull the swingaway away from the rear of the boom and engage the swingaway anchor fittings with the boom nose attachment lugs. Install the retainer pin securing the sliding support in the "OUT" position.
- 5. Remove the clip pins from the two right side attachment pins stowed in the base of the swingaway and remove the two attachment pins from the swingaway. Insert the two right side attachment pins through the right side boom attachment and swingaway anchor fittings. Install the clip pins in the attachment pins.
- 6. Remove the clip pins from the hitch pin that secures the boom extension to the rear stowage bracket. Remove the hitch pin, unlocking the boom extension from the boom and stow in the stowage lug.
- 7. Attach a length of rope to the boom extension tip to aid in swinging the boom extension into place ahead of the boom nose.
- 8. Raise the boom to horizontal and extend the boom approximately 51 to 64 cm (20 to 25 in). Make certain that the boom extension stowage lugs clear the guide pins and ramp on the front and rear stowage brackets.

When erecting the boom extension, ensure that all personnel and equipment are kept clear of the swing path.


9. Slightly raise and/or lower the boom to help control the boom extension. Using the rope attached to the top of the boom extension, manually swing the extension into place ahead of the boom nose, engaging the attachment fittings with the anchor fittings on the left side of the boom nose.




ltem	Description	Item	Description
1	Swingaway Pin on Nose Assembly or	6	Right Side Attachment Pins
•	Telescoping Section	7	Left Side Attachment Pins
2	Swingaway Base	8	Mast Assembly
3	Main Boom base Section	9	Telescoping Section Pin (Optional)
4	Upper Boom nose Sheaves	10	Rear Stowage Bracket
5	Lower Boom Nose Sheaves	11	Front Stowage Bracket



4



ltem	Description	Item	Description
1	Boom Base Section	9	Alignment Jack
2	Inner Mid Section	10	Offset Pin
3	Outer Mid Section	11	Mast Assembly Stowage Pin
4	Fly Section	12	Mast Assembly
5	Upper Sheave Cable Retainer	13	Mast Assembly Cable Retainer
6	Left SIde Attachment Pins	14	Right Side Attachment Pins
7	Boom Nose Dead End Lug	15	Jack handle
8	Lower Sheave Cable Retainer		







Do not modify the attachment points to permit the installation of the attachment pins.



Do not place blocking under the boom extension sheave wheel.

- **10.** Install the top left side attachment pin and clip pin into the upper anchor and attachment fittings of the boom nose.
- **11.** Extend the boom extension alignment jack until the lower left side boom nose and boom extension adapter lugs are aligned.
- **12.** Install the bottom left side attachment pin and clip pin into the lower anchor and attachment fittings of the boom nose.
- **13.** Release pressure on the boom extension alignment jack and properly stow the jack handle.
- **14.** Extend and lower the boom until blocking can be placed under the swingaway. Remove the rope from the tip of the boom extension.
- **15.** Lower the swingaway onto the cribbing. Remove and stow the pins securing the swingaway to the boom nose.
- **16.** Retract the boom, freeing the swingaway from the boom nose.

Installation

- 1. Position the crane so the swingaway lies in front of the crane with the swingaway base facing the crane. Fully extend and set the outriggers.
- 2. Extend and lower the boom to engage the anchor and attachment fittings on the swingaway.
- **3.** Install the four attachment pins and clip pins to secure the swingaway to the boom nose. Raise the boom, lifting the swingaway from the cribbing on which it was resting. (Use boom extension alignment jack if required, see step 11 above.)
- 4. Attach a length of rope to the boom extension tip.
- 5. Raise the boom to horizontal.
- 6. Extend the boom approximately 51 to 64 cm (20 to 25"). Make certain that the boom extension stowage lugs will

line up in front of the guide pins and ramp on the stowage brackets when the boom extension is positioned to the side of the boom.

- 7. Ensure the hitch pin and clip pin are removed from the rear stowage bracket.
- 8. Extend the boom extension alignment jack until the bottom left side attachment pin is free. Remove the bottom left side boom extension clip pin and attachment pin.
- **9.** Release pressure on the boom extension alignment jack. Completely retract the jack and properly stow the jack handle.
- **10.** Remove the top left side attachment pin and clip pin from the upper anchor and attachment fittings of the boom nose.

When stowing the boom extension, ensure that all personnel and equipment are kept clear of the swing path.

CAUTION

Do not allow the boom extension to slam into the stowage bracket when swinging into the stowed position.

- **11.** Using the rope attached to the tip of the boom extension, manually swing the extension to the side of the boom.
- **12.** Align the stowage lugs on the boom extension with the guide pins and ramp on the stowage brackets and fully retract the boom.
- **13.** Install the hitch pin and clip pin securing the boom extension to the rear stowage bracket.
- 14. Remove the attachment pins and clip pins from the anchor and attachment fittings on the right side of the boom nose and stow them in the base of the swingaway. Stow left side attachment pins and clips in outside attachment fittings on swingaway.
- **15.** On the rear stowage bracket, remove the retainer pin securing the sliding support in the "OUT" position. Push in on the handle to push the swingaway against the rear of the boom and disengage the swingaway anchor fittings from the boom nose attachment lugs. Install the retainer pin securing the sliding support in the "IN" position.
- **16.** Rig the boom nose and hoist cable as desired and operate the crane using normal operating procedures.

HOOK BLOCK

Description

A 27 metric ton (30 ton) hook block, a 30 metric ton (33 ton) hook block, and a 6.8 metric ton (7.5 ton) headache ball are available for the crane. The hook blocks utilizes a one-piece pivot block and the hook is equipped with a safety latch. Both hook blocks are the quick reeve design. Grease fittings are provided to ensure lubrication of all moving parts.

CAUTION

Do not use a swivel type headache ball with 18 x 19 wire rope.

Maintenance

Periodic Maintenance

It is recommended that the hook block and/or headache ball be inspected every 50 hours. A complete disassembly inspection should be conducted every quarter or 500 hours in the area of the hook, hex nut, and threaded areas for corrosion and proper fit. After assembly of the hook, a liberal coating of multipurpose grease should be applied to the nut and threaded areas by brush or hand to prevent corrosion.

For hook blocks and other load handling devices not manufactured by Grove Worldwide; follow the manufacturer's inspection and testing recommendations to assure an adequate preventative maintenance program is established.



SECTION 5 HOIST AND COUNTERWEIGHT

SECTION CONTENTS

Theory of Operation 5- Maintenance 5- Warm-up Procedure 5- Removal 5- Installation 5-	1
Warm-up Procedure5-Removal5-Installation5-	1
Removal	1
Installation5-	1
	2
	3
Functional Check 5-	3
Servicing 5-	3
Fluid Level 5-	3
Usage and Inspection 5-	4
Preventative Maintenance 5-	4
Oil Sampling 5-	6
Brake Test Procedure 5-	6

Hoist to Boom Alignment	-7
Preparation	-7
Tools Required	-7
Procedure	-8
Piston Motor and Control Valve5	-9
Description5	-9
Maintenance	-9
Description	-9
Maintenance	-9
Hoist Drum Rotation Indicator System 5-1	12
Description	12
Maintenance	12
Counterweight Removal 5-1	14

DESCRIPTION

One hoist is available; the HP15C-17G (Figure 5-1). The hoist incorporates one dual displacement piston motor which drives a reduction unit within the hoist. The hoist utilizes planetary reduction with a multi-disc automatic brake that is spring applied and hydraulically released. An overrunning clutch allows the hoist to be raised without releasing the brake while at the same time holding the load until there is sufficient pressure to release the brake when hoisting down. The hoist motor controls both speed and torque of the hoist.

There are two modes in which the hoist operates. One mode is high speed. The pilot solenoid valve shifts the selector spool on the motor to provide minimum motor displacement. This gives high line speed and low torque.

The second mode is low speed. The pilot solenoid valve shifts the selector spool on the motor to provide maximum motor displacement. This gives low line speeds and high torque.

THEORY OF OPERATION

The hoist assembly is controlled by electric remote controllers located in the cab. When the control lever in the cab is moved from neutral, it causes the main hoist section of the directional control valve to shift the valve spool to route hydraulic flow to the hoist motor control valve. The hoist motor control valve is used to stop or slow the hoist when the load is trying to drive the hoist down too quickly. The motor control valve is piloted open by the hoist down pressure. If the load lowers faster than the flow of oil in the hoist down line, the pilot pressure decreases and the motor control valve partially closes to restrict the oil leaving the motor until a balance occurs. This results in the load lowering at a uniform speed based on the position of the hoist control lever.

During stopping, when the hoist down flow ceases, the pilot pressure holding the motor control valve open decays to zero and the motor control valve spool closes, thus blocking all flow of oil out of the hoist motor. This same pressure decay allows the spring applied pressure released hoist brake to apply when the load is fully stopped. This brake acts as a "parking brake" and holds the load in the stopped position.

MAINTENANCE

Warm-up Procedure

A warm-up procedure is recommended at each start-up and is essential at ambient temperatures below +40°F (4°C).

The prime mover should be run at its lowest recommended RPM with the hydraulic hoist control valve in neutral allowing sufficient time to warm up the system. The hoist should then be operated at low speeds, forward and reverse, several times to prime all lines with warm hydraulic oil, and to circulate gear lubricant through the planetary gear sets.



Failure to properly warm up the hoist, particularly under low ambient temperature conditions, may result in temporary brake slippage due to high back pressures attempting to release the brake, which could result in property damage, severe personal injury or death.

Removal

- 1. If the CE option is provided, remove the hoist covers.
- 2. Remove all cable from the hoist drum.

- **3.** Tag and disconnect the hydraulic lines to the hoist. Cap or plug all lines and openings.
- **4.** Tag and disconnect the electrical wires to the hoist rotation indicator.
- **5.** Tag and disconnect the electrical wires to the hoist hispeed solenoid valve.
- 6. Remove the hoist mounting nuts, capscrews, washers, and shims (if shims are used, mark their location).
- **NOTE:** The HP15C-17G hoist assembly, less the cable, weighs approximately 300 kg (661 pounds).
- **7.** Using an adequate lifting device, remove the hoist from the crane.



ltem	Description	
1	Auxiliary Hoist	
2	Main Hoist	
3	Turntable	
4	Capscrew	
5	Washer	
6	Hex Nut	
7	Shims	



Installation

- 1. Ensure the mounting plate and hoist pads are clean and free from debris and the hoist has not been damaged during handling.
- **2.** With the hoist supported by a suitable lifting device, position the hoist on the mount.
- **3.** Check the hoist to boom alignment according to the HOIST TO BOOM ALIGNMENT procedure in this section.
- 4. Place a level between the boom pivot shaft bushings.
- 5. Place a level across the top of the hoist drum and determine if the hoist is sitting in the same plane in relation to the level positioned between the boom pivot shaft bushings.
- 6. With the hoist level, check to determine if all the hoist mounting pads are in contact with the mounting plate by rocking the hoist.
- 7. Keeping the hoist level, use a feeler gauge to determine the amount of gap existing between the pads and the mounting plate.
- 8. Add shims to satisfy any existing gaps. Altering the shim thickness to fit a tapering gap is acceptable. Install the capscrews, washers and nuts and torque see *Fasteners and Torque Values*, page 1-12.
- 9. Remove the lifting device from the hoist.
- **10.** Connect the hydraulic lines to the hoist ensuring the proper lines are connected to the correct ports as marked during removal.
- **11.** Connect the electrical wires to the hoist hi speed solenoid valve as marked during removal.

- **12.** Connect the electrical wires to the hoist rotation indicator sensor box as tagged during removal.
- Install the cable, following the procedures outlined under INSTALLING CABLE ON THE HOIST, in the Operator's Manual.

Functional Check

- 1. Attach a test weight to the hook and raise and lower the load several times.
- 2. Check the hoist for smooth operation of the hoist motor and brake system.
- **3.** Ensure the hydraulic connections are secure and free from leaks.

Servicing

Remove the large plug from the center of the drum support. Fill with AGMA EO-4 (Grove Spec 6829100213) gear lubricant until level with the plug opening. Check every 1000 hours or 12 months.

Fluid Level

- **NOTE:** Failure to align the fill/drain plug (1) with the upper access hole (2) as shown in (Figure 5-2) prior to checking the oil level will result in an inaccurate reading.
- 1. Rotate the hoist drum until the fill/drain plug (1) appears in the upper access hole (2) shown in (Figure 5-2).


This will ensure that the planetary gears are in proper alignment and will permit an accurate reading of the oil level in the hoist.

- **2.** Allow the hoist to stand idle for 20 minutes before checking the oil.
- **3.** The oil level should be visible in the sight glass (3).

Table 5-1

Reading	Diagnosis	Action Required
Oil is not visible in the sight glass.	The hoist is under filled.	Fill the hoist with oil from the upper access hole until the oil level rises within the sight glass. Do not fill above 1/8 in (3 mm) from the top of the site glass.
		Refer to Hoist, page 9-23 for the correct type of oil.
Oil is visible in the sight glass and the level is no more than 1/8 in (3 mm) from the top of the sight glass.	The oil level is correct.	No action is required.
Oil level is more than 1/8 in (3 mm) from the top of the sight glass or the oil is escaping from the vent plug (4).	The hoist is overfilled.	Drain the hoist drum from the upper access hole until the oil level falls to within 1/8 in (3 mm) from the top of the sight glass.

Compare your reading with Table 5-1 and take the required action.



Usage and Inspection

Inspection procedures for hoists are divided into five general categories based upon their usage or duty cycle, which in turn determines appropriate intervals for inspections. The usage categories must be assigned by the crane user on a consistent crane-by-crane basis. The five crane/hoist usage categories are as follows:

Idled - The crane/hoist has not been used for three months.

Infrequent Usage - The crane/hoist is used less than ten hours per month based on a three month average

Moderate Usage - Crane/hoist used 10 - 50 hours per month based on a three month average.

Heavy Usage - Crane/hoist used 50 - 200 hours per month.

Severe Usage - Crane/hoist is operated more than 200

hours per month OR where 50% of the lifts exceed 75% of the rated capacity for the hoist.

The following chart lists the inspections that are required for each type of usage category.

USAGE CATEGORY	PRE-USE DAILY INSPECTION	QUARTERLY	SEMI-ANNUAL INSPECTION	ANNUAL INSPECTION
IDLED Not used for 3 months or longer	REQUIRED BEFORE PLACED IN SERVICE	REQUIRED BEFORE PLACED IN SERVICE	REQUIRED BEFORE PLACED IN SERVICE	
INFREQUENT USAGE less than ten hours per month	REQUIRED	REQUIRED	REQUIRED	REQUIRED
MODERATE USAGE 10-50 hours per month	REQUIRED	REQUIRED	REQUIRED	REQUIRED
HEAVY USAGE 50-200 hours per month	REQUIRED	REQUIRED	REQUIRED QUARTERLY (3 months)	REQUIRED SEMI-ANNUALLY (6 months)
SEVERE USAGE 200+ hours per month or 50% of lifts exceed 75% rated capacity	REQUIRED	REQUIRED	REQUIRED QUARTERLY (3 months)	REQUIRED SEMI-ANNUALLY (6 months)

Preventative Maintenance

It is extremely important to be aware of the possibility that deterioration of internal critical components within the hoist reduction unit can occur. Hoist reduction units incorporate planetary gears, multi-disc brake assemblies, and sprag clutches which do not have an infinite life span. Although these components have been designed to achieve long service life, reliability can be substantially reduced by a variety of influencing factors such as:

- High cycle operation.
- Operating in high ambient temperatures.



- High external contaminations, such as dusty or sandy conditions.
- Level of maintenance.

The following should be carried out following instructions in *Lubrication*, page 9-1 and/or manufacturers instructions.

1. Pre-Use or Daily Inspection.

Must include but is not limited to the following inspections that will be performed prior to placing the crane into service and then as necessary during extended operation. This inspection must be performed by a qualified crane operator or qualified crane technician.

- Check for external oil leaks and repair as necessary. This is extremely important due to the accelerated wear that will result from insufficient lubricating oil in the hoist. Hoists with a sight glass; check oil level daily. Hoists without a sight glass; check oil level monthly if no external oil leaks are detected. Lubricant level must be maintained between the minimum and maximum levels; midway up sight glass or at bottom of level plug port as equipped. Use ONLY the recommended type of lubricant. Refer to Lubrication, page 9-1.
- Check hydraulic fittings and hoses for chaffing, deterioration or corrosion and repair as necessary.
- Visually inspect for corroded, loose or missing bolts, pins or other fasteners and replace or tighten as necessary.
- Visually inspect rotation indicator transmitters, anti-twoblocking switches and other safety equipment and repair as necessary.
- 2. Quarterly Inspection (every three months).

Must include but is not limited to the following inspections that must be performed by a qualified crane operator or qualified crane technician.

- Perform the pre-use inspection.
- Inspect for corrosion of fasteners, hoist base, drum, etc. and repair/replace as required to maintain the structural integrity of the hoist.
- Check the hoist oil level. Inspect for any oil leaks from the hoist gearbox.
- 3. Every 250 hours or 3 months.
- If applicable, lubricate the cable guide roller and cable guard roller bearings.
- 4. Semi-Annual Inspections (every six months).

Must include but is not limited to the following inspections that must be performed by a qualified crane operator or qualified crane technician.

- Perform the Pre-Use and Quarterly inspections.
- Take a sample of the lubricant from the hoist gear cavity as described in *Gear Oil Sampling and Analysis*, page 5-6 and analyze it for wear metals content, correct viscosity, lubricant deterioration, moisture and other contaminants. If the oil sample contains a high amount of metallic particles, the hoist must be taken out of service to undergo a tear down inspection.
- **NOTE:** Oil analysis alone cannot detect nor warn against a fatigue failure.
- 5. Annual Inspection.

This inspection must be carried out by a qualified crane technician. The annual inspection MUST include, but not be limited, to the following:

- Perform the Pre-Use/Daily Inspection, Quarterly inspection and Semi-Annual Inspection.
- Change the lubricating oil in the hoist gear cavity after an oil sample has been taken as described in *Gear Oil Sampling and Analysis*, page 5-6. Refill the hoist to the proper level with recommended lubricant. Refer to *Lubrication*, page 9-1.



Failure to use the proper type and viscosity of planetary gear oil may contribute to intermittent brake clutch slippage which could result in property damage, severe personal injury or death. Some gear lubricants contain large amounts of EP (extreme pressure) and anti-friction additives which may contribute to brake clutch slippage or damage to brake friction discs or seals. Oil viscosity with regard to ambient temperature is also critical to reliable brake clutch operation. Our tests indicate that excessively heavy or thick gear oil may contribute to intermittent brake clutch slippage. Make certain that the gear oil viscosity used in your hoist is correct for your prevailing ambient temperature.

• Check for correct function of the hoist brake by conducting a high line pull load test, ensuring the brake holds without creeping and that the hoist control is correct. The function of the hoist brake should be checked more often if abnormal operating conditions or characteristics exist.

6. Every 10,000 hours or every ten years, it is recommended that the hoist assembly be disassembled and that all major components be examined for damage and/or wear, i.e. gears, spline couplings, shafts, etc. New components must be installed if any are found to be worn or if there is evidence of heat or other damage. The hoist should be reassembled using all new seals, bearings, fasteners, washers, brake discs, brake stators, sprag clutch, and springs. A comprehensive hoist line pull and load holding test must be conducted following the repair work.

Oil Sampling

Oil Change

The hoist gear oil must be changed after the first 100 operating hours then on an annual basis, at a minimum thereafter. In severe duty applications, the gear oil should be changed every six months. Use the recommended lubricants. Refer to *Lubrication*, page 9-1.

Gear Oil Sampling and Analysis

Proper gear oil sampling and analysis is a vital part of a comprehensive preventive maintenance program. Information obtained from the oil analysis allows the maintenance technician to substitute preventive maintenance for more costly unscheduled down time or a far more dangerous failure. Early detection of accelerated component wear allows the scheduling of corrective maintenance.



Hot oil may cause personal injury and/or burns to unprotected skin. Make certain the oil has cooled to a safe temperature (typically less than 110°F or 43°C) before taking an oil sample, changing oil or servicing the hoist.

Prepare the hoist by cleaning the drain plug area and drain extension tube in order to obtain an uncontaminated sample. Operate the hoist in both directions for one or two minutes to thoroughly mix the gear oil then take the sample from the midstream flow of the oil to obtain an accurate representation of the oil condition. After taking the oil sample continue with the oil change or refill the hoist gear cavity to the proper level with recommended lubricant.

General Guidelines for Iron Contaminant Level

100-500 ppm

Normal

500-800 ppm

Caution - Abnormal Sample. Change oil and retake sample after 50 hours of operation. If second sample is above 500 ppm, remove hoist from service and perform tear-down inspection to determine source of contamination.

800+ ppm

Unacceptable. Remove hoist from service and perform teardown inspection to determine source of contamination.

Iron contaminant levels will be on the high side of "Normal' during initial break-in.

Equally important as the level of contamination is the change in level of contamination. An effective oil analysis program should provide the technician with a view of the progression of wear or a trend. If a sample shows a sudden rise in contaminant level action should be taken to determine what has changed.

NOTE: Oil analysis alone cannot detect nor warn against a fatigue failure.

Brake Test Procedure

These planetary hoists have a spring applied, hydraulically released, multiple disc brake inside the hoist housing. This brake holds a suspended load when the directional control valve is in neutral, or when hydraulic power is lost. An overrunning brake clutch assembly permits the power train and drum to rotate in the direction to lift a load, while the brake remains fully applied. A load cannot be lowered, however, without applying hydraulic pressure to the release port and releasing the brake.

(Test to be performed with no load on the hoist)

Remove and cap or plug the brake release line from fitting in the hoist brake release port.

With the hydraulic power unit running, move the directional control valve handle slowly to the full open, lowering position.

Increase the engine speed, if necessary, to bring system pressure up to the relief valve setting. The hoist drum should remain stationary.

If the hoist drum rotates, the hoist should be disassembled and the brake components should be examined for wear. In addition, the brake springs should be measured for the correct free length in those hoist using helical compression springs.



RT530E-2 SERVICE MANUAL

Replace any parts showing excessive wear and any spring whose length is shorter than the minimum shown in the applicable hoist Service Manual.

Reassemble the brake and hoist and repeat the above steps.

When testing is complete, reattach the brake release line to the brake release port.

The following should be carried out along with the instructions in *Lubrication*, page 9-1.

- Annually, have the hoist oil condition tested. This will give advance warning of developing wear patterns. Any signs of abnormal contamination should be treated seriously and the internal components of the hoist should be examined carefully, at the earliest opportunity.
- 2. Annually, check for correct function of the hoist brake by conducting a high line pull load test, ensuring the brake holds without creeping and that the hoist control is correct. The function of the hoist brake should be checked more often if abnormal operating conditions or characteristics exist.
- 3. Every 10,000 hours or every ten years as part of a preventative maintenance program, we recommend that hoist assemblies be opened in a properly controlled workshop environment. The major internal components (gears, spline couplings, shafts, etc.) should be examined for damage and/or wear. New components should be installed if any are found to be worn or if there is evidence of heat or other damage. Reassemble the hoist using all new seals, bearings, fasteners, washers, brake discs, brake stators, sprag clutch, and springs.

Failure to implement and adhere to a hoist inspection and maintenance program may result in damage to the crane, other property damage, and/or serious injury or death to persons working on or near the crane.

A comprehensive hoist line pull and load holding test must be carried out following any such repair work.

Manitowoc Crane Care offers prepackaged kits that include all the seals, bearings, fasteners, washers, brake disks, brake stators, sprag clutch, and springs that are required for reassembling the hoist after inspection. During the inspection, if components not included in the kit are found to be worn or damaged, contact your Manitowoc Cranes distributor or Manitowoc Crane Care to order replacement.

HOIST TO BOOM ALIGNMENT


Preparation

Boom alignment must be completed before attempting hoist alignment. If the hoist is not properly aligned, the cable can be damaged or fine control could be affected.

The crane must be set on outriggers fully extended and the crane must be leveled. The boom must be over the rear on TM/TMS models and over the front on RT/Industrial models.

Tools Required

- two foot square
- mason cord
- chalk
- protractor



Procedure

The hoist mounting location will determine the alignment procedure used. Shift one side of the hoist back or forward to align the hoist with the boom sheave for cranes that have the hoist mounted either directly to the boom or on a mount attached to the boom. It may be necessary to shim under one side of the hoist to make it level.

The hoist must be checked in two directions, one at 0 degree and the other is above 45 degrees boom angle on any crane that the hoist is not mounted directly to the boom, stationary mounted.

Check the hoist at 0 degree to see if the hoist is aligned to the boom nose sheave. The main hoist is aligned to the right hand sheave and the auxiliary hoist is aligned to the center sheave (Figure 5-4)

- **NOTE:** The hoist cable will have gaps in it during spooling if the alignment is not correct.
- **NOTE:** The hoist is not level if the cable is piling up on one side of the drum.
- The boom must be extended one half of full extension on all hoist alignments. This length is used because when the main hoist cable is positioned on the top right hand boom nose sheave, the cable must leave the center of

the drum at a 90 degree angle. The boom has the ability to extend, retract, and change the angle of departure from the drum. Extend the boom half way to provide a center point of adjustment to check the fleet angle of the cable.

- 2. All the cable must be removed from the hoist drum to check the fleet angle. Using mason cord or cat gut fishing line you will be able to pull the line tight to make an accurate measurement of the fleet angle. Find the centerline of the hoist drum by using a square and drawing a line horizontal on the drum. Put a line vertical to the horizontal line in the absolute center of the drum by using a tape measure. With the boom at 0 degree, tie the line tight to the boom nose and have it in the center of the right hand boom nose sheave.
- **NOTE:** If this special equipment is not available, sufficient accuracy in locating a centerline may be obtained by using a steel square against the machine's inner surfaces of both flanges. It is advisable to avoid using any cast surfaces in this procedure unless a check from both flanges indicates that the resultant line is straight.
- **3.** Tie the line around the hoist drum so that the line is very tight and the line is crossing the absolute center of the drum at the centerline mark you put on the drum.



- 4. Using a protractor, lay it on the vertical line on the hoist drum so the string line is in the center of the protractor. The string line will be at the 90 degree mark on the protractor if the hoist is straight with the boom nose sheave. If it is not at the 90 degree mark, the hoist mounting bolts will have to be loosened and the hoist moved so it is.
- **NOTE:** This test is for cable leaving gaps while spooling.

CAUTION

Do not alter holes or stop blocks on the crane mounting plate, as very small adjustments result in large angular changes. Extreme care should be taken to avoid overcorrection.

- 5. Elevate the boom above 45 degrees boom angle to check if the hoist is level. Reposition the hoist drum and tighten the cord so you can have the cord in the center of the protractor at the 90 degree mark. If the cord is not at the 90 degree mark, the hoist will have to be shimmed until the cord is at the 90 degree mark.
- **NOTE:** This test is for cable piling up on one side of the hoist drum.

PISTON MOTOR AND CONTROL VALVE

Description

The piston motor is a bent axis, bidirectional, variable displacement heavy-duty motor. The motor is bolted to the hoist and is geared directly to the hoist planetary.

The motor control valve is bolted to the motor.

Maintenance

Removal

- 1. Thoroughly clean the external surfaces of the drum and motor with steam or clean solvent and blow dry.
- 2. Tag and disconnect the hydraulic lines connected to the hoist motor and the motor control valve.
- **3.** Remove the capscrews and lockwashers that secures the motor and motor control valve to the hoist.
- **NOTE:** The HP15C-17G hoist motor weighs approximately 28 kg (62 lb).
- 4. Place the motor and motor control valve in a clean, dry suitable work area.

Installation

NOTE: Care must be taken to assure the primary thrust plate remains properly located in its counterbore when the motor is re-installed. If the winch is

operated with the primary thrust plate wedged between the primary gears and the planet carrier, or with a thrust washer out of position severe damage to internal winch components could result.

- 1. Install a new O-ring on the motor pilot then lubricate with petroleum jelly or gear oil. Engage the motor shaft with the brake clutch inner race and lower into place.
- 2. Apply Loctite No. 243 to the mounting bolts, and install the bolts and lockwashers. Torque the bolts to 102 Nm (75 lb-ft).
- 3. Connect the hydraulic lines as tagged during removal.
- **4.** Fill the drum with oil. Refer to Section 9 LUBRICATION in this manual.
- 5. Idler Drum and Cable Follower

Description

The main and auxiliary hoists are equipped with an idler drum on the forward side of the hoist. The main hoist idler drum is used to keep the hoist cable from coming in contact with the boom. When the crane is also equipped with an auxiliary hoist, the idler drum on the auxiliary hoist is used to keep the hoist cable from coming in contact with the main hoist. The cable follower is mounted on the rear side of it's respective hoist. The cable follower applies a downward spring pressure against the cable onto the hoist drum, to ensure that the cable will be uniformly wound onto the hoist drum, and also prevent cable from jumping under abnormal line conditions.

Maintenance

Idler Drum

Removal and Disassembly

- 1. Remove the bolt, washer, and lockwasher from the right side of the idler roller (Figure 5-5).
- **2.** Support the idler roller and withdraw the shaft from the left side. Take care not to lose the dowel pin on the end.
- 3. Remove the roller from between the side plates.

Cleaning and Inspection

- 1. Clean all rust and dirt from the shaft.
- 2. Inspect the shaft and roller for cracks, scoring, or grooving. Replace if necessary.

Assembly and Installation

- 1. Position the roller between the side plates
- **2.** Install the shaft through the left side plate and the roller. Ensure the flat on the shaft end aligns with the stop welded on the side plate, align the dowel pin.

HOIST AND COUNTERWEIGHT

3. Secure the shaft to the right side plate with a bolt, washer and lockwasher. Apply Loctite 243 to the bolt threads.

Cable Follower

Removal and Disassembly

- Loosen the adjusting nuts and remove the tension spring and adjusting rod from both sides of the hoist (Figure 5-5).
- 2. Remove the tack welds from the bolt heads securing the arm to the cable follower roller.
- **3.** Support the cable follower roller and remove the bolts and washers securing the arms to the angles on each end of the roller. Remove the cable follower roller.
- 4. Disassemble the cable follower roller as follows.
 - **a.** Remove the two bolts and washers securing the angle to the right side of the shaft.
 - **b.** Remove the shims and roller from the shaft.
 - **c.** If necessary, remove the bearing and bearing housing from both ends of the roller.
- 5. Remove the bolt and locknut securing the arm to the spring attaching lever on each side of the hoist. Remove arms and levers from the side plates.
- **NOTE:** Be sure to mark each arm and lever as to what side (left or right) they were removed from. This will be helpful during installation.

Cleaning and Inspection


- 1. Clean all grease from the shaft, bearing, and roller.
- 2. Check the shaft, roller, and bearings for cracks, scoring, or grooving. Replace if necessary.

3. Check the spring tension. If the springs will not provide sufficient tension when adjusted, replace them.

Assembly and Installation

- 1. Install the left arm through the bushing on the left side plate. Install left spring attaching lever on the arm and secure with a bolt and locknut. Apply Loctite 243 to the bolt threads.
- 2. Repeat step 2 on the right side.
- **3.** Assemble the cable follower roller as follows.
 - **a.** Apply high strength retaining compound Loctite 680 to the bearing housings and the bearings. Install them in both ends of the roller.
 - **b.** Install the shaft into the roller with a least one shim on each end.
 - **c.** Position the angle on the right side of the shaft and secure with two bolts and washers. Apply Loctite 243 to the bolt threads.
- 4. Position the cable follower roller on the arms and secure with four bolts and washers. Center the roller between the hoist drum flanges and tighten the bolts. Tack weld the bolt heads.
- 5. Attach one end of the tension springs to the levers on each side. Install the adjusting rod through the lug on each side plate and connect to the other end of the spring. Install the adjusting nuts on each rod and tighten enough to take the slack out of the springs.
- **6.** Using a grease gun, apply grease to the fittings on each side plate bushing.
- 7. Adjust the roller as follows.





- a. With one layer of cable on the hoist drum, adjust the bolts on the front of each side plate (that push against each arm) so the roller applies pressure on the layer of cable, and does not interfere with filler/ riser protrusions on the hoist drum flanges. Tighten jam nuts to secure setting.
- **b.** With a full drum of cable, the adjusting spring length from eye to eye should not exceed 25.7 cm (10.12 in). Adjust rods as necessary and tighten jam nuts to secure this setting.

Complete Assembly

Removal

- 1. Remove all tension from the springs on each side by loosening the nuts and jam nuts.
- 2. Support the weight of the assembly and remove the two bolts and washers securing each side plate to the hoist. Remove the idler drum and cable follower assembly from the hoist.
- **3.** If necessary to completely disassemble or remove any part of the assembly, refer to the applicable paragraphs in this Sub-section.

Installation

- 1. Position the idler drum and cable roller assembly on the hoist and secure each side plate to the hoist with two bolts and washers.
- Adjust the tension on the cable follower. Refer to instructions in paragraph titled CABLE FOLLOWER -Assembly and Installation in this Sub-Section.

HOIST DRUM ROTATION INDICATOR SYSTEM

Description

The hoist drum rotation indicator system (Figure 5-6) is an electrically operated system that provides the operator with a touch indication of drum rotation so the operator will know if

and at what speed the hoist drum is rotating, even under the most distracting conditions.

The rotation indicator system consists of the rotation indicator sensor and thumb thumper solenoid. The rotation sensor is located on the hoist. The pulsing thumb thumper solenoid is located in the applicable hoist control lever handle. Actuation of the thumb thumper is controlled by the Can-Bus system from input supplied by the rotation indicator sensor.

Maintenance

General



Disconnect the batteries before performing any maintenance on this system. Serious burns may result from accidental shorting or grounding of live circuits.

Proper circuit operation can be checked for each individual electrical component. If a malfunction occurs within the system, repairs should be limited to finding and replacing the faulty component(s). To determine which component is at fault, refer to the troubleshooting section of your Can-Bus CD.

Rotation Sensor in Hydraulic Motor

The rotation sensor is screwed into the hoist housing and senses the rotation of the primary drive end driven gear. When installing the sensor, ensure it contacts the top land of a gear tooth and not between teeth (Figure 5-6). Screw the sensor in until contact is made, then back out 1/2 turn and tighten lock nut.


Thumb Thumper Solenoid

The thumb thumper solenoid provides feedback proportional to the hoist line speed by pulsing the rubber button on top of the hoist controller. The thumb thumper will cease operation at high line speeds to prevent damage to the solenoid.



HOIST AND COUNTERWEIGHT

RT530E-2 SERVICE MANUAL



ltem	Description		
1	Thumb Thumper		
2	Controller		
3	Rotation Sensor Connection		
4	Two Speed Solenoid Connection		

5

COUNTERWEIGHTREMOVAL

Fixed Counterweight Description

The counterweight is pinned to the rear of the turntable and weighs 3810 kg (8400 pounds). For cranes without an auxiliary hoist, an additional 350.6 kg (773 pounds) counterweight is bolted to the hoist mounting area in lieu of the auxiliary hoist.

Fixed Counterweight Removal

Death or serious injury could result from being crushed by a falling counterweight.

Ensure the retainer pin is properly installed to secure the counterweight mounting pin.

- **NOTE:** Use of a forklift to remove/install the fixed counterweight is not recommended.
- **NOTE:** Refer to (Figure 5-7) for counterweight removal.
- 1. Fully extend and set the outriggers.
- **NOTE:** Turntable lock pin can only be engaged with boom over front.
- 2. Rotate the superstructure so the counterweight is over the front of the carrier to gain additional clearance. Engaging the pin type turntable lock will aid alignment.
- **NOTE:** The counterweight weighs approximately 3810 kg (8400 pounds).
- 3. Lower and fully retract the boom
- 4. Shut down crane.
- 5. Attach an adequate lifting device to the counterweight.
- **6.** Ensure the four counterweight leveling capscrews are set for maximum clearance with the turntable.

- **7.** Slowly raise counterweight until pin assembly can be removed by pushing and turning the pin.
- 8. Remove pin assembly from opposite side.
- **9.** Lower counterweight until attaching lugs are clear of the turntable.
- **10.** Back counterweight away from turntable until it is clear of crane.
- **11.** Replace pin assembly in turntable counterweight mounting lugs.
- **12.** Move counterweight far enough from crane to allow the turntable/superstructure to clear during repositioning.
- **13.** Rotate superstructure to the normal travel position.

Fixed Counterweight Installation


- 1. Fully extend and set the outriggers.
- 2. Rotate the superstructure so the counterweight will be over the front of the carrier to gain additional clearance.
- 3. Shut down crane.

CAUTION

When lifting/handling the counterweight, keep the chains/ straps vertical to minimize side pull on the lifting lugs.

- **NOTE:** The counterweight weighs approximately 3810 kg (8400 pounds).
- **NOTE:** Use of a forklift to remove/install the fixed counterweight is not recommended.
- 4. Attach an adequate lifting device to the counterweight and lift the counterweight into place on the superstructure, aligning the mounting holes on the counterweight to the holes in the superstructure.
- 5. Install the counterweight mounting pins and secure them in place with hitch pin retainers.
- 6. Remove the lifting device from the counterweight.
- 7. Using the four counterweight leveling bolts, level the counterweight and eliminate any relative movement between the counterweight and turntable. Maximum width of counterweight shall not exceed 6.0 mm (0.25 in) out of level with the turntable bearing when measured from either counterweight outer edge.





Item	Description
1	Counterweight
2	Pin Assembly
3	Capscrew
4	Hex Nut
5	Jam Nut
6	Grill
7	Retaining Nut
8	Flat Washer
9	Lock Washer
10	Capscrew
11	Lock Pin

THIS PAGE BLANK



~ 7

SECTION 6 SWING SYSTEM

SECTION CONTENTS

Introduction	6-1
Description	6-1
Theory of Operation	6-1
Maintenance	6-3
Troubleshooting	6-3
Swing Motor	6-6
Description	6-6
Maintenance	6-6
Swing Gearbox And Brake	6-7

6-7
6-9
6-9
6-9
-14
-14
-16
-18

INTRODUCTION

Description

The purpose of the swing system is to allow the crane superstructure to rotate atop the carrier frame. The superstructure swing system provides full 360 degree rotation in both directions and is equipped with free swing capabilities.

Swing is activated using the Swing Enable Switch. When the swing lever is actuated, hydraulic pressure is routed to the swing motor to drive the gearbox in the appropriate direction. As the gearbox rotates, the pinion gear meshes with the teeth on the swing bearing and rotates the superstructure. Swing speed is regulated by the Control Lever (Joystick). The maximum rotation speed is 2.0 - 2.5 rpm with no load. Positioning the lever to the left or right actuates a control valve through electric signal to provide 360 degree continuous rotation in the desired direction. Braking is accomplished by moving the control lever to the center and applying Swing Brake Pedal or engaging the Swing Brake Switch.

The swing system consists of an electric remote controller, a directional control valve, the swing drive, the swing brake assembly, the brake pedal and power brake valve, and a swing brake release solenoid valve.

The crane is equipped with a pin type turntable lock as standard and an optional 360 degree positive swing lock. The 360 degree positive swing lock meshes with the swing gear teeth at any point of rotation. The pin type turntable lock will only lock the turntable in a straight ahead position over the front of machine. Both swing locks are operated from the cab.


Theory of Operation

Swing Drive

Decerietien

The hydraulic power for the swing drive (Figure 6-1) is supplied by the engine driven hydraulic pump. Oil flows from the pump to the hydraulic Port 5 swivel. Flow from the swivel is routed to the service brake dual accumulator charge valve. Bypass flow from the dual accumulator charge valve is routed to the front steering flow divider valve in the swing directional control valve. Bypass flow from the flow divider valve is used to supply the swing directional control valve.

When the electronic control is positioned to select right or left swing, the flow through the control valve is directed to the swing motor. If the SWING BRAKE selector switch is in the OFF position, the superstructure will rotate in the desired direction. Shifting the control to neutral and depressing the brake pedal will stop the swing.



ltem	Description	ltem	Description
1	Plug	8	Dipstick
2	Plug	9	Breather
3	Plug	10	Plug
4	Elbow	11	Motor
5	Pipe	12	Gearbox and Brake
6	Breather	13	Pinion
7	Plug		



Maintenance

Troubleshooting

	Symptom Probable Cause		Solution
1. Boom swing		a. Damaged relief valve.	a. Replace relief valve.
	operation erratic in either direction.	 Swing brake dragging (not releasing properly). 	g b. Readjust and/or replace necessary parts.
	-	c. Low engine rpm.	c. Increase engine rpm to obtain smooth swing operation.
		d. Low hydraulic oil.	d. Replenish hydraulic oil to proper level.
	-	e. Improper movement of control to neutral.	e. Feather controls to neutral to maintain smooth stopping action.
	-	f. Insufficient lubricant on swing bearing	f. Lubricate bearing properly. Refer to Section 9 - LUBRICATION.
		g. Crane not level.	g. Level crane using outriggers.
		h. Damaged swing motor.	h. Repair or replace swing motor.
	-	i. Excessive overload.	i. Reduce load. Refer to load capacity chart.
	-	 j. Restricted or partly clogged hydraul hose or fittings. 	c j. Replace hose or fittings.
	-	k. Pump cavitation in swing section.	k. Tighten suction hose or replace any damaged fitting. Check hydraulic tank level.
		I. Improperly torqued turntable bolts.	I. Torque turntable bolts evenly.
	-	 Excessive preload on upper and lower pinion shaft bearing. 	r m. Adjust as necessary.
		n. Improperly torqued swing mote attachment bolts.	r n. Torque swing motor attachment bolts.
		o. Malfunction of the swing box.	o. Remove swing box and make necessary repairs.
		p. Worn or damaged pump.	p. Repair or replace damaged pump.
	0	 q. Damaged swing directional contr valve. 	ol q. Repair or replace swing directional control valve.
		r. Damaged swing pinion.	r. Replace pinion.
		s. Damaged turntable bearing.	s. Replace turntable bearing.
2.	Boom swing	a. Crane not level.	a. Level crane using outriggers.
	one direction only.	 b. Turntable bearing binding due to continuous limited swing. (Example concrete pourer.) 	
		c. Restricted hose or fitting.	c. Replace hose or fitting.
		 d. Damaged swing directional contr valve. 	d. Replace swing directional control valve.
		e. Damaged swing pinion.	e. Replace pinion.
		f. Damaged turntable bearing.	f. Replace turntable bearing.

Symptom	Probable Cause	Solution	
3. Boom will not swing in either direction.	a. Damaged relief valve.	 Remove, clean, and repair or replace relief valve. 	
	b. Damaged swing motor.	b. Repair or replace swing motor.	
	c. Swing brake not releasing properly.	c. Repair as necessary.	
	d. Damaged hydraulic remote control valve.	 d. Replace hydraulic remote control valve. 	
	e. Internal damage to swing box.	e. Remove swing box and repair.	
	f. Worn or damaged hydraulic pump.	f. Replace pump section.	
	g. Damaged swing directional control valve.	g. Replace swing directional control valve.	
	h. Damaged swing pinion.	h. Replace pinion.	
	i. Damaged turntable bearing.	i. Replace turntable bearing.	
	j. Excessive overload.	j. Reduce load. Refer to load capacity chart.	
4. Swing operation	a. Damaged relief valve.	a. Adjust, repair or replace valve.	
slow in either direction.	b. Improperly adjusted swing brake.	b. Readjust.	
	c. Damaged hydraulic remote control valve.	 c. Replace hydraulic remote control valve. 	
	d. Improperly lubricated swing bearing.	d. Lubricate bearing per recommendations.	
	e. Improper size hose and/or fittings installed.	e. Refer to the Parts Manual.	
	f. Clogged or restricted hydraulic hoses or fittings.	f. Clean or replace damaged parts.	
	g. Worn or damaged output shaft bearings	g. Replace bearings.	
	h. Worn or damaged swing motor.	h. Repair or replace motor.	
	i. Worn or damaged hydraulic pump.	i. Repair or replace pump.	
	j. Crane not level.	j. Level crane.	
	k. Damaged swing directional control valve.	 k. Replace swing directional control valve. 	
5. Swing operation	a. Crane not level.	a. Level crane.	
slow in one direction only.	 b. Damaged hydraulic remote control valve. 	 b. Replace hydraulic remote control valve. 	
	c. Damaged swing directional control valve.	c. Replace the swing directional control valve.	
	d. Clogged or restricted hose.	d. Replace hose or fitting.	
	e. Improperly torqued turntable bearing.	e. Torque turntable bearing.	



	Symptom	Probable Cause	Solution
6.	Swing brake	a. Improper brake adjustment.	a. Adjust brake.
	operation erratic.	b. Air in swing brake system.	b. Bleed brake system.
		c. Brake pedal not fully retracted.	c. Check brake pedal return spring; repair or replace spring.
		d. Dirty or glazed brake disc.	d. Clean or replace disc.
	·	 e. Malfunction of the glide swing powe brake valve. 	e. Repair or replace glide swing power brake valve.
		f. Kinked or bent lines and/or hoses and fittings.	f. Straighten or replace as required.
7.	Swing brake system will not operate.	a. Damaged swing brake release valve.	a. Replace release valve.
		 b. Damaged glide swing power brake valve. 	b. Repair or replace glide swing power brake valve.
		 c. Internal damage to the swing brake assembly. 	c. Repair or replace affected parts.
		 d. Loose or restricted brake lines of fittings. 	d. Tighten or replace lines and fittings.
8.	Swing brake pedal is spongy.	 a. Damaged glide swing power brake valve. 	 a. Repair or replace the glide swing power brake valve.
		 b. Loose or restricted brake lines of fittings. 	 b. Tighten or replace brake lines and fittings.
9.	Swing brake drags.	 a. Damaged glide swing power brake valve. 	 a. Repair or replace the glide swing power brake valve.
		b. Damaged swing brake release valve.	b. Replace release valve.
		c. Internal damage to the swing brake assembly.	c. Repair or replace affected parts.
		d. Loose or restricted brake lines of fittings.	d. Tighten or replace brake lines and fittings.
10.	Boom swings slowly.	a. Insufficient hydraulic volume.	 a. Check delivery of hydraulic pump. Ensure sufficient fluid is available to pump. Check pump drive speed.
		b. Damaged relief valve.	b. Adjust, repair, or replace valve.
		c. Damaged swing motor.	c. Repair or replace motor.
11.	Swing motor continues to operate when swing control is in neutral.	 a. Hydraulic remote control valve sticking or valve otherwise damaged. 	a. Repair or replace valve.
		 b. Control valve sticking or valve otherwise damaged. 	b. Repair or replace valve.
12.	Swing motor turning in wrong direction.	a. Improper port connections.	a. Reverse port connection.
13.	Swing motor noisy.	a. Air in system.	 a. Refer to Section 2 - HYDRAULIC SYSTEM, for removal of air from the system.
		b. Motor binding.	b. Repair or replace motor.

SWING MOTOR

Description

The swing motor is mounted on the swing brake housing and drives the swing gearbox through the brake assembly. The swing motor is a hydraulic gerotor type with low speed and high torque characteristics. It has only three moving parts, the commutator valve, the drive, and the gerotor star. The motor has two ports for connection to the hydraulic system.

Maintenance

Removal

- 1. Ensure the swing brake and swing lock are engaged.
- 2. Clean the port area around the motor. Tag and disconnect the hydraulic hoses from the motor assembly. Cap or plug all openings.

CAUTION

Oil can be hot and cause burns.

3. Remove the drain plug, loosen the filler and level plugs, and drain the oil. After oil is drained, replace the drain plug and any other plugs that may have been removed.

CAUTION

Pull straight up on the motor assembly to avoid damaging the splined shaft.

 Remove the two screws securing the motor and lift the swing motor free of the flange. Remove and discard the O-ring from the groove in the swing brake.

Installation

CAUTION

Use care when engaging the swing motor drive gear, do not force the shaft to engage.

- 1. Install a new O-ring in the groove of the swing brake. Position the swing motor on the swing brake, engaging the shaft with the brake input shaft.
- Apply Loctite 243 to the screw threads. Install the screws and secure the motor to the brake housing. Torque the screws see Fasteners and Torque Values (pg 1-12).
- **3.** Connect the hydraulic lines to the swing motor as tagged during removal.

Test

- **1.** Test swing of superstructure in each direction. Stop and start swing several times.
- 2. Inspect for hydraulic leaks and repair as necessary.



SWING GEARBOX AND BRAKE

Description

The swing gearbox and brake, used in conjunction with the swing motor, rotates and stops the superstructure. A pedal on the cab floor is used to activate the swing brake. The swing gearboxes are bolted to the superstructure base plate, and its pinion gear meshes with the ring gear of the turntable bearing to rotate the turntable.

The swing gearbox utilizes double reduction planetary gearing. The multi-disc swing brake assembly is an integral part of the swing gearbox and is located between the swing motor and the swing gearbox. The brake mechanism is a disc pack that is hydraulically released and spring applied.

Maintenance

NOTE: The swing brake can be removed and disassembled independently of the swing gearbox.

Swing Brake

Removal

- 1. Engage the turntable lock pin.
- Tag and disconnect the hydraulic lines connected to the swing motor and the brake. Cap and/or plug all openings.
- **3.** Remove the swing motor from the swing brake according to the procedures found in this Section under SWING MOTOR REMOVAL.

CAUTION

Use care when removing the capscrews securing the brake, as there is tension on the bolts due to internal brake springs.

- 4. Unscrew the screws securing the brake to the gearbox. Lift the brake using the brake flange, then remove the Oring.
- 5. Cover the opening of the swing gearbox to ensure no dirt, dust, etc., gets into the gearbox.

Installation

- 1. Install a new o-ring onto the brake housing.
- Apply Loctite 243 to the screws. Install brake onto gearbox and secure with the screws. Torque the screws 50 to 60 Nm (36.8 to 44.2 pounds-foot).
- Install the swing motor into the swing brake according to the procedures found in this Section under SWING MOTOR - INSTALLATION.
- 4. Connect the hydraulic lines to the motor and brake.

5. Bleed all air from the brake assembly.

Gearbox

Removal

- **1.** Engage the turntable lock pin.
- **2.** Tag and disconnect the hydraulic lines from the swing motor and swing brake. Cap and/or plug all openings
- **3.** Unscrew the three screws securing the pinion gear cover. Remove the cover.
- 4. Remove the gear from the shaft.
- **NOTE:** The complete gearbox assembly with motor weighs approximately 126 kg (277.7 pounds).
- 5. Attach a suitable lifting device to the swing gearbox. Remove the capscrews, flatwashers and bushings securing the gearbox to the mounting plate.
- **NOTE:** Take note of the swing motor port orientation to ensure proper installation.
- 6. Remove the swing gearbox.
- 7. If necessary, remove the swing motor according to the procedures found in this Section under SWING MOTOR REMOVAL.
- 8. If necessary, remove the swing brake according to the procedures found in this Section under SWING BRAKE REMOVAL.
- **9.** Cover the opening of the swing gearbox to ensure no dirt, dust, etc., gets into the gearbox.

Installation

- If removed, install the swing brake according to the procedures found in this Section under SWING BRAKE INSTALLATION.
- 2. If removed, install the swing motor according to the procedures found in this Section under SWING MOTOR INSTALLATION.
- **3.** Attach a suitable lifting device to the swing gearbox and lift and position the swing gearbox in place on the mounting plate.
- 4. Install the capscrews, flatwashers and bushings. Torque the capscrews 85 to 93 Nm (63 to 69 lb-ft).
- 5. Apply Loctite 243 to screws. Install the pinion gear on the output shaft. Install the cover and secure with three screws. Torque screws 50 Nm (36.8 lb-ft).
- 6. Connect the hydraulic lines to the swing brake.
- 7. Connect the hydraulic lines to the swing motor.
- 8. Service the gearbox as indicated under SERVICING.

Servicing

As with all highly stressed mechanisms, reasonable operating procedures are always required. Normal maintenance should only consist of proper lubrication and a periodic check of mounting bolt torque values. Lubrication consists of maintaining the gearbox oil level. Oil in a new gearbox should be drained and flushed out after approximately 250 hours of operation, and replaced with premium quality SSGL-5 (spec 6829012964) after approximately 500 hours of operation or each year, whichever occurs first. Operation in high humidity or polluted air areas will require more frequent changes to minimize moisture or contaminate accumulation. Change the oil as follows.

- 1. Unscrew the drain plug. To ensure all oil has been removed, unscrew the filler and level plugs.
- 2. After oil is drained, replace the drain plug and any other plugs that were removed to drain the oil.
- 3. Flush the case with a light flushing oil.

- **NOTE:** Cleaning of the gearbox with a solvent is recommended to prevent an accumulation of grit and grime. Avoid steam cleaning where moisture and dirt might be driven into the vent of the swing bearing.
- **4.** To refill with oil, fill through filler plug until it begins to flow out of the level plug.
- 5. Tighten the level and filler plugs.

Checking The Oil Level

- 1. Check the oil level through level plug.
- 2. If no oil is visible on the level plug, add oil until the level is between min and max on the level plug.
- 3. Refer to Lubrication, page 9-1.

Testing

- 1. Test swing of superstructure in each direction. Stop and start swing several times.
- 2. Inspect for hydraulic leaks and repair as necessary.



SWING BEARING

Description

The swing bearing is an anti-friction roller bearing that mates the Superstructure to the Carrier. The bearing inner race is bolted to the Superstructure and the outer race is bolted to the Carrier. The inner race contains two grease fittings for lubrication of the bearing which are hosed to two fittings at the front right side of the turntable center section.

Maintenance

General

The swing bearing is the most critical maintenance point of the crane. It is here, at the centerline of rotation, that stresses of loads are concentrated. In addition, the bearing provides the only attachment between the superstructure and carrier. Therefore, proper care of the bearing and periodic maintenance of the turntable-to-bearing attach bolts -IS A MUST -to ensure safe and efficient operation.

Torquing Turntable Bolts

General



Failure to maintain proper torque of the turntable bearing attaching bolts will result in damage to the crane and possible injury to personnel.

Maintaining proper torque value for bolts is extremely important for structural strength, performance, and reliability of the crane. Variations in torque can cause distortion, binding, or complete separation of the superstructure from the carrier.

CAUTION

Repeated re-torquing may cause bolts to stretch. If bolts keep working loose, they must be replaced with new bolts of the proper grade and size.

Proper identification of bolt grade is important. When marked as a high strength bolt (grade 8 and metric grade 10.9), the serviceman must be aware of bolt classifications and that he is installing a high strength heat-treated tempered component and the bolt must be installed according to specifications. Special attention should be given to the existence of lubricant and plating that will cause variation from dry torque values. When a high strength bolt is removed, or un-torqued, the bolt must be replaced with a new bolt of the same classification.



It is mandatory that bearing attaching bolts be inspected for lack of torque and retorqued, as required, after the first 300 hours of crane operation. The bolts may loosen in service due to vibration, shock-loads, and temperature changes, therefore, periodic inspection should be accomplished every 500 hours thereafter, ensuring the bolts are properly torqued.

KNOW YOUR TORQUE WRENCH! Flexible beam type wrenches, even though they might have a pre-set feature, must be pulled at right angle and the force must be applied at the center of the handle. Force value readings must be made while the tool is in motion. Rigid handle type, with torque limiting devices that can be pre-set to required values, eliminate dial readings and provide more reliable, less variable readings.

NOTE: If multipliers and/or special tools are used to reach hard to get at areas, ensure torque readings are accurate.


Torque wrenches are precision instruments and must be handled with care. To ensure accuracy, calibrations must be made on a scheduled basis. Whenever there is a possibility that a torque wrench may have been either overstressed or damaged, it should immediately be removed from service until recalibrated. When using a torque wrench, any erratic or jerking motion can result in the application of excessive or improper torque. ALWAYS use a slow, even movement and STOP when the predetermined value has been reached.

If it is reported by the crane operator or suspected that the crane has been overloaded beyond the capacities specified above the bold line on the cranes' capacity chart, then all turntable bolts must be inspected for looseness and retorqued to specifications.

Turntable bolts should be torqued according to the procedures outlined in this section.

When using step wrenches, calculated wrench settings are valid only when the following conditions are met.

- 1. Torque wrenches must be those specified and forces must be applied at the handle grip. The use of handle extensions will change applied torque to the bolt.
- 2. All handles must be parallel to the step wrench during final tightening. Multiplier reaction bars may be misaligned no more than 30 degrees without causing serious error in torque.
- **3.** Multiplier bar handles must be propped or supported within the outer 1/4 of the handle length, or serious under or over tightening will occur.



The inner race of the bearing is secured to the turntable by 36, 1 inch, grade 8 bolts. The outer race of the bearing is secured to the carrier frame by 36, 7/8 inch, grade 8 bolts.

Torque Values

Torque all inner race turntable bolts (Figure 6-2) to a final torque of 1162 to 1260 Nm (857 to 929 pounds-foot).

Torque all outer race turntable bolts (Figure 6-2) to a final torque of 769 to 834 Nm (567 to 615 pounds-foot).

See Fasteners and Torque Values (pg 1- 12).

Tools Required

(Figure 6-3) lists the complete set of special tools required to torque the turntable bolts.

Inner Race Torquing

- 1. Extend and set the outriggers. Fully elevate the boom.
- 2. Torque eight bolts 930 to 1008 Nm (686 to 743 lb-ft) using the following sequence pattern; 36, 18, 10, 28, 5,


23, 14, and 32. Tools used are the socket, multiplier, backlash adapter, necessary extensions, and torque wrench.

 Return to bolt 1 and torque all bolts sequentially in a clockwise direction to the final torque of 1162 to 1260 Nm (857 to 929 lb-ft) The same tools are used as in step 1.

Outer Race Torquing

- 1. Extend and set the outriggers. Fully elevate the boom.
- 2. Torque eight bolts 615 to 667 Nm (454 to 492 lb-ft) using the following sequence pattern; 36, 18, 10, 28, 5, 23, 14, and 32. Tools used are the socket, multiplier, backlash adapter, necessary extensions, and torque wrench.
- **3.** Return to bolt 1 and torque all bolts sequentially in a clockwise direction to the final torque of 769 to 834 Nm (567 to 615 lb-ft). The same tools are used as in step 1.





Removal

1. Fully extend and set the outriggers enough to take up the slack in the pads.

NOTE: Do not raise the machine on the outriggers.

- 2. Ensure the boom is in the travel position and the turntable lock pin is engaged.
- 3. Elevate the boom slightly and shut down the engine.
- 4. Tag and disconnect the battery cables from the batteries.
- **NOTE:** The boom assembly weighs approximately 5792 kg (12,769 pounds) with stowed boom extension. Removal of the swingaway boom extension will simplify boom removal, therefore, the above weight is for the boom without the swingaway boom extension attached. The lift cylinder weighs approximately 578 kg (1274 pounds).
- 5. Remove the boom and lift cylinder following the procedures outlined in Section 4, BOOM.

- 6. Remove the counterweight and auxiliary hoist following procedures outlined in Section 5 - HOIST and COUNTERWEIGHT.
- 7. Tag and disconnect all water and oil lines from the bottom of the swivel. Cap or plug all lines and openings.
- Locate the connectors and ground wire that joins the 8. swivel wiring harness to the receptacles and ground stud on the carrier.
- 9. Disconnect the swivel wiring harness connectors from the carrier wiring receptacles. Remove the ground wire from the ground stud.
- 10. Remove the clamp securing the swivel wiring harness to the retainer plate on the bottom of the hydraulic swivel assembly.
- 11. Coil the wiring harness and secure it to the swivel to prevent damage to the harness during turntable removal.
- 12. On the bottom of the hydraulic swivel, bend the retainer tabs away from the capscrew heads. Remove the capscrews securing the two retainer plates to the spool.

Remove the retainer plates from the spool and the lugs on the carrier frame.

NOTE: The swivel assembly will be removed with the turntable.



Ensure the lifting device is capable of fully supporting the weight of the superstructure. Ensure the superstructure will not tilt or slide during lifting and moving. Failure to do so may result in death or injury to personnel and damage to equipment.

- **NOTE:** If a lifting device capable of lifting the entire superstructure is not available, superstructure weight may be reduced by removing various components such as the hoist(s).
- 13. Attach a suitable lifting device to the four superstructure lifting lugs (two near the boom pivot shaft bushings and two near the lower lift cylinder pivot shaft bushings). Take in cable or chain to remove slack. Do not pull up on the superstructure.



Ensure the superstructure is fully supported before proceeding.

- **NOTE:** It will be necessary to rotate the superstructure while attached to the lifting device. Outer race bolts can only be removed from the swing drive side of the turntable.
- **14.** Remove the 36 bolts and washers securing the turntable bearing outer race to the carrier.



Ensure that any blocking material used is capable of fully supporting the weight of the superstructure and will not allow it to tilt or shift. Failure to do so may result in death or injury to personnel.

- **15.** Carefully lift the superstructure, using care not to damage the swivel assembly, and set it on blocking that will not allow the superstructure to tilt or shift, or rest on the swivel. Leave the lifting device attached.
- **NOTE:** If the same bearing is to be used again, mark the position of the bearing on the superstructure so it can be installed in the exact position it was before removal.

- **NOTE:** The bearing weighs approximately 260 kg (573 pounds). Ensure the bearing lifting device is capable of supporting the weight.
- **16.** Place an adequate lifting device under the bearing and remove the 36 bolts and washers securing the turntable bearing to the superstructure.
- **17.** Using the lifting device, remove the turntable bearing from under the superstructure.

Inspection


Check the bearing teeth for chipping or cracking. If any evidence of these is found, replace the bearing. Ensure the bolt holes are free of dirt, oil, or foreign material.

Installation

Anytime a turntable bolt has been removed, it must be replaced with a new bolt.

- **NOTE:** If the same bearing is to be used again, align the marked teeth on the pinion shaft and the marked teeth on the bearing.
- **NOTE:** Installation is in the travel position. Ensure the swing lock is disengaged before attempting to mate the bearing to the superstructure.
- 1. Using an appropriate lifting device, position the turntable bearing under the superstructure. If the same bearing is being used, position it as marked prior to removal.
- 2. Install 36 new bolts and washers securing the bearing to the superstructure. Refer to Inner Race Torquing in this Sub-Section.
- **3.** Using an appropriate lifting device, align the superstructure over the carrier in the travel position and carefully lower the superstructure, being careful not to damage the swivel assembly, into position on the carrier bearing plate.
- **NOTE:** It will be necessary to rotate the superstructure while attached to the lifting device. Outer race bolts can only be installed from the swing drive side of the turntable.
- **4.** Install 36 new bolts and washers. Refer to Outer Race Torquing in this Sub-Section.
- **NOTE:** If a new bearing is being installed, a new pinion gear must also be used. Align the high point (maximum eccentricity) on the bearing with the new pinion gear high point (Figure 6-4).





Orient ring gear such that its point of max eccentricity ("high point") is located between the swing drives. Position swing drives so that pinion is centered within cutout in base plate and motor ports face towards the outboard side as shown.

CAUTION

Do Not Clamp Over Pinion.

- Using shims, set backlash by moving the swing drive assemblies toward the bearing in order to mesh the pinion with the ring gear teeth (see Figure 6-5).
- Check tooth engagement squareness and vertical tooth engagement.
- Remove backlash shims and recheck backlash.

- 5. Apply Loctite 271 to the capscrews. Position the two retainer plates on the bottom of hydraulic swivel spool, engaging the lugs on the carrier frame, and secure them to the spool with four capscrew retainers and bolts. Torque the bolts 298 to 322 Nm (220 to 237 poundsfoot). Bend all the retainer tabs to make contact with the bolt heads.
- 6. Plug the swivel wiring harness connectors into the carrier receptacles. Secure the ground wire to the ground stud using a washer, lockwasher, and nut.
- **7.** Install the clamp securing the swivel wiring harness to the retainer plate on the bottom of the hydraulic swivel.
- 8. Connect all water and hydraulic lines to the ports on the bottom of the swivel as tagged during removal.
- **9.** Install the boom and lift cylinder following the procedures outlined in Section 4, BOOM.
- **NOTE:** The counterweight structure weighs approximately 3818 kg (8417 lb).
- **10.** Install the counterweight and auxiliary hoist following procedures outlined in Section 4 of the Operator's Manual.
- 11. Reconnect the batteries.
- **12.** Check the slew potentiometer in the electrical swivel for proper orientation. Refer to SWIVELS in this Section

Testing

Activate the crane and check for proper function.

NOTE: If the superstructure does not turn freely after bearing and pinion replacement, contact your local distributor.

SWIVELS

Description

The swivel assembly (Figure 6-5) consists of a 10 port hydraulic swivel, a 2 port water swivel, a 2 port refrigerant swivel and a 20 conductor slip ring electrical swivel. Solid connections cannot be used to transfer oil, heater hot water and electricity between the carrier and superstructure due to the continuous 360 degree swing. The use of swivels efficiently accomplishes this function.

The barrel portion of the hydraulic swivel is attached to the turntable base plate by four capscrews, washers and bushings. The spool portion of the swivel rides upon a thrust ring at the top of the swivel case. The spool portion is held stationary with the carrier by bolts, and bolt retainer plates attached to the swivel retainer plate which engages the carrier frame lugs with capscrews and hex nuts. This allows

the spool to remain stationary with the carrier as the case rotates with the superstructure.

The spool portion of the water swivel is integral with the hydraulic swivel. The hydraulic and water swivel spools remain stationary with the carrier as the superstructure rotates. The water swivel case engages to hydraulic case by four dowel pins.

The electrical swivel center or collector ring assembly is secured by setscrews to a center post which is bolted to the spool of the hydraulic swivel. This allows the collector ring assembly to remain stationary with the carrier. The outer portion or brush assembly is mounted on two studs which are located on the mounting plate assembly which is retained to the water swivel barrel by a bolt. This allows the brush assembly to rotate with the superstructure around the stationary collector core.



ltem	Description	12, 13, 14,	15		
1	Slip Ring Assembly	12, 13, 14,		2,	3
2	Capscrew				
3	Washer		PIAD		
4	Hydraulic Swivel				16, 17
5	Retaining Plate				
6	Capscrew			0	
7	Hex Nut		A		
8	Adapter				4
9	Hose Nipple				
10	Adapter			0	
11	Plate				
12	Capscrew		~	0 9	
13	Jam Nut		· ·		
14	Flatwasher		000	5 0 0 5	
15	Capscrew		200		6, 7
16	Hose Nipple			UD MARCH	
17	Adapter		8, 9, 10	95 (1)	
18	Turntable Base Plate				6733-1
19	Carrier Top Plate				0735-1
20	Capscrew		Forward 🛶		20, 21
21	Washer				22
22	Bushing	_			
23	Plug	18			
24	Retaining Plate				
			19 4		
				© [°]	
				® _	
					3 6752-2
		(
		۱.	0		

Hydraulic Swivel

Description

Each of the ports on the spool and case of the swivel is stamped with the port number. The function of each port is described below.

Port #	Max Test Pressure kPa (bar) (psi)	Function
1	25000 (250) (3625)	Brake - Front
2	25000 (250) (3625)	Load Sense
3	25000 (250) (3625)	Brake - Rear
4	5000 (50) (725)	Dual Return
5	30000 (300) (4351)	Swing/Brake/Steer
6	32000 (320) (4641)	Lift/Tele/Hoist
7	25000 (250) (3625)	Front Steer - Left
8	25000 (250) (3625)	N/A
9	25000 (250) (3625)	Front Steer-Right
10	500 (5) (73)	Case Drain
11	500 (5) (73)	A/C
12	500 (5) (73)	A/C
A	500 (5) (73)	Heater Supply (Coolant)
В	500 (5) (73)	Heater Return (Coolant)

Theory of Operation

The hydraulic swivel allows oil to flow from the pumps to various crane functions on the superstructure. All oil is routed into the spool portion of the swivel where, through a series of internally drilled passages, oil is transferred to circumferential channels on the spool exterior. These channels correspond with a mating port on the outer case of the swivel. Each channel is separated by a series of nylon and O-ring seals that prevent transfer of oil and pressure. Return flow from the crane superstructure is accomplished in the same manner through another set of ports.

Engine coolant flows from the carrier mounted engine to the hot water heater in the operator's cab through ports A and B of the swivel.

Maintenance

Removal

- 1. Extend and set the outriggers. Ensure the crane is level and the boom is over the front.
- **2.** Elevate the boom and note at what boom angle you have the most clearance between the lift cylinder and the turntable side plate. Shut down the engine.

- **3.** Measure the distance from the top of the lift cylinder to the base of the boom section where the lift cylinder attaches. Cut two pieces of 10 x 10 cm (4 x 4 in) oak to fit.
- **NOTE:** It might be necessary to raise the boom slightly to allow installation of the blocking.
- **NOTE:** This blocking is to add extra support for the boom. Any seepage or leakage in the holding valves or internally in the cylinders will allow the boom to settle over a period of time.
- **4.** Use the oak blocking to block between the barrel of the lift cylinder and the boom base section.
- 5. Evacuate A/C system and capture refrigerant.
- **6.** Tag and disconnect the hydraulic lines from the case of the hydraulic swivel. Cap or plug all lines and openings.
- **7.** Tag and disconnect the hydraulic lines and water lines from the spool of the hydraulic swivel. Cap or plug all lines and openings.
- **8.** Tag and disconnect the water lines from the case of the water swivel. Cap or plug all lines and openings.



- **9.** Disconnect the swivel wiring harness connectors from the carrier receptacles and the yellow ground wire from the connector mounting bracket on the carrier frame. If necessary, remove the electrical swivel. Refer to ELECTRICAL SWIVEL in this Section.
- **NOTE:** The hydraulic swivel weighs approximately 214 kg (472 lb). The hydraulic, water, and electrical swivel combined weigh approximately 233 kg (514 lb).
- **10.** On the bottom of the swivel, bend the retainer tabs away from the capscrews. Remove the capscrews and capscrew retainers securing the two retainer plates to the spool. Remove the retainer plates from the spool and the lugs on the carrier frame.
- **NOTE:** It may be necessary to remove some drive line components to remove the swivel.
- **11.** Position an adequate supporting device beneath the swivel.
- **12.** Remove the capscrews, washers, and bushings securing the swivel barrel to the turntable base plate and lower the swivel to the ground.

Installation

- **NOTE:** The hydraulic swivel weighs approximately 214 kg (472 lb). The hydraulic, water, and electrical swivel combined weigh approximately 233 kg (514 lb).
- 1. Raise the swivel into position.
- Secure the hydraulic swivel to the turntable base plate with the bushings, capscrews and washers. Torque the capscrews see Fasteners and Torque Values (pg 1- 12).

- **3.** Apply Loctite 271 to the capscrews. Position the two retainer plates on the bottom of hydraulic swivel spool, engaging the lugs on the carrier frame, and secure them to the spool with four capscrew retainers and bolts. Torque the bolts 298 to 322 Nm (220 to 237 lb-ft). Bend all the retainer tabs to make contact with the bolt heads.
- 4. If removed, install the electrical swivel. Refer to ELECTRICAL SWIVEL in this Section. Connect the swivel wiring harness connectors to the carrier receptacles and the yellow ground wire to the mounting bracket on the carrier frame. Use the bolt and star washers taken off at removal and refer to Grove Engineering Specification A-829-100386 for proper electrical termination of grounds.
- **NOTE:** Allow a 1/32" max gap between bolt and the retaining lug on the frame. Do not tighten bolt against lug.
- 5. Install the clamp, lockwasher, flat washer and capscrew to the bottom of the swivel retainer plate securing the wiring harness.
- 6. Connect the hydraulic lines and water lines to the spool of the hydraulic swivel as tagged during removal.
- 7. Connect the hydraulic lines to the hydraulic swivel case as tagged during removal.
- **8.** Connect the water lines to the water swivel case as tagged during removal.
- **9.** Remove the blocking material from the lift cylinder.
- **10.** Activate all systems; cycle all functions and observe for proper operation and any leakage.
- 11. Charge A/C system.

6

Electrical Swivel

Description

The swivel assembly consists of a 20 conductor slip ring and cover assembly.

Each brush set incorporates two brushes, leads, and clips which are attached to a brush holder assembly. The brush set leads are formed into harnesses which are routed through the mounting plate on the swivel. The collector ring leads are formed into one harness which is routed downward through the center of the hydraulic swivel. Extending from the base of the hydraulic swivel, the collector ring leads are also formed into connectors which plug into receptacles from the chassis power supply.

The swivel cover is secured with a seal and bolts

The electrical swivel also incorporates a slew potentiometer. The potentiometer controls functions in the load moment indicating, working area definition, and rear axle oscillation lockout systems.

Theory of Operation

The electrical swivel is located on top of the water swivel and transfers electricity between the carrier and superstructure. Wiring harnesses transmit the electricity between the carrier and superstructure.

Maintenance

Removal

1. Perform steps 1 through 4 of HYDRAULIC SWIVEL - REMOVAL in this section.

Disconnect the batteries before performing any maintenance on the electrical system. Serious burns may result from accidental shorting or grounding of live circuits.

- 2. Disconnect the batteries. Refer to Section 3 ELECTRIC SYSTEM.
- **3.** Locate the connectors which join the collector ring harness to the receptacles for the carrier.
- 4. Tag the connectors and their receptacles with numbers. Disconnect the connectors from the chassis wiring receptacles.
- 5. Remove the clamp securing the wiring harness to the retainer plate on the bottom of the hydraulic swivel assembly.

- 6. Secure the connectors and wires from each of the numbered connectors so the harness can be withdrawn through the center of the hydraulic swivel.
- **7.** Tag and disconnect the connectors from the receptacles on the cab bulkhead mounting plate.
- **8.** Remove the setscrews and remove the cover from the electrical swivel.
- **9.** Loosen the capscrews securing the electrical swivel mounting tube to the center post on the water swivel.
- **10.** Remove the capscrew and jam nut securing the electrical swivel case to the plate on the case of the water swivel.

CAUTION


When withdrawing the wiring harness through the center of the hydraulic and water swivels, ensure the wires do not get caught and damaged.

11. Remove the swivel and wiring harness from the crane. If necessary, remove the spacer bushing from the center post.

Installation

- 1. If removed, install the spacer bushing on the center post. Route the collector core wiring harness through the center of the hydraulic and water swivels.
- **NOTE:** The boom should be centered directly over the front of the crane before adjustment is made to the slew potentiometer.
- 2. Slide the electrical swivel mounting shaft onto the center post.
- **3.** Ensure the threaded hole on the bottom of the electrical swivel base is aligned with the mounting hole in the plate on the water swivel case. Install the capscrew through the hole in the plate and install the jam nut. Screw the capscrew into the hole in the electrical swivel base until the capscrew head is approximately 6.0 mm (0.23 in) from the bracket. Tighten the nut against the electrical swivel (Figure 6-6).
- 4. Apply medium strength Loctite to the setscrews securing the electrical swivel to the center post and tighten them 5 to 6 Nm (44 to 53 lb-in)
- **5.** Install the swivel cover and secure with capscrews and washers.
- 6. Connect the wiring harness connectors to the receptacles on the cab bulkhead mounting plate as tagged during removal.





ltem	Description		
1	Swivel		
2	Capscrew		
3	Hex Nut		
4	Capscrew		
5	Washer		
6	Bushing		
7	Retaining Plate		

- 7. Plug the connector into the carrier wiring receptacle, connect the wires as tag during removal. Install the yellow ground wire to the connector mounting bracket on the carrier frame using the bolt and star washers taken of at removal and refer to Grove Engineering Specification A-829-100386 for proper electrical termination of grounds.
- **8.** Install the clamp securing the harness to the retainer plate on the bottom of the hydraulic swivel assembly.
- 9. Connect the batteries.

CAUTION

It is imperative that the slew potentiometer be adjusted anytime work is done to the electrical swivel.

10. Activate all systems, cycle all functions, and observe for proper operation. Adjust the slew potentiometer in accordance with SLEW POTENTIOMETER ADJUSTMENT procedures in this Sub-Section.

Preventive Maintenance

It is recommended that a normal inspection of the electrical swivel collector ring and brush assembly be established. An example of this could be at approximately 100 to 150 engine operating hours. When this time limit is reached, perform the following.

- 1. Check the collector ring and brush assembly for any corrosion, pitting, arcing, and wear.
- 2. Check the collector ring setscrews and ensure they are tight.
- **3.** Check the brush and arm assembly springs. Ensure they are holding the brushes firmly against the collector rings.

Slew Potentiometer Adjustment

- 1. Rotate the superstructure over the front and engage the house lock pin.
- 2. Remove the electrical swivel cover.

CAUTION

Do not attempt to rotate the slotted shaft in the center of the slew potentiometer.

- 3. Disengage the house lock pin and swing the superstructure approximately 10 degrees to the right (clockwise). Slowly swing back to the left and engage the house lock pin.
- **NOTE:** If the superstructure swings past the house lock pin engaged position, step 3 must be repeated.
- **4.** Loosen the three screws that secure the slew potentiometer to the mounting plate.
- 5. Rotate the body of the slew potentiometer until the slew angle indicates 0.6 ± 0.1 degree.
- **NOTE:** The slew angle indication in step 6 may not be obtainable due to limited wire length on the potentiometer, or the electrical terminals interference with one of the three mounting screws. If this occurs, reposition the collar set screwed to the potentiometer shaft and repeat steps 3 thru 5.
- 6. Tighten the three screws that secure the slew potentiometer to the mounting plate. Install the electrical swivel cover.
- 7. Disengage the house lock pin and swing approximately 10 degrees to the left (counterclockwise). Slowly swing back to the right and engage the house lock pin.
- **NOTE:** If the superstructure swings past the house lock pin engaged position, step 7 must be repeated.
- If the angle indicated on the console does not exceed ± 1.0 degree, proceed to step 10. If the indicated angle exceeds ± 1.0 degree, return to step 3.
- **9.** Disengage the house lock pin and swing approximately 10 degrees to the right (clockwise). Slowly swing back to the left and engage the house lock pin.

- **NOTE:** If the superstructure swings past the house lock pin engaged position, step 10 must be repeated.
- **10.** If the angle indicated on the console does not exceed \pm 1.0 degree, proceed to step 12. If the indicated angle exceeds \pm 1.0 degree, return to step 3.
- **11.** Disengage the house lock pin and swing approximately 10 degrees to the left (counterclockwise). Slowly swing back to the right and engage the house lock pin.
- **NOTE:** If the superstructure swings past the house lock pin engaged position, step 12 must be repeated.
- 12. Verify the angle indicated on the console does not exceed \pm 1.0 degree. If the indicated angle exceeds \pm 1.0 degree, return to step 3.



SECTION 7 POWER TRAIN

SECTION CONTENTS

Engine
Description
Maintenance
Fuel System 7-7
Description
Maintenance 7-7
Air Intake System 7-9
Description
Air Intake 7-9
Charge-Air Cooler System (CAC) 7-12
Exhaust System 7-13
Removal
Installation7-13
Slip Joint Exhaust Connectors

Water Cooling System	7-15
Description	7-15
Maintenance	7-15
Test Equipment	7-18
Antifreeze/Coolant	7-18
Radiator Removal and Installation	7-18
Drive Train	7-20
Description	7-20
Maintenance	7-20
Transmission/Torque Converter	7-20
Description	7-20
Theory of Operation	7-20
Maintenance	7-21
Servicing Crane After Transmission/Torque Converter Overhaul	7-24

ENGINE

Description

The engine is a Cummins QSB6.7L (Figure 7-1) Tier 4 Final diesel engine. This Service Manual does not include detailed information on the engine itself. A separate manual as prepared in detail by the engine manufacturer, is supplied with this Service Manual. However, a short description and maintenance of certain components of the fuel system, air intake system, and water cooling system is provided in this section.

The engine is electronically controlled by the Electronic Control Module (ECM), it is the control center of the system. It processes all of the inputs and sends commands to the fuel systems as well as vehicle and engine control devices.

Engine speed is controlled by the foot throttle pedal in the cab. It controls engine RPM which increases or decreases proportionately with the amount of foot pressure applied to the pedal. The foot throttle pedal is electrically connected to the superstructure control module which sends the signal to the engine ECM via the J1939 data link.

The engine and its components are enclosed in a hood assembly with a grill in the rear of the hood for adequate air circulation. Access to the engine is gained through a door assembly in the right side of the hood. The air intake filter is mounted on the rear of the left rear fender. The muffler is mounted on the left side of the hood behind the rear fender.



Do not spray starting fluid into the air inlet. The spray will contact the heater elements and could explode causing personal injury.

To aid in starting the engine in cold weather, the engine is equipped with electric air heating elements that are located in the engine's intake air stream to aid in cold starting and reduce white smoke at start-up. In the preheat mode, the engine should not be cranked until the WAIT-TO-START lamp turns off. The WAIT-TO-START lamp is illuminated during the preheat time that takes place when the ignition switch is in the ON position during cold weather starting. The ECM checks intake manifold temperature to determine how long to energize the air heater before extinguishing the WAIT-TO-START lamp. Once the engine is started, the electric air heating element will be energized again for a time period determined by intake air temperature.

Maintenance

Engine Removal


- **1.** Set the outriggers and position the boom to over the side.
- 2. Open and remove the hood door assembly.
- **3.** Disconnect the air filter tubing at the engine and air cleaner. Remove and lay aside.
- 4. Disconnect the exhaust tubing at the engine and muffler. Lay to the side.
- **5.** Tag and disconnect the engine electrical harness connector from the carrier harness connector and battery cables.
- 6. Remove the start and grid heater relay panel and place to the side of the frame. Lay the relay panel with the harness on the engine. If a remote crank option is present, disconnect the remote crank harness connector from the engine harness and tie up excess harness so it is out of the way.
- 7. Drain the engine coolant system.
- 8. Drain the engine lubrication system.
- 9. Drain the transmission/torque converter oil system.
- **10.** Evacuate A/C system and capture refrigerant.
- **11.** Remove the engine hood assembly and pump cover from the machine.
- **12.** Disconnect and remove the drive shaft(s) between the transmission/torque converter and the axle(s). Refer to DRIVE LINES in this Section.


- 13. Tag and disconnect all lines from the radiator. Disconnect the coolant level sensor harness from the engine harness and tie up excess harness so it is out of the way. Remove the radiator. Refer to RADIATOR -Removal in this Section.
- **14.** Tag and disconnect all lines and tubing from the engine, transmission/torque converter, and all other components.

The lifting device must be able to support the combined weight of the engine and transmission.

- **NOTE:** The engine and transmission/torque converter assembly weighs approximately 1200 kg (2646 pounds).
- **15.** Attach to the engine a lifting device capable of supporting the weight of the engine and transmission/ torque converter.
- **16.** With the lifting device supporting the weight of the engine, remove the capscrews, washers and locknuts securing the front of the engine to the frame.
- **17.** Remove the capscrews, washers, nuts, insulator and mounting plate securing the rear of the engine to the frame.
- **18.** Using the lifting device, lift the engine and transmission/ torque converter as an assembly from the crane.
- **19.** If a new engine is to be installed, remove all components, fittings, etc., from the old engine and install them on the new engine in the same locations.
- **NOTE:** Ensure that the same grade hardware, torque values, and Loctite as were installed by the factory are used.







Engine Front View

FIGURE 7-1 continued

1	Capscrew	7	Mounting Plate
2	Washer	8	Washer
3	Dockwasher	9	Hex Nut
4	Locknut	10	Dockwasher
5	Capscrew	11	Isolator
6	Washer	12	Capscrew



Engine Installation

The lifting device must be able to support the combined weight of the engine and transmission.

- **NOTE:** Use the same grade hardware, torque values, and Loctite that were used by the factory.
- **NOTE:** Apply medium strength sealant (Loctite 243) to engine attaching hardware.
- **1.** With all components and fittings installed on the new engine, lift the engine into the crane.
- With the engine in position, install the mounting plate, insulator, nuts, washers and capscrews and secure rear of engine (Figure 7-1). Torque M16 grade 10.9 capscrews see Fasteners and Torque Values (pg 1- 12).
- At the front of the engine install the capscrews, washers and locknuts and secure the engine to the frame. Torque the M12 grade 8.8 bolts, see Fasteners and Torque Values (pg 1- 12).
- **4.** Remove the lifting device.
- 5. Connect all lines and tubing to the engine, torque converter, and all other components in accordance with the identification marks made during removal.

CAUTION

Do not apply sealant to the inside of the hydraulic suction hoses.

- 6. Install the radiator. Refer to RADIATOR Installation in this Section. Connect all hoses and electrical harnesses to the radiator as tagged during removal.
- **7.** Connect the drive shafts between the transmission/ torque converter and the axles. Refer to DRIVE LINES in this Section.
- 8. Install the hood assembly. Install the pump cover.
- **9.** Position the start and grid heater relay panel on the right side on the frame and secure with the hardware. If equipped with a remote crank option, reconnect to the engine harness.Connect the battery cables and engine electrical harness connector in accordance with the identification marks made during removal.
- **10.** Connect the air filter tubing at the engine and the air filter. Connect the exhaust tubing to the engine and muffler.
- **11.** Charge the A/C system.
- **12.** Install the hood top door assembly.
- **13.** Service the transmission, engine lubrication system, and engine cooling system. Refer to Section 9 -LUBRICATION.
- **14.** Start the engine. Check all hoses and fittings for leaks. Recheck all fluid levels.


Engine Drive Belts

The proper operation of engine belt-driven components such as the alternator, fan, and water pump depend on the proper condition and tension of the engine drive belt.

NOTE: Belt tension is maintained with an automatic belt tension device. Refer to engine manufacturer's manual for special tools or belt tension specifications.

The engine drive belt should be inspected visually on a daily basis. The drive belt should be inspected for cracks, frayed areas, and glazed or shiny surfaces (Figure 7-2). A drive belt that is glazed or shiny indicates belt slippage.

Engine drive belt damage can be caused by various factors such as incorrect tension, incorrect belt size, misaligned engine pulleys, incorrectly installed belt, or by oil, grease, or hydraulic fluid on the belt.





FUEL SYSTEM

Description

The fuel system consists of the fuel tank, strainer, lift pump, injection fuel pump, fuel-water separator filter and the fuel injectors. All components except the fuel tank are installed on the engine or supplied with the engine for remote mounting.

Fuel Tank

The fuel tank (Figure 7-3) is a steel cylinder-type tank located on the left side of the machine. The fuel tank has a draw capacity of 220 I (58 gal). A connection on the bottom of the tank provides for fuel supply to the engine. Surplus fuel from the engine is provided to the bottom of the fuel tank below the fuel level. The tank is equipped with a non-vented filler cap, chain-attached to the tank, and a fuel quantity sender unit which provides a signal to a fuel quantity gauge on the instrument panel in the cab.

Injection Fuel Pump

The fuel oil is finely atomized as it is injected into the cylinder and ignited by the heat of the compression. It is metered also, before injection, to meet the load requirements imposed upon the engine. Surplus fuel, returning from the injectors, is bypassed back to the fuel tank or to the inlet side of the pump. The continuous flow of fuel through the injectors helps to cool the injectors and to purge air from the system.

Fuel Filter-Water Separator

The fuel filter-water separator removes impurities from the fuel and also removes water from the fuel before it reaches the engine. The filter is mounted on the left side of the machine

The fuel mixture passes through the outer wrap of the first stage of the filter paper, where large droplets of water are formed as it is stripped from the fuel. The water falls out into the void between the two paper elements and goes to a reservoir in the bottom of the housing, where it can be drained through a drain plug at the bottom of the housing.

Maintenance

NOTE: The entire fuel system must be maintained air tight to prevent loss of prime.

Fuel Tank

The fuel tank should be kept filled, especially overnight, to reduce condensation to a minimum. Refer to the applicable engine manual for the recommended schedule for draining any water or sediment from the tank.

Removal

- 1. Position a suitable container under the fuel tank and drain all fuel from the tank.
- 2. Tag and disconnect the lines from the bottom of the tank.
- **3.** Disconnect the electrical lead from the fuel quantity sender unit.
- 4. Support the weight of the tank, loosen and remove the hardware securing the straps to the mounting brackets. Remove the tank and steps.
- 5. If a new tank is to be installed, remove the fittings, the fuel quantity sender, and steps from the tank and install them in the new tank.

Installation


- Position the new tank on the mounting brackets and install the hardware on the two straps. Torque the capscrews see Fasteners and Torque Values (pg 1- 12).
- 2. Connect the electrical lead to the fuel quantity sender unit.
- **3.** Connect the two lines to the fittings on the bottom of the tank in accordance with the identification marks made during removal.
- 4. Service the tank.

Fuel Filter-Water Separator

Draining

The sump of the fuel filter-water separator should be drained daily, 30 minutes after the engine is shut down, to remove any water and sediment. Adhere to the following procedure.

- **1.** Open the drain plug.
- 2. Drain until fuel appears.
- 3. Close the drain plug.



Item	Description
1	Fuel Tank
2	Fuel Level Sensor
3	Fuel Supply
4	Fuel Return
5	Mounting Bracket
6	Fuel Cooler



AIR INTAKE SYSTEM

Description

The air intake system (Figure 7-3) controls quality and amount of air available for combustion. System components are the Air Cleaner, Turbocharger, Charge Air Cooler, and Cylinder Head. Inlet air is pulled through the Air Cleaner, compressed, and heated in the compressor side of the Turbocharger. Air is pushed through the Charge Air Cooler to the Air Inlet Manifold. Cooling the inlet air increases combustion efficiency, lowers fuel consumption, and increases horsepower. Air is forced into the cylinder head to fill the inlet ports. Air flow from the inlet port into the cylinder is controlled by the intake valves.

The Air Cleaner (Figure 7-1) is the dry-type with a replaceable element and is located on the right rear fender. An Air Intake Restriction Monitor (AIRM) system is designed to calculate real-time air filter restriction at operational flow rate using the temperature and pressure input from the Temperature Barometric Atmospheric Pressure (TBAP) sensor installed on the air cleaner housing.

Electric heating elements heat intake air when starting the engine in cold temperatures. Starting and white smoke control are enhanced by the use of the intake air heater. A Wait-to-Start Lamp indicates when to crank the engine.

Air Intake

Air Cleaner Checks

Dust bypassing the air cleaner, even through small holes, can cause rapid engine wear. Ensure all connections between the air cleaner and engine are tight and sealed. If these connections are all well sealed and there is still evidence of dust leakage, check the following places for possible trouble:

- **NOTE:** Dust that gets by the air cleaner system can often be detected by looking for dust streaks on air transfer tubing or just inside the intake manifold inlet.
- 1. Inspect air cleaner outlet tube for damage.
- **2.** Ensure element sealing surface is not damaged and seals well against the element.
- 3. Inspect element sealing surface for damage.
- 4. Check for structural failures. Replace damaged parts.

Filter Restriction Check

As a dry cleaner element becomes loaded with dust, vacuum on the engine side of the air cleaner (at air cleaner outlet) increases.

Vacuum is generally measured as restriction in inches of water. The engine manufacturer places a recommended limit on the amount of restriction without loss of engine performance before the element must be cleaned or replaced.

The TBAP sensor attached to the air cleaner housing provides input to the Air Intake Restriction Monitor (AIRM) system to activate a fault code when the filter needs to be replaced. The Engine Warning Indicator will blink for 30 seconds at engine start for fault code 5576 indicating the air cleaner is becoming clogged. The indicator will be on solid for fault code 3341 indicating the filter is clogged and must be changed. If the TBAP's accuracy is suspect, a water manometer connected to the filtered pressure tap is the most accurate and dependable method of measuring.


To use the manometer, hold it vertically and fill both legs approximately half full with water. One of the upper ends is connected to the restriction tap on the outlet side of the air cleaner with a flexible hose. The other end is left open to the atmosphere.

Maximum restriction in the air cleaner occurs at maximum air flow. On this turbocharged diesel engine, the maximum air flow occurs only at maximum engine power.

With the manometer held vertically and the engine drawing maximum air, the difference in the height of the water columns in the two legs, measured in inches or centimeters is the air cleaner restriction. The restriction for this engine is 25 inches of water.

If initial restriction on a new or clean filter reads above the maximum allowed for the engine, check the following items.

- 1. Ensure air cleaner inlet is not plugged.
- 2. Inspect air cleaner outlet to be sure it is not plugged by paper, rags, etc.
- **3.** Ensure correct size connections are used between air cleaner and engine.
- 4. Ensure all inlet accessories are the correct size and not plugged by any foreign object.




1	Air Cleaner	7	Intake Tube
2	Mounting Brackets	8	Elbow
3	Vacuator Valve	9	Intake Tube
4	TBAP Sensor	10	Adapter
5	Bracket (also bolts to engine hood)	11	Bracket (also bolts to engine hood)
6	Rubber Hump Reducer	12	Bracket (also bolts to engine hood)

Filter Element Replacement

CAUTION

Never service air cleaner while engine is running.

1. Lift clips (1) ((Figure 7-5)) securing cover to air cleaner body. Remove cover.



- 2. Remove Primary Filter from Air Cleaner and inspect for foreign material and marks of dust. Replace as necessary
- **3.** Remove Secondary Filter (not shown) from behind the Primary Filter. Replace Secondary Filter every third time the Primary Filter is changed.
- 4. Thoroughly clean sealing surface and inside of air filter housing. Inspect all intake system and air cleaner parts.
- 5. Install cover on air cleaner housing. Secure with clips (1).
- 6. Check connections and ducts for an airtight fit. Make sure all clamps, bolts, and connections are tight. Check for holes in piping.
- **NOTE:** Air intake system leaks may send dust directly to the engine.

Element Cleaning

Cleaning filter elements is not recommended. Cummins and most other manufacturers will not warrant a cleaned air filter.




Air Cleaner Body

Remove foreign material (leaves, lint or other foreign matter) that may have collected inside the air cleaner body before installing filter element. Inspect inside of body for dents or other damage that would interfere with air flow or fins on the element or inside the body. Repair any body dents, being careful not to damage sealing surfaces. Be sure to clean sealing surface of the outlet tube and inside of the outlet tube, taking care not to damage the sealing area on the tube.


Precleaner

The precleaner (1, (Figure 7-6)) prevents large debris from entering the air cleaner. Clean periodically especially when working in severe dust conditions. Remove cover by releasing two latches on sides of the precleaner. Remove all debris from inside and reassemble.



Vacuator Valve

Vacuator valves (2, Figure 7-6) (Figure 7-7) are designed to expel loose dust and dirt from the air cleaner body automatically, lengthening air filter element service life. The valve lips must point straight down and be kept free from debris to operate effectively. Mud and chaff can lodge in these lips periodically and hold them open during engine operation.



Check condition of valve and lips frequently and keep clean. Valve lips should be open only when engine is shut down, or running at low idle speed. If the valve is turned outside in, check for a clogged air cleaner inlet. Malfunction of this valve does not reduce air cleaner effectiveness, but does allow the element to get dirty faster and reduces service life. If a valve is lost or damaged, replace it with a new valve of the same part number.

Duct Work

- Check intake pipe cap and screen for accumulation of leaves, trash, and other debris that could restrict air flow. Repair screen or replace cap if any large holes are found in the screen.
- 2. Check all mounting hardware for security to eliminate possible vibration of intake piping. Such vibration leads to early failure of hoses, clamps, and mounting parts, and can cause hoses to slip off the connecting pipes, allowing un-filtered air into the engine air intake.
- **3.** Check hoses for cracks, chafing, or deterioration. Replace at the first sign of probable failure.

7

Charge-Air Cooler System (CAC)

The Charge-Air Cooler (CAC) (Figure 7-8) is used to cool engine air after it has passed through a turbocharger, but before it enters the engine. The charge-air cooler provides better horsepower, increased fuel efficiency, and reduces engine emissions.

The CAC system consists of the ducting to and from the charge-air cooler and a hydraulically driven fan. The charge-air cooler system must be air-tight in order to work efficiently.

Ducting consists of metal tubing, hose clamps, and bellows. Torque small diameter constant tension clamps to 5.6 Nm (50 in-lb). Torque large diameter constant tension clamps to 10.2 – 11.3 Nm (900 – 100 in-lb).


Maintenance

Check the hose clamps for proper torque.

Inspect the bellows for cracks or holes.

Clean the charge-air cooler, removing any dirt or debris.

Verify the fan is operating correctly and there are no hydraulic leaks.



1	CAC	3	CAC Hot Air Inlet
2	Engine Coolant Radiator	4	CAC Cold Air Outlet



EXHAUST SYSTEM

NOTE: Refer to Figure 7-9.

The Tier 4 exhaust system (Figure 7-9) consists of a Diesel Oxidation Catalyst (DOC), Decomposition Reactor Tube (DRT), a Selective Catalytic Reduction (SCR) unit, and various tubes, elbows, and clamps.

Removal

Burn Hazard!

Do not touch exhaust system parts until they are at ambient temperature. Severe burning may result.

- 1. Remove sheet metal guard (Not shown) to gain access to exhaust system.
- 2. Tag and disconnect electrical and DEF connections.
- **3.** Remove clamps (3), and muffler clamp (8), and exhaust tube (5).
- 4. Loosen V-band clamps (3) to remove adapter elbow (7), elbow (11), and DRT (9).
- 5. Remove mounting bands from mounting bracket (2) and remove DOC (10).
- 6. Remove mounting bands from mounting bracket (2) and remove SCR (1).
- 7. If necessary loosen clamp (13) and remove tailpipe (12).
- 8. Inspect exhaust system parts. Repair or replace parts if damaged or missing.

Installation

- **NOTE:** Leave clamps and mounting hardware loose until assembly is complete.
- 1. Install SCR (1) with mounting bands to mounting bracket (2).
- **2.** Install DOC (10) with mounting bands to mounting bracket (2).
- **3.** Attach adapter elbow (7) with gasket (4) and V-band clamp (3) to SCR (1).
- 4. Attach DRT (9) to elbow (11) and adapter elbow (7) with gaskets (4) and V-band clamps (3).
- 5. Attach elbow (11) to DOC (10) with gasket (4) and V-band clamp (3).
- 6. Install exhaust tube (5) with muffler clamp (8). Attach to DOC (10) with gasket (4) and V-band clamp (3).
- 7. Install clamp (13) and tail pipe (12) on SCR (1).
- **8.** Connect electrical connections and DEF line as tagged during disassembly.
- **9.** Adjust position of all components.Tighten clamps and mounting hardware.
- 10. Install sheet metal guard.

Slip Joint Exhaust Connectors

Tighten slip joint exhaust couplers to prevent exhaust leaks at the following intervals:

After 1000 Hours, or One Year

Visually inspect exhaust connector. Tighten V-clamp nuts one full turn.

2000 Hours or 2 Years


Tighten V-clamp nuts 11/2 turn.

4000 Hours or 4 Years

Tighten V-clamp nuts 11/2 turn.

5000 Hours or 5 Years

Remove and replace V-clamps and gaskets. Torque V-clamps to 9.6 to 11.3 Nm (85 to 100 in-lb).



1	Selective Catalytic Reduction (SCR) Assembly	8	Muffler Clamp
2	Mounting Band	9	Decomposition Reactor Tube (DRT)
3	V-Band Clamp	10	Diesel Oxidation Catalyst (DOC)
4	Gasket	11	Elbow
5	Exhaust Tube	12	Tail Pipe
6	Insulation	13	Clamp
7	Adapter Elbow		



WATER COOLING SYSTEM

Description

The cooling system consists of a radiator, surge tank, engine cooling circuit, charge air cooler circuit, connecting hoses, and connecting tubes. Cooling system capacity is approximately 24.6 l (26 qt).

The radiator consists of the top section charge air cooler and bottom section engine water cooler. Temperature is controlled by a 83°C (181°F) thermostat located between top of the engine and top of the radiator. Antifreeze/coolant must be properly inhibited against corrosion. It is recommended a mixture of AFC-50/50 blended ethylene-glycol, low silicate, fully formulated, engine antifreeze/coolant concentrate and water which does not require a pre-charge of supplemental coolant additives (SCA) for use in initial fill of heavy duty liquid cooled internal combustion engines be used at all times.

The crane is equipped with a cab hot water heater. Hot water is supplied by the engine coolant system through a strainer and two port water swivel to the cab heater. The strainer can be cleaned and is located on the left side of the transmission by the rear engine/transmission mount. Refer to Section 9 -LUBRICATION for service of the strainer.

Maintenance

General

The cooling system is often neglected because effects or damage from an improperly maintained system usually occur gradually. The cooling system needs to be maintained with the same attention as other systems.

Circulation of water through the cooling system relies entirely on the water pump. The water pump draws coolant from the radiator and forces it through the water jacket and cylinder head. There, it accumulates heat and flows to the radiator tank. Coolant then flows through the radiator core and is cooled by air from the fan. This process of removing heat from coolant as it circulates keeps the engine at its efficient operating temperature.

The following paragraphs point out several facts about cooling system components, effects of cooling system neglect, and procedures for cooling system maintenance.

Effects of Cooling System Neglect

Whenever an engine does not perform at top efficiency, a neglected cooling system may be at fault even though the part directly responsible is not a part of the cooling system. Most of these problems can be traced to overheating; however, an engine that is running too cold can be just as troublesome.

Overheating

An overheating engine may cause the following:

- 1. Burned valves.
- **2.** Pinging or knocking.
- 3. Excessive fuel consumption.
- 4. Poor lubrication increased engine wear.
- 5. Sticking valves.
- 6. Short injector life.
- 7. Engine hot spots.
- 8. Need for higher grade fuel.

Overcooling

The following engine troubles result when an engine is overcooled:

- 1. Excessive fuel consumption.
- 2. Sludge formation in crankcase.
- 3. Corrosive acids formed in crankcase.
- 4. Excessive fuel deposits in the exhaust system.

Antifreeze/Coolant

Heavy duty diesel engines require a balanced mixture of water and antifreeze/coolant. For maximum rust, freeze, and boiling point protection, a 50/50 blended, fully formulated extended life antifreeze/coolant should be maintained at all times. Refer to *Lubrication*, page 9-1. Do not use more than 50 percent antifreeze/coolant in the mixture unless additional freeze protection is required. Never use more than 68 percent antifreeze/coolant under any condition. Antifreeze/coolant at 68 percent provides the maximum freeze protection; antifreeze/coolant protection decreases above 68 percent.

Rust Prevention

To keep engines operating at like new efficiency, all forms of rust formation must be prevented. The formation of rust in the cooling system is a result of the interaction of water, iron, and oxygen, and can only be prevented by maintaining full strength corrosion protection at all times. Supplemental coolant additives (SCA) are recommended for this cooling system. Antifreeze/coolant alone does not provide sufficient protection for heavy-duty diesel engines. Refer to Section 9 for SCA specification and compatible brands.

Engine Antifreeze/Coolant Fill Procedure (when level is low)

- 1. Fill the system with a 50/50 blended, fully formulated extended life antifreeze/coolant. Fill to the bottom of the surge tank filler neck. Fill slowly. Flow exceeding 3 gpm (11.2 l/min) can give a false reading.
- **NOTE:** If the engine coolant is changed, the coolant filter must also be changed.
- 2. Wait one minute and recheck the antifreeze/coolant level. Refill as necessary repeating step 1.
- **3.** Run the engine for 5 minutes and recheck the antifreeze/coolant level. Refill as necessary repeating step 1. Refer to *Lubrication*, page 9-1.

Antifreeze/Supplemental Coolant Additives Maintenance Summary

Cooling System Level Check Interval

Daily or 10 hours

The cooling system level should be checked every 10 hours of operation or daily, whichever comes first. Refer to *Lubrication*, page 9-1.

SCA Level Check/Coolant Filter Change Interval

6 months or 500 hours

 Check SCA Levels (use only Coolant Test Kit, Grove P/ N 9414101675, to check the coolant additive concentration in the cooling system).

The Coolant Filter contains molybdate. Therefore, it is important to use the Grove Coolant Test Kit, which checks the molybdate level, regardless of whether the SCA used to replenish the coolant system contains molybdate or not.

Only add coolant additive if levels are less than 1.2 units/ gal (see *Standard Lubricants*, page 9-2 for specification and recommended additives).

- **NOTE:** An inadequate concentration of coolant additive can result in major corrosive damage to the cooling system components. Over concentration can cause formation of a "gel" that can cause restriction or plugging of coolant passages, and overheating.
- Change coolant filter.

Install charged filter if SCA levels are normal or below normal; install non-charged filter if SCA levels are above normal (contact Manitowoc Crane Care for filter part number).

1 year or 1000 hours

Test antifreeze/coolant for contamination.

Condemning limits are:

- Sulfate level greater than or equal to 1500 ppm.
- Chloride level greater than or equal to 200 ppm.
- The pH level is less than 6.5
- Oil or fuel contamination can be identified by odor or color.

If condemned, flush the system using a commercially available flushing agent. Refill system with fully formulated extended life coolant. Refer to *Lubrication*, page 9-1.

NOTE: Remove the radiator cap when draining the system to ensure proper draining.

Cleaning

CAUTION Burn Hazard!

The cooling system contains very hot pressurized liquid and injury can result when removing the radiator cap at operating temperature. Use proper protection to remove the radiator cap.

- Coolant shut-off valves to heaters and other accessories should be open to allow complete circulation during cleaning, flushing, and draining. Run the engine with radiator covered if necessary until temperature is up to operating range 160 to 180° F (71 to 82° C). Stop the engine, remove the radiator cap, and drain the system by opening the drain cocks on the radiator and engine block.
- **NOTE:** Use a cleaning compound that is not corrosive to aluminum to prevent damage to the radiator.
- 2. Allow the engine to cool, close the drain cocks, and pour the cleaning compound into the surge tank according to the directions. Fill the system with water.
- **3.** Place a clean drain pan to catch the overflow, and use it to maintain the level in the radiator. Do not spill the solution on the vehicle paint.
- 4. Replace the radiator cap and run the engine at moderate speed, covering the radiator if necessary, so the system reaches a temperature of 180° F (82° C) or above, but does not reach the boiling point. Allow the engine to run at least two hours, or according to recommendations of the manufacturer of the cleaning compound, at 180° F (82° C) so the cleaning solution may take effect. Do not drive the vehicle or allow the liquid level in the radiator to drop low enough to reduce circulation.
- 5. Stop the engine as often as necessary to prevent boiling.



- 6. With the engine stopped, feel the radiator core with bare hands to check for cold spots, and then observe the temperature gauge reading. When there is no change in temperature for some time, drain the cleaning solution.
- 7. If clogging of the core is relieved but not fully corrected, allow the engine to cool, pressure-flush the system (see *Pressure Flushing*) and repeat the cleaning operation.
- 8. If problem persists, replace radiator.

Pressure Flushing

- 1. Disconnect both radiator hoses that connect the radiator to the engine.
- 2. Clamp a convenient length of hose to the radiator core outlet opening, and attach another suitable length of hose to the radiator inlet opening to carry away the flushing stream.
- **3.** Connect the flushing gun to compressed air and water pressure, and clamp the gun nozzle to the hose attached to the radiator outlet opening.
- **4.** Fill the core with water. Turn on air pressure in short blasts to prevent core damage.
- 5. Continue filling the radiator with water and applying air pressure as above until the water comes out clear.
- 6. Clamp the flushing gun nozzle firmly to a hose attached securely to the engine water outlet opening. Fill the engine block with water, partly covering the water inlet opening to permit complete filling.
- 7. Turn on compressed air to blow out water and loose sediment. Continue filling with water and blowing out with air until flushing stream comes out clear.
- 8. When the vehicle is equipped with a water heater connected to the cooling system, flush the heater, following the same procedure as for the radiator core.
- **9.** After completing the flushing operation, clean out the surge tank overflow pipe; inspect the water pump; clean the thermostat and the radiator cap control valves. Check the thermostat for proper operation before installation.
- **10.** Blow insects and dirt from the radiator core air passages, using water, if necessary, to soften obstructions.

Component Inspection

Radiator/Surge Tank

- 1. Side Tanks Look for leaks, particularly where the tank is attached to the core. Vibration and pulsation from pressure can fatigue soldered seams.
- 2. Filler Neck The sealing seat must be smooth and clean. Cams on filler neck must not be bent or worn so

as to allow a loose fitting cap. Ensure the overflow tube is not plugged.

3. Radiator Cap - This is the pressure-setting type. Its purpose is to hold the cooling system under a slight pressure, increasing the boiling point of the cooling solution and preventing loss of solution due to evaporation and overflow.

The cap has a spring-loaded valve, the seat of which is below the overflow pipe in the filler neck. This prevents the escape of air or liquid while the cap is in position. When the cooling system pressure reaches a predetermined point, the cap valve opens and will again close when the pressure falls below the predetermined point.

When removing the pressure type cap, perform the operation in two steps. Loosening the cap to its first notch raises the valve from the gasket and releases the pressure through the overflow pipe. In the first stage position of the cap, it should be possible to depress the cap approximately 0.13 in (3 mm). The prongs on the cap can be bent to adjust this condition. Care must be taken that the cap is not too loose as this would prevent proper sealing.



Loosen cap slowly and pause a moment to avoid possible burning by hot water or steam. Continue to turn the cap to the left until it can be removed.

- 4. Tubes are very small and can easily become clogged by rust and scale. The general condition of the cooling system and operating temperature are indications as to whether or not tubes are clean. Another good test is to feel the core for cold spots.
- 5. Fins are thin metal sheets that dissipate heat picked up by the tubes. They should be kept free of bugs, leaves, straw etc., so as to allow the free passage of air. Bent fins should be straightened.

Engine Water Jacket

The water jacket permits coolant to be circulated around the cylinder walls, combustion chamber, and valve assemblies. Some of these coolant passages are small and can easily become clogged, if the cooling system does not receive the proper maintenance.

- Core Plugs These are sometimes mistakenly called freeze plugs. They do not provide protection against freezing expansion, but are only present because of engine block casting methods. Remove and replace
- **2.** core plugs that show signs of leaking or rusting through. Use an installation tool for core plug replacement.

- **3.** Drain Plugs The water jacket of each engine could have one or more drain plugs. These should receive seasonal care and be kept free of rust and scale.
- 4. Gaskets All gaskets must be in good condition to prevent both internal and external leaks. If there are external leaks around gaskets, there may also be internal leaks into the engine. Proper tightening of the head bolts with a torque wrench is essential for preventing leaks around the head gasket.

Water Pump

The pump should be checked carefully for leaks and proper lubrication. Replace or rebuild if leaking, cracked, or worn.

Fans and Belts

The fan should be checked for cracked or broken blades.

Refer to Engine Drive Belts, page 7-6.

Thermostat

The thermostat is of the nonadjustable type and is incorporated in the cooling system for the purpose of retarding or restricting the circulation of coolant during engine warm up. Engine overheating and loss of coolant is sometimes due to an inoperative thermostat. To check for this condition, remove the thermostat and test by submerging it in hot water and noting the temperature at which the thermostat opens and closes. Use an accurate high temperature thermometer for making this test.

Hoses and Clamps

Hoses and their connections must be checked regularly because they are often the source of hidden trouble. Hoses may often times appear in good condition on the outside while the inside will be partially deteriorated. If there are any doubts about a hose doing its job, replacement should be made. The clamps should be inspected to make sure they are strong enough to hold a tight connection.

Test Equipment

The antifreeze/coolant concentration must be checked using a refractometer. "Floating ball" type density testers or hydrometers are not accurate enough for use with heavy duty diesel cooling systems.

Antifreeze/Coolant


Heavy duty diesel engines require a balanced mixture of water and antifreeze/coolant. Fill the system with a AFC-50/ 50 blended, fully formulated extended life antifreeze/coolant at all times. Refer to Section 9 - LUBRICATION. Do not use more than 50 percent antifreeze/coolant in the mixture unless additional freeze protection is required. Never use more than 68 percent antifreeze/coolant under any condition. Antifreeze/coolant at 68 percent provides the maximum freeze protection; antifreeze/coolant protection decreases above 68 percent.

Radiator Removal and Installation

Removal

- 1. Set the outriggers and position the boom to over the side.
- 2. Open the drain cock at the end of the hose coming from the water pump (under the front of engine) and drain the coolant into a suitable container. Dispose of in accordance with local and EPA regulations.
- **3.** Tag and disconnect all hoses from the top, middle, and bottom sections of the radiator assembly.
- **4.** Remove the hardware attaching the fan guard to the shroud. The fan guard will remain with the engine.
- **5.** Remove the hardware securing the support plate on each side of the radiator.
- **NOTE:** The radiator assembly weighs approximately 44.4 kg (97.9 lb).
- 6. Attach an adequate lifting device to the radiator assembly.
- 7. Remove the hardware securing the radiator to the mount bracket and remove the radiator assembly from the carrier.





Item	Description
1	Radiator Assembly
2	Drain Cock
3	Fan Guard
4	Overflow Tank

Installation

- 1. Position the radiator assembly in the carrier using a lifting device and secure the radiator to the mount bracket with the hardware.
- **2.** Secure the support plates to each side of the radiator using a bolt.
- 3. Attach the fan guard to the shroud using the hardware.
- **4.** Connect all hoses to the radiator assembly as tagged during removal.
- 5. Ensure the drain cock is closed.
- 6. Service the engine coolant system, transmission oil system, and the hydraulic system as necessary. Start the engine, operate all systems and check for leaks.

DRIVE TRAIN

Description

The drive train consists of the transmission/torque converter assembly and three drive lines.

The transmission/torque converter is mounted to and driven by the engine. The torque converter assembly provides for mounting and driving the pumps. The transmission is a hydraulic range shift with six forward speeds and six reverse speeds. The transmission is controlled electrically by a shift lever/knob located on the right side of the steering column and an axle drive mode selector rocker switch located on the left side of the front console.

The transmission/torque converter oil is cooled by passing the oil through an externally mounted transmission cooler. The cooler is part of the radiator. An oil filter is located on the left side of the frame bottom rail.

Three drive lines are used. Two drive lines are connected between the transmission and the front axle and the other drive line is connected between the transmission/torque converter and the rear axle.

Maintenance

Drive Lines

CAUTION

Do not disassemble drive lines when removing them from the crane. Dirt can enter the spline and cannot be purged. In addition, the drive lines are assembled in a specific orientation when manufactured and can easily be incorrectly reassembled.

Removal

- 1. Support the drive line being removed so it does not fall when disconnected.
- 2. Remove the bolts from the bearing cap on each end of the drive line.
- 3. Remove the drive line.

Installation

- 1. Position the drive line, install the bearing cap bolts and tighten bolts securely.
- 2. Torque the inboard bearing cap bolts on the drive line to 85 to 112 Nm (63 to 83 lb-ft) and outboard bearing caps to 122 to 149 Nm (90 to 110 lb-ft).

Lubrication

The drive line slip joints require lubrication. Refer to Section 9 - Lubrication.

Transmission/Torque Converter

Description

The transmission/torque converter assembly is mounted to the engine and is connected to front and rear axles by two drive shafts. The main hydraulic pump is mounted on the torque converter housing.

Theory of Operation

The transmission and torque converter function together and operate through a common hydraulic system. Therefore, it is necessary to consider both units in discussing operation.

With the engine running, the converter charging pump draws oil from the transmission sump through the removable oil suction screen and directs it through the pressure regulating valve and oil filter.

The pressure regulating valve maintains pressure to the transmission control for actuating the direction and speed clutches. This requires a small portion of the total volume of oil used in this system. The remaining volume of oil is directed through the torque converter circuit to the oil cooler and returns to the transmission for positive lubrication. This regulator valve consists of a hardened valve spool operating in a closely fitted bore. The valve spool is spring loaded to hold the valve in a closed position. When a specific pressure is achieved, the valve spool works against the spring until a port is exposed along the side of the bore. This sequence of events provides the proper system pressure.

After entering the converter housing, oil is directed through the reaction member support to the converter blade cavity and exits in the passage between the turbine shaft and reaction member support. The oil then flows out of the converter to the oil cooler. After leaving the cooler, the oil is directed to a fitting on the transmission. Then, through a series of tubes and passages, lubricates the transmission bearings and clutches. The oil then gravity drains to the transmission sump.

The torque converter consists basically of three elements and their related parts to multiply engine torque. Engine power is transmitted from the engine flywheel to the impeller element through the impeller cover. This element is the pump portion of the hydraulic torque converter and is the primary component which starts oil flowing to other components causing torque multiplication. This element can be compared to a centrifugal pump, in that it picks up fluid at its center and discharges at its outer diameter.

The torque converter turbine is mounted opposite the impeller and is connected to the torque converter output shaft. This element receives fluid at its outer diameter and discharges at its center. Fluid directed by the impeller out into the particular design of blading in the turbine and reaction member is the means by which the hydraulic torque converter multiplies torque.



The reaction member of the torque converter is located between and at the center of the inner diameters of the impeller and turbine elements. Its function is to take the fluid which is exhausting from the inner portion of the turbine and change its direction to allow correct entry for recirculation into the impeller element.

The torque converter will multiply engine torque to its designed maximum multiplication ratio when the output shaft is at zero rpm. Therefore, as the output shaft is decreasing in speed, the torque multiplication is increasing.

The shift control valve assembly consists of a valve body with selector valve spools. A detent ball and spring in the selector spool provides one position for each speed range. A detent ball and spring in the direction spool provides three positions, one each for forward, neutral, and reverse.

With the engine running and the lever in the neutral position, oil pressure from the regulating valve is blocked at the control valve, and the transmission is in neutral. Movement of the forward and reverse spool will direct oil, under pressure, to either the forward or reverse direction clutch, as desired. When either directional clutch is selected, the opposite clutch is relieved of pressure and vents back through the direction selector spool. The same procedure is used in the speed selector.

The direction or speed clutch assembly consists of a drum with internal splines and a bore to receive a hydraulically actuated piston. The piston is oil tight by the use of sealing rings. A steel disc with external splines is inserted into the drum and rests against the piston. Next, a friction disc with splines at the inner diameter is inserted. Discs are alternated until the required total is achieved. A heavy back-up plate is then inserted and secured with a snap ring. A hub with OD splines is inserted into the splines of discs with teeth on the inner diameter. The discs and hub are free to increase in speed or rotate in the opposite direction as long as no pressure is present in that specific clutch.

To engage the clutch, the control valve is placed in the desired position. This allows oil under pressure to flow from the control valve, through a tube, to a chosen clutch shaft. This shaft has a drilled passageway for oil under pressure to enter the shaft. Oil pressure sealing rings are located on the clutch shaft. These rings direct oil under pressure to the desired clutch. Pressure of the oil forces the piston and discs against the heavy back-up plate. The discs, with teeth on the outer diameter, clamping against discs with teeth on the inner diameter, enables the hub and clutch shaft to be locked together and allows them to drive as a unit.

There are bleed balls in the clutch piston which allow quick escape for oil when the pressure to the piston is released.

Maintenance

General Information

- 1. Always check the oil level with the engine idling, and the transmission in neutral and at normal operating temperature (82 to 93°C [180 to 200°F]).
- **2.** Change the oil filter element every 500 hours. Drain and refill the system every 1000 hours or 6 months.

Troubleshooting

The following data is presented as an aid to locating the source of difficulty in a malfunctioning unit. It is necessary to consider the torque converter charging pump, transmission, oil cooler, and connecting lines as a complete system when checking for the source of trouble, since the proper operation of any unit therein depends greatly on the condition and operation of the others. By studying the principles of operation together with the data in this section, it may be possible to correct any malfunction which may occur in the system. Troubleshooting procedures basically consist of hydraulic checks.

Hydraulic Checks

Before checking transmission/torque converter and associated hydraulic system for pressures and rate of oil flow, it is essential that the following preliminary checks be made.

- Check oil level in transmission. This should be done with oil temperature at 82 to 93°C (180 to 200°F). Do not attempt these checks with cold oil.
- 2. To bring the oil temperature to this level, it is necessary to either work the machine or stall out the converter. When it is impractical to work the machine, stall out the converter as follows.
 - a. Apply the parking brake.
 - b. Position the shift lever to forward and high speed.
 - **c.** Accelerate the engine to between half and threequarter throttle.

CAUTION

Full throttle stall speeds for an excessive length of time will overheat the torque converter.

- **d.** Hold converter stalled until desired temperature is reached.
- **NOTE:** Make all troubleshooting checks with converter outlet temperature at least 82.3 to 93.3°C (180 to 200°F).

Troubleshooting Procedures

	SYMPTOM		PROBABLE CAUSE		REMEDY
1.	Low clutch pressure.	а.	Low oil level.	а.	Fill to proper level. Refer to Section 9 - LUBRICATION.
		b.	Clutch pressure regulating valve spool stuck open.	b.	Clean valve spool and housing.
	-	C.	Faulty charging pump.	C.	Replace pump.
		d.	Broken or worn clutch shaft or piston sealing rings.	d.	Replace clutch shaft or sealing rings, as applicable.
		e.	Clutch piston bleed valve stuck open.	e.	Clean bleed valves thoroughly.
2.	Low converter charging pump	a.	Low oil level.	a.	Fill to proper level.
	pressure.	b.	Suction screen plugged.	b.	Clean suction screen.
	-	C.	Defective oil pump.	c.	Replace pump.
3.	Overheating.	а.	Worn oil sealing rings.	a.	Remove, disassemble, and rebuild converter assembly.
	-	b.	Worn oil pump.	b.	Replace pump.
	-	c.	Low oil level.	c.	Fill to proper level.
4.	Noisy converter.	a.	Worn oil pump.	a.	Replace pump.
		b.	Worn or damaged bearings.	b.	A complete disassembly will be necessary to determine what bearing is faulty.
5.	Lack of power.	a.	Low engine RPM at converter stall.	а.	Tune engine and check governor.
			See "Overheating" and make same checks.	b.	Make corrections as explained in "Overheating."

Removal


- 1. Extend and set the outriggers just enough to take up the slack in the outrigger pads. Chock the wheels.
- 2. Position the boom over the side and stop the engine.
- **3.** Remove the engine and transmission/torque converter from the crane as an assembly. Refer to ENGINE in this Section.
- 4. Remove the hydraulic pumps from the transmission/ torque converter. Cover all openings. Refer to Hydraulic Pumps in Section 2 for removal of the pump.
- **NOTE:** The transmission/torque converter weighs approximately 374 kg (824.5 lb) dry.
- 5. Attach an adequate lifting device to the transmission/ torque converter and take up any slack.
- 6. Remove the hardware securing the drive plate assembly to the flywheel.

7. Remove the hardware securing the transmission/torque converter housing to the engine flywheel housing.

Installation

- **NOTE:** The transmission/torque converter assembly weighs approximately 374 kg (824.5 lb) dry.
- 1. If a new transmission/torque converter is to be installed, remove all fittings and brackets from the old one and install them in the same locations on the new transmission/torque converter.
- Install the piston and single section hydraulic pumps on the transmission/torque converter. Refer to Hydraulic Pumps in Section 2 for installation of the hydraulic pump.
- **3.** Position the transmission/torque converter to the engine with the lifting device.
- **4.** Remove all burrs from the flywheel mounting face and nose pilot bore. Clean the drive plate surface with solvent (Figure 7-11).





- 5. Check the engine flywheel and housing for conformance to standard S.A.E. No. 3-S.A.E. J-927 tolerance specifications for bore size, pilot bore runout and mounting face flatness. Measure and record engine crankshaft end play.
- 6. Install two 63.5 mm (2.50 in) long transmission to flywheel housing guide studs in the engine flywheel housing as shown in the figure titled Transmission/ Torgue Converter Installation. Rotate the engine flywheel to align a drive plate mounting screw hole with the flywheel housing front access hole.
- Install a 101.6 mm (4.00 in) long drive plate locating stud 0.3750-24 fine thread in a drive plate nut.
- 8. Rotate the transmission/torque converter to align the locating stud in the drive plate with the flywheel drive plate mounting screw hole positioned in step 6. Locate the transmission on the flywheel housing, aligning the drive plate to the flywheel and the transmission to the flywheel housing guide studs. Install the transmission to flywheel housing nuts and washers. Tighten the bolts to 41 to 43 Nm (30 to 32 lb-ft). Remove the transmission to engine guide studs. Install the two remaining bolts and washers and tighten the bolts to 41 to 43 Nm (30 to 32 lb-ft).
- Remove the drive plate locating stud. Install one drive 9. plate attaching screw and lockwasher. Snug the screw but do not tighten. NOTE: Some engine flywheel housings have a hole located on the flywheel housing circumference in line with the drive plate screw access hole. A screwdriver or pry bar used to hold the drive plate against the flywheel will facilitate installation of the drive plate screws. Rotate the engine flywheel and install the remaining seven flywheel to drive plate attaching screws and lockwashers. Snug the screws but do not tighten. After all eight screws and lockwashers have been installed, torgue the screws to 38 to 41 Nm (28 to 30 lb-ft). This will require torquing each screw, then rotating the engine flywheel until all eight screws have been torqued.
- **10.** Measure the engine crankshaft end play after the transmission/torque converter has been completely installed on the engine flywheel. This value must be within 0.025 mm (0.001 in) of the end play recorded in step 5.
- **11.** Install the engine and transmission/torque converter in the crane as an assembly. Refer to Section 7 POWER TRAIN.
- **12.** Service the crane as required in Servicing The Crane After Transmission/torque Converter Overhaul in this section.
- **13.** Cycle all functions and observe for proper operation.

Servicing Crane After Transmission/Torque Converter Overhaul

The transmission/torque converter and its allied hydraulic system are important links in the drive line between the engine and the wheels. The proper operation of either the unit or the system depends greatly on the condition and operation of the other; therefore, whenever repair or overhaul of the transmission/torque converter is performed, the balance of the system must be considered before the job can be considered completed.

After the overhauled or repaired transmission/torque converter has been installed in the crane, the oil cooler and connecting hydraulic system must be thoroughly cleaned. This can be accomplished in several ways, and a degree of good judgment must be exercised as to the method employed.

The following are considered the minimum steps to be taken:

- 1. Drain the entire system thoroughly.
- 2. Disconnect and clean all hydraulic lines. Where feasible, hydraulic lines should be removed from the machine for cleaning.
- **3.** Replace oil filter elements, cleaning out the filter cases thoroughly.
- 4. The oil cooler must be thoroughly cleaned. The cooler should be back flushed with oil and compressed air until all foreign material has been removed. Flushing in the direction of normal oil flow will not adequately clean the cooler. If necessary, the cooler assembly should be removed for cleaning, using oil, compressed air and a steam cleaner for that purpose.

CAUTION

Do not use flushing compounds for cleaning purposes.

5. Remove the drain plug from the transmission/torque converter and inspect the interior of the unit housing, gears, etc. If the presence of considerable foreign material is noted, it will be necessary for the unit to be removed, disassembled, and cleaned thoroughly. It is realized this entails extra labor, however, such labor is a minor cost compared to the cost of difficulties which can result from the presence of such foreign material in the system.



- 6. Assemble all components and use only the type oil recommended. Fill the transmission through the fill pipe until fluid is at the top of the fill range on the dipstick. Run the engine for two minutes at idle (950 rpm) to prime the torque converter and hydraulic lines. Recheck the level of oil in the transmission with the engine running at idle (950 rpm). Add oil as necessary to bring the level to the LOW mark on the dipstick. After the oil temperature reaches 82 to 93°C (180 to 200°F), add oil to bring the level to the FULL mark on the dipstick.
- **7.** Recheck all drain plugs, lines, connections, etc., for leaks and tighten where necessary.

Lubrication

Type Of Oil

Hydraulic Oil (HYDO) or equivalent. Refer to Section 9 - LUBRICATION.

Capacity

System Capacity (includes torque converter, lines, and transmission) - Approximately 24 I (25 qt).

Check Period

Check oil level every 10 hours or DAILY with engine running at 950 RPM and oil at 83 to 94°C (180 to 200°F). Maintain oil level to FULL mark.

Normal Drain Period

NOTE: Normal drain periods and filter change intervals are for average environmental and duty-cycle conditions. Severe or sustained high operating temperatures or very dusty atmospheric conditions will cause accelerated deterioration and contamination. For extreme conditions, judgment must be used to determine the required change intervals.

Every 500 hours, change oil filter element. Every 1000 hours or 6 months, drain and refill system as follows: Drain with oil at 66 to 93°C (150 to 200°F).

- **NOTE:** It is recommended filter elements be changed after 50 and 100 hours of operation on new and rebuilt or repaired units, then at normal intervals thereafter.
 - a. Drain transmission and remove pump screen. Clean screen thoroughly and replace, using a new gasket.
 - **b.** Remove and discard oil filters. Clean filter housing and install new filters.
 - c. Refill transmission to LOW mark.
 - **d.** Run engine at 950 RPM to prime converter and lines.
 - e. Recheck level with engine running at 950 RPM and add oil to bring level to LOW mark. When oil temperature is hot (83 to 94°C [180 to 200°F]), make final oil level check. BRING OIL LEVEL TO FULL MARK.

THIS PAGE BLANK



SECTION 8 UNDERCARRIAGE

SECTION CONTENTS

Axles	. 8-1
Description	. 8-1
Maintenance	. 8-2
Wheels and Tires	. 8-7
Steering Systems	. 8-8
Description	. 8-8
Theory of Operation	. 8-8
Maintenance	. 8-9
Rear Steering System	8-10
Hydraulic Pumps	8-11
Front Steering Control Valve	8-11
Integrated Outrigger/Rear Steer Manifold	8-11
Steer Cylinders	8-12
Rear Axle Oscillation Lockout System	8-13
Description	8-13
Axle Oscillation Lockout Cylinders	8-13
Brake System	8-14
Description	8-14
Theory of Operation	8-14

Maintenance8-1	5
Service Brakes	
Description8-1	6
Maintenance	6
Corrosion Protection 8-2	20
Parking Brake Actuator8-2	2
Description	2
Maintenance 8-2	2
Parking Brake 8-2	23
Description8-2	23
Maintenance	23
Park Brake Valve 8-2	24
Description	24
Outriggers8-2	24
Outrigger Circuit	24
Outrigger Beam 8-2	28
Extension Cylinder8-3	2
Jack Cylinder	3
Outrigger Control Valves	5

AXLES

Description

To provide maximum maneuverability, both the front and rear axles are steerable. The rear axle (Figure 8-1) is mounted on a pivoting cradle (fifth wheel) which allows the axle to oscillate while traversing uneven terrain. The front axle (Figure 8-2) is bolted directly to the frame. All four wheels utilize a hydraulic braking system. The axles are equipped with disc type brakes. A disc-type parking brake is mounted on the front axle input shaft, at the transmission.

Each axle incorporates a single reduction carrier with hypoid gearing mounted in the axle center. The final reduction is of planetary design spur gearing built into the wheel hubs.

The design of these axles permits the hypoid gearing of the differential carrier and the axle shafts to carry only a nominal torsional load while at the same time providing the highest practical numerical gear reduction at the wheels.

The hypoid pinion and differential assembly of the first reduction are supported by tapered roller bearings. The pinion bearing preload is adjusted and maintained by a hardened precision spacer between the inner and outer bearing. The differential tapered bearing preload is adjusted and maintained by the positioning of the threaded adjusting rings in the carrier leg and cap bores.

In the planetary wheel ends, the spur teeth of the sun gear mesh with teeth of the planet spur gears. The planet spur gears rotate on planet pins which are mounted in a spider. The planet spur gear teeth in turn mesh with teeth of the floating ring gear.

Power is transmitted by the hypoid gear set in the differential carrier to the axle shafts and the sun gear of the final reduction, through the revolving planet gears, and into the planetary spider which drives the wheel hub.

As an option, the front axle and rear axle may be provided with a differential lock. When in the locked mode, the axle shafts and the differential are locked together and there is no differential action between the wheels.

Maintenance

NOTE: The axles do not have to be removed from the crane to remove the planetary wheel ends or the drive units.

Removal

- **1.** Using the outriggers, raise the wheels off the ground.
- **2.** Install blocking under the frame at the outboard ends of the four outrigger boxes.


CAUTION

Do not disassemble drive lines when removing them from the crane. Dirt can enter the spline and cannot be purged. In addition, the drive lines are assembled in a specific orientation when manufactured and can easily be incorrectly reassembled.

- **3.** Disconnect and remove the drive line from the applicable axle. Do not disassemble the drive lines. Refer to *Power Train*, page 7-1.
- **4.** Tag, disconnect, and cap the hydraulic brake line at each wheel.
- **5.** Tag, disconnect, and cap the hydraulic lines to the steer cylinders.


- 6. On the left side of the rear axle only, tag and disconnect the electrical wires from the rear wheels not centered switch.
- **NOTE:** Each tire and wheel assembly weighs approximately 414 kg (912 lb).
- 7. Remove the tire and wheel assemblies from the axle.
- **NOTE:** Each axle weighs approximately 1053 kg (2321 lb) with oil.
- **8.** Position jacks, which are capable of handling the weight of the axle, under the axle for support.
- **9.** Remove the eight nuts, washers, and capscrews securing the axle to the frame/cradle (Figure 8-1) (Figure 8-2).
- **10.** Lower the axle to the ground and remove it to a clean working area.
- **11.** If a new axle is to be installed, remove the following from the old axle and install them on the new one.
 - **a.** The steer cylinders. Refer to Steer Cylinders in this section.
 - **b.** The rear wheels not centered switch actuator bracket (rear axle only).





Description
Cotter Pin
Pin
Pin
Lockout Cylinder
Steer Cylinder
Pin Weld
Pin Weld
Capscrew
Lockwasher
Flatwasher

Item	Description		
12	Capscrew		
13	Washer		
14	Hex Nut		
15	Capscrew		
16	Lockwasher		
17	Flatwasher		
18	Sensor Plate		
19	Capscrew		
20	Lockwasher		
21	Rear Axle		
22	Grease Fitting		
23	Flatwasher		



ltem	Description		
1	Front Axle		
2	Capscrew		
3	Hex Nut		
4	Washer		
5	Pin Weld		
6	Capscrew		
7	Lockwasher		

ltem	Description		
8	Flatwasher		
9	Steer Cylinder		
10	Pin Weld		
11	Grease Fitting		
12	Flatwasher		
13	Lockwasher		
14	Capscrew		



Cleaning

Completely assembled axles may be steam cleaned on the outside only, to facilitate initial removal and disassembly, providing all openings are closed. Breathers, vented shift units, and all other openings should be tightly covered or closed to prevent the possibility of water entering the assembly.

Installation

- 1. If a new axle is to be installed, remove the following from the old axle and install them on the new one.
 - **a.** The steer cylinders. Refer to Steer Cylinders in this section.
 - **b.** The rear wheels not centered switch actuator bracket (rear axle only).
- **2.** Position the axle under the crane on jacks which are capable of handling the weight of the axle.
- **3.** Raise the axle into place and secure with the eight attaching capscrews, washers and nuts. Torque the capscrews. Refer to *Fasteners and Torque Values*, page 1-12.
- **4.** Install the wheels onto the axle. Refer to Wheels and Tires in this section.
- 5. Connect the hydraulic lines to the steer cylinder as tagged during REMOVAL.
- 6. Connect the hydraulic brake line to each wheel as marked during removal.
- 7. On the left side of the rear axle only, connect the electrical wires to the rear wheels not centered switch. Refer to Rear Steer Indicator Adjustment in this subsection and adjust the switch.
- 8. Connect the drive line to the applicable axle. Refer to Drive Lines in Section 7 POWER TRAIN.
- **9.** Refer to Brake System in this section and bleed the hydraulic brake system.

10. Remove the blocking under the outrigger beams and retract the outriggers to lower the wheels to the ground.

Wheel Alignment Check Procedure


- 1. Check the axle for wheel alignment. The wheels are to be straight ahead with no toe-in or toe-out. Adjust if necessary by turning the tie rod ends in the direction necessary.
- 2. Turn the wheels to the extreme left. Check the clearance between the inside of the tire and the nearest object. If the clearance is less than 25 mm (1.0 in) on the rear axle or 13 mm (0.5 in) on the front axle, adjust the axle stop to provide clearance. Do not adjust axle stop if clearance is greater than 25 mm (1.0 in).

Check the steer cylinders to see that they are not bottomed out. To check the steer cylinders, remove the pin at the rod end and apply pressure to move the cylinder rod. The cylinder rod should travel a minimum of 3.0 mm (0.12 in).

3. Turn the wheels to the extreme right and repeat step 2 for the right side.

Rear Steer Indicator Adjustment Procedure

- 1. Ensure the wheels are straight ahead.
- **NOTE:** Refer to (Figure 8-3) to perform the following adjustments.
- 2. Ensure proximity sensor switch is centered in the slot of the sensor plate bolted to the top of the axle trunnion cap. Adjust by moving the sensor mounting bracket.
- **3.** Ensure a maximum gap of 5 mm (0.2 in) exists between the sensor switch and the sensor plate. Adjust by loosening switch mounting bolts and moving switch up or down on the mounting bracket. Tighten the mounting bolts.
- Turn the rear wheels to verify proper operation. The Rear Wheels Not Centered indicator in cab should not be illuminated when rear wheels are centered and the sensor switch is centered in the slot of the sensor plate.



ltem	Description		
1	Sensor Plate		
2	Proxy Switch		
3	Bracket		
4	Rear Steer Bracket Shim		
5	Capscrew		
6	Hex Nut		
7	Flat Washer		
8	Lock Washer		



Wheels and Tires

Description

The standard tire size for this unit is 20.5×25 -24 ply. A size 16.00×25 -28 ply tire is also available.

WARNING Possible equipment damage and/or personal injury!

Driving the crane with a tire under inflated at 80% or less of its recommended pressure can cause the wheel and/or tire to fail. Per OSHA Standard 1910.177(f)(2), when a tire has been driven under inflated at 80% or less of its recommended pressure, it must first be completely deflated, removed from the axle, disassembled, and inspected before re-inflation.

CAUTION

Do not mix tires and rims of different manufacturers.

Each wheel assembly (tire and rim) is mounted on the planetary hub with 12 grade 8 lug nuts.

NOTE: The tire diameters, widths, and weights may vary slightly depending on the tire manufacturer.

Off-highway tires are designed to operate with a certain sidewall deflection or bulge. Correct air pressure ensures prior deflection which, in turn, ensures proper traction, flotation, support of load, and prevents excessive flexing of the tire. Over inflation increases rim stresses, which results in lowered rim life.

Refer to and adhere to the inflation pressures in the Load Chart Book in the crane cab.


Maintenance

DANGER

Do not attempt to demount or mount tires without proper training. The high pressures involved can cause tire and rim parts and tools to fly with explosive force, if proper procedures are not used, causing severe injury or death to personnel and damage to the crane and surrounding area.

Mounting Wheel Assemblies

NOTE: Do not lubricate the wheel studs or lug nuts.



NOTE: Prior to wheel installation, remove any dirt or grease from wheel mounting surface.

- 1. Position the wheel assembly on the mounting studs being careful not to damage threads. Install the lug nuts and tighten them to 68 Nm (50 lb-ft) in the sequence shown in (Figure 8-4)
- 2. Ensure the wheel assembly is positioned properly on the hub.
- **3.** Torque the lug nuts 461 to 488 Nm (340 to 360 lb-ft) in the sequence shown in (Figure 8-4).
- 4. Retorque lug nuts after approximately one hour of travel.

STEERING SYSTEMS

Description

To maximize maneuverability, the crane can be steered by the front axle, the rear axle, or by the front and rear axles simultaneously. The crane utilizes two separate steering systems, one to control front axle steering and one for rear axle steering.

Front Steering System

NOTE: Pump figures in following text are theoretical.

The front steering system consists of a hydraulic pump, load sense steer priority flow divider valve (part of the swing directional control valve), load sense steering control valve, and two steer cylinders.

The hydraulic pump is driven by the engine and supplies a hydraulic flow of 82.9 l/min (21.9 gpm) to the load sense steering priority flow divider. The load sense steer priority flow divider valve provides 26.5 l/min (7 gpm) to the load sense steering control valve and the remainder to the swing system.

When the steering wheel is turned, the load sense steering control valve sends a load sense signal to the load sense steer priority flow divider. As the load sense pressure increases, the priority flow divider spool shifts to direct oil from the hydraulic pump to the steering control valve, and to direct oil from the L (left) port and R (right) port of the steering control valve to the steer cylinders.

Rear Steering System

The rear steering system is controlled through a section of the integrated outrigger/rear steer manifold and consists of the control valve and two steer cylinders. It is activated by the rear steer control switch located on the left armrest in the cab.

A rear steer indicator system is provided to indicate when the rear wheels are not centered. This system consists of an indicator light located on the CCS Main Screen display in the cab and a switch located on the right side of the rear axle. When the rear wheels are turned to the left or right, the amber indicator light will illuminate.

Theory of Operation

Front Steering System

A hydraulic oil flow from pump number 2 flows through port 5 of the hydraulic swivel to the steer/swing directional control valve. Regulated flow from the steer priority flow divider valve is routed to the steering control valve upon turning of the steering wheel and pressurizing of the load sense line. The steering control valve routes the oil to the appropriate ends of the front steer cylinders to turn the wheels in the desired direction.

Rear Steering System

Hydraulic flow from pump number 1 is directed through the integrated outrigger valve to the rear steer/outrigger manifold. When the rear steer control switch in the cab is positioned to steer left (push top of switch) or steer right (push bottom of switch), a signal is sent to the directional control valve spool, routing the supply pressure to the appropriate ends of the rear steer cylinders to turn the wheels in the desired direction.



Maintenance

Front Steering System

Troubleshooting

Table 8-1

	Symptom		Probable Cause		Solution	
1.	Hard to steer left and right.	a.	Hydraulic oil low.	a.	Refill hydraulic reservoir. Refer to Section 9 - LUBRICATION	
		b.	Clogged or loose hydraulic lines or fittings.	b.	Clean or tighten lines or fittings. (Refer to your Manitowoc Crane Care Parts Manual)	
		c.	Defective flow divider valve(s).	c.	Repair or replace valve(s).	
		d.	Defective steering control valve.	d.	Repair or replace valve.	
		e.	Defective hydraulic pump.	e.	Repair or replace pump.	
2.	Hard to steer either left or right.	a.	Clogged or loose hydraulic lines or fittings.	a.	Clean or tighten lines or fittings. Refer to Section 9 - LUBRICATION	
		b.	Defective steer cylinder.	b.	Repair or replace cylinder.	
3.	Steering is erratic left and right.	a.	Hydraulic oil low.	a.	Refill hydraulic reservoir. Refer to Section 9 - LUBRICATION.	
		b.	Clogged or loose hydraulic lines or fittings.	b.	Clean or tighten lines or fittings.	
		C.	Defective steering control valve.	C.	Repair or replace valve.	
		d.	Defective hydraulic pump.	d.	Repair or replace pump.	
4.	Noisy hydraulic pump caused by cavitation.	a.	Hydraulic oil low.	a.	Refill hydraulic reservoir. Refer to Section 9 - LUBRICATION	
		b.	Suction line plugged or too small.	b.	Clean line and check for size.	
5.	Hydraulic pump shaft seal	a.	Worn shaft seal.	a.	Replace shaft seal.	
	leakage.	NOTE:	If replacing the shaft seal does not stop leakage, the pump should be disassembled and checked for the following:			
		b.	Broken diaphragm seal or backup gasket.	b.	Replace seal or gasket.	
		C.	Bearing out of position.	C.	Replace bearing.	
		d.	Excessive internal wear.	d.	Replace pump.	

Functional Check

A normal periodic functional check of the entire steering system will generally be adequate to ensure satisfactory service.

- 1. Check all fittings for leakage. An accumulation of moist, black dirt is a good indication of leakage.
- 2. With the engine running at idle and at full throttle, and with the machine standing still and moving, turn the steering wheel through the full range of travel. Note any speed irregularities and sticky sensation. This may indicate dirt in the fluid. If the steering wheel continues to rotate when started and released, a condition known as Motoring exists. This may also indicate dirty fluid in the system.
- **3.** Ensure the system has adequate power. If there is an indication of hard steering, this can be caused by either

Rear Steering System

Troubleshooting

Table 8-2

a reduced oil flow to the control valve or a reduced system relief pressure. Adequate oil flow under all conditions can best be checked by timing the full travel of the cylinder with the steered axle unloaded and loaded. If there is a great difference at low engine speed and slight difference at high engine speeds this may indicate a defective pump. Adequate oil pressure can only be determined by connecting a pressure gauge (24 MPa/240 bar [3500 psi] full scale recommended) at the accessory manifold with swing directional valve gauge test port (GP5). With the engine running at a medium speed, turn the steering wheel to one end of the travel and hold the cylinders at the travel limit briefly, just long enough to read the pressure gauge. Never hold the system at relief pressure for more than a few seconds at a time. The pressure gauge should indicate 2500 psi (17.3 MPa).

Symptom	Probable Cause	Solution	
1. Rear steering inoperative.	a. Hydraulic oil low.	a. Refill hydraulic reservoir. Refer to Section 9 - LUBRICATION.	
	b. Clogged, broken, or loose hydraulic lines or fittings.	 b. Clean, tighten, or replace lines or fittings. 	
	c. Steer cylinder locked.	c. Repair or replace cylinders.	
	d. Defective control valve.	d. Repair or replace valve.	
	e. Defective steer cylinder(s).	e. Repair or replace cylinder(s).	
	f. Lack of electrical signal	f. Check electrical connections/ wiring	
2. Hard to steer left and right.	a. Hydraulic oil low.	a. Refill hydraulic reservoir.	
	 b. Clogged or loose hydraulic lines or fittings. 	 b. Clean or tighten lines or fittings. 	
	c. Defective steering control valve.	c. Repair or replace valve.	
	d. Defective hydraulic pump.	d. Repair or replace pump.	
	e. Clogged or loose hydraulic lines or fittings.	 Clean or tighten lines or fittings. 	
	f. Defective steer cylinder.	f. Repair or replace cylinder.	
	g. Damaged relief.	g. Replace relief valve.	



Symptom	Probable Cause	Solution		
3. Steering is erratic left and right.	a. Hydraulic oil low.	a. Refill hydraulic reservoir.		
	 b. Clogged or loose hydraulic lines or fittings. 	b. Clean or tighten lines or fittings.		
	c. Defective steering control valve.	c. Repair or replace valve.		
	d. Defective hydraulic pump.	d. Repair or replace pump.		

Hydraulic Pumps

Description

Front Steer

The hydraulic pump is mounted off of drive pads of the torque converter and driven by the engine. Pump number 2 provides the hydraulic flow necessary to power the front steer cylinders and swing circuit. The pump is a gear type pump that provides a flow of approximately 82.9 l/min (21.9 gpm).

Rear Steer

The hydraulic pump is mounted off of drive pads on the torque converter and is driven by the engine. Pump number 1 supplies oil to the integrated outrigger/rear steer valve, boom lift, telescope, hoist and pilot function. The pump is an axial piston pump that provides a flow of approximately 236.2 l/min (62.4 gpm).

Front Steering Control Valve

Description

The steering control valve is located under the dash and is actuated by a conventional steering wheel and steering column, providing precise, full hydraulic steering. Precise steering is accomplished by a metering system within the valve that is directly connected to the steering column and wheel.

Maintenance

Removal

- 1. Tag and disconnect the electrical connector to the valve.
- **2.** Tag and disconnect the hydraulic hoses from the valve. Cap or plug the lines and ports.
- **3.** Remove the capscrews and washers and remove the valve from the steering column.

Installation

- Secure the valve to the steering column and secure with the capscrews and washers. Torque the capscrews see Fasteners and Torque Values (pg 1- 12).
- 2. Connect the hydraulic hoses to the ports on the valve as tagged during removal.
- **3.** Connect the electrical connector to the valve as tagged during removal.
- 4. Verify proper operation of the valve.
- 5. Check valve and hydraulic connections for leaks. Make repairs as needed.

Integrated Outrigger/Rear Steer Manifold

The integrated outrigger/rear steer manifold controls the outrigger and rear steer circuit. The valve is mounted on the frame center section to the rear of the front axle.

The manifold is made up of two sections; an inlet section and a working section.

The inlet section contains a 17,200 kPa/172 bar (2500 psi) relief valve and a solenoid valve. The solenoid valve is normally open. It unloads the pump during cranking, and bypasses oil from the inlet port to the tank port. Activation of either the outriggers or the rear steer circuit energizes the solenoid valve to close and allow oil to flow to the selected circuit.

The rear steer section contains a three position four way solenoid controlled directional valve that controls left and right rear steer.

The outrigger section contains a three position four way solenoid controlled directional valve, two check valves and two load sense valves, that controls outrigger extend and retract.

Maintenance

Removal

- **1.** Tag and disconnect the electrical connectors to the valve.
- **2.** Tag and disconnect the hydraulic hoses from the valve. Cap or plug the lines and ports.

3. Remove the capscrews and washers securing the valve to the frame bracket. Remove the valve.

Installation

- 1. Secure the valve to the frame bracket with the washers and capscrews. Torque the capscrews see Fasteners and Torque Values (pg 1- 12).
- 2. Connect the hydraulic hoses to the ports on the valve as tagged during removal.
- **3.** Connect the electrical connectors to the valve as tagged during removal.
- 4. Verify operation as follows:
 - Operate the rear steer left and right to verify smooth operation.
 - On outriggers, swing over the front outriggers to ensure the oscillation cylinders lockout.
- 5. Check valve and hoses for leaks. Make repairs as needed.
- NOTE: For further information on the Integrated Outrigger/ Rear Steer Manifold, refer to Section 2 -HYDRAULIC and PRESSURE SETTINGS.

Steer Cylinders

Description

The steer cylinders are mounted on the axles, two cylinders on each axle. The barrel end of each cylinder is attached to the axle housing and the rod end is attached to the steering lug on the axle end. The front cylinders are controlled hydraulically by the steering control valve. The rear cylinders are controlled by the integrated outrigger/rear steer valve.

Maintenance

NOTE: For Disassembly and Assembly procedures, refer to Steer Cylinders in Section 2 - HYDRAULIC and PRESSURE SETTINGS.

Removal

- 1. Tag and disconnect the hydraulic lines going into the steer cylinder. Cap or plug all openings.
- 2. Remove the capscrews, flatwashers and spring lockwashers securing each pin weld in the rod end and barrel end of the cylinder.
- NOTE: Steer cylinder weighs approximately 9.07 kg (19.9 lb).
- 3. Remove both pin welds and two thrust washers (rod end only), and remove the cylinder from the axle.

Installation

- 1. Position the cylinder onto the attachment fittings on the axle and install both pin welds.
- 2. Secure each pin weld with the capscrew, flatwashers and spring lockwashers. Torque the capscrews see Fasteners and Torque Values (pg 1- 12).
- **3.** Connect the hydraulic lines to the cylinder as tagged during removal.
- **4.** Operate the steering system and check the cylinder for proper operation and any leakage.



REAR AXLE OSCILLATION LOCKOUT SYSTEM

Description

The rear axle oscillation system consists of two lockout cylinders, an axle lockout valve, an axle oscillation relay and an area potentiometer. The lockout cylinders are mounted between a cradle (fifth wheel) and the carrier frame. The axle oscillation lockout valve is located on the left inner center frame rail and hydraulically controls the lockout cylinders.

The area definition potentiometer in the electrical swivel energizes and deenergizes the axle oscillation relay. When the superstructure is more than 6 degrees left or right of directly over the front, the axle oscillation relay is deenergized.

When the axle oscillation relay's contacts are open, the normally closed solenoid valves are deenergized and isolate the lockout cylinders from hydraulic oil supply. This keeps the cylinders from oscillating (moving up and down to damp axle movement) because hydraulic oil cannot leave the cylinders. Instead, the cylinders remain full of hydraulic oil and more rigid.

When the axle oscillation relay's contacts are closed, the solenoid valves are energized and open. This allows hydraulic oil in and out of the cylinders, allowing them to oscillate.

NOTE: For further information on the lockout valve, refer to Section 2 - HYDRAULIC and PRESSURE SETTINGS.

Axle Oscillation Lockout Cylinders

Description

A 12.7 cm (5 inch) diameter bore lockout cylinder is installed on the left and right side of the rear axle. The barrel end of each cylinder is attached to each side of the carrier frame and the rod ends are attached to each side of the cradle (fifth wheel).

The lockout cylinders are connected hydraulically so that hydraulic oil flows from the rod side of the left cylinder to the barrel side of the right cylinder and from the rod side of the right cylinder to the barrel side of the left cylinder.

Maintenance

NOTE: For disassembly and assembly procedures, refer to Axle Oscillation Lockout Cylinder in Section 2 -HYDRAULIC and PRESSURE SETTINGS.

Removal

- 1. Raise the crane up on outriggers.
- 2. Rotate the turntable more than 6 degrees in either direction from directly over the front to lock out the oscillation cylinders.
- 3. Remove the wheel and tire assembly from the axle.
- 4. Tag and disconnect both hydraulic hoses from the ports on the cylinder. Cap or plug both hoses and the ports on the cylinder.
- **5.** At the rod end of the cylinder, remove one of the cotter pins securing the retaining pin to the cradle attach fitting.
- **6.** Tap out the retaining pin, freeing the rod end from the cradle.
- 7. At the barrel end of the cylinder, remove one of the cotter pins securing the retaining pin to the frame attach fitting.
- 8. Tap out the retaining pin and remove the cylinder.

Installation

- 1. Position the barrel end of the cylinder in the frame attach fitting and tap in the retaining pin.
- 2. Secure the retaining pin with the cotter pin.
- **3.** Align the rod end of the cylinder in the cradle attach fitting and tap in the retaining pin.
- 4. Secure the retaining pin with the cotter pin.
- 5. Remove the caps or plugs from the two hydraulic hoses and the cylinder ports and connect the hoses to the appropriate cylinder ports as tagged during removal.
- 6. Install the wheel and tire assembly on the axle. Tighten the lug nuts in accordance with the procedure in Wheel And Tire Assemblies in this section.
- **7.** Lubricate both ends of the cylinder using the fittings provided.

BRAKE SYSTEM

Description

The brake system includes all the components necessary for the application of the service brakes and the parking brake.

Service Brakes

The service brakes are full power hydraulic disc brakes which are hydraulically controlled and are used to apply the brake assemblies on all four wheels. The system consists of the tandem brake valve with treadle pedal, the dual accumulator charge valve, two hydraulic accumulators, the brake assemblies, and all the associated hoses and tubing. The operator depresses the pedal on the tandem brake valve, located on the cab floor, and the valve modulates the brake line pressure to the brake assemblies at each wheel. The full powered brake system supplies a high brake system pressure with relatively low reactive pedal forces, while controlling the maximum brake line pressure. The service brake dual accumulator charge valve regulates flow to the hydraulic accumulators to provide fully powered independently separate, primary (front) and secondary (rear), service brake circuits. Hydraulic pressure is constantly maintained in the brake circuits by the accumulators and the charging valve.

NOTE: For Description and Maintenance of the tandem brake valve with treadle pedal, the accumulators, and the dual accumulator charge valve, refer to VALVES in Section 2 - HYDRAULIC and PRESSURE SETTINGS.

Parking Brake

The parking brake is a hydraulic release, spring apply, disctype brake, located on the transmission. The system consists of a two-position switch, a three-way solenoid valve, actuator, one brake assembly, and all the associated hardware and tubing. The selector switch, located on the steering column in the cab, is used to activate the solenoid valve which controls the park brake actuator, which applies and releases the park brake.

Theory of Operation

Service Brakes

Braking begins when the operator depresses the brake pedal in the cab. Mechanical linkage transfers the force created by the lever action of the brake pedal to the hydraulic brake valve which modulates the brake line pressure to the brake assemblies at each wheel. Hydraulic oil from hydraulic pump number 2 flows to swivel port 5 to the accessory manifold to the dual accumulator charge valve. The dual accumulator charge valve charges the accumulators from the open center circuit upon demand and within its present operating charge rate and the high limit pressure setting. However, when the open center circuit pressure reaches the brake relief setting, which is higher than the high accumulator charge limit, then the accumulators will be charged to the regulated maximum pressure setting. The dual accumulator charge valve regulates flow to the hydraulic accumulators to provide fully powered independently separate, primary (front) and secondary (rear), service brake circuits. Hydraulic pressure is constantly maintained in the brake circuits by the accumulators and the charging valve. The charged accumulators supply pressurized fluid to the closed tandem brake valve.

After the accumulators are fully charged, the high limit check opens and all of the pump flow is directed to the excess flow port and on to the front steer and swing circuits. When pressure to the steering or swing circuit becomes greater than accumulator pressure, the main check valve opens and charges the accumulator without the aid of the charging valve. In this condition, the maximum accumulator pressure is the brake circuit relief valve setting of 16 MPa (2320 psi).

Once the operator depresses the brake pedal, the tandem brake valve modulates fluid out to the brakes to provide the means of braking. The tandem brake valve will modulate the pressure in the brake system by increasing or decreasing pressure as required in proportion to the input force from the operator via the brake pedal. The hydraulic force acts within the brake assemblies to force the brake pads against the brake discs, acting to slow wheel rotation. Fully powered separate primary (front) and secondary (rear) braking circuits are provided with independent accumulators. A low pressure warning switch is used to sense the accumulator pressures and warn the operator through visual brake warning indicator light on the cab console in the event the pressure in the accumulators drops to an unsafe operating level. In the event of engine failure, the accumulators are pre-charged with dry nitrogen gas and properly sized to provide power-off stopping capacity for secondary braking.

Parking Brake

Hydraulic flow from the transmission charge pump is routed to the parking brake control valve. When the PARK BRAKE switch is in the ON position, the parking brake solenoid valve shifts to route flow from the hydraulic parking brake actuator back to the transmission sump. The actuator spring pulls on the lever on the brake assembly, applying the parking brake.



Maintenance

Troubleshooting

Symptom	Symptom Probable Cause	
1. Brakes are poor.	a. Lining thickness less than 3mm (0.125 in).	a. Replace lining.
	b. Brake pedal operation.	b. Free mechanical linkage.
	c. Restriction or leaks in lines.	c. Check all lines for leaks and restrictions.
	d. Low hydraulic oil flow.	d. Check the hydraulic oil level in reservoir and check flow from the tandem brake valve.
	e. Air in brake lines.	e. Bleed the brakes.
	 f. Brake pads/linings are grease-soaked. 	f. Replace pads/linings.
	g. Engine not running.	g. Start engine. Due to the operation, the engine must be running to provide full brake power.
	h. Brake relief valve stuck open.	h. Replace the relief valve.
	i. Dual accumulator charge valve not charging	 Check valve operation and repair or replace valve.
	j. Accumulators not pre- charged.	j. Check accumulator pre- charge.
 Hard brake pedal with engine running. 	a. Pedal travel being interfered with.	 Check all pedal linkage and ensure it is free and adjusted properly.
3. Brakes lock up.	a. Too much hydraulic flow.	a. Check the flow from the flow divider. Too much flow will cause the brakes to be applied by the oil trapped in the power boost chamber.
	 b. Brake pedal push rod improperly adjusted, causing brakes to be always applied. 	 Adjust the push rod linkage so the brake pedal and push rod fully return.
4. Uneven braking or pad wear.	a. Lining thickness less than 3 mm (0.125 in).	a. Replace the lining.
	b. Grease on the pads/linings.	b. Replace the pads/linings.

General

A schedule for the periodic adjustment, cleaning, inspection, and lubrication of brake equipment should be established by the operator on the basis of past experience and severity of operation.

The disc brakes are not adjustable. Brakes should be cleaned, inspected, and linkage lubricated periodically to assure maximum performance.

Bleeding the Brake System

The brake system should be bled whenever air becomes entrapped within the brake system (usually characterized by a spongy feeling during brake pedal application), whenever any brake system line has been opened, or whenever any brake component has been replaced.

Always start at the point in the system that is furthest from the tandem brake valve and work back toward the tandem brake valve. Bleed every bleeder screw on every caliper/ actuator on every wheel. When you complete a bleeder screw, go to the next closest bleeder screw on the same caliper/actuator. When you complete a wheel, go to the furthest bleeder screw on the next closest wheel.

Pressure Bleeding the Brake System.

- **NOTE:** Before bleeding the brake system, ensure the hydraulic accumulators are fully charged.
- 1. Install the bleeding adapter.
- 2. Using a clean bleeding tank, fill the tank at least half full with hydraulic oil. Position the tank so it will not have to be moved again until all bleeding is finished.
- **3.** Connect a 241 kPa/2.4 bar (35 psi) air source to the bleeder tank.
- 4. Open the bleeder tank valve and bleed all air out of the hose to be connected to the adapter. Connect the bleeder hose to the adapter and open the bleeder valve.
- 5. Connect the end of the bleeder hose to the bleeder screw on the caliper/actuator. Submerge the other end in a glass jar partially filled with the proper type of clean hydraulic oil.
- 6. Open the bleeder screw and allow fluid to flow into the jar until it is a solid stream free of air bubbles. Close the bleeder screw and torque to 11.3 to 13.6 Nm (100 to 120 pounds-inch).
- 7. Repeat steps 5 and 6 for the remaining wheel calipers/ actuators.
- 8. Remove the air supply from the bleeder tank.
- **NOTE:** Close the bleeder tank valve and disconnect the hose and the bleeder adapter.
- 9. Remove the bleeder tank and hose.
- 10. Remove the bleeder adapter.

Manually Bleeding the Brake System

- **NOTE:** Before bleeding the brake system, ensure the hydraulic accumulators are fully charged.
- 1. Connect the end of the bleeder hose to the bleed screw on the caliper. Submerge the other end in a jar partially filled with clean hydraulic oil.
- 2. Open the bleed screw on the caliper/actuator and allow fluid to flow into the jar, while depressing the brake pedal. Depress the brake pedal and close the bleeder screw, then release the brake pedal. Torque the bleeder screw to 11.3 to 13.6 Nm (100 to 120 pounds-inch).

- **3.** Repeat step 2 until a solid stream free of air bubbles is obtained.
- 4. Repeat steps 1 thru 3 for the remaining wheel calipers/ actuators.

SERVICE BRAKES

Description

The brakes utilized on the axles are hydraulic disc-type brakes. Two brake assemblies are used at each wheel end on the front axle. One brake assembly is used at the wheel end on the rear axle. The action of the brake pads riding against the brake discs acts to slow the rotation of the wheels.


Maintenance

NOTE: To perform maintenance on the brake caliper, remove the tire and wheel assembly. Refer to AXLES in this section.

Removal

Linings

- 1. the caliper housing. Remove the end plates.
- 2. Loosen the bleeder screws to release hydraulic pressure in the caliper.



- **3.** Use a piece of wood against the linings as a pry bar to push the pistons completely into the housing. Tighten the bleeder screws (Figure 8-5).
- **4.** Remove the linings from the caliper housing. If necessary, discard the linings.




Caliper

- 1. Disconnect the hydraulic brake line from the inlet fitting on the caliper. Cap or plug all openings.
- 2. Remove the linings as described previously.
- 3. Remove the bolts securing the caliper housing to the mounting bracket. Remove the caliper housing from the mounting bracket. If shims are used mark the position of the shims.

Disassembly

Caliper


- 1. Remove the inlet fitting and o-ring from the cylinder cap.
- 2. Drain and discard the brake fluid.
- **3.** Clean the outside of the housing with isopropyl alcohol. Dry the housing with a clean cloth.
- **4.** If installed, remove the bolts that secure the end plates to the housing. Remove the end plates and linings.
- 5. Remove the pistons from the side of the housing opposite the mounting plate according to the following procedure.
 - **a.** Use a C-clamp to hold a 12.7 mm (0.5 in) block of wood against two pistons on the mounting side of the housing. Ensure the C-clamp is not in the area in front of the piston bore (Figure 8-6).




DANGER

Do not place hand in front of pistons when forcing them out. Serious personal injury may occur.


b. Apply compressed air to the inlet fitting to force the pistons out of the other housing. If one piston comes out before the other piston, put a piece of wood in front of the piston that comes out first. Apply compressed air to force the other piston out of the housing (Figure 8-7).




- **c.** Remove the wood block and the C-clamp from the housing.
- **d.** Remove the pistons from the bores that are opposite from the mounting plate.
- 6. Remove the two bleeder screws from the housing.
- 7. Remove the cylinder caps from the housing using an open end wrench. Remove and discard the O-rings (Figure 8-8).



8. Remove the pistons from the mounting plate side of the housing. Push on the ends of the pistons to force them out of the disc side of the housing (Figure 8-9).



- 9. Remove the dust seals from the housing.
- **10.** Remove and discard the O-ring and the backup rings (Figure 8-10).



- Inspect the ring grooves in the housing for scratches and rust. Remove small scratches and rust with emery cloth. Replace the housing if there are large scratches or large amounts of rust. Refer to Inspection - Caliper Parts.
- 12. Inspect the pistons and the bores for scratches and rust. Remove small scratches and rust with emery cloth. Replace the components if they are worn or if there are large scratches or large amounts of rust. Refer to Inspection - Caliper Parts.

Inspection


Periodic On-Vehicle

Inspect the caliper, linings, and disc for any damage.

Shoes, Linings, and End Plates

Remove the shoes and linings. To help prevent abnormal lining wear, replace worn, bent, or cracked end plates and distorted backing plates. Inspect end plate bolts for wear. Replace the bolts if worn. Inspect the linings for:

- Lining Wear. Replace the linings when the thickness of the lining is less than 3.2 mm (0.125 in) from the back plate (Figure 8-11).
- Lining Wear Not Even. Replace the linings if the thickness of the two linings is significantly different. Check the pistons for correct operation. Replace the piston and/or housing if a piston is cocked in the bore. Check that the disc surface is flat and parallel to the linings (Figure 8-11).




- Oil or Grease on Linings. Replace the linings.
- Cracks on Linings. Replace linings that have large or deep cracks.
- **NOTE:** Small, tight cracks on the surface of the lining are normal when the caliper is used under high temperature conditions.

Caliper for Leaks

Inspect the following areas for fluid leaks (Figure 8-12).





- **Pistons.** If fluid leaks at a piston, disassemble the caliper. Inspect the piston, the bore, the o-rings, and back-up rings. Service as necessary.
- Cylinder Cap. If fluid leaks at a cylinder cap, tighten the cylinder cap, the inlet fitting, and the plug. If the leak continues, disassemble the caliper. Inspect the cylinder cap threads, the housing threads, and the o-ring. Service as necessary.
- **Bleeder Screw.** If fluid leaks at the bleeder screw, tighten the bleeder screw. If the leak continues, replace the bleeder screw.
- Inlet Fitting. If fluid leaks at the inlet fitting, tighten the fitting. If the leak continues, replace the o-ring.


Dust Seals

Ensure the dust seals are soft and flexible. Disassemble the caliper and replace dust seals that are hard or damaged.

Disc


GROVE

If the disc is worn beyond the wear limits, replace the disc (Figure 8-13).




Caliper Parts

- Inspect the pistons, housing bores, and o-ring grooves for scratches or corrosion. Remove small scratches or corrosion with fine emery cloth. Replace the components if they are worn beyond wear limits or if there are large scratches or large amount of corrosion.
- 2. Measure the diameter of the piston. Replace the piston if the outer diameter is worn less than 76.073 mm (2.995 in) (Figure 8-14).



8

3. Measure the diameter of the housing bore. Replace the housing if the diameter is worn to more than 76.276 mm (3.003 in) (Figure 8-15).



- 4. Inspect the linings as described previously.
- 5. Inspect the threads of the caliper, cylinder caps, and all fittings. Replace any component that has thread damage that cannot be repaired.
- 6. Discard all back-up rings, o-rings, and dust seals. Use new ones when assembling the caliper.

Cleaning



Use of cleaning solvents, hot solution tanks, or alkaline solutions incorrectly, can cause serious personal injury. To prevent serious personal injury, follow the instructions supplied by the manufacturer of these products. Do not use gasoline to clean parts. Gasoline can explode and cause serious personal injury.

CAUTION

Use only solvent cleaners to clean ground or polished metal parts. Hot solution tanks or water and alkaline solutions will damage these Parts. Isopropyl alcohol, kerosene, or diesel fuel can be used for this purpose.

• Use solvent cleaners to clean all metal parts that have ground or polished surfaces. Examples of ground or polished parts are the piston and the piston bore in the caliper.

- Metal parts with rough surfaces can be cleaned with solvent cleaners or with alkaline solutions.
- Use a wire brush to clean the threads of fasteners and fittings.
- Use soap and water to clean parts that are not made of metal.
- Scrape away build-ups of mud and dirt on the linings. Replace all linings contaminated with oil or grease.
- Immediately after cleaning, dry all parts with clean paper or rags.

Corrosion Protection

Apply brake system fluid to the cleaned and dried parts that are not damaged and are to be immediately assembled. **Do Not** apply fluid to the brake linings or the disc.

If parts are to be stored, apply a special material that prevents corrosion to all surfaces. **Do Not** apply the material to the brake linings or the disc. Store the parts inside special paper or other material that prevents corrosion.

Assembly

Caliper

CAUTION

Use only specified components when assembling the calipers. Do not mix components from other calipers. Installing the wrong components may cause the caliper not to operate correctly and may cause damage to equipment. Use of non manufacturer's parts can cause damage, loss of braking, and serious personal injury.


- **NOTE:** The o-rings, back-up rings, pistons, and bores must be lubricated before installing the pistons.
- Lubricate all pistons, bores, o-rings, and back-up rings with silicone grease. If silicone grease is not available, use the same type of fluid that is used in the brake system.
- 2. Install new o-ring and a new back-up ring in the groove in the middle of the bore. The o-ring is installed toward the outboard end of the bore. The back-up ring is installed toward the lining side of the bore (Figure 8-16).

CAUTION


Do not use silicone grease on the dust seal.

3. Install a new dust seal in the top groove of the bore (Figure 8-16).






4. Install the pistons in the housing. Push the pistons in from the lining side of the housing. Ensure the pistons are straight in the bores. Push each piston into the bore until the top of the piston is even with the top of the dust seal (Figure 8-17).



5. Install a new o-ring in the groove of the cylinder cap. Ensure the o-ring is not cut by the threads on the cylinder cap.

- **NOTE:** Apply extra grease on o-ring before installing cylinder caps. this will keep o-ring from catching on threads as cylinder cap is threaded into housing.
- 6. Install the cylinder caps in the caliper housing. Tighten the cylinder caps to 102 Nm (75 pounds-foot) minimum as shown in (Figure 8-18).



- 7. Install the bleeder screws in the housing. Tighten to 11.3 to 13.6 Nm (100 to 120 pounds-inch).
- 8. Install the o-ring and the inlet fitting in the cylinder cap.

Installation

Linings


CAUTION

Always replace both linings. If only one lining is replaced, possible disc damage can occur.

- 1. Install the linings in the caliper housing.
- Position the end plates on the housing and secure with bolts. Apply Loctite 271 or equivalent to the bolt threads. Tighten the bolts to 224 to 285 Nm (165 to 210 poundsfoot).
- **3.** Ensure the linings move freely in the housing.
- 4. Bleed the brake system.
- 5. Apply and release the brakes three times to ensure the caliper operates correctly. Check for fluid leaks. Ensure the linings move freely.

Caliper

- 1. Position the caliper housing on the mounting bracket. If shims where used, place them as marker during removal.
- 2. Secure the caliper housing with the bolts and tighten them to 678 to 813 Nm (500 to 600 lb-ft).
- 3. Install the linings. Refer to INSTALLATION Linings.
- 4. Ensure the housing is installed correctly on the mounting bracket. The disc must be within ± 1.5 mm (± 0.06 in) of being centered between the lining end plates.
 - **a.** To increase outboard clearance and decrease inboard clearance, install a shim either between the housing and mounting bracket or between the hub and disc.
 - **b.** The shims must be steel, ground flat, and parallel and must cover the entire mounting surface of the hub or housing. The linings must move freely in the housing and between the end plates (Figure 8-19).



- 5. Connect the hydraulic brake line to the inlet fitting.
- 6. Bleed the brake system.
- 7. Apply and release the brakes three times to ensure the caliper operates correctly. Check for fluid leaks. Ensure the linings move freely.

PARKING BRAKE ACTUATOR

Description

The spring-applied, hydraulically-released parking brake actuator is located on the transmission and is used to apply and release the parking brake.

Maintenance

Removal

1. Chock the wheels to prevent crane movement.

CAUTION

Do not exceed 1861.5 kPa/18.6 bar (270 psi) hydraulic pressure to avoid damage to the brake. 1172.1kPa/11 bar (170 psi) is required to fully release the brake.

- 2. Start the engine, ensure the transmission is in neutral, and position the Park Brake switch to Off. This will pressurize the brake actuator to release the tension on the brake linkage. Engine must remain running.
- **3.** Remove the capscrews securing actuator to the brake caliper. Slide the actuator off the actuator rod.
- **4.** Position the Park Brake switch to On (press top of switch) and shut down the engine.
- 5. Disconnect the hydraulic line from the brake actuator, then cap or plug all openings.

Installation

- **NOTE:** Mount brake so that the linings are parallel with the disc within 0.381 mm (0.015 inch). Disc is to be located the proper distance from the mounting surface per assembly drawing.
- 1. Slide brake over disc and into mounting position.
- **2.** Start hex mounting bolts into mounting surface far enough to just support the brake.
- Remove plug, loosen the coupling nut and then tighten socket setscrew until linings are clamped to the disc. This locates and holds the brake in the proper position to set the hex mounting bolts and hex nuts.
- 4. Tighten hex mounting bolts until they make contact with the urethane springs, then tighten 4 flats approximately 1.778 mm (0.07 inch) more. This puts the proper amount of pre-load on the urethane springs.
- 5. Tighten jam nut/sleeves against mounting surface and torque 271 Nm (200 lb-ft).

CAUTION

Brake linings are susceptible to contamination. When installing or servicing brakes, keep all oil and fluids away from linings. Poor brake performance may result if linings are contaminated.



- **6.** Attach brake line to inlet port located on top of the hydraulic cylinder.
- 7. Apply hydraulic pressure to the brake.
- 8. With plug removed, loosen coupling nut and set running clearance to 0.5 to 0.7mm (0.020 to 0.030 inch) total by adjusting the socket setscrew. Torque the coupling nut while holding the socket setscrew in position. Torque nut 68 to 75 Nm (50 to 55 ponds-foot).
- **9.** replace plug. Torque plug 61 to 68 Nm (45 to 50 poundsfoot).
- **10.** Even up running clearance to 0.25 to 0.3 mm (0.010 to 0.015 inch) each side by adjusting the socket head capscrew.
- **NOTE:** Re-adjust the brake when running clearance reaches a total of 2.54 mm (0.100 inch).
- **11.** Position the Park Brake switch to On (press top of switch) and shut down the engine.

Adjustment

1. Chock the wheels to prevent crane movement.

CAUTION

Do not exceed 1861.5 kPa/18.6 bar (270 psi) hydraulic pressure to avoid damage to the brake. 1172.1kPa/11 bar (170 psi) is required to fully release the brake.

- 2. Start the engine, ensure the transmission is in neutral, and position the Park Brake switch to Off (press bottom of switch). This will pressurize the brake actuator to release the tension on the brake linkage. Screw the caging nut up under the actuator chamber.
- **3.** Install the rod ball joint until the ball joint will just connect to the brake linkage with the brake lever in a horizontal position.
- 4. Lock the rod ball joint with the jam nut and back off the caging nut.
- 5. Position the Park Brake switch to On (press top of switch) and shut down the engine.

PARKING BRAKE

Description

The parking brake is mounted on the transmission. The brake is a disc-type brake that is controlled by a switch on

the front console in the cab and is spring-applied and hydraulically released by an actuator.

Maintenance

Removal

1. Chock the wheels to prevent crane movement.

CAUTION

Do not exceed 1861.5 kPa/18.6 bar (270 psi) hydraulic pressure to avoid damage to the brake. 1172.1kPa/11 bar (170 psi) is required to fully release the brake.

- 2. Start the engine, ensure the transmission is in neutral, and position the Park Brake switch to Off (press bottom of switch). This will pressurize the brake actuator to release the tension on the brake linkage. Screw the caging nut up under the actuator chamber.
- **3.** Position the Park Brake switch to On (press top of switch) and shut down the engine.
- 4. Tag and disconnect the hydraulic hose from the actuator. Cap or plug all openings.
- 5. Unthread the two mounting bolts securing the brake assembly to the mounting bracket, then carefully remove the brake assembly from the mounting bracket and the brake disc.

Installation

- 1. Position the brake over the disc and align mounting bracket holes.
- 2. Thread the mounting bolts into the mounting bracket until the caliper is centered over the brake disc.
- **3.** Torque the jam nuts to 136 to 163 Nm (100 to 120 footpounds) against the mounting bracket.
- 4. Connect the hydraulic hose to the actuator.
- 5. Start the engine, ensure the transmission is in neutral, and position the Park Brake switch to Off (press bottom of switch). This will pressurize the brake actuator to release the spring tension. Unscrew the caging nut from under the actuator chamber.
- **6.** Position the Park Brake switch to On (press top of switch) and shut down the engine.

PARK BRAKE VALVE

Description

The range shift/parking brake valve controls the flow of oil to the parking brake, hi-low range and axle disconnect actuators by the use of two solenoid valves. The valve is located on the center of the frame. Pressure is supplied to the valve from the transmission charge pump.

The parking brake solenoid valve is a two position three-way valve. In its de-energized position, the inlet port is blocked and the parking brake actuator is drained to the reservoir. When the solenoid is energized, the reservoir port is blocked and pressurized oil is directed to the actuator, engaging the parking brake.

The range shift solenoid valve is a two position four-way valve. In its de-energized position, pressurized oil flows to the "B" port of the range shift actuator, while the "A" port is drained to the reservoir along with the axle disconnect actuator for two wheel drive/high range. When the solenoid is energized, pressurized oil is directed to the "A" port of the range shift actuator and the axle disconnect actuator while port "B" of the range shift actuator is drained to the reservoir for four wheel drive/low range.

Removal

- 1. Tag and disconnect the electrical connectors to the valve.
- **2.** Tag and disconnect the hydraulic hoses from the valve. Cap or plug the lines and ports.
- **3.** Remove the capscrews, lockwashers, flatwashers and nuts securing the valve to the frame. Remove the valve.

Installation

- 1. Secure the valve to the frame with the nuts, flatwashers, lockwashers and capscrews. Torque the capscrews 25 to 27 Nm (18 to 20 lb-ft).
- 2. Connect the hydraulic hoses to the ports on the valve as tagged during removal.
- **3.** Connect the electrical connectors to the valve as tagged during removal.

Functional Tests

- 1. Start and idle engine.
- 2. With units on outriggers, check for proper two/four wheel operation.
- **NOTE:** For further information on the park brake valve, refer to Section 2 HYDRAULIC and PRESSURE SETTINGS.

OUTRIGGERS

Outrigger Circuit

Description

The outrigger circuit consists of four extension cylinders, four jack cylinders, an integrated outrigger/rear steer valve, front and rear outrigger control manifolds, pilot operated check valves and four Outrigger Monitoring System (OMS) (Optional-Standard in North America) string potentiometers. The front two extension cylinders are mounted in the front outrigger beams and the rear two extension cylinders are mounted in the rear outrigger beams. The front and rear outrigger beams are mounted in their respective outrigger boxes; in turn a jack cylinder is mounted on the end of each outrigger beam. The integrated outrigger/ rear steer valve is mounted on the front face of the carrier frame front cross member. The front and rear outrigger control manifolds are mounted on the inside center of their respective outrigger box. An OMS string potentiometer (if equipped) is mounted inside each outrigger box. The potentiometer is connected by a cable to the outrigger beam to monitor the beam's horizontal position-fully retracted, mid-extend, or full extended.

The outrigger selector controls are located in the cab on the CCS display or jog dial. Both the integrated outrigger valve and the manifold solenoid valves are electrically actuated from these controls. The solenoid switches must be depressed and held to actuate the solenoid valves. The integrated outrigger valve switch is spring loaded to the off position. The console is placarded with switch positions.

A sight bubble level is mounted on the right side of the cab. The sight bubble level provides the operator with a visual indication of crane level attitude.

Theory of Operation

NOTE: Refer to Section 3 - OPERATING CONTROLS and PROCEDURES in the Operator's Manual for operation of the outrigger switches.



Maintenance

Troubleshooting

Symptom	Probable Cause	Solution
1. Slow or erratic operation of outrigger extension cylinders.	a. Damaged relief valve.	a. Remove relief valve; clean or replace.
	b. Low hydraulic oil.	 b. Replenish oil to proper level. Refer to Section 9 - LUBRICATION
-	c. Sticking solenoid valve spool.	c. Repair or replace valve spool.
-	 Improper ground to base of solenoid. 	d. Ground properly.
	e. Damaged O-rings and swivel	e. Remove swivel and replace O-rings.
	 f. Directional selector switch sticking. 	f. Clean or replace switch.
	g. Collector ring dirty or glazed.	g. Clean and deglaze collector ring.
	h. Damaged wiring to solenoid.	h. Replace wiring.
	 Weak brush springs on collector ring. 	i. Replace brush springs.
-	j. Damaged extension cylinder (internal parts).	 Remove extension cylinder and repair as necessary.
	k. Bent cylinder rods.	 k. Replace piston rods and seals.
	I. Excessive material on outrigger beams.	I. Clean outrigger beams.
6.05	m. Binding outrigger beam.	 m. Repair or replace outrigger beam.
	n. Damaged outrigger valve.	n. Repair or replace valve.
	o. Damaged valve coil.	o. Replace coil.
	 p. Main hydraulic pump cavitation. 	 p. Replace or tighten hose or fitting.

Symptom	Probable Cause	Solution
Slow or erratic operation of outrigger extension cylinders. (continued)	 q. Partially shifted hydraulic spool in selector valve or manifolds. 	q. Disassemble, clean, and polish spool and valve housing with very fine emery cloth (water paper).
	 Insufficient voltage for operation of solenoid valve. 	 Solenoids require a minimum of 9.5 volts to energize. Check outrigger wiring and electrical coupling collector rings.
	s. Damaged piston seals.	s. Replace all cylinder seals.
	t. Worn or damaged hydraulic pump section.	t. Repair or replace pump section.
	u. Scored cylinder barrel.	u. Repair or replace extension cylinder.
	v. Cracked or damaged piston.	v. Replace rod weld and all cylinder seals.
	w. Piston loose on piston rod.	w. Replace all cylinder seals and torque piston locknut.
2. Sticking spool.	a. Dirt in the system.	a. Change oil and flush system.
	b. Distortion caused by tie bolts being overtorqued.	b. Retorque tie bolts.
	c. Flow in excess of valve rating.	c. Limit flow through valve to that recommended. Check pump output and cylinder ratio.
	d. Pressure in excess of valve rating.	 Check relief valve setting or pump compensation with that recommended.
	e. Electrical failure.	e. Check wiring and solenoids.
3. External leakage.	a. Damaged O-ring or quad rings.	a. Check for chipped packings and replace.
	b. Loose tie bolts.	b. Retorque tie bolts.
	c. Damaged solenoid.	c. Replace damaged parts.
4. Solenoid failure.	a. No current.	a. Check power source of at least 85% of coil rating.
	b. Damaged solenoid assembly.	b. Replace solenoid.
	c. Short in solenoid.	c. Replace coil.
	d. Loss of solenoid force.	d. Decrease time of solenoid energization, decrease cycle rate.



	Sympt	om			Probable Cause		Solution
5. Out	trigger jack	cylinder	slow or	a.	Low in hydraulic oil.	a.	Replenish oil to proper level.
erra	atic.		-	b.	Damaged main relief valve.	b.	Repair or replace valve.
			-	C.	Damaged holding valve seals.	c.	Replace holding valve seals.
				d.	Bent cylinder rod.	d.	Replace cylinder rod and seals.
				е.	Bent outrigger housing.	e.	Repair or replace outrigger housing.
				f.	Excessive material on beams.	f.	Clean outrigger beams.
				g.	Sticking solenoid valve spool.	g.	Repair or replace valve spool.
				h.	Damaged wiring to solenoid.	h.	Repair or replace wiring.
				i.	Weak brush springs on collector rings.	i.	Replace brush springs.
				j.	Collector ring dirty or glazed.	j.	Clean or deglaze collector ring.
			Î	k.	Directional selector switch sticking.	k.	Clean or replace switch.
				I.	Main hydraulic pump cavitation.	I.	Replace or tighten hose and fittings.
				m.	Worn or damaged hydraulic pump section.	m.	Repair or replace pump section.
	trigger jack	cylinder	retracts	a.	Damaged piston seals.	a.	Replace all cylinder seals.
und	der load.			b.	Damaged holding valve seals.	b.	Replace seals.
				C.	Damaged holding valve.	C.	Replace valve assembly.
				d.	Scored cylinder barrel.	d.	Repair or replace cylinder.
				e.	Cracked or damaged piston.	е.	Replace piston and all cylinder seals.
	trigger jack	-		a.	Damaged piston seals.	a.	Replace all cylinder seals.
whi	ile machine is	traveling].	b.	Scored cylinder barrel.	b.	Replace jack cylinder.
				c.	Cracked or damaged piston.	C.	Replace piston and seals.
			Ĭ	d.	Piston loose on cylinder rod.	d.	Replace seal and retorque.
	trigger syster			a.	Hydraulic oil low.	a.	Replenish system.
•	om stowed o wn position).	or exten	aed and	b.	Loose or broken wire on switch.	b.	Repair or replace wiring.
				с.	Clogged, broken, or loose lines or fittings.	C.	Clean, tighten, or replace lines or fittings.
				d.	Damaged relief valve or damaged control valve.	d.	Repair or replace valve.

Symptom	Symptom Probable Cause			
9. Outrigger system activates, but selected outrigger will not stow or	 Clogged, broken, or loose hydraulic lines or fittings. 	 a. Clean, tighten, or replace lines or fittings. 		
extend and lower as desired.	 b. Loose or broken wire on control switch or solenoid valve. 	b. Repair or replace wiring.		
-	c. Damaged solenoid valve.	c. Repair or replace valve.		
-	d. Damaged control switch.	d. Replace switch.		
-	e. Damaged hydraulic cylinder.	e. Repair or replace cylinder.		
10. Outriggers will not set.	a. Improper sequence of activation.	a. Activate individual control switch; then activate system control switch.		
11. Two outriggers activate from single control switch.	a. Damaged solenoid valves.	a. Repair or replace.		
12. The two outriggers will not stow.	a. Hydraulic lock.	a. Recycle individual outrigger(s).		
13. Individual outrigger will not set or	a. Damaged piston seals.	a. Replace seals.		
stow.	b. Damaged check valve.	b. Repair or replace valve.		
	c. Loosen or broken wire on control switch or solenoid valve.	c. Repair or replace wiring.		
-	d. Damaged solenoid valve.	d. Repair or replace valve.		

Outrigger Beam

Description

The outrigger beam assembly (Figure 8-20) consists of an outrigger beam, a jack cylinder, an extension cylinder, an Outrigger Monitoring System (OMS) (Optional—Standard in North America), string potentiometer, and the required hoses and mounting hardware.

Theory of Operation

When the outrigger extension is activated, it extends or retracts the outrigger beam within the outrigger box. The outrigger beam can be extended to the mid-extend position by allowing the lock pin to ride on the top of the beam while it's extending. The lock pin will automatically drop into the hole when the beam reaches the mid-extend position.

The stabilizer cylinder is mounted to the end of the beam and applies force to the outrigger beam vertically. This sequence of events provides for lifting and stabilizing the crane for operation.

The jack cylinder is mounted to the end of the beam and applies force to the outrigger beam vertically. This sequence of events provides for lifting and stabilizing the crane for operation.

Maintenance

Removal


- 1. On the jack cylinder end of the beam, remove the set screw from the side adjustable wear pad and back off the wear pad from the outrigger box.
- 2. Remove the cover from the opposite end of the outrigger box. Remove the setscrew from the side adjustable wear pad and back off the wear pad from the beam.
- **3.** Remove the setscrews from the bottom adjustable wear pads and back off the wear pads leaving approximately 6 mm (0.23 in) protruding
- **4.** Extend the outrigger slightly to facilitate attaching a lifting device to the outrigger beam.



Be sure any blocking material used is capable of supporting the weight of the outrigger beam. Do not allow it to tilt or slide. Failure to do so could result in death or injury to personnel.


5. Place blocking material under the outrigger beam.






ltem	Description		lte
1	Outrigger Box Assembly	-	10
2	Hex Nut	-	11
3	Capscrew	-	12
4	Pin	-	13
5	Hex Nut	-	14
6	Capscrew	-	15
7	Adjusting Plate	-	16
8	Hex Nut	-	17
9	Setscrew	-	18

ltem	Description
10	Capscrew
11	Plate
12	Wear Pad
13	Flatwasher
14	Cotter Pin
15	Clevis Pin
16	Extension Cylinder
17	Cover
18	Jack Cylinder



m	Description	Item	Description
	Jack Cylinder	5	Jack Cylinder Retract Port
	Extension Cylinder	6	Extension Cylinder Retract Port
	Outrigger Beam	7	Extension Cylinder Extend Port
	Jack Cylinder Extend Port	8	OMS Potentiometer





- **6.** Tag and disconnect the hydraulic lines at the cylinder barrel end of the extension cylinder. Cap all lines and fittings.
- **NOTE:** Do not allow the end of the outrigger extension cylinder to fall when the cylinder mounting shaft is removed. Use blocking to limit the drop or an adequate soft support to cushion any distance the rod will drop.
- 7. Remove the cotter pin and clevis pin securing the cylinder barrel end of the extension cylinder to the outrigger housing. Carefully extend the outrigger beam until the extension cylinder is free of the housing and carefully lay the end of the cylinder on the bottom of the outrigger beam or leave on blocking.
- **NOTE:** Lifting belts or straps should be used for lifting purposes so as to avoid nicking or scratching the bottom edges of the outrigger beam (Figure 8-21).
- 8. After attaching a suitable lifting device of straps or belts (Figure 8-21) instead of chains to prevent nicking the bottom edges of the outrigger beam, pull the outrigger beam out of the outrigger box, re-adjusting the lifting attachment to prevent the extension cylinder from sliding out of the outrigger beam when the beam clears the outrigger box.



Be sure any blocking material used is capable of supporting the weight of the outrigger beam. Do not allow it to tilt or slide. Failure to do so could result in death or injury to personnel.

- **NOTE:** The outrigger beam assembly weighs approximately 374 kg (824 lb).
- 9. Position the outrigger beam on the blocking material.

Inspection

Inspect the outrigger beams for bends, evidence of cracks, or other damage. Check the outrigger beam internally for hydraulic fluid, which may indicate a leaking cylinder, loose connection, or damaged hydraulic line.

Installation

- **NOTE:** Apply anti-seeze compound on clevis pins and setscrews during installation.
- 1. Apply grease (EPMPG) to the bottom of the outrigger beam.
- **2.** If removed, install the side adjustable wear pad in the outrigger beam.

- **3.** Install the bottom wear pads with approximately 6 mm (0.23 in) protruding. This will prevent the beam side plates from riding on the bottom of the box (Figure 8-22).
- 4. Attach a suitable lifting device of straps or belts instead of chains to prevent nicking the bottom edges of the outrigger beam.
- 5. Slide the beam into the outrigger housing and align the cylinder bushing with the mounting hole.
- 6. Apply anti-seeze compound to the clevis pin. Secure the cylinder barrel to the housing with the clevis pin and cotter pin.

CAUTION

Be sure that the piston side of all outrigger cylinders are connected to the solenoid valve bank. Reversal of port connection of the rod and piston sides could result in severe damage to the cylinders as very high pressure intensification will occur.


CAUTION

During initial start-up and checking of the outrigger operation, each control switch must be operated before operating the selector valve. If hydraulic lines are reversed to one or more cylinders, this will prevent damage to the cylinders.

- 7. Connect the hydraulic lines as tagged prior to removal.
- 8. Install the side adjustable wear pad in the outrigger box.
- **9.** Adjust the wear pads, refer to WEAR PAD ADJUSTMENT in this Sub-Section.
- 10. Install the end cover.
- **NOTE:** At installation, be sure that the outrigger jack cylinder hydraulic hoses are not trapped against the outrigger box when the beam is fully retracted.

Wear Pad Adjustment.

- **NOTE:** When adjusting wear pads, refer to Wear Pad Adjustment (Figure 8-22).
- 1. Adjust the bottom wear pads until a gap of 3 mm (0.11 in) is obtained between the top of the beam and the top of the outrigger box. Install and lock setscrew against wear pad.
- Adjust outrigger box side wear pad until a gap of 2 mm (0.07 in) is obtained between beam and shims welded in top and bottom of box. Install and lock set screw against wear pad.
- **3.** Adjust outrigger beam side wear pad until a gap of 2 mm (0.07 in) is obtained between shim welded on beam and side of box. Install and lock set screw against wear pad.



Item	Description
1	Capscrew
2	Washer
3	Plate
4	Wear Pad
5	Wear Pad
6	Slotted Setscrew
7	Setscrew
8	Hex Nut

Extension Cylinder

Description

Two outrigger extension cylinders are utilized within each outrigger box assembly. The extension cylinders provide the

force for the outrigger beam's horizontal movement. The cylinder weighs approximately 42 kg (92.5 pounds).

Maintenance

NOTE: Refer to Cylinders in Section 2 - HYDRAULIC AND PRESSURE SETTINGS for Disassembly and Assembly of the cylinder.


Removal

- 1. Remove the outrigger beam. Refer to OUTRIGGER BEAM REMOVAL in this section.
- **2.** Remove the cotter pin and clevis pin securing the rod end of the extension cylinder to the outrigger beam.
- 3. Pull the extension cylinder from the outrigger beam until the hydraulic hoses on the rod end of the cylinder can be accessed. Tag and disconnect the hoses from the rod end of the cylinder. Cap or plug all openings.
- 4. Remove the cylinder.



Installation

- **1.** Place the cylinder in the beam.
- **NOTE:** Keep hydraulic fittings and hoses close to angles shown (Figure 8-23) and as low as possible to prevent rubbing with the beam top plate and side plate, and for proper tracking during beam extension and retraction.



- 2. Position the extension cylinder so the hydraulic ports on the rod end of the cylinder can be accessed. Connect the hydraulic hoses to the ports as tagged during removal.
- **3.** Push the cylinder into the outrigger beam. Align the cylinder rod with the clevis in the beam. Apply anti-seeze to the clevis pin and secure in place with the clevis pin and cotter pin.
- 4. Install the outrigger beam. Refer to OUTRIGGER BEAM INSTALLATION in this section.

Functional Check

- 1. Activate the hydraulic system; extend and retract the outrigger.
- 2. Observe the operation of the outrigger beam.
- **3.** Check the hydraulic connections for any evidence of leakage.

Jack Cylinder

Description

Four jack cylinders are used on the crane, one at the end of each outrigger beam. The jack cylinders provide the force for the outrigger beam's vertical movement. The cylinder weighs approximately 64.6 kg (142.4 pounds).

Maintenance

NOTE: Refer to CYLINDERS in Section 2 - HYDRAULIC and PRESSURE SETTINGS for Disassembly and Assembly of the cylinders.

Removal

- 1. Extend the outrigger beam slightly for improved access to the jack cylinder; shut down the engine.
- 2. Tag and disconnect the hydraulic hoses from the jack cylinder. Remove the fittings from the ports. Cap or plug all openings.
- **3.** Remove the nut and washer and remove the cylinder cap.
- 4. Place a jack capable of supporting the weight of the jack cylinder at the base of the cylinder barrel. Jack up the cylinder just enough to relieve any pressure on the cylinder retaining pin.
- Remove the cotter pins securing the cylinder retaining pin and remove the cylinder retaining pin and cylinder cap retaining bracket.
- 6. Jack the jack cylinder up just enough to insert the retaining pin back into the cylinder. Insert the retaining pin into the lugs on the cylinder and secure the pin in place with the cotter pins.

CAUTION

Use a nylon strap to remove the cylinder. This will ensure the retaining pin is not damaged.

7. Fasten a nylon strap onto the cylinder retaining pin and use an adequate lifting device to lift the jack cylinder out of the tube on the beam assembly.

Installation

- Apply grease (EPMPG) to the ID of the jack cylinder support tube.
- **2.** If removed, install wear ring in groove in bottom of support tube and in groove at top on jack cylinder.
- 3. Place a jack beneath the cylinder tube on the outrigger beam. Using the same method as described under REMOVAL, lower the jack cylinder into the cylinder tube on the outrigger beam until the retaining pin is just above

the tube. Position the jack so that it will support the cylinder in this position. Remove the lifting device from the cylinder.

- 4. Remove the retaining pin and cotter pins from the cylinder.
- **5.** Lower the jack until the holes in the cylinder rod align with the holes in the outrigger beam.
- **6.** Apply anti-seeze compound to the retaining pin. Secure the cylinder and cylinder cap retaining bracket to the support tube with the retaining pin and cotter pins.
- 7. Install the cylinder cap.
- **8.** Install the fittings in the cylinder ports and connect the hoses as tagged during removal.

Functional Check

- 1. Activate the hydraulic system.
- 2. Extend and retract the jack cylinder.
- 3. Check for smooth operation of the cylinder.
- **4.** Check all hydraulic connections and hoses for evidence of leakage.

Outrigger Jack Cylinder Internal Leak Test

Use the following procedure to troubleshoot and diagnose an internal leak, a leaking pilot operated check valve or a thermal contraction on an outrigger jack cylinder.



Perform the following procedures with the crane positioned on a firm level surface with outriggers fully extended and set, and the crane in the travel position

Remove hoses from one cylinder at a time.

Checking Cylinder For Internal Piston Seal Leak

1. Fully extend and set the outriggers.


CAUTION

When performing step number 2, remove hose to adapter connection slowly. Trapped pressure may exit between the outrigger cylinder and the work port pilot operated check valves in the outrigger selector valve.

2. Remove the rod side cylinder hose from the suspected leaking jack cylinder (Figure 8-24). Oil will flow until the cavity in the cylinder port block empties. Once the port block cavity empties, oil should stop flowing from the rod side port.

Check for the following conditions:

- **a.** If <u>oil stops flowing</u>, the cylinder's internal piston seal is sealing properly.
- **b.** If <u>oil continues to flow</u> out the rod port, the cylinder's internal piston seal is leaking.



3. After determining the condition of the cylinders internal piston seal, let the rod side hose disconnected and continue to test the pilot operated check valve.

Testing Pilot Operated Check Valve For Leakage

1. Fully extend and set the outriggers.

CAUTION

When performing step number 2, remove hose to adapter connection slowly. Trapped pressure may exit between the outrigger cylinder and the work port pilot operated check valves in the outrigger selector valve.

- 2. Remove the piston side cylinder hose from the suspected leaking jack cylinder (Figure 8-24). Oil will flow until the cavity in the cylinder port block empties. Once the port block cavity empties, oil should stop flowing from the piston side port.
 - **a.** If <u>oil stops flowing</u>, the cylinder's pilot operated check valve is sealing properly.
 - **b.** If <u>oil continues to flow</u> out the piston port, the cylinder's pilot operated check valve is leaking.

If oil flow is not noticed from either port, the cylinder and pilot operated check valve are functioning properly, and any cylinder contraction during normal operation can be attributed to thermal contraction of the oil.



Outrigger Control Valves

Description

There are four valve assemblies responsible for controlling the outrigger system, the integrated outrigger/rear steer valve, the front and rear outrigger control manifolds, and the pilot operated check valves.

NOTE: For a more detailed description and maintenance of the valves, refer to Valves in Section 2 - HYDRAULIC and PRESSURE SETTINGS.

Pilot Operated Check Valve

The pilot operated check valves are located in the outrigger jack port blocks. The check valve provides two functions; the

first function is a holding valve, the second function provides a thermal relief of the jack.

Integrated Outrigger/Rear Steer Manifold

The integrated outrigger/rear steer valve is mounted on the frame center section to the rear of the front axle. Refer to Section 2 - HYDRAULIC and PRESSURE SETTINGS.

Outrigger Control Manifold

The front and rear outrigger control manifolds are located on the respective outrigger boxes. Each manifold consists of four 2-position, 2-way solenoid valves.

8

THIS PAGE BLANK



SECTION 9 LUBRICATION

SECTION CONTENTS

General	·1
Environmental Protection 9-	1
Lubrication Intervals	
Arctic Conditions Below -9°C (15°F)	
Arctic Conditions Down To -40°C (-40°F) 9-	3
Surface Protection For Cylinder Rods 9-	-5
Wire Rope Lubrication	-5
Lubrication Points 9- CraneLUBE 9- Cummins Oil Registration List 9- Safety 9- Steering and Suspension 9-	.5 .5 .5

Axles)-8
Drive Train	10
Outriggers	15
Turntable	17
Boom	19
Hoist	23
Hydraulic	25
Diesel Exhaust Fluid (DEF) Tank9-	27
Carwell® Rust Inhibitor9-	28
Protecting Cranes From Rusting	28
Cleaning Procedures	28
Inspection and Repair9-	29
Application	29
Areas of Application9-	29

GENERAL

Following the designated lubrication procedures is important in ensuring maximum crane lifetime and utilization. The procedures and lubrication charts in this section include information on the types of lubricants used, the location of the lubrication points, the frequency of lubrication, and other information.

ENVIRONMENTAL PROTECTION

Dispose of waste properly! Improperly disposing of waste can threaten the environment.

Potentially harmful waste used in Manitowoc cranes includes — but is not limited to — oil, fuel, grease, coolant, air conditioning refrigerant, filters, batteries, and cloths which have come into contact with these environmentally harmful substances.

Handle and dispose of waste according to local, state, and federal environmental regulations.

When filling and draining crane components, observe the following:

- Do not pour waste fluids onto the ground, down any drain, or into any source of water.
- Always drain waste fluids into leak proof containers that are clearly marked with what they contain.

- Always fill or add fluids with a funnel or a filling pump.
- Immediately clean up any spills.

LUBRICATION INTERVALS

The service intervals specified are for normal operation where moderate temperature, humidity, and atmospheric conditions prevail. In areas of extreme conditions, the service periods and lubrication specifications should be altered to meet existing conditions. For information on extreme condition lubrication, contact your local Manitowoc distributor or Manitowoc Crane Care.

CAUTION

Chassis grease lubricants must not be applied with air pressure devices as this lubricant is used on sealed fittings.

CAUTION

Multipurpose grease installed during manufacture is of a lithium base. Use of a noncompatible grease could result in damage to equipment.

9

Standard Lubricants

Standard lubricants are used on all Manitowoc cranes unless the crane is ordered with a cold weather package.

TABLE 9-1: Standard Lubricants

These standard lubricants are effective in ambient temperatures down to -9°C (15°F). Refer to Table 5-1 for a list of the recommended standard lubricants.

Lubricant/Fluid	Grove Spec.	Recommended Lubricant				
Lubricant/Fluid	Grove Spec.	Туре	Grade	Classification		
Axle/Swing Box Gear Oil		Century Unigear Semi-synthetic				
	6829012964	Texaco Multigear SS	80W-90			
		Chevron DELO				
Engine Oil	6829104182	Conoco Fleet Supreme EC Mobil Delvac 1300 Super	15W-40	CJ-4		
Hydraulic/Transmission Oil	6829006444	Kendall Hyken 052 Exxon Torque Fluid 56 Esso Torque Fluid 56 BP-Eldoran UTH & Trak-Tran 9 BP- Blend- 7367	10W-20	John Deere Std. JDM J20C		
		Exxon Mobil 424	10W-30	-		
Hoist Gear Oil	6829100213	Mobil: 600XP 150 Texaco: Meropa 150		AGMA No. 4 EP		
Grease, Multipurpose	6829003477	Citgo Lithoplex MP# 2				
		Texaco Starplex Moly # 2				
		Phillips 66 Philube M				
		Mobil Mobilgrease XHP 222 Special	NLGI 2			
		Chemtool Inc, Lube-A-Boom				
Grease, 3% Moly	6829015304					
Open Gear Lube	6829102971	Fuchs Ceplattyn 300 Spray	NLGI 1-2			
Antifreeze Coolant	0	Old World Industries, Inc. Fleet Charge SCA				
	6829101130	Caterpillar DEAC	Mix 50/50			
		Fleetguard Complete EG				
Supplemental Coolant		Fleetguard DCA4				
Additive (SCA)	6829012858	Fleetguard DCA2				
		Penray Pencool 3000				
Diesel Exhaust Fluid	6829003476	Fleetguard StableGuard TM Urea 32 Premix		ISO 22241-1 DIN V 70070		
	80019225	AdBlue®				
		TerraCair Ultrapure® DEF				



Arctic Conditions Below -9°C (15°F)

In general, petroleum based fluids developed especially for low temperature service may be used with satisfactory results. However, certain fluids, such as halogenated hydrocarbons, nitro hydrocarbons, and phosphate ester hydraulic fluids, might not be compatible with hydraulic system seals and wear bands. If you are in doubt about the suitability of a specific fluid, check with your authorized distributor or Manitowoc Crane Care.

NOTE: All fluids and lubricants may be purchased by contacting Manitowoc Crane Care.

Regardless of temperature and oil viscosity, always use suitable start-up procedures to ensure adequate lubrication during system warm-up.

Arctic Conditions Down To -40°C (-40°F)

All Weather Package and Lubricants

Engineering recommends the following lubricants for components for ambient temperatures to -40°F. Special lubricants alone are not sufficient to operate at extreme low temperatures. We also recommend the use of appropriately sized heaters for the hydraulic tank, engine oil pan, engine jacket water and batteries. The operator needs to follow the guide lines as stated in the operator manual. We assume that the customer has take steps for use of an appropriate engine antifreeze coolant, have taken care of the fuel, fuel system and starting system. And has done whatever they feel necessary to add insulation for under hood temperatures and meet the engine manufacturer's intake air temperature. Other lubricants may be used if they meet the specification of the lubricant that is requested. Please consult factory. It is also recommended that the crane be equipped with the following accessories:

-29°C (-20°F) Package

- Battery heater
- Fuel line heater
- Engine hood insulation
- Fan clutch
- Radiator air shutters
- Air diverter
- Diesel fired cab heater
- Cold weather alternator
- Fluids suitable to -29°C (-20°F)
 - Arctic windshield washer fluid
 - Arctic fuel

-40°C (-40°F) Package

- Coolant heater (to circulate warm coolant through heaters and engine)
- Transmission heater
- Swivel heater
- Battery heater
- Fuel line heater
- Hydraulic reservoir heater
- Engine hood insulation
- Fan clutch
- Radiator shutters
- Air diverter
- Diesel fired cab heater
- Cold weather alternator
- Super-capacitor starting system
- Fluids suitable to -40°C (-40°F):
 - Arctic windshield washer fluid
 - Arctic fuel

TABLE 9-2: All Weather Lubricants

Lubricent/Eluid	Grove Spee	Recommended Lubricant				
Lubricant/Fluid	Grove Spec.	Туре	Grade	Classification		
Axle/Swing Box Gear Oil		Petro-Canada Traxon E Syn- thetic				
		CITGO, Synthetic Gear Lube				
	6829014058	Eaton, Roadranger EP	75W-90	GL-5		
		Mobil, Mobilube SCH				
		Shell, Spirax S				
		Sunoco Duragear EP				
Engine Oil		Shell Rotella® T6 0W-40				
	80056036	Mobil Delvac 1 ESP 0W-40	0W-40	Synthetic CJ-4		
		Caterpillar at DE0-ULS				
Hydraulic/Transmission Oil		Petro-Canada Duratran Syn- thetic THF		John Deere Std. JDM J20C &		
	6829101559	Chevron All Weather THF		J20d		
		Texaco TDH Oil SS				
Hoist Gear /Swing Drive Oil		Petro-Canada ENDURATEX				
	6829103636	Synthetic EP 150		AGMA No. 4 EP		
		Mobil SHC629				
Grease, Multipurpose	6829104275	Petro-Canada Precision Syn- thetic EP1		EM-3MG		
		Mobil, Mobilith SHC 220	NLGI 2			
Grease, 3% Moly	68291015304	Mobilgrease CM-P				
Open Gear Lube	6829102971	Vultrex OGL Synthetic All Sea- son	NLGI 1-2			
Antifreeze Coolant		Petro-Canada AFC				
	6829104212	Old World Industries, Inc Fleet Charge SCA	Premix 60/40			
20		Fleetguard Compleat EG Anti- freeze/Coolant	00/40			
Supplemental Coolant		Fleetguard DCA4				
Additive (SCA)	6829012858	Fleetguard DCA2				
		Penray Pencool 3000				
Windshield Washer fluid	90037773	Splash De-icer				
Diesel Exhaust Fluid	6829003476	Fleetguard StableGuard TM Urea 32 Premix		ISO 22241-1 DIN V 70070		
	80019225	AdBlue®				
		TerraCair Ultrapure® DEF				



SURFACE PROTECTION FOR CYLINDER RODS

Steel cylinder rods include a thin layer of chrome plating on their surfaces to protect them from corroding. However, chrome plating inherently has cracks in its structure which can allow moisture to corrode the underlying steel. At typical ambient temperatures, hydraulic oil is too thick to penetrate these cracks. Normal machine operating temperatures will allow hydraulic oil to warm sufficiently to penetrate these cracks and if machines are operated daily, protect the rods. Machines that are stored, transported, or used in a corrosive environment (high moisture, rain, snow, or coastline conditions) need to have the exposed rods protected more frequently by applying a protectant. Unless the machine is operated daily, exposed rod surfaces will corrode. Some cylinders will have rods exposed even when completely retracted. Assume all cylinders have exposed rods, as corrosion on the end of the rod can ruin the cylinder.

It is recommended that all exposed cylinder rods be protected using Boeshield® T-9 Premium Metal Protectant. Manitowoc Crane Care has Boeshield® T-9 Premium Metal Protectant available in 12 oz. cans that can be ordered through the Parts Department.

Cylinder operation and inclement weather will remove the Boeshield® protectant; therefore, inspect machines once a week and reapply Boeshield® to unprotected rod.

WIRE ROPE LUBRICATION

Wire rope is lubricated during manufacturing so that the strands, and individual wires in strands, may move as the rope moves and bends. A wire rope cannot be lubricated sufficiently during manufacture to last its entire life. Therefore, new lubricant must be added periodically throughout the life of a rope to replace factory lubricant which is used or lost. For more detailed information concerning the lubrication and inspection of wire rope, refer to WIRE ROPE in Section 1- INTRODUCTION in the Service Manual.

LUBRICATION POINTS

A regular frequency of lubrication must be established for all lubrication points. Normally, this is based on component operating time. The most efficient method of keeping track of lube requirements is to maintain a job log indicating crane usage. The log must use the engine hourmeter to ensure coverage of lube points that will receive attention based on their readings. Other lubrication requirements must be made on a time basis, i.e. weekly, monthly, etc.

All oil levels are to be checked with the crane parked on a level surface in transport position, and while the oil is cold, unless otherwise specified.

On plug type check points, the oil levels are to be at the bottom edge of the check port.

All grease fittings are SAE STANDARD unless otherwise indicated. Grease non-sealed fittings until grease is seen extruding from the fitting. One ounce(28 grams) of EP-MPG equals one pump on a standard one pound (0.45 kg) grease gun.

Over lubrication on non-sealed fittings will not harm the fittings or components, but under lubrication will definitely lead to a shorter lifetime.

On sealed U-joints, care must be exercised to prevent rupturing seals. Fill only until expansion of the seals first becomes visible.

Unless otherwise indicated, items not equipped with grease fittings, such as linkages, pins, levers, etc., should be lubricated with oil once a week. Motor oil, applied sparingly, will provide the necessary lubrication and help prevent the formation of rust. An Anti-Seize compound may be used if rust has not formed, otherwise the component must be cleaned first.

Grease fittings that are worn and will not hold the grease gun, or those that have a stuck check ball, must be replaced.

Where wear pads are used, cycle the components and relubricate to ensure complete lubrication of the entire wear area.

CraneLUBE

Manitowoc highly recommends the use of CraneLUBE lubricants to increase your crane's reliability and performance. Contact your Manitowoc Distributor for information about the Manitowoc's CraneLUBE lubrication program.

Cummins Oil Registration List

Cummins has a program that lists engine oils that it has tested to meet its engineering specifications. Listing of recommended oils is on QuickServe® Online. Log on to quickserve.cummins.com and login with a current username and password or create a new account by selecting "Create an Account" under information, choose Limited Owners Plan and register. Once logged in, click on the "Service" Tab in the top red bar, "Service Tools" mini-tab and "Oil Registration Lists" link within the Service Tools list. This will load a list of the different Cummins Engineering Specification numbers. Select the one that applies to your engine to view the registered oils.

Safety


To lubricate many of the locations the engine will need to be started. After positioning areas of the unit for lubrication the engine must be turned off and the moved areas stable before approaching.



Movement of the superstructure and the boom may create a crushing and/or pinching hazard. Failure to observe this warning could result in death or serious injury.

Stee	Steering and Suspension							
ltem	Lube Point Description	Figure No.	Approved Lubricant	Lube Capacity	Lube Interval	Application		
1	Steer Cylinder Pivot Pins	Figure 9-1	EP-MPG Extreme Pressure Multipurpose Grease A6-829-003477	Until grease extrudes	500 hours or 3 months	8 grease fittings		
2	Upper and Lower King Pins	Figure 9-1	EP-MPG Extreme Pressure Multipurpose Grease A6-829-003477	Until grease extrudes	500 hours or 3 months	8 grease fittings		
3	Fifth Wheel Pivots	Figure 9-1	EP-MPG Extreme Pressure Multipurpose Grease A6-829-003477	Until grease extrudes	500 hours or 3 months	2 grease fittings		
4	Lockout Cylinder Pivot Pins	Figure 9-1	EP-MPG Extreme Pressure Multipurpose Grease A6-829-003477	Until grease extrudes	500 hours or 3 months	4 grease fittings		





GROVE

ltem	Lube Point Description	Figure No.	Approved Lubricant	Lube Capacity	Lube Interval	Application		
Axle	Axles							
6	Axle Tech Differentials	As seen in Figure 9-2	GL-5 Extended Service Interval Gear Lubricant 6829012964	20.8 I (44 pt)	 Check level every 500 hours or 3 months Drain and fill every 4000 hours or 2 years 	Fill to bottom of hole in housing on the steer cylinder side		
	When checking lu TION: Use of non-app	ube level, also proved lubrica	check and clean h nt may damage co	nousing breath mponents and	sufficient. It must be level v ers. /or invalidate published lubr i pint), check for leaks.			
9	Axle Tech Planetary Hubs and Wheel Bearings	As seen in Figure 9-2	GL-5 Extended Service Interval Gear Lubricant 6829012964	3.1 l (6.5pt)	 Check level every 500 hours or 3 months Drain and fill every 4000 hours or 2 years 	Fill to the bottom of the level hole in the housing with the fill plug and the oil level mark horizontal.		






FIGURE 9-2

ltem	Lube Point Description	Figure No.	Approved Lubricant	Lube Capacity	Lube Interval	Application
Drive	e Train					
13a 13b	a. Engine Crankcase b. Filter	Figure 9-3	Engine Oil T3 Engine - SAE 15W-40 6829003483 T4 Engine - 6829104182 SAE 15W-40 80056036 EO-0W/40	17.5 l (18.5 qt)	 Check level every 10 hours or daily Drain, fill and replace filter every 500 hours or 6 months 	 Check level through dipstick. Fill engine oil through fill cap on engine valve cover.
14a 14b	a. Transmission, Torque Converter b. Filter	Figure 9-3	HYDO Hydraulic Oil 6829006444	23.6 l (25 qt)	 Check level every 10 hours or daily Drain and refill every 1000 hours or 6 months Change transmission filter after first 50 and 100 hours of service, then every 500 hours thereafter 	Through fill pipe to FULL mark on dipstick

NOTE:

Check fluid level with engine running at 750 rpm idle and the oil at 82 to 93° C (180 to 200 ° F). Do not attempt an oil level check with cold oil. To bring the oil temperature to this range, it is necessary to either work the crane or stall the converter. Converter stall should be accomplished by engaging shift lever in forward high range with the brakes applied and then accelerating the engine to half or three-quarter throttle. Hold the stall until the required converter temperature is reached and stabilized.


Do not operate the converter at stall condition for longer than 30 seconds at one time. Shift to neutral for 15 seconds and repeat the procedure until the desired temperature is reached. Excessive temperature, i.e, 120° C (250° F) maximum will cause damage to transmission clutches, fluid, converter and seals.

- Drain and fill with the oil at 65 to 93° C (150 to 200° F).
- Transmission filters are located on the outside left hand frame in the area of the hydraulic oil cooler.
- To add fluid:
 - a. Fill to FULL mark on dipstick
 - b. Run engine at 750 rpm to prime torque converter and lines
 - c. Check oil level with engine running at 750 rpm and oil at 82 to 93° C (180 to 200° F). Add oil to bring oil level to FULL mark on dipstick.




RT530E-2 SERVICE MANUAL

Item	Lube Point Description	Figure No.	Approved Lubricant	Lube Capacity	Lube Interval	Application
15	Engine Cooling System and SCA Levels	Figure 9-3	AFC 50/50 50/50 Blended Fully Formulated Antifreeze Coolant 6829101130 SCA 6829012858	28.4 I (30 qt)	 Check coolant level every 10 hours or daily Check SCA levels every 500 hours Check coolant for contamination every 1000 hours 	See Service Manual
16	Coolant Strainer (Cab Heater)	Figure 9-3			Change strainer screen after first 100 hours and every 2000 hours or 12 months intervals thereafter.	Close shutoff valves. Unscrew hex plug to clean filter.






ltem	Lube Point Description	Figure No.	Approved Lubricant	Lube Capacity	Lube Interval	Application
Drive	e Train (continue	ed)				
17	Driveline - Slip Joints	Figure 9-4	EP-MPG Extreme Pressure Multipurpose Grease 6829003477	Until grease extrudes	500 hours or 3 months	2 grease fittings
52	Air Cleaner Filter	Figure 9-4			 Replace/Clean filter element when indicator shows red (25" H20). View indicator through grill from rear of crane. Refer to Service Manual 	Remove panel behind ladder to access air filter.
53a 53b	a. Fuel Filter b. Water Separator	Figure 9-4		8	 Change filter every 500 hours or 6 months. Drain water trap every 10 hours or daily. 	 Fuel filter is located on the intake manifold of engine. Strainer is located near battery box.






ltem	Lube Point Description	Figure No.	Approved Lubricant	Lube Capacity	Lube Interval	Application			
Outr	Outriggers								
18	Outrigger Beams (Outside)	Figure 9-5	EP-MPG Extreme Pressure Multipurpose Grease 6829003477		50 hours or 1 week	Brush lubricant on bottom of outrigger beams			
19	Jack Cylinder Support Tubes	Figure 9-5	EP-MPG Extreme Pressure Multipurpose Grease 6829003477		50 hours or 1 week	Brush lubricant on OD of jack cylinder barrel and wear band before installing jack cylinders			
51	Jack Cylinder Barrels	Figure 9-5	EP-MPG Extreme Pressure Multipurpose Grease 6829003477	0	50 hours or 1 week	Brush lubricant on OD of jack cylinder support tubes (4) places before installing jack cylinders			
54	Outrigger Beams (Inside)	Figure 9-5	EP-MPG Extreme Pressure Multipurpose Grease 6829003477		50 hours or 1 week	Brush lubricant on inside bottom of outrigger beams where beam extension cylinder guide supports travel			






ltem	Lube Point Description	Figure No.	Approved Lubricant	Lube Capacity	Lube Interval	Application
Turn	table	I		<u> </u>	I	
20	Turntable Gear Box	Figure 9-6	GL-5 Extended Service Interval Gear Lubricant 6829012964	4.0 l (4.25 qt)	 Check and fill every 50 hours Drain and fill after first 250 hours and every 500 hours or 12 months thereafter. 	Use dipstick. If no dipstick, fill to top of case.
21	Turntable Gear and Drive Pinion	Figure 9-6	EP-OGL Open Gear Lubricant 6829102971	Coat all teeth	500 hours or 6 months	Spray on
22	Turntable Bearing	Figure 9-6	EP-MPG Extreme Pressure Multipurpose Grease 6829003477	Until grease extrudes entire circumfere nce of bearing	500 hours or 6 months rotating 90° and grease the	2 grease fittings at the front of the turntable
		0				






ltem	Lube Point Description	Figure No.	Approved Lubricant	Lube Capacity	Lube Interval	Application
Boor	n			1		
25	Upper Lift Cylinder Pin	Figure 9-7	EP-MPG Extreme Pressure Multipurpose Grease 6829003477	Until grease extrudes	500 hours or 3 months	1 grease fittings
29	Hook Block Swivel Bearing	Figure 9-7	EP-MPG Extreme Pressure Multipurpose Grease 6829003477	Until grease extrudes	250 hours or 3 months	1 grease fitting
30	Hook Block Sheaves	Figure 9-7	EP-MPG Extreme Pressure Multipurpose Grease 6829003477	Until grease extrudes	250 hours or 3 months	4 grease fittings - 35 Tons 3 grease fittings - 35 Tons
31	Telescope Cylinder Wear Pads	Figure 9-7	EP-MPG Extreme Pressure Multipurpose Grease 6829003477	Thoroughly coat	Every boom teardown or 125 hours/3 months	2 places by brush Extend boom for access through holes
32	Side Wear Pads	Figure 9-7	EP-MPG Extreme Pressure Multipurpose Grease 6829003477	Thoroughly coat all areas the wear pad moves on	250 hours or 3 months	12 places by brush; with boom in extended position
33	Boom Section Upper Wear Pads	Figure 9-7	EP-MPG Extreme Pressure Multipurpose Grease 6829003477	Thoroughly coat all areas the wear pad moves on	50 hours or 1 week	6 places by brush; with boom in extended position through access holes
34	Boom Section Lower Wear Pads	Figure 9-7	EP-MPG Extreme Pressure Multipurpose Grease 6829003477	Thoroughly coat all areas the wear pad moves on	50 hours or 1 week	3 places by brush; with boom in extended position
35	Extend Cable Sheaves	Figure 9-7	EP-MPG Extreme Pressure Multipurpose Grease 6829003477	Until grease extrudes	250 hours or 3 months	3 grease fittings Extend boom for access through holes
36	Retract Cable Sheaves	Figure 9-7	EP-MPG Extreme Pressure Multipurpose Grease 6829003477	Until grease extrudes	250 hours or 3 months	4 grease fittings






ltem	Lube Point Description	Figure No.	Approved Lubricant	Lube Capacity	Lube Interval	Application
Boo	m (continued)		L	I		
37	Boom Pivot Shaft	Figure 9-8	EP-MPG Extreme Pressure Multipurpose Grease 6829003477	Until grease extrudes	250 hours or 3 months	2 grease fittings
38	Boom Extension Sheave	Figure 9-8	EP-MPG Extreme Pressure Multipurpose Grease 6829003477	Until grease extrudes	250 hours or 3 months	1 grease fitting
39	Boom Extension Roller	Figure 9-8	EP-MPG Extreme Pressure Multipurpose Grease 6829003477	Until grease extrudes	250 hours or 3 months	4 grease fittings
40	Upper Boom Nose Sheave	Figure 9-8	EP-MPG Extreme Pressure Multipurpose Grease 6829003477	Until grease extrudes	250 hours or 3 months	1 grease fitting
41	Lower Boom Nose Sheave	Figure 9-8	EP-MPG Extreme Pressure Multipurpose Grease 6829003477	Until grease extrudes	250 hours or 3 months	1 grease fitting
42	Auxiliary Boom Nose Sheave	Figure 9-8	EP-MPG Extreme Pressure Multipurpose Grease 6829003477	Until grease extrudes	250 hours or 3 months	1 grease fitting
43	Mast Sheave	Figure 9-8	EP-MPG Extreme Pressure Multipurpose Grease 6829003477	Until grease extrudes	500 hours or 12 months	1 grease fitting






ltem	Lube Point Description	Figure No.	Approved Lubricant	Lube Capacity	Lube Interval	Application
Hois	t			I	I	
45	Main Hoist	Figure 9-9	AGMA Extreme Pressure Gear Lubricant 6829100213	5.2 l (5.5 qt)	 Check and fill every 50 hours or weekly Drain and fill every 1000 hours or 12 months 	Oil level must be visible in the sight glass
46	Auxiliary Hoist	Figure 9-9	AGMA Extreme Pressure Gear Lubricant 6829100213	5.2 I (5.5 qt)	 Check and fill every 50 hours or weekly Drain and fill every 1000 hours or 12 months 	Oil level must be visible in the sight glass
NOTE	Ensure hoist is le hoist is le	evel and oil te ler filled. Oil e	mperature is 21°C scaping from vent	±11°C (70°F : plug is an indi	bist sit idle for 20 minutes fo ±20°F). If oil level is not vis cation the hoist may be over rain until oil level falls within	ible in sight glass, the er filled. If hoist is over
47	Cable Follower (Arms)	Figure 9-9	EP-MPG Extreme Pressure Multipurpose Grease 6829003477	Thoroughly coat	250 hours or 3 months	Spray on
NOTE	: Lubricate more frinecessitate.	requently than	interval indicated	in table if envi	ronmental conditions and/c	or operating conditions






ltem	Lube Point Description	Figure No.	Approved Lubricant	Lube Capacity	Lube Interval	Application	
Hydr	raulic	L		1			
48	Hydraulic Tank	Figure 9-10	HYDO Hydraulic Oil 6829006444	397.4 l (105 gal)	Check fluid level every 10 hours or daily.	 Use sight gauge on side of tank, with boom down and all outrigger cylinders retracted. Drain and refill as 	
						necessary	
 NOTE: Environmental and other conditions can dramatically affect the condition of hydraulic oil and filters. Therefore, specific intervals for servicing/changing hydraulic oil, filters and hydraulic tank breathers cannot be set. However, it is imperative for the continued satisfactory performance of Grove cranes that inspections be performed on the basis of how and where each crane is used. Air borne and ingested contaminants can significantly reduce the life of oil and the condition of hydraulic oil filters and tank breathers. Under normal operating conditions, it is recommended that hydraulic oil, filters and breathers be inspected and oils sampled at least every 3 to 6 months and more frequently for severe operating conditions. The inspections should be for air borne and/or ingested particles and water that deteriorate and contaminate the oil (e.g., oil appears "milky" or no longer has a transparent clear to amber color). The return filter by-pass indicator should be observed daily to determine if the contaminants content may be high. If the indicator reaches the red zone or indicates a by-pass condition, the hydraulic oil must be sampled. The hydraulic tank breather should also be inspected to assure that it is not restricting air flow into and out of the reservoir. To inspect hydraulic oil, fill a small glass container with a sample of reservoir oil and another glass container with fresh oil. Let the samples stand, undisturbed, for one to two hours and then compare the samples. If the reservoir oil is heavily contaminated with water the sample will appear "milky" with only a small layer of transparent oil on top. If the "milky" appearance was due to air foaming, it will dissipate and the oil should closely match the fresh oil. Should you have any questions, please contact your local authorized Manitowoc 							
	distributor.	o oil chall moat	of avagad ISO #4/	106 close 17/1	4 cleanliness level.		
	I he hydrauli	c on shall meet	of exceed ISO #44 HYDO	+UD CIASS 17/1			
49	Hydraulic Filter	Figure 9-10	Hydraulic Oil 6829006444		Change filter when the indicator is red		
	6-0						





Lube Point Description	Figure No.	Approved Lubricant	Lube Capacity	Lube Interval	Application			
Diesel Exhaust Fluid (DEF) Tank								
DEF Tank	Figure 9-11	DEF 6829003476 80019225	19 L (5 gal)	Fill when level is low per indicator.	Left rear side of carrier.			
NOTE: Use caution when adding Diesel Exhaust Fluid (DEF) to avoid spills during vehicle fill-up.								
	DEF Tank Use caution wher	Description Complexity I Exhaust Fluid (DEF) Tar DEF Tank Figure 9-11 Use caution when adding Diese	DescriptionFigure No.LubricantI Exhaust Fluid (DEF) TankDEFDEF TankFigure 9-11DEF TankSigure 9-11Use caution when adding Diesel Exhaust Fluid (DescriptionFigure No.LubricantCapacityI Exhaust Fluid (DEF) TankDEF TankDEF TankFigure 9-11Use caution when adding Diesel Exhaust Fluid (DEF) to avoid	DescriptionFigure No.LubricantCapacityLube IntervalI Exhaust Fluid (DEF) TankDEF TankFigure 9-11Ber TankFigure 9-11Ber TankFigure 9-11Ber TankFigure 9-11Ber TankBer TankFigure 9-11Ber TankBer Tank <t< td=""></t<>			



CARWELL® RUST INHIBITOR

Protecting Cranes From Rusting

Manitowoc Crane Group's cranes are manufactured to high quality standards, including the type of paint finish demanded by today's industry. In partnership with our paint supplier, we are also doing our part to help prevent premature corrosion of cranes.

Grove cranes are treated with a rust inhibitor called CarwellT32-CP-90. While a rust inhibitor cannot guarantee a machine will never rust, this product helps protect against corrosion on Grove cranes treated with this product.

Carwell is a treatment, not a coating. It contains no silicones, solvents, CFCs or anything that would be classified as hazardous under OSHA Regulation 29CRF-19-10.1200. The product is a liquid blend of petroleum derivatives, rust inhibitors, water-repelling and water-displacing agents.

Special equipment is used to spray a light film onto the entire undercarriage and various other areas of each new crane prior to shipment. When applied the product has a red tint to allow applicators to view coverage during application. This red tint will turn clear on its own within approximately 24 hours after application.

Once applied, treatment can appear to leave a slightly "oily" residue on painted surfaces. Until the red tinting fades it can be mistaken for a hydraulic oil leak. While the product is not harmful to painted surfaces, glass, plastic or rubber, it must be removed using standard steam-cleaning techniques.

This treatment works in various ways: (1) it eliminates the moisture containing salt, dirt and other pollutants by lifting and removing them from the metal surface; (2) the film creates a barrier to repel further moisture from coming in contact with the metal; and (3) it penetrates crevices.

In addition to the factory-applied treatment, Grove crane owners must provide proper maintenance and care to help ensure long-term protection of their crane against corrosion. This procedure provides information and guidelines to help maintain the paint finish on Grove cranes.

The most common causes of corrosion include the following:

- Road salts, chemicals, dirt, and moisture trapped in the hard-to-reach areas;
- Chipping or wear of paint, cased by minor incidents or moving components;
- Damage caused by personal abuse, such as using the decks to transport rigging gear, tools, or cribbing; and
- Exposure to harsh environmental hazards such as alkaline, acids, or other chemicals that can attack the crane's paint finish.

While the surfaces of the crane that are easily seen have the biggest impact on the appearance of the crane, particular

attention should be given to the undercarriage of the crane to minimize the harmful effects of corrosion.

Exercise special care and increase the frequency of cleaning if the crane is operated:

- on roads where large quantities of salt or calcium are applied to treat icy and snowy road surfaces;
- in areas that use dust control chemicals;
- anywhere there are increased levels of wetness especially near salt water;
- during prolonged periods of exposure to damp conditions (e.g., moisture held in mud), where certain crane parts may become corroded even though other parts remain dry; or
- in high humidity, or when temperatures are just above the freezing point.

Cleaning Procedures

Manitowoc Crane Care recommends washing the crane at least monthly. More frequent cleaning may be needed when operating in harsh environmental conditions.

 High pressure water or steam is effective for cleaning the crane's undercarriage and wheel housings. Keeping these areas clean will not only help retard effects of corrosion, but will also improve the ability to identify potential issues before they grow into larger problems.

High pressure water can be forced into spaces and infiltrate beyond seals. Avoid pressure washing in the vicinity of electrical controls, panels, wiring, sensors, hydraulic hoses and fittings, or anything that can be damaged by high pressure cleaning/spraying.

- Rinse the dirt and dust off before washing the crane. Dirt can scratch the crane's finish during washing/cleaning.
- Hard to clean spots caused by road tar or bugs should be treated and cleaned after rinsing and prior to washing. Do not use solvents or gasoline.
- Wash using only soaps and detergents recommended for automotive paint finishes.
- Rinse all surfaces thoroughly to prevent streaking caused by soap residue.
- Allow crane to dry thoroughly. Accelerate drying by using compressed air to remove excess water.
- **NOTE:** Polishing and waxing with an automotive-type wax is recommended to maintain original paint finish.



Inspection and Repair

- Immediately following cleaning, Manitowoc Crane Care recommends an inspection to detect areas that may have become damaged by stone chips or minor mishaps. A minor scratch (one that has not penetrated to the substrate surface) can be buffed with an automotive-type scratch remover. It is recommended that a good coat of automotive wax be applied to this area afterwards.
- All identified spots and/or areas that have been scratched through to the metal should be touched up and repaired as soon as possible to prevent flash rusting. To repair a major scratch (down to bare metal) or minor damage, follow these procedures:
- **NOTE:** Manitowoc Crane Care recommends that a qualified body repairman prepare, prime and paint any major scratch(es) or minor damage.



To the extent any damage is structural in nature, Manitowoc Crane Care must be contacted and consulted as to what repairs may be required.

- For scratches and marks in highly visible areas:
- Sand to remove the scratch and feather outward from the mark to blend the repair into the original surface. Body putty may be applied as necessary to hide the defect; then sand smooth.
- Cover all bare metal with a primer that is compatible with the original paint finish
- and allow to dry thoroughly.
- Prepare the surface prior to applying the finish coat of paint.
- Apply a finish coat paint using accepted blending techniques. Use of original paint colors is recommended to insure the best color match possible.

For scratches and marks in areas of low visibility:

• Consider touching up the spots with a brush technique to cover the bare metal. This will retard the effects of corrosion and enable you to do the repair at a later time during a normal maintenance interval.

Spots should be touched up with quality paint. Primers tend to be porous; using a single coat of primer only will allow air and water to penetrate the repair over time.

Application

Depending upon the environment in which a crane is used and/or stored, the initial factory application of Carwell T32-CP-90 should help inhibit corrosion for up to approximately 12 months. It is recommended that the treatment be periodically reapplied by the crane owner after that time to help continue to protect against corrosion of the crane and its components.

However, if a crane is used and/or stored in harsh environments (such as islands, coastal regions, industrial areas, areas where winter road salt is regularly used, etc.), reapplication of treatment is recommended sooner than 12 months, e.g., repeat treatment in 6-9 months.


- Do not apply to recently primered and painted areas for at least 48 hours after paint is properly dried and cured. For minor touch up areas a 24 hour period is needed for cure time before applying treatment.
- **NOTE:** Unit must be completely dry before applying treatment.
- Do not allow product to puddle or build-up on weather stripping, rubber gaskets, etc. Unit should not have puddles or runs evident anywhere.
- To ensure proper coverage of treatment, the product needs to be fogged on the unit.
- Use of pressure pots to apply the treatment to the unit being processed is recommended.
- Carwell treatment is available in 16 ounce spray bottles from Manitowoc Crane Care (order part number 8898904099).
- After treatment application is complete, wash or clean film residue from lights, windshield, grab handles, ladders/steps and all access areas to crane, as necessary.

Contact Manitowoc Crane Care with any questions.


Areas of Application

Refer to Figure 9-12 and Figure 9-13

- The underside of the unit will have full coverage of the rust inhibitor. These are the only areas that a full coat of the rust inhibitor is acceptable on the painted surfaces. Areas include; Valves, hose end and fittings, Swivel, pumps, axles, drive lines, transmission, slew ring fasteners and all interior surfaces of the frame.
- Frame application areas are; hose ends and fittings, all unpainted fasteners and hardware, all bare metal surfaces, outrigger pads, and back up alarm hardware.
- Superstructure applications are; hose end and fittings, wire rope on hoist roller tensioning springs on hoists, all unpainted fasteners and hardware, valves, slew ring fasteners and all bare metal surfaces.
- Boom applications areas are; pivot pins, hose end and fittings, jib pins and shafts, all bare metal surfaces, headache ball pins/ hook block pins and fasteners.
- All hardware, clips, pins, hose connections not painted will have treatment applied.







1	Hoist Tension Springs	12	O/R Pins, Clips
2	Boom Extension Pins, Clips	13	O/R Beam Wear Pad Adjustment Hardware
3	Boom Nose Pins, Clips	14	Entire underside of unit
4	Hook Block\Headache Ball	15	Valve Bank
5	Boom Extension Hanger Hardware	16	Powertrain Hardware inside compartment
6	Pivot Shaft	17	Hoist Hose Connections
7	Hose Connections inside turntable	18	Wire Rope
8	All Hardware, Clips, Pins, Hose Connections not painted O/R Pins, Clips	19	Counterweight Mounting Hardware
9	Turntable Bearing Fasteners	20	Counterweight Pins
10	O/R Hose Connections	21	Hose Connections
11	Hook Block Tie Down Cable	22	Mirror Mounting Hardware

Crane Care

Alphabetical Index

Accessory With Swing Directional Control Manifold	2-33
Air Intake System.	
Axle Oscillation Lockout Cylinder	
Axle Oscillation Lockout Valve (Optional CE Units).	2-52
Axle Oscillation Lockout Valve (Standard Units)	2-50
Axles	
Boom Assembly	4-13
Boom Disassembly	. 4-6
Boom Extension and Retraction Cable	4-20
Brake System	
Carwell® Rust Inhibitor	9-27
Check Valves	
Counterweight Removal	
Cross Axle Differential Lock Valve.	
Cylinders	2-54
Directional Control Valves	
Drive Train	
Dual Accumulator Charge Valve	
Dual Rod Telescope Cylinder	
Engine	
Environmental Protection.	
Exhaust System.	
Fuel System General Maintenance	
Hoist Drum Rotation Indicator System.	
Hoist to Boom Alignment	
Holding Valves.	
Hook Block.	
Hydraulic Accumulator Service Brake	
Hydraulic Pumps	
Integrated Outrigger/Rear Steer Manifold	
Lift Circuit	
Lift Cylinder	
List of Specifications	
Lubrication Intervals.	
Lubrication Points	
Oil Cooler	
Outrigger Control Manifold.	
Outrigger Extension Cylinder	
Outrigger jack Cylinder	
Outriggers	
Park Brake Valve	
Parking Brake Actuator	8-22
Parking Brake	8-23
Pilot Operated Check Valve.	2-44
Piston Motor and Control Valve	. 5-9
Pressure Setting Procedures	2-17
Range Shift/Parking Brake Valve	
Rear Axle Oscillation Lockout System.	
Service Brakes.	
Steer Cylinder	
Steering Control Valve.	
Steering Systems.	
Supply Pressure and Return Circuit	
	-

Surface Protection For Cylinder Rods	-5
Swing Bearing	-9
Swing Gearbox and Brake	-7
Swing Motor	-6
Swingaway Boom Extension 4-2	29
Swivels	14
Tandem Brake Valve with Treadle Pedal 2-3	36
Telescope Circuit 4-2	
Valves	
Water Cooling System	15
Wire Rope Lubrication	-5
Wire Rope 1-1	17



