



TOWER CRANE INTERMEDIATE FALL CAPACITIES 3900W SERIES-2 CRAWLER

**204' NO. 9A TOWER WITH NO. 18 BOOM
 24' CRAWLERS — EXTENDED
 84,600 LB. COUNTERWEIGHT**

**CAUTION
 OUTSIDE ASSIST REQUIRED**

LIFTING CAPACITIES: Capacities for various boom lengths, and operating radii are for freely suspended loads and do not exceed 75% of a static tipping load. **CAPACITIES SHOWN BY SHADED AREAS ARE BASED ON STRUCTURAL COMPETENCE.**

Capacities are shown in pounds. Weight of all load blocks, hooks, weight ball, slings, hoist lines, etc., beneath boom and intermediate fall point sheaves, is considered part of the intermediate fall load. Boom is not to be lowered beyond radii where combined weights are greater than rated capacity. Where no capacity is shown, operation is not intended or approved.

OPERATING CONDITIONS: Machine to operate on a firm surface with crawlers fully extended and roller path level within a tolerance of 1/4" in 10 ft. and properly supported, and be rigged in accordance with and under conditions referred to in rigging drawing No. 65079 and load line specification chart No. 5326 and chart No. 6633-A for recommended procedure for operating under various wind conditions. **CAUTION: OUTSIDE ASSIST REQUIRED. SEE CHART NO. 6473 FOR TOWER AND BOOM RAISING PROCEDURE.**

A maximum of two hoist lines may be used with one over the intermediate fall and one over the boom point. **SIMULTANEOUS HANDLING OF LOADS WITH HOIST LINES OVER THE INTERMEDIATE FALL AND BOOM POINT IS NOT PERMITTED.**

Crane operator judgment must be used to allow for dynamic load effects of swinging, hoisting or lowering, travel, wind conditions, as well as adverse operating conditions and physical machine depreciation.

OPERATING RADIUS: Operating radius is the horizontal distance from the axis of rotation to the center of vertical hoist line. Boom angle is the angle between horizontal and centerline of boom butt and inserts and is an indication of operating radius. In all cases, operating radius shall govern capacity.

INTERMEDIATE FALL POINT ELEVATION: Intermediate fall point elevation, in feet, is the vertical distance from ground level to centerline of intermediate fall point shaft.

MACHINE EQUIPMENT: Machine equipped with 24' 0" extendible crawlers, 48" treads, 16' retractable gantry, 10 part boom hoist reeving, four 1 1/4" tower pendants, two 1 1/4" boom pendants, two 3/8" intermediate suspension pendants, 1st cwt. = 43,000 lbs., 2nd cwt. = 30,000 lbs., 3rd cwt. = 11,600 lbs.

LOAD LINE SPECIFICATIONS	
INTERMEDIATE FALL: 1" — 6x25 Filler Wire, Improved Plow Steel, Regular Lay, IWRC. Minimum Breaking Strength 44.9 Ton. Maximum Load on Intermediate Fall — 15,000 lbs. (Approx. Weight Per Ft. in lbs. 1.85)	

Boom Lgth.: Feet	Oper. Rad.: Feet	Boom Angle: Deg.	Int. Fall Point: Elev.	Capacity:
120	25	72.8	271.5	15,000
	30	68.0	269.6	15,000
	35	63.1	267.2	15,000
130	40	57.9	264.3	12,700
	45	52.3	260.6	11,200
140	50	46.3	256.1	10,000
	55	39.6	250.5	8,900
	60	31.6	243.2	8,100
150	65	21.1	232.5	7,500

Combined From Charts:
 No. 6753-C1 11-28-84
 No. 5326 9-4-80