



## Reinforce the safety on your jobsite making your anemometers checked



J-68416-11

### Sensor to be checked

Exclusively for Manitowoc **H-68416-10** anemometer from the « Wind Kit » or for sensors integrated in the viso indicator.

**J-68416-11** sensor.



### Certificate of good working order checking delivered on the spot:

- Contact the nearest Manitowoc after-sales service in order to make the good working order, the calibration and the alarms of your anemometer checked.
- This quick checking could take place on the jobsite or on your stockyards on request of the customer or / and of the work inspection, and then in the frame of in-depth maintenance exams, every 4 years.

