

## **Spare Parts News**



# **Dialog Wind Anemometer**

### Sturdy and reliable:

- Digital system,
- Tested and certified by the CETIAT,
- Complete basic assembly including sensor + alarm block + H-68416-10 main display + cables



100

#### Sensor: J-68416-11

- Cup holder set Z-68416-25,
- Non-oxidizing tight bearings,
- Electronic card protected by double varnishing,
- Polyurethane cables with compound-filled connector link.

#### Indicator: N-68416-15

- Adjusting of the alarm and prealarm thresholds by means of access code,
- Fixing by «non-slip» magnets,
- 4 button keypad with signal lamps + buzzer,
- Button for testing the correct working order,
- Choice of speed unit: km/h, m/s or miles/h
- Internal buzzer and display for fault signalling and identification



#### Alarm block: P-68416-16

- Adjustable luminous alarm frequency (5 W lamps),
- Programmable alarm bell (110 dB siren at 1 m),
- Fixing by «non-slip» magnets,
- Protecting by roller bar.

#### **Options**:

- Repeater: Additional display box (wire link, cable 60m) Q-68416-17
- Giant Vision display : <u>see our Spare Parts News Affb</u>
- For cranes with collector, we propose a solution with radio repeater, pack including: sensor + alarm block + main display + repeater display F-71406-54

#### Scan or click to access online support:

Please contact your usual Potain agent as of now.



If you require more information, Please get in touch your usual correspondent or contact us via e-mail address: Potainparts@manitowoc.com Commercial, non-contractual document, reproduction prohibited - Anel 06 22 EN