

### Dialog Wind Anemometer

Sturdy and reliable:

- Digital system,
  - Tested and certified by the CETIAT,
  - Complete basic assembly including sensor + alarm block + main display + cables
- H-68416-10**



#### Sensor: J-68416-11

- Cup holder set **Z-68416-25**,
- Non-oxidizing tight bearings,
- Electronic card protected by double varnishing,
- Polyurethane cables with compound-filled connector link.



#### Indicator: N-68416-15

- Adjusting of the alarm and prealarm thresholds by means of access code,
- Fixing by «non-slip» magnets,
- 4 button keypad with signal lamps + buzzer,
- Button for testing the correct working order,
- Choice of speed unit: km/h, m/s or miles/h
- Internal buzzer and display for fault signalling and identification



#### Alarm block: P-68416-16

- Adjustable luminous alarm frequency (5 W lamps),
- Programmable alarm bell (110 dB siren at 1 m),
- Fixing by «non-slip» magnets,
- Protecting by roller bar.

#### Options :

- Repeater: Additional display box (wire link, cable 60m) **Q-68416-17**
- Giant Vision display : [see our Spare Parts News Affb](#)
- For cranes with collector, we propose a solution with radio repeater, pack including: sensor + alarm block + main display + repeater display **F-71406-54**