

### **Luffing Jib Raising Procedure**

Luffing Jib No. LJ10:501 on Boom No. B60:500 with Mast No. M10:503 or Mast No. M11:503 MLC300 VPC-MAX

#### Recommended boom and luffing jib raising and lowering procedure

MLC300 VPC-MAX SERIES 1 must be equipped with 135 100 kg VPC (Variable Position Counterweight); MLC300 VPC-MAX SERIES 2 must be equipped with 175 100 kg VPC; MLC300 VPC-MAX SERIES 3 must be equipped with 215 000 kg VPC. Refer to Luffing Jib Rigging **No. 81023384** for boom and luffing jib make-up of inserts, struts, strut raising and lowering procedure, jib stop operation and miscellaneous parts, etc. Refer to the Operator Manual for setup and installation.

**Caution:** Any time luffing jib point rollers are in contact with ground during raising or lowering procedure, release swing brake. Structural damage can occur.

**Caution:** Do not under any condition allow boom-to-luffing jib angle to become less than 70 degrees. Structural damage can occur.

#### Raising:

Starting position for the jib stops is resting on the boom top's jib stop lugs. Luff up jib strut until straps on inserts are clear of strap supports. Slowly raise boom while luffing jib point rollers are allowed to roll on ground. Tension should be applied to luffing jib hoist to keep jib straps clear of strap supports. Boom up and luff down until boom-to-luffing jib angle reaches value specified in Tables 1 thru 3 or luffing jib is vertical, whichever occurs first. Tighten luffing jib suspension with luffing jib hoist. Boom and luffing jib are then raised together using boom hoist until boom reaches 83 degrees or the operating radius is within capacity chart and the luffing jib is above horizontal.

**Warning:** Failure to lower luffing jib to 145 degree boom-to-luffing jib angle will not allow jib stops to engage. Structural damage and/or loss of luffing jib stability can occur.

#### Lowering:

Position boom at 83 degrees prior to lowering luffing jib. Lower luffing jib until boom-to-luffing jib angle reaches value specified in Tables 1 thru 3. Lower boom until luffing jib point rollers contact ground. If luffing jib is hanging vertical, raise luffing jib a few degrees forward of vertical. Should luffing jib fail to roll along ground it may be necessary to provide outside assistance. Continue to lower boom while luffing jib rolls along ground. Keep enough tension on luffing jib hoist to keep jib straps clear of strap supports.

**Warning:** If luffing jib fails to roll once luffing jib point rollers contact ground, lock counterweight until boom-to-luffing jib angle has reached 135 degrees. Luffing jib point rollers must remain on ground with jib straps slack. Once boom-to-luffing jib angle has reached 135 degrees unlock counterweight and continue booming down. Failure to lock and unlock counterweight as instructed may result in a loss of machine stability.

**Warning:** Do not under any condition allow boom-to-luffing jib angle to become greater than 145 degrees before luffing jib point rollers contact ground. Jib stop may engage boom top during lowering. Structural damage can occur.



## **Luffing Jib Raising Procedure**

Luffing Jib No. LJ10:501 on Boom No. B60:500

with Mast No. M10:503 or Mast No. M11:503

MLC300 VPC-MAX

Refer to Tables 1 thru 3 for raising ability with the maximum weight of load blocks, hooks, weight balls, slings and hoist lines beneath boom and jib point sheaves. For block weights shown with #, load blocks, hooks, weight balls and slings must remain on ground until combined weights are within rated capacity of chart.

Table 1

MLC300 VPC-MAX SERIES 1											
		Over End or Side of Crawlers									
		10,6 m Counterweight Position				14,6 m Counterweight Position					
	D (.			W	Weight Under Load Poi			Point			
Boom	Boom to Luffing Jib	Boom	Jib	Boom	Jib	Boom	Jib	Boom	Jib	Boom to Luffing Jib	
Length	Angle	#	#	3 600 kg	2 800 kg	#	#	3 600 kg	2 800 kg	Angle	
Meters	Degrees		Luffing Jib Length - Meters								
	145	24,0	- 54,0	24,0	- 42,0	24,0	- 72,0	24,0	- 66,0	145	
42,0	90	24,0	- 96,0	24,0	- 84,0	24,0	- 96,0	24,0	- 96,0	90	
	70	24,0 - 96,0		24,0	- 90,0	24,0	- 96,0	24,0	- 90,0	70	
	145	24,0 - 42,0		24,0	- 30,0	24,0	- 60,0	24,0	- 54,0	145	
48,0	90	24,0 - 90,0		24,0	- 72,0	24,0	- 96,0	24,0	- 96,0	90	
	70	24,0	- 96,0	24,0	- 96,0	24,0	- 96,0	24,0	- 96,0	70	
	145	24,0 - 30,0			-//	,	- 48,0	24,0	- 42,0	145	
54,0	90	24,0 - 72,0		24,0	- 60,0	24,0	- 96,0	24,0	- 90,0	90	
	70	24,0	- 96,0	24,0	- 96,0	,	- 96,0	,	- 96,0	70	
	145	_	- /	-	_	24,0	- 36,0		- 30,0	145	
60,0	90	,	- 48,0	-	_	,	- 90,0		- 72,0	90	
	70	30,0 - 96,0		30,0 - 96,0		30,0 - 96,0		30,0 - 96,0		70	
	145	0-		_	-		1,0	-	_	145	
66,0	90			_		24,0 - 72,0		24,0 - 54,0		90	
	70	30,0	- 72,0	-	_	30,0	- 96,0	30,0	- 96,0	70	
	145					<u> </u>		_		145	
72,0	90									90	
	70	_	_	_		36,0	- 96,0	36,0	- 96,0	70	
	145	_	_	_	_	_	_	_	_	145	
78,0	90	_	_	-	_	-	_	_	_	90	
	70	<u> </u>		<u> </u>		36,0	- 66,0			70	



## Luffing Jib Raising Procedure Luffing Jib No. LJ10:501 on

Luffing Jib No. LJ10:501 on Boom No. B60:500 with Mast No. M10:503 or Mast No. M11:503 MLC300 VPC-MAX

Table 2

MLC300 VPC-MAX SERIES 2										
		Over End or Side of Crawlers								
	10,6 m Counter				weight Position 14,6 m Counterweight Position					
		Weight Under Load Point								
Boom	Boom to Luffing Jib	Boom Jib		Boom Jib		Boom Jib		Boom Jib		Boom to Luffing Jib
Length	Angle	#	#	3 600 kg	2 800 kg	#	#	3 600 kg	2 800 kg	Angle
Meters	Degrees				ffing Jib Le		ers	<u> </u>	] 5	Degrees
	145	24,0 -	- 72,0	24,0	- 60,0	24,0	- 96,0	24,0	- 84,0	145
42,0	90	24,0 - 96,0		24,0 - 96,0		24,0 - 96,0		24,0 - 96,0		90
	70	24,0 - 96,0		24,0 - 90,0		24,0 - 96,0		24,0 - 90,0		70
	145	24,0 -	- 60,0	24,0	- 48,0	24,0	- 84,0	24,0	- 72,0	145
48,0	90	24,0 - 96,0		24,0 - 96,0		24,0 - 96,0		24,0 - 96,0		90
	70	24,0 - 96,0		24,0 - 96,0		24,0 - 96,0		24,0 - 96,0		70
	145	24,0 -	- 48,0	24,0 - 42,0		24,0 - 72,0		24,0 - 66,0		145
54,0	90	24,0 - 96,0		24,0 - 90,0		24,0 - 96,0		24,0 - 96,0		90
	70		24,0 - 96,0		24,0 - 96,0		24,0 - 96,0		24,0 - 96,0	
	145	24,0 - 36,0		24,0 - 30,0		24,0 - 60,0		24,0 - 54,0		145
60,0	90	24,0 -	- 90,0	24,0	- 72,0	24,0	- 96,0	24,0	- 96,0	90
	70	30,0 -	- 96,0	30,0	- 96,0	30,0	- 96,0	30,0	- 96,0	70
	145	24,0		_		24,0 - 54,0		24,0 - 42,0		145
66,0	90	24,0 - 72,0		24,0 - 48,0		24,0 - 96,0		24,0 - 96,0		90
	70	30,0 -	- 96,0	30,0	- 96,0		- 96,0	1	- 96,0	70
	145	<b>-</b>	_	_		24,0	- 42,0		- 30,0	145
72,0	90		,0	_	_	,	- 96,0		- 78,0	90
	70	36,0 -	- 96,0	36,0	- 96,0		- 96,0	36,0	- 96,0	70
	145	_		_		24,0		_		145
78,0	90	-	_	_	_	,	- 72,0	· · · · · ·	- 48,0	90
	70	_		_	_	36,0	- 96,0	36,0	- 96,0	70
	145	_		_				_		145
84,0	90	_		<u> </u>		24,0 - 30,0				90
	70	_				36,0 - 96,0		36,0 - 96,0		70



# Luffing Jib Raising Procedure Luffing Jib No. LJ10:501 on

Luffing Jib No. LJ10:501 on Boom No. B60:500 with Mast No. M10:503 or Mast No. M11:503 MLC300 VPC-MAX

Table 3

MLC300 VPC-MAX SERIES 3										
		Over End or Side of Crawlers								
		10,6 ı	m Counter	weight Position 14,6 m Counterweight Position					sition	
				V	Weight Under Load Point					
Boom	Boom to Luffing Jib	Boom	Jib	Boom	Jib	Boom	Jib '	Boom	Jib	Boom to Luffing Jib
Length	Angle	#	#	3 600 kg	2 800 kg	#	#	3 600 kg	2 800 kg	Angle
Meters	Degrees			Lu	ŭ	ngth - Mete	ers		Degrees	
	145	24,0 - 90,0		24,0 - 78,0		24,0 - 96,0		24,0 - 96,0		145
42,0	90	24,0 - 96,0		24,0 - 96,0		24,0 - 96,0		24,0 - 96,0		90
	70	24,0 - 96,0		24,0 - 90,0		24,0 - 96,0		24,0 - 90,0		70
	145	24,0 - 78,0		24,0 - 66,0		24,0 - 96,0		24,0 - 84,0		145
48,0	90	24,0 - 96,0		24,0 - 96,0		24,0 - 96,0		24,0 - 96,0		90
	70	24,0 - 96,0		24,0 - 96,0		24,0 - 96,0		24,0 - 96,0		70
	145	24,0 - 66,0		24,0 - 60,0		24,0 - 96,0		24,0 - 78,0		145
54,0	90	24,0 - 96,0		24,0 - 96,0		24,0 - 96,0		24,0 - 96,0		90
	70	24,0 - 96,0		24,0 - 96,0		24,0 - 96,0		24,0 - 96,0		70
	145	24,0 - 54,0		24,0 - 48,0		24,0 - 84,0		24,0 - 66,0		145
60,0	90	24,0 - 96,0			- 96,0	24,0 -		24,0 - 96,0		90
	70	30,0 - 96,0		30,0 - 96,0		30,0 - 96,0		30,0 - 96,0		70
	145	24,0 - 42,0			- 36,0		- 72,0	24,0	- 60,0	145
66,0	90	24,0 - 96,0		24,0 - 84,0		24,0 - 96,0		24,0 - 96,0		90
	70	30,0 - 96,0		30,0 - 96,0		30,0 - 96,0		30,0 - 96,0		70
	145		- 30,0		ł,0	24,0 -			- 48,0	145
72,0	90	24,0 - 78,0		24,0 - 60,0		24,0 - 96,0		24,0 - 96,0		90
	70	36,0 - 96,0		36,0 - 96,0		36,0 - 96,0		36,0 - 96,0		70
	145	_		_	_	24,0 -	•	_	_	145
78,0	90	24,0	- 48,0	24	ł,0	24,0 -	- 96,0	24,0	- 96,0	90
	70	36,0 - 96,0		36,0 - 96,0		36,0 - 96,0		36,0 - 96,0		70
	145	_		_		24,0 - 36,0		_		145
84,0	90	_		_		24,0 - 90,0		24,0 - 72,0		90
	70	36,0 - 72,0		_		36,0 - 96,0		36,0 - 96,0		70
	145	_		_		24,0				145
90,0	90	_	_	_	_	24,0 -	,		- 36,0	90
	70					42,0 - 96,0		42,0 - 96,0		70