## THOUSE THE STATE OF THE STATE O

## TOWER CRANE JIB LIFTING CAPACITIES\_\_\_\_\_4100W 133' TO 253' NO. 22A TOWER WITH 120' NO. 23 BOOM AND 4100W SERIES-1

133' TO 253' NO. 22A TOWER WITH 120' NO. 23 BOOM AND NO. 124 JIB EXTENSION — 18' JIB STRUT 26'6" CRAWLERS — EXTENDED CAUTH 122,400 LB. COUNTERWEIGHT ASSIST

CAUTION OUTSIDE ASSIST REQUIRED

O DEGREE JIB OFFSET ANGLE

Chart supplements Tower Capacity Chart No. 6193-A, No. 6193-B or No. 6193-C. Capacities for various tower lengths, jib lengths and operating radii are for freely suspended loads and do not exceed 75% of a static tipping load. CAPACITIES BASED ON STRUCTURAL COMPETENCE ARE DENOTED BY SHADED AREAS. Capacities are shown in pounds.

Machine to operate on a firm surface with crawlers fully extended and roller path level within a tolerance of ¼" in 10 ft. and properly supported. Crane operator judgment must be used to allow for dynamic load effects of swinging, hoisting or lowering, travel, wind conditions, as well as adverse operating conditions and physical machine depreciation. Refer to Tower Rigging No. 50805, Jib Assembly No. 43348, Chart No. 5527 for recommended procedure for operating under various wind conditions and Chart No. 5393 for tower and boom raising procedure.

Operating radius is the horizontal distance from the axis of rotation to the center of vertical hoist line or load block. Boom angle is the angle between horizontal and centerline of the boom butt and inserts and is an indication of operating radius. In all cases, operating radius shall govern capacity.

Weight of all load blocks, hooks, weight ball, slings, hoist lines, etc., beneath boom and jib point sheaves, is considered part of the jib load. Boom and jib are not to be lowered beyond radii where combined weights are greater than rated capacity. Where no capacity is shown, operation is not intended or approved. Maximum capacity on 1"—6 x 25 IPS, IWRC is 20,000 lbs. All machines with towers over 183 ft. require outside assist in raising tower and boom. Jib to be attached with tower in vertical position and with boom in a position which will allow jib to be attached.

30 FOOT JIB		
Jib Point Radius Feet	Boom Angle: Deg.	Capacity:
50	73.0	20,000
55	71.0	20,000
60	69.0	20,000
65	67.0	20,000
70	64.9	20,000
75	62.8	20,000
80	60.6	20,000
85	58.4	20,000
90	56.1	20,000
95	53.8	20,000
100	51.4	20,000
105	48.9	20,000
110	46.3	20,000
115	43.6	20,000
120	40.7	19,400
125	37.7	18,800
130	34.4	18,200
135	30.9	17,600
140	26.9	17,200
145	22.2	16,700

40 FOOT JIB				
Jib Point Radius Feet	Boom Angle: Deg.	Capacity:		
55 60 65 70 75	72.5 70.6 68.7 66.7 64.8	14,000 14,000 14,000 14,000		
80	62.8	14,000		
85	60.7	14,000		
90	58.7	14,000		
95	56.6	14,000		
100	54.4	14,000		
105	52.1	14,000		
110	49.8	14,000		
115	47.4	14,000		
120	44.9	14,000		
125	42.3	14,000		
130	39.6	14,000		
135	36.6	14,000		
140	33.5	14,000		
145	30.0	14,000		
150	26.2	14,000		

50	50 FOOT JIB		
Jib Point Radius Feet	Boom Angle: Deg.	Capacity:	
55	73.4	10,000	
60	71.6	10,000	
65	69.8	10,000	
70	68.0	10,000	
75	66.2	10,000	
80	64.4	10,000	
85	62.5	10,000	
90	60.6	10,000	
95	58.6	10,000	
100	56.6	10,000	
105	54.6	10,000	
110	52.5	10,000	
115	50.3	10,000	
120	48.1	10,000	
125	45.8	10,000	
130	43.4	10,000	
135	40.9	10,000	
140	38.2	10,000	
145	35.4	10,000	
150	32.3	10,000	
155	29.0	10,000	
160	25.3	10,000	
165	20.9	10,000	

60 FOOT JIB		
Jib Point Radius Feet	Boom Angle: Deg.	Capacity:
55	73.9	5,000
60	72.2	5,000
65	70.6	5,000
70	68.9	5,000
75	67.2	5,000
80	65.4	5,000
85	63.7	5,000
90	61.9	5,000
95	60.1	5,000
100	58.3	5,000
105	56.4	5,000
110	54.5	5,000
115	52.5	5,000
120	50.5	5,000
125	48.4	5,000
130	46.2	5,000
135	44.0	5,000
140	41.7	5,000
145	39.2	5,000
150	36.6	5,000
155	33.9	5,000
160	30.9	5,000
165	27.7	5,000
170	24.1	5,000
175	19.9	5,000