

# Maximum Allowable Travel Specifications

## 16000 SERIES 5

Boom No. 58BRS with 24.9 ft (7,6 m) Extended Upper Boom Point

### Jobsite Travel

16000 SERIES 5 must be equipped with 368,000 lb (166 920 kg) crane counterweight, 41,300 lb (18 735 kg) auxiliary crane counterweight and 120,000 lb (54 430 kg) carbody counterweight. Refer to Wind Conditions chart for maximum wind speed for various boom lengths and capacity charts for boom lengths lifted using Boom Raising System.

#### 1. Machine Travel With Load

- A. Machine can swing and travel with 360 degree rating.
- B. Grade in any direction must not exceed 1 percent (0.5 degrees).
- C. Travel surface must be firm, level and uniformly supporting. Capacity charts are based on static conditions; therefore judgment must be used to allow for dynamic effects of traveling with load. Carry load as close to ground as possible. Stabilize load with taglines. Travel slowly and smoothly to avoid shock loading boom and rigging.

#### 2. Machine Travel Without Load

- A. Load blocks and/or hook and weight balls may be suspended beneath upper boom points or tied off to machine. Total combined suspended weight beneath upper boom points must not exceed 15,000 lb (6 805 kg).
- B. Machine to travel on a firm and uniformly supporting surface. Travel allowed with 360 degree swing up to 1 percent (0.5 degrees) grade; crane upperworks must be in-line with crawlers and grade when grade exceeds 1 percent. Grade in direction of travel should not exceed 20 percent (11.3 degrees); side-to-side grade must not exceed 2 percent (1.1 degrees) measured at boom hinge pins.
- C. Refer to tables 1 and 2 for boom angle, boom length and direction for various grades. Adjust boom within boom angle range shown in table with machine in a level position before traveling onto grade. Do not change boom angle after crane has been traveled onto grade. Boom angle is angle between horizontal and centerline of boom butt and inserts. Refer to table below for grade vs. angle when traveling.
- D. Do not exceed 2 percent (1.1 degrees) side-to-side grade at boom hinge pins when cutting (turning on grade).
- E. **Warning:** Travel prohibited for boom angle range not shown in tables 1 and 2. *Crane could tip.*

Percent Grade Vs. Angle In Degrees	
Percent Grade	Angle
1	0.5
5	2.9
10	5.7
15	8.5
20	11.3

# Maximum Allowable Travel Specifications

## 16000 SERIES 5

Boom No. 58BRS with 24.9 ft (7,6 m) Extended Upper Boom Point

Table 1: Boom 58BRS with 24.9 ft (7,6 m) Extended Upper Boom Point

MACHINE TRAVEL WITHOUT LOAD						
Boom Length		Boom Angle Range in Degrees				
		Percent Grade				
Feet	Meters	0 - 1%	2 - 5%	6 - 10%	11 - 15%	16 - 20%
BOOM FACING UPHILL						
292.0	89,0	50 - 72	50 - 69	50 - 66	50 - 63	50 - 55
301.8	92,0	55 - 72	55 - 69	55 - 66	55 - 63	55 - 60
311.7	95,0	55 - 72	55 - 69	55 - 66	55 - 63	55 - 60
321.5	98,0	60 - 72	60 - 69	60 - 66	60 - 63	—
331.4	101,0	60 - 72	60 - 69	60 - 66	60 - 63	—
341.2	104,0	60 - 72	60 - 69	60 - 66	60 - 63	—
351.0	107,0	60 - 72	60 - 69	60 - 66	60 - 63	—

Table 2: Boom 58BRS with 24.9 ft (7,6 m) Extended Upper Boom Point

MACHINE TRAVEL WITHOUT LOAD				
Boom Length		Boom Angle Range in Degrees		
		Percent Grade		
Feet	Meters	0 - 1%	2 - 5%	6 - 10%
BOOM FACING DOWNHILL				
292.0	89,0	50 - 72	55 - 72	65 - 72
301.8	92,0	55 - 72	60 - 72	65 - 72
311.7	95,0	55 - 72	60 - 72	70 - 72
321.5	98,0	60 - 72	65 - 72	70 - 72
331.4	101,0	60 - 72	65 - 72	70 - 72
341.2	104,0	60 - 72	65 - 72	—
351.0	107,0	60 - 72	65 - 72	—