


Maximum Allowable Travel Specifications

Boom No. 55-79A with 100 Ft. (30.5m) Mast No. 56

Meets
ANSI B30.5
Requirements
Similar To
AS1418.1 and
AS1418.5



Jobsite Travel

18000 must be equipped with 528,000 Lb. (239 500 kg) crane counterweight and 320,000 Lb. (145 150 kg) carbody counterweight. Refer to operators manual for maximum wind speed for various boom lengths. Refer to capacity charts for maximum boom and jib lengths lifted/lowered unassisted. Maximum available travel speed is 0.7 MPH (0.3 m/s).

1. Machine Travel With Load

- A. Machine can swing and travel with 360 degree rating.
- B. Grade in any direction must not exceed 1 percent (0.5 degrees).
- C. Travel surface must be firm, level and uniformly supporting. Capacity charts are based on structural and/or stability; therefore judgment must be used to allow for dynamic effects of traveling with load. Carry load as close to ground as possible. Stabilize load with taglines. Travel slowly and smoothly to avoid shock loading boom and rigging.

2. Machine Travel Without Load

- A. Load blocks and/or hook and weight balls may be suspended beneath lower and upper boom points or tied off to machine. Total combined suspended weight beneath lower and upper boom points must not exceed 25,000 Lbs. (11 340 kg).
- B. Machine to travel on a firm and uniformly supporting surface. Travel allowed with 360 degree swing up to 1 percent (0.5 degrees) grade; crane upperworks must be in-line with crawlers and grade when grade exceeds 1 percent. Grade in direction of travel should not exceed 30 percent (16.7 degrees); side-to-side grade must not exceed 2 percent (1.1 degrees) measured at boom hinge pins.
- C. Refer to table 1 on page 2 for boom angle, boom length and direction for various grades. Adjust boom within boom angle range shown in table with machine in a level position before traveling onto grade. Do not change boom angle after crane has been traveled onto grade. Boom angle is angle between horizontal and centerline of boom butt and inserts. Refer to table below for grade vs. angle when traveling.
- D. Do not exceed 2 percent (1.1 degrees) side-to-side grade at boom hinge pins when cutting (turning on grade).
- E. **Warning:** Travel prohibited for boom angle range not shown in table 1 on page 2. *Crane could tip.*

Percent Grade Vs. Angle In Degrees	
Percent Grade	Angle
1	0.5
10	5.7
20	11.3
30	16.7



Maximum Allowable Travel Specifications

Boom No. 55-79A with 100 Ft. (30.5m) Mast No. 56

Meets
ANSI B30.5
Requirements
Similar To
AS1418.1 and
AS1418.5

18000




Table 1: Boom No. 55-79A

MACHINE TRAVEL WITHOUT LOAD					
Boom Length (not including jib)		Boom Angle Range in Degrees			
		Percent Grade			
Feet	Meters	0 - 1%	2 - 10%	11 - 20%	21 - 30%
BOOM FACING DOWNHILL OR UPHILL					
120	36.6	30 - 72	30 - 66	30 - 40	—
140	42.7	30 - 72	30 - 66	30 - 50	—
160	48.8	30 - 72	30 - 66	30 - 50	30 - 40
180	54.9	30 - 72	30 - 66	30 - 60	30 - 40
200	61.0	30 - 72	30 - 66	30 - 60	30 - 40
220	67.1	30 - 72	30 - 66	30 - 60	30 - 50
240	73.2	30 - 72	30 - 66	30 - 60	40 - 55
260	79.2	30 - 72	30 - 66	30 - 60	50 - 55
280	85.3	30 - 72	30 - 66	40 - 60	—
300	91.4	30 - 72	40 - 66	50 - 60	—
320	97.5	40 - 72	50 - 66	—	—
340	103.6	40 - 72	50 - 66	—	—
360	109.7	50 - 72	55 - 66	—	—
380	115.8	50 - 72	60 - 66	—	—
400	121.9	55 - 72	60 - 66	—	—