

GMK 5110-1, 5130-2
1000-hour Maintenance Kit
Chassis engine E3b / T4i, Super engine E3a / T3 (no DEF)
Part Number 03144315



Manitowoc Crane Care congratulates you for making the purchase of this maintenance kit. Good maintenance at the right time will make a difference in the daily reliability and long-term life of your GMK.

We offer this guide to help you utilize this kit efficiently.

Should you have any feedback or questions regarding this maintenance kit, please contact Manitowoc Crane Care.

The 1000-hour kit basically follows the 12-month maintenance plan (M12) as shown in chapter 5 of the Maintenance manual. Please refer to the given Maintenance manual (**3 112 751 or 752 for GMK 5130-2, 3 112 811 or 812 for GMK 5110-1**) for specific details and requirements.


















Please note that there may appear to be some discrepancies with the part numbers given in the Maintenance manual compared to those in the kit. The kit contains the latest recommendations, where any discrepancies are a function of our continuous improvement program. For example, superseded part numbers may be for Engineering Design changes, improved technology, more cost-effective solutions or a different supply chain.

Consider additional maintenance items when completing, Y2, Y3, Y5, Y6 or Y10 intervals, such as transmission oil and filter, hoist inspection, slewing sensor, cable drums etc. – please refer to the Maintenance manual for more details.

5.2.6

















Maintenance plan M 12

M 12

Maintenance work on the CARRIER: Every twelve months/after 20,000 - 25,000 km (12,430 - 15,530 mi)	
Engine – Notes;  <i>Engine manufacturer's documentation</i>	 p. 7 - 13
Fuel system – Changing fuel filter 2	 p. 7 - 26
Exhaust system with exhaust emission control ¹⁾ – Having the urea system checked	 p. 7 - 33
Transmission – Checking the oil level	 p. 7 - 35
Axle lines – Axle centre drives – changing the oil – Final drives – changing the oil	 p. 7 - 47  p. 7 - 52
Suspension – Pressure accumulator – checking the gas pressure	 p. 7 - 70
Compressed air system – Replacing the filter cartridge of the compressed air drier	 p. 7 - 75
Hydraulic system – Changing the ventilation filter – Taking oil samples depending on the oil sample test results: – Changing the hydraulic oil – Changing the hydraulic oil filter	 p. 7 - 81  p. 7 - 82  p. 7 - 87  p. 7 - 91
Air-conditioning system – Checking the entire air conditioning system – Changing the pollen filter	 p. 7 - 104  p. 7 - 106
Other maintenance work – Lubricating the cab door – Lubricating the connecting and socket pins	 p. 7 - 117  p. 7 - 118

¹⁾ Additional equipment *Urea System*

M 12

Maintenance work on the SUPERSTRUCTURE: Every 12 months/after 1,000 oper. hrs.	
Engine – Notes;  <i>Engine manufacturer's documentation</i>	 p. 8 - 9
Fuel system – Changing fuel filters 2 and 3	 p. 8 - 23
Hoists – Changing the oil/Checking the oil	 p. 8 - 30
Slewing gear – Changing the oil/Checking the oil	 p. 8 - 36
Ball slewing bearing – Measuring tilting play	 p. 8 - 41
Hydraulic system – Changing the ventilation filter – Pressure accumulator – checking the gas pressure – Taking oil samples depending on the oil sample test results: – Changing the hydraulic oil – Changing the hydraulic oil filter	 p. 8 - 48  p. 8 - 49  p. 8 - 49  p. 8 - 54  p. 8 - 51
Main boom – Checking the locking system	 p. 8 - 62
Hook blocks – Lubricating	 p. 8 - 82
Air-conditioning system – Checking the entire air conditioning system	 p. 8 - 86
Other maintenance work – Lubricating the crane cab door – Lubricating the connecting and socket pins	 p. 8 - 91  p. 8 - 92

1. What's in the box?



List of contents

03142356	Super hydraulic oil filter 2	1
03142360	Chassis hydraulic oil tank breather	1
03316035	Super engine oil filter	1
03316343	Super engine air filter outer	1
03316344	Super engine air filter inner	1
03319602	Super hydraulic oil tank breather	1
03319653	Chassis engine fuel filter 2	1
03322877	Chassis and super engine fuel filter 1	2
03325700	Super hydraulic oil filter 1	1
03328365	Chassis engine oil filter	1
03328573	Super engine fuel filter 2	1
03329152	Chassis hydraulic oil filter 1 & 2	2
04157569	Super engine fuel filter 3	1
04157573	Chassis cab pollen filter	1
04286260	Chassis air dryer filter	1
04286278	Chassis engine air filter	1

00117125	Seal - slew units oil level	2
00117132	Seal - slew units oil drain	2
00117134	Seal - transfer case oil drain	1
00117145	Seal - axle centre drive level & drain, final drives	10
00117151	Seal - transfer case oil level, axle centre drives level	5
01371208	Seal - axle centre drives drain (4)	5
01377793	Seal - main & aux hoist level, hoist drain	10
03135778	Seal - Chassis hydraulic oil filter 1 & 2	2
03135853	Seal - super hydraulic oil filter 1	1
03326049	Seal - super hydraulic oil filter 2	1
03328331	Seal - transmission oil level	1
03329825	Seal - super engine oil drain plug	1

2. The Filters


1x 03142356 Superstructure hydraulic oil filter 2




1x 03142360 Chassis hydraulic oil tank breather



1x 03316035 Superstructure engine oil filter



1x 03316343 Superstructure engine air filter (outer)




1x 03316344 Superstructure engine air filter (inner)




1x 03319602 Superstructure hydraulic oil tank breather




1x 03319653 Chassis engine fuel filter 2





2x 03322877 Chassis and Superstructure engine fuel filter 1



1x 03325700 Superstructure hydraulic oil filter 1



1x 03328365 Chassis engine oil filter



1x 03328573 Superstructure engine fuel filter 2




2x 03329152 Chassis hydraulic oil filter 1 & 2



1x 04157569 Superstructure engine fuel filter 3



1x 04157573 Chassis cab pollen filter



1x 04286260 Chassis air dryer filter with oil coalescer



1x 04286278 Chassis engine air filter



3. The Seals (see contents list for usage)



4. Additional maintenance items (not in the kit)

Oil condition analysis:

As part of the annual maintenance, you should take samples from the hydraulic system (7.14.6 and 8.8.8) to determine the condition of the hydraulic oil. We recommend our oil analysis kit, which is available under part number 03141012. The kit contains: an oil sample bottle, oil description form (to be completed) and return envelope. The price of this kit includes laboratory analysis of the sample and report that will be sent to your email address.



DEF (Ad-Blue) Filter:

GMK 5110-1, 5130-2 Chassis engine: 1x 04157650



Oils and Greases

Many oils and greases will be available locally to you, we strongly recommend that the specifications given in chapter 6 of the Maintenance manual be followed when selecting any local equivalents.

These oils and greases have no equivalent and should be ordered from Manitowoc Crane Care as required:

- Sliding surface boom grease
 - 400 gr. cartridge for spray gun **03329071**
 - 10 kg can **01373458**
 - 25 kg bucket **02314698**
- Cylinder rod corrosion protection (400ml spray) **01929824**
- Boom pinning bolt grease (400g cartridge) **03313195**
- Suspension lubricant (1-liter bottle) **02310863**
- Turntable bearing gear teeth adhesive grease (400ml spray) **S-01032-63**
- Central lub. system, cardan shafts etc. high graphite, wide temperature Universal grease (1kg can) **04163374**

Suspension pressure accumulators

To perform the check of nitrogen pressure in the accumulators as explained in 7.5.4, 7.11.4 and 8.8.7 of the Maintenance manual, Manitowoc Crane Care offers a test kit P/No 02257617 (gas bottle adapter and pressure regulator also required). Reference service bulletin SB D15-022 GMK suspension hydraulic accumulators.

Maintenance video


You may also find our video outlining some simple maintenance procedures useful, under the following link:

<https://www.manitowoccranes.com/en/Resources/videos/2016/Grove-GMKpreventive-maintenance>

Maintenance App

When planning your routine crane maintenance, consider utilizing our GMK Maintenance App.

- Freely accessible giving all details for current GMK production models
- Individual maintenance plans by interval or engine hours / mileage
- Including a description of the relevant tasks from the maintenance manual



Visit our dedicated website: <https://eu100.manitowoc.com/GMKMaintenance/>

Read the Quick Start Guide for using the App:

